HP DeskJet
2700 All-in-One
series User Manual



USER MANUAL



ABOUT THIS ITEM

- **All-in-one versatility –** Tackle the essentials from one device – ; simple printing at home with print, scan and copy versatility with this printer made from up to 20% recycled plastic.

- **Mobile setup with HP Smart app –** Get started fast with easy setup that guides you, step by step; simply download the HP Smart app, connect to Wi-Fi, and share your printer across all your devices.

- **Worry-free wireless –** Dual-band Wi-Fi with self-reset enables you to get better range and more reliable connections; plus, Bluetooth and USB connectivity deliver a hassle-free experience so you can start printing quickly.

- **Quality you can count on –** Original HP ink cartridges deliver sharp text and vibrant graphics for all your everyday documents and photos. Choose high-yield cartridges to get a better value for frequent printing.

- **Get ink your way, every day -** Buy Original HP 67 Ink or get HP Instant Ink Delivery Service: Ink ordered by your printer, delivered to your door and pay a lot less

Product Description

The HP DeskJet 2752 is the perfect all-in-one printer for your home office. It allows you to print, scan, and copy with ease. The printer uses high-quality HP inks that deliver laser-quality prints with exceptional clarity, so you can trust your documents will look professional. It also has wireless connectivity, so you can print from anywhere.

Design for convenience and affordability. It runs on energy-efficient designs that help reduce your energy costs and conserve the environment. The printer has a compact design that fits comfortably on your desk or counter, and it is easy to set up and use. It supports a variety of paper sizes, so you can print the documents you need with ease. In addition, it is compatible with most operating systems and has a variety of connection options including Apple AirPrint and Google Cloud Print.

The HP DeskJet 2752 is an ideal choice for home office use. It prints quickly, quietly, and reliably, so you can trust it to handle your printing needs. With its affordable price, reliable performance, and energy-efficient design, the HP DeskJet 2752 is the perfect printer for your home. Get your documents printed quickly and easily with the HP DeskJet 2752!

Control panel features

1. **Power button:** Turns the printer on or off.

2. **Control panel display :** Indicates number of copies, wireless status and signal strength, Wi-Fi Direct status, warnings or errors, and ink levels.

3. **Ink Alert light**: Indicates low ink or cartridge problems. For more information, see Control panel error codes and status on.

4. **Cancel button:** Stops the current operation.
   Resume button: Resumes a job after a disruption (for example, after loading paper or clearing a paper jam).

5. **Resume light:** Indicates the printer is in a warning or error state. For more information, see Control panel error codes and status on.

6. **Wireless button:** Turns on or off the printer wireless capabilities.
   Wireless light: Indicates whether the printer is connected to a wireless network.


Information button: Prints out a printer information page on its current status.

- **Information light:** If the light is blinking in white and the Wi-Fi Direct icon on the display is blinking fast at the same time, press the Information button to confirm a connection.

- If it is amber (possibly blinking), it indicates an HP Instant Ink warning or error. Press the button to print an information page, check the HP Instant Ink section for diagnostic results, and then follow the instructions on the page.
  NOTE: HP Instant Ink service is not available in all countries. To check availability, visit hpinstantink.com.

- **Start Copy Color button:** Starts a color copy job. To increase the number of color copies, press the button multiple times quickly.

- **Start Copy Black button:** Starts a black-and-white copy job. To increase the number of black-and-white copies, press the button multiple times quickly.




HP DeskJet 2700 All-in-One

HOW TO USE


- Raise the input tray.




- Slide the paper-width guide to the left.



- Insert a stack of paper into the input tray with the short edge down and the print side up, and slide the stack of paper down until it stops.



- Slide the paper-width guide to the right until it stops at the edge of the paper.



- Lower the output tray and pull out the output tray extender



To change the default paper size detected by the printer

- Open the embedded web server (EWS). For more information, see Open the embedded web server.
- Click the Settings tab.
- In the Preferences section, click Tray and Paper Management, and then select the desired option.

Wi-Fi Direct connection security setting

- If the Wi-Fi Direct connection security for the printer is Automatic, the Wi-Fi Direct password is set to 12345678 and cannot be changed.

- If the Wi-Fi Direct connection security for the printer is set to Manual (the default setting), you need to do one of the following to connect to the printer on your mobile device or compter.

    - If the Information button (Graphic - Information button) is blinking white, press it within 30 seconds.

    - If the printer prints out a page with a PIN code, follow the instruction on the page.

TIP:

- You can also turn on Wi-Fi Direct or change the Wi-Fi Direct connection security setting from the EWS. For more information about using the EWS, see Open the embedded web server.

- To find the Wi-Fi Direct name and password, press the Information button ( ) to print a printer information page.





Manuals.plus

- **What are the basic safety precautions to follow when using the HP DeskJet 2700 All-in-One series printer?**

  Always follow basic safety precautions when using this product to reduce the risk of injury from fire or electric shock. Read and understand all instructions in the documentation that comes with the printer. Observe all warnings and instructions marked on the product. Unplug this product from wall outlets before cleaning. Do not install or use this product near water, or when you are wet. Install the product securely on a stable surface. Install the product in a protected location where no one can step on or trip over the line cord, and the line cord cannot be damaged. If the product does not operate normally, see Solve a problem. There are no user-serviceable parts inside. Refer servicing to qualified service personnel.

- **What is the purpose of the Printer Information Page and how can it be printed?**

  The Printer Information Page provides a summary of the printer information and its current status. It can be printed by pressing the Information button on the control panel.

- **How can the wireless capabilities of the HP DeskJet 2700 All-in-One printer be turned on or off?**

  The wireless capabilities of the HP DeskJet 2700 All-in-One printer can be turned on or off by pressing the Wireless button on the control panel.



Manuals.plus

- **What should be done if the Ink Alert light is blinking?**

  If the Ink Alert light is blinking, it indicates low ink or cartridge problems. For more information, see Control panel error codes and status on.

- **What should be done if the Resume light is blinking?**

  If the Resume light is blinking, it indicates the printer is in a warning or error state. For more information, see Control panel error codes and status on.

- **What should be done if the Wi-Fi Direct icon is blinking fast in sync with the blinking Error icon for three seconds, and then stays on?**

  If the Wi-Fi Direct icon is blinking fast in sync with the blinking Error icon for three seconds, and then stays on, it means that Wi-Fi Direct has reached the maximum of five connections.

Manuals.plus

Like And Subscribe us for more Videos Manuals.plus

