

BRAUN BN0278 Automatic Watch User Manual

Contents

1 BRAUN BN0278 Automatic Watch
2 Product Information
3 Product Usage Instructions
4 Braun BN0278 automatic watch
5 Description of the display and control buttons
6 Guarantee
7 Documents / Resources
7.1 References
8 Related Posts

BRAUN BN0278 Automatic Watch



Product Information

Specifications

- Model: Automatic Watch Power Reserve
- Power Reserve: Maximum period of 30 hours
- Movement: Automatic 3 hand movement with date

Description of the Display and Control Buttons

- to. Normal running and manual winding position (turn clockwise)
- b. Date adjust (turn anti-clockwise). Watch runs.
- c. Hand-setting
- d. Date calendar

Product Usage Instructions

Power Reserve and Winding

In order to maintain power, the watch may be taken off the wrist for a maximum period of 30 hours. If this period is exceeded, the movement will stop and another manual wind will be necessary. It must be remembered that if the watch is worn while sleeping, the movement of the wrist is insufficient to maintain the automatic winding function. **Caution:** Do not overwind your watch as this may cause damage to the movement.

Operating the Watch

To operate the watch, follow these steps:

1. For normal running and manual winding positions, turn the crown clockwise (position a).
2. To adjust the date, turn the crown anti-clockwise (position b).
3. To set the hands, use the crown (position c).
4. The date calendar is displayed on the watch (position d).

Frequently Asked Questions

- Q: How long can the watch be taken off the wrist without winding?
  A: The watch can be taken off the wrist for a maximum period of 30 hours without winding.
- Q: What happens if the power reserve is exceeded?
  A: If the power reserve is exceeded, the movement of the watch will stop and manual winding will be necessary.
- Q: Can I wear the watch while sleeping?
  A: It is not recommended to wear the watch while sleeping as the movement of the wrist is insufficient to maintain the automatic winding function.
- Q: What should I do if my watch stops running?
  A: If your watch stops running, manually wind it by turning the crown clockwise (position a).


Braun BN0278 automatic watch

An automatic or self-winding watch is a mechanical watch in which the mainspring is wound automatically as a result of the natural motion of the wearer's arm, making regular manual winding unnecessary. The winding of the automatic mechanism depends on the intensity of your movements. When you receive the watch for the first time it may not be running. This is because the watch has no power to operate. The watch must be given an initial manual wind with 15 to 20 turns of the crown and then while the watch is worn it will wind itself and maintain the correct time. When setting the time please ensure the hands only move in a clockwise direction to avoid damage. The accuracy tolerance of our automatic movements is -40 to +40 seconds per day, worn under normal conditions.

Automatic watch power reserve

In order to maintain power the watch may be taken off the wrist for a maximum period of 30 hours. If this period is exceeded the movement will stop and another manual wind will be necessary. It must be remembered that if the watch is worn while sleeping the movement of the wrist is insufficient to maintain the automatic winding function. **Caution**: Do not overwind your watch as this may cause damage to the movement.

Description of the display and control buttons



Automatic 3 hand movement with date

- Normal running and manual winding position (turn clockwise)
- Date adjust (turn anti-clockwise). Watch runs.
- Hand-setting
- Date calendar

Setting the date

To ensure that the date indicator jumps to the next day at midnight (and not at 12h noon), set the date first to the previous day then forward the hands until the date jumps. Now you know that the hands are positioned at midnight and you can set the hands to the correct (a.m. or p.m.) time.
Note: The date is changed during the period between 6:00pm and 6:00am. Do not set the date between these times as it will not alter correctly on the following day and it may cause damage to the movement.

Guarantee

5 year guarantee against material and workmanship defects. The guarantee is valid in those countries where the watch is officially being sold. This guarantee does not include bracelet/straps and lenses. This guarantee does not cover damage caused by misuse or neglect.
Important: Please retain this instruction manual for future reference.

Braun contact

Should you have a problem with your product, please check your local service centre at: **www.braun-clocks.com** **www.braun-watches.com** or contact +44 808 175 3235 (calls free within the UK) or +44 20 8208 1833
Certain trademarks used under license from The Procter & Gamble Company or its affiliates.

Documents / Resources

	BRAUN BN0278 Automatic Watch [pdf] User Manual BN0278 Automatic Watch, BN0278, Automatic Watch, Watch

References

- Braun-Clocks: Braun Shop online | Buy Braun Clocks & Watches
- Emit Collection | Buy Online Watches & Accessories Store
- User Manual

Manuals+,