

Bol FWMOU0090-Left hand Ergonomic Vertical Wireless Left Handed Mouse User Guide

Contents

1 Bol FWMOU0090-Left hand Ergonomic Vertical Wireless Left Handed Mouse
2 Product Information
3 Product Usage Instructions
4 Frequently Asked Questions
5 PRODUCT OVERVIEW
6 Installing a wireless mouse
7 Documents / Resources
7.1 References

BOL

Bol FWMOU0090-Left hand Ergonomic Vertical Wireless Left Handed Mouse



Product Information

This product is a wireless mouse that operates on a 2.4GHz frequency. It comes with a USB receiver that needs to be connected to the USB port of your laptop or desktop. The mouse requires 2 AAA batteries, which should be inserted into the battery compartment located at the bottom of the mouse. The mouse also has an on/off switch.

Specifications

- Wireless Technology: 2.4GHz
- USB Receiver: Included
- Battery Type: AAA

Product Usage Instructions

1. Locate the USB receiver, which is located at the bottom of the mouse.
2. Insert the USB receiver into the USB port of your laptop or desktop.
3. Open the battery compartment at the bottom of the mouse and insert 2 AAA batteries.
4. Slide the on/off switch to the ON position.
5. In most cases, the mouse should start working immediately.

Frequently Asked Questions

Q: How do I know if the mouse is connected to my device?

A: Once you have completed the installation steps, you should see a cursor moving on your screen when you move the mouse.

Q: How long do the batteries last?

A: The battery life may vary depending on usage, but on average, the batteries should last for several months.

Q: Can I use this mouse with a Mac?

A: Yes, this mouse is compatible with both Windows and Mac operating systems.

Q: Is the USB receiver compatible with USB 3.0 ports?

A: Yes, the USB receiver can be used with both USB 2.0 and USB 3.0 ports.

Q: Can I adjust the sensitivity of the mouse?

A: No, this mouse does not have adjustable sensitivity settings.

PRODUCT OVERVIEW



Installing a wireless mouse

1. This mouse is equipped with a USB 2.4 receiver GHz, located under the mouse.
2. Insert the USB receiver into the USB port of your laptop or desktop computer.
3. Insert 2 AAA batteries into the battery compartment located at the bottom of the mouse.

4. Slide the power button to ON. In the In most cases, the mouse works immediately.

Documents / Resources

	Bol FWMOU0090-Left hand Ergonomic Vertical Wireless Left Handed Mouse [pdf] User Guide FWMOU0090-Left hand Ergonomic Vertical Wireless Left Handed Mouse, FWMOU0090-Left hand, Ergonomic Vertical Wireless Left Handed Mouse, Vertical Wireless Left Handed Mouse, Wireless Left Handed Mouse, Left Handed Mouse, Mouse

References

- User Manual

Manuals+, Privacy Policy