

SONY®

重要信息

Important information

©2017–2018

索尼用户网站

在 www.sonymobile.com/support, 用户只需在其中单击几下鼠标就可以获得帮助和提示。用户可在这里找到最新的软件更新以及有关如何更高效地使用产品的提示。

安全及有效使用指南

请遵循以下准则。否则,可能会给您带来潜在的健康风险或导致产品出现故障。如果对产品是否能正常使用存有疑问,请在为产品充电或使用产品前,先让索尼认证的服务合作伙伴进行检查。



有关保养及安全使用我们的产品的建议

警告

控制、调整或执行此处指定程序以外的程序可能会导致危险的辐射暴露。

为安全起见

- 请勿让水或异物进入部件。这可能会导致火灾或触电。如果水或异物进入了部件,请立即将其关闭,并断开电源线和连接线。
- 请勿拆卸或改装部件。这可能会导致故障、火灾或触电。
- 如果有雷击的可能性,请勿使用部件。雷击可能会导致触电。如果可能发生闪电,请拔下部件以防止引起火灾、触电和故障。

关于安全

- 无线功能已纳入本部件。无线电波可能会影响其他设备的运作。请勿在以下位置使用本设备。
 - 在飞机上。
 - 自动控制的设备附近,如自动门或火灾报警器。如果在使用本部件的过程中遇到其他装置问题(如干扰),请立即停止使用本部件。
- 请勿长时间持续观看投影屏幕。长时间持续观看投影屏幕可能会导致眼睛疲劳。如果您感到任何不适或疼痛,请立即停止使用部件并休息。如果休息后仍感到不适或疼痛,请咨询医生。
- 请勿在光滑的表面上进行投射。光线可能会反射到您的眼睛中,并且可能会对眼睛造成伤害。
- 务必让儿童远离部件。如果连接线缠绕在颈部或出现类似的误操作,可能会导致事故或伤害。

- 此设备可能会包含某些可拆分的小部件，从而导致窒息危险。保持此设备远离儿童或其他受监管人员，以防止此类危险。他们可能会弄伤自己或他人。
- 此设备可能包含小型磁铁。吞食磁铁可能会造成严重伤害，如窒息危险或肠道损伤。让此设备（或配件名称）远离儿童或其他受监管人员，以防止任何此类伤害。如果您知道或怀疑您或任何人吞食了磁铁，请立即就医。
- 此设备包含可能干扰起搏器、除颤器、可编程分流阀或其他医疗设备的磁铁。请勿将此设备放置在此类医疗设备或使用此类医疗设备的人员附近。如果您使用任何此类医疗设备，请在使用此产品前咨询您的医生。

关于处理

- 如果长时间不使用部件，请将其拔下。
- 请勿坠落、撞击、压缩部件或在上放置重物。
- 设备的工作温度范围为 5° C 至 35° C。如果在超出工作温度范围的极冷或极热的地方使用部件，可能会导致故障。
- 请勿将部件放置在油烟、蒸汽、湿气或灰尘过多的地方。这可能会导致火灾或触电。
- 请勿将部件安装在可能引起危险的不合适的地方。部件可能会坠落而造成伤害。
- 请勿让部件遭受强烈撞击。如果对部件施加强大的力量，例如在上放置重物、使其坠落或在上踩踏，这可能会造成伤害或故障。虽然投影窗口是用钢化玻璃制成的，如果强力推动或敲击，它可能会破裂而造成伤害。
- 移动部件时，请注意不要坠落。如果部件坠落，则可能会破裂或造成伤害。

关于放置

- 请勿将部件放在任何灰尘或香烟的烟雾过多的地方。灰尘和香烟焦油粘附在部件（如投影窗口）内部的元件上而导致故障。
- 请勿将部件放置在温度过高或过冷的地方，或者湿度极高的地方。特别是在阳光充足时或在夏天期间，汽车内部会变得非常热，将部件留在车内可能会导致其变形或发生故障。
- 请勿将部件放在不平稳的表面上。部件可能会坠落或倾倒而造成伤害。

- 请勿将部件放置在有水的地方。这可能会导致火灾或触电。
- 请勿将部件放置/存储在阳光直射或靠近加热器的地方。热量可能会在部件内积聚而引起火灾。

关于交流电源转换器和连接线

- 请勿损坏电源线。这可能会导致火灾或触电。
- 请务必使用部件附带的交流电源转换器。如果部件使用其他交流电源转换器，可能会导致火灾、触电或故障。
- 请勿用湿手触摸电源插头。这可能会导致触电。
- 在连接交流电源转换器和连接线之前，请关闭部件和连接的设备，并从壁式插座上拔下电源插头。
- 请勿将电源线或连接线缠绕在交流电源转换器周围。这可能会导致电源线或连接线断裂。
- 移动部件之前，请断开电源线和连接线。连接线可能会被损坏，从而引起火灾或触电，或者连接的设备可能会坠落或倾倒而造成伤害。
- 径直插入连接器。如果以某个角度插入，引脚可能会造成短路进而引起火灾。

关于风扇噪音

投影仪内部装有风扇，用于防止过热，打开风扇后会产生轻微的噪音。这种噪音不是故障。但是，如果有任何异常噪音，请咨询合格的索尼人员。

关于光源维护

本部件使用激光，因此需要特别小心，而且必须使用专门用于检查和维护光源元件的设施。请务必咨询合格的索尼人员。

关于清洁

- 清洁之前，请务必关闭部件并将其从壁式插座上拔下。
- 如果使用脏布用力擦拭部件，可能会刮伤部件。
- 如果将挥发性液体（如杀虫剂）洒在部件上，或者使橡胶或乙烯制品长时间与部件保持物理接触，部件可能会受到影响或表面颜色会褪色。
- 请勿用裸手触摸投影窗口。
- 清洁投影窗口的表面：

用软布（如眼镜清洁布）轻轻擦拭。如果有顽固的污渍，请用水沾湿的布擦净。切勿使用酒精、苯、稀释剂、酸性清洁剂、碱性清洁剂、研磨性清洁剂、化学灰尘布等。

· **清洁外部：**

用软布轻轻擦拭。如果有顽固的污渍，请使用浸泡过稀释的中性洗涤剂并彻底拧干的软布擦净污渍，然后再用干布擦拭外部。请勿使用酒精、苯、稀释剂等。

关于投影仪

- 虽然本部件是使用精确度非常高的技术制造的，但投影屏幕上可能会有一些永久的黑色或白色像素。此外，颜色或亮度可能会出现带条纹的不均匀度。这是投影仪的结构所引起的，并不是故障。每个投影仪部件的颜色平衡各不相同；因此，使用多个 LCD 投影机时，即使它们的型号相同，投影仪之间的颜色再现也可能会有所不同。
- 移动眼睛时或在特定条件下，根据观看的内容，您可能会看到诸如红色、蓝色或绿色等原色；这不是故障。这是由显示图像的部件所采用的场序彩色系统特有的“颜色分离”现象造成的。这种现象可以通过减少图像和背景之间的对比度来减弱，例如降低部件的亮度或增加房间的亮度。

关于冷凝

如果将投影仪突然从寒冷的地方移动到温暖的地方，或者在冬天的早晨刚打开房间加热器之后，投影仪的表面或内部可能会发生冷凝。如果发生冷凝，请关闭投影仪，直到冷凝消失。如果在存在冷凝的情况下使用投影仪，可能会导致故障。

关于通风孔

- 请勿堵塞通风孔（进气/排气）。如果通风孔被堵塞，热量将在部件内部积聚，因而导致火灾或故障。为了保持良好的通风，请遵守以下事项：
 - 远离墙壁和物体放置部件。
 - 请勿使用可能堵塞通风孔的盖子。
 - 请勿将部件放置在软布、纸质文件、厚地毯或碎纸片上。它们可能会被吸入并堵塞进气孔。
- 请勿将手或物体靠近排气孔。这可能会导致灼伤或变形。

关于投影窗口

- 请勿窥视投影窗口。光线可能会伤害眼睛。

- 请勿挡住投影窗口。光线会加热障碍物，这可能会导致毁坏、变形、灼伤或火灾。

有关部件发热的警告

- 使用部件或给部件充电时，部件或交流电源转换器可能会变热；这不是故障。如果部件温度过高，为了安全起见，它可能会自动关闭。在这种情况下，在部件冷却后，在较凉快的地方使用部件。
- 如果部件或交流电源转换器非常热，则可能会发生故障。请立即关闭部件并从壁式插座上拔下交流电源转换器，然后咨询合格的索尼人员。
- 请勿长时间持续触摸正在运转的部件或交流电源转换器。长时候接触皮肤可能会导致灼伤。即使透过衣物触摸，长时候接触也可能导致灼伤。
- 请勿用布或床上用品覆盖部件或交流电源转换器。覆盖后热量将会积聚，从而导致变形、故障或火灾。

关于充电

- 在 5° C 至 35° C 的环境温度下给部件充电。在此温度范围之外，可能无法给部件充分充电。
- 给部件充电或使用部件时，部件的温度可能会升高；这不是故障。
- 如果长时间不使用部件，请每六个月充电一次以防电池毁坏。
- 部件长时间未用时，充电时间可能会更长。
- 当电池使用时间下降到初始时间的一半时，可能已经达到其使用寿命的期限。关于可充电电池的更换，请咨询合格的索尼人员。

关于交流电源中断

使用电源按钮关闭部件时，不会完全停止给部件供电。若要完全停止给部件供电，请从壁式插座上拔下电源插头。将交流电源转换器放置在壁式插座附近，以便您可以在意识到问题时快速拔下插头。

个人医疗设备

移动设备/带有射频发射装置的设备可能会影响植入的医疗设备。可通过保持索尼产品和医疗设备之间的距离超过 15 厘米（6 英寸）来降低干扰风险。如果怀疑存在干扰，请关闭设备。要在个人医疗设备附近使用，请咨询医师和设备制造商。

GPS/基于位置的功能

某些产品提供 GPS/基于位置的功能。定位功能“按原样”提供，且“不保证没有错误”。索尼不对此类位置信息的准确性作出任何陈述或保证。

设备使用基于位置的信息，可能会出现中断或出错，而且可能还依赖于网络服务的可用性。请注意，在建筑物内部或建筑物临近区域等一些环境中，功能可能有所减弱或被阻止。

恶意软件

恶意软件是指会损害设备的软件。恶意软件或有害应用程序包括病毒、蠕虫、间谍软件和其他有害程序。尽管设备采用了安全措施来阻止此类攻击，但索尼不保证或声明设备不会引入恶意软件。但是，您可通过下列方法降低遭受恶意软件攻击的风险：下载内容或接受应用程序时小心谨慎、避免打开或响应未知来源的消息、使用受信任服务来访问互联网以及仅从已知的可靠来源将内容下载到设备。

配件

索尼建议用户使用索尼品牌的原装配件以确保安全有效地使用该产品。使用第三方的配件可能会降低产品的性能或给您的健康安全带来危险。

对废旧电气、电子设备和电池的处理

为避免造成环境污染，请将废弃产品按照当地法律法规要求进行处置。



有害物质说明

在正常使用条件下，除电池外我们的环保使用期限是 10 年。



产品中有害物质的名称及含量

部件名称	有害物质					
	铅(Pb)	汞(Hg)	镉(Cd)	六价铬(Cr(VI))	多溴联苯(PBB)	多溴二苯醚(PBDE)
设备	X	0	0	0	0	0
电池	X	0	0	0	0	0
配件和充电器	X	0	0	0	0	0

本表格依据 SJ/T 11364 的规定编制。

O: 表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

X: 表示该有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。(打“X”的技术原因是因为目前为止没有可替换技术。)

记忆卡

如果设备带有可拆卸的记忆卡，则通常可以与购买的设备兼容，但可能无法与其他设备或其记忆卡的功能兼容。请在购买或使用之前检查其他设备的兼容性。如果设备配有记忆卡阅读器，则请在购买或使用前检查记忆卡的兼容性。

一般来说，记忆卡在出厂之前已经进行了格式化。要重新对记忆卡进行格式化，请使用兼容的设备。有关详细信息，请参考设备的操作说明或与相关的索尼联系中心联系。

SIM 卡

如果您的设备配备有标准尺寸的 SIM 卡槽，则将不兼容的 SIM 卡（例如微型 SIM 卡、带有非索尼适配器的微型 SIM 卡或具有微型 SIM 卡尺寸的标准 SIM 卡）插入 SIM 卡槽可能会永久损坏 SIM 卡或设备。索尼不保证且对因使用不兼容或改装 SIM 卡而导致的任何损坏概不负责。

警告！

如果设备在插入本设备或其他设备时需要转换器，请不要在没有所需转换器的情况下直接将记忆卡插入。

记忆卡使用注意事项

- 切勿将记忆卡暴露在潮湿的环境中。
- 切勿用手或任何金属物触碰卡的连接端。
- 切勿击打、弯折或跌落记忆卡。
- 切勿尝试拆卸或改装该记忆卡。
- 切勿在潮湿、易腐蚀、过热的地方（例如夏天的轿车里）使用或存放记忆卡。避免阳光直接照射。勿将其置于加热器附近。
- 切勿过于用力按压或弯折记忆卡适配器。
- 切勿让污垢、灰尘、或外界物质污染记忆卡适配器的插入口。
- 确保您已正确地插入了记忆卡。
- 将记忆卡插入到记忆卡适配器。记忆卡需被完全插入，否则可能无法正常使用。
- 请备份您的重要数据。对于记忆卡上数据的任何丢失或损坏，本公司不予负责。
- 当您在您进行格式化，读取或写入数据时，切勿取出记忆卡或记忆卡适配器、关闭设备、或将记忆卡置于带静电或强电场之处，否则可能会导致数据损坏或丢失。

个人信息保护

请在处理产品前清除个人数据。要删除数据，请执行重新设定。从设备记忆库删除数据并不能确保这些数据无法恢复。索尼不保证能够防止信息恢复，也不对即使重新设定后仍有信息泄露承担任何责任。

对于支持 3D 视图功能的设备

在支持 3D 的监视器上观看使用此设备（如适用）拍摄的 3D 图像时，您可能会发生眼部疲劳、疲倦或眩晕等不适症状。为避免发生此类症状，我们建议您定时休息。但您需要自行决定所需的休息时间长度和频率，因为这因人而异。如您感到任何不适，请停止观看 3D 图像，直到您感觉好一些，并根据需要就医。此外，也请参阅您已连接或与本设备一起使用的设备或软件随附的操作说明。请注意，儿童的视力仍处于发展阶段（尤其是 6 岁以下的儿童）。让您的孩子观看 3D 图像之前，请先咨询儿科医师或眼科医师，并确保您的孩子在观看此类图像时遵循上述注意事项。

音量警告！

请注意调整音量，过高的音量可能会损害您的听力。

针对包含激光发射器和相应驱动电路的设备

使用激光技术的自动对焦传感器。

激光输出的目的是在所有合理可预见的条件下，包括符合 IEC 60825-1:2014（第三版）的单一故障，可保持在 1 级激光安全限制内。

最终用户许可证协议

随本设备及其媒体一同提供的软件归 Sony Mobile Communications Inc.（索尼移动）和（或）其子公司、供应商和授权商所有。

索尼授予您一个非独占有限许可证，您只能将此软件与安装了此软件或随附此软件的设备配合使用。软件的所有权不会出售、转移或以其他方式转让。

请勿使用任何手段破解此软件的源代码或任何部分，复制或分发此软件，或修改此软件。如果第三方以书面形式同意遵守本许可证协议的条款，则您有权将对此软件的权利和义务以及随附此软件的设备一起转让给第三方。

本许可证在整个设备使用期内一直有效。以书面形式将您对设备的权利转让给第三方可终止本许可证。

违反这些条款和条件会立即终止许可证。

索尼及其第三方供应商和授权商保留对此软件的所有权利、所有权和权益。如果软件包含第三方的资料或代码，则这些第三方也应是这些条款的受益方。

本许可证受日本法律管辖。若适用，上述规定适用于消费者的法定权利。

如果随您的设备一同提供的软件还有附加条款和条件，则这些规定也应约束您对此软件的拥有和使用。

出口法规

出口法规：本设备或软件可能需遵守欧盟、美国和其他国家/地区的进出口法规。您应遵守这些适用法律和法规，获取并保留本协议规定的交付货物所要求的进出口许可。除上述条款外，购买者还必须遵守其他法规，例如，购买者不得有意将货品出口或再出口到欧洲理事会法规(EC) 428/2009 第 II 章中的条款所规定的目的地。特别是，在没有限制的情况下，购买者还需要遵守由美国商务部工业安全局管理的美国政府出口管理法规(“EAR”，15 C.F.R. § § 730-774, <http://www.bis.doc.gov/>)和由美国财政部外国资产管理局管理的经济制裁法规(30 C.F.R. § § 500 et. seq., <http://www.treas.gov/offices/enforcement/ofac/>)。

有限保修

Sony Mobile Communications Inc. (地址：4-12-3 Higashi-Shinagawa, Shinagawa-ku, Tokyo 140-0002, Japan) 或其当地的子公司针对本设备、随设备一同提供的原装配件和/或计算产品(下文中统称为“产品”)提供此“有限保修”。

如果您的产品需要保修服务，请将其送交到向您销售产品的经销商，或联系当地的索尼联系中心(可能需按各国家/地区费率收取费用)，或访问 www.sonymobile.com 了解详情。

义务

如果在保修期内，在正常使用和维护条件下，本产品由于设计、材料或工艺缺陷导致无法使用，产品销售国家/地区*的索尼授权分销商或服务合作伙伴可根据此处规定的条款和条件，自行决定维修、更换产品，或退款。

若返回的产品不符合以下保修条件，索尼及其服务合作伙伴保留收取手续费的权利。

请注意，索尼产品经维修或更换后，您的某些个人设置、下载信息和其他信息可能会丢失。目前，根据适用的法律、其他法规或者技术限制，可能不允许索尼对某些下载信息进行备份。索尼不对丢失的信息承担任何责任或者赔偿任何损失。在将索尼产品送交维修或更换前，您应备份保存在索尼产品上的所有信息，例如下载信息、日历和联系人。

条件

1. 修理或更换本产品时，必须提供本产品以及由索尼授权经销商开具的带有购机日期和序列号**的原始购机凭证，才能进行有限保修。如果在最初从经销商处购买本产品后，上述信息被涂抹或更改，索尼保留拒绝提供保修服务的权利。
2. 如果索尼维修或更换了本产品，则维修的部位或更换的产品将在原始保修期的剩余时间内或自维修日期算起的九十(90)天内（以较长期限为基准）继续享有保修服务。维修或更换可能需要使用功能等同的改装部件。更换的零件或元件归索尼所有。
3. 本保修不包括因以下原因导致的任何产品故障：
 - 正常损耗。
 - 在超过相关 IP 等级限制（如果适用）的环境中使用（包括浸液损坏或检测到因这种使用而造成设备内部有液体）。
 - 使用不当或者未遵照索尼的产品使用维护说明书进行使用。由于事故、软件或硬件改装或调整或者不可抗力导致的产品故障也不在本保修范围之内。

可充电电池可以充放电一百多次。但是，它最终将用坏，这属于正常损耗，并不是缺陷。通话或待机时间显著减少时，应及时更换电池。索尼建议您只使用索尼认可的电池和充电器。

各设备之间的亮度和颜色可能会有微小差异。显示屏上可能会有极小的亮点或暗点。当个别点出现故障时即会出现此种情况，而且无法进行调整。两个坏点像素在可接受范围之内。

各设备的相机图像外观可能会有微小差异。这种现象并不罕见，不能视为相机模块的缺陷。
4. 由于本产品运行的蜂窝系统由与索尼无关的运营商提供，因此索尼对该系统的运行、可用性、覆盖范围、服务或服务范围不承担任何责任。
5. 由非索尼授权人员对产品进行安装、改装、维修或开启而造成的产品故障，均不在本保修范围之内。
6. 由于使用本产品专用的索尼品牌的原装配件之外的配件或其他外围设备引起的产品故障，不在本保修范围之内。

对于由病毒、木马、间谍软件或其他恶意软件引起的本产品或外围设备的故障，索尼不承担任何明示或暗示的保修。索尼强烈建议您在本产品 and 任何外围设备上适当安装可用的防病毒软件，并定期进行更新，以更好地保护您的设备。但是，您理解此类软件不可能为本产品或其外围设备提供万无一失的保护，对于由防病毒软件未实现预定目的而引起的故障，索尼不承担任何明示或暗示的保修。
7. 若本产品上的封签有任何损坏，本保修将失效。

8. 索尼只承认此有限保修，其他任何书面或口头的明示保修一概无效。所有暗示保修，包括（但不限于）对适销性或针对某一特殊用途的适用性的暗示保修，均以此有限保修的持续时间为准。对任何性质的偶然或继发性损失，包括（但不限于）利润损失或商业损失，在法律容许的最大范围内，索尼或其许可方在任何情况下均不承担任何责任。某些国家/省不允许排除或限制偶然或继发性损失，也不允许限制默示保修期限，因此，上述限制或排除情况可能不适用于您。
- 提供的保修不影响消费者根据现行适用法律所享有的法定权利，也不会影响其享有与经销商间签订的购销合同中规定的权利。

国家/地区特定条款

如果您购买产品的所在地属于欧洲经济区(EEA)的国家/地区成员或者为瑞士或土耳其共和国，并且该产品专门在 EEA 或者瑞士或土耳其销售，则根据您需要维修服务的所在国家/地区中实行的保修条件，您的产品可以在 EEA 的任何国家/地区或者瑞士或土耳其享有维修服务，前提是索尼授权分销商在该国家/地区销售同款产品。若要了解您的产品是否在您所在的国家/地区销售，请致电当地的索尼联系中心。请注意，除了在最初购买所在的国家/地区之外，某些服务可能无法在其他地方享有，例如这种原因：您产品的内部或外部可能与其他国家/地区销售的相同型号有所不同。另请注意，有时还可能无法维修 SIM 卡锁定的产品。

****在某些国家/地区，可能需要更多信息（如有效的保修卡）。**

商标、声明和版权

© 2017–2018 Sony Mobile Communications Inc.（索尼移动）及其附属机构。保留所有权利。

Xperia 是 Sony Mobile Communications Inc.（索尼移动）的商标或注册商标。

索尼是 Sony Corporation 的商标或注册商标。

蓝牙是 Bluetooth SIG Inc.的商标或注册商标，索尼被授权许可使用此标志。

本用户指南中提到的所有产品和公司名称是其各自所有者的商标或注册商标。

本用户指南中未明确授予的任何权利均予保留。更多信息，请访问 www.sonymobile.com。

Sony Consumer Web site

At www.sonymobile.com/support there is a support section where help and tips are only a few clicks away. Here you will find the latest computer software updates and tips on how to use your product more efficiently.

Guidelines for Safe and Efficient Use

Please follow these guidelines. Failure to do so might entail a potential health risk or product malfunction. If in doubt as to its proper function, have the product checked by a Sony certified service partner before charging or using it.



Recommendations for care and safe use of our products

Caution

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

For your safety

- Do not let water or foreign objects get into the unit. It may cause a fire or electric shock. If water or foreign objects have gotten into the unit, turn it off immediately, and disconnect the power cord and connection cables.
- Do not disassemble or modify the unit. It may cause a malfunction, fire or electric shock.
- If there is a possibility of lightning strike, do not use the unit. A lightning strike may cause an electric shock. If lightning is likely, unplug the unit to prevent a fire, electric shock and malfunction.

On safety

- Wireless functions are incorporated into this unit. Radio waves may affect the operation of other devices. Do not use this device in the following locations.
 - On an airplane.
 - Near automatically-controlled equipment, such as automatic doors or fire alarms. If other equipment experiences problems such as interference while the unit is being used, immediately stop using the unit.
- Do not continue viewing the projected screen for a long time. Continuously viewing the projected screen for a long time may

cause eye strain. If you feel any discomfort or pain, immediately stop using the unit and have a rest. If the discomfort or pain persists after taking a rest, consult a doctor.

- Do not project onto a glossy surface. The light may be reflected into your eyes and may adversely affect them.
- Keep the unit away from children. If a cable becomes wrapped around the neck or similar misuse, it may cause an accident or injury.
- This device may contain small parts that could become detached and create a choking hazard. Keep this device away from children or other supervised individuals to prevent such hazard. They could hurt themselves or others.
- This device may contain small magnet(s). Swallowing magnet(s) could cause serious harm, such as choking hazard or intestinal injuries. Keep this device (or name of accessory) away from children or other supervised individuals to prevent any such harm. If you know or suspect that you or anyone has swallowed a magnet, seek medical attention immediately.
- This device contains magnet(s) which may interfere with pacemakers, defibrillators, programmable shunt valves, or other medical devices. Do not place this device close to such medical devices or persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

On handling

- If the unit is not to be used for a long time, unplug it.
- Do not drop, hit, compress, or put a heavy object on the unit.
- The operating temperature range of the unit is 5 °C to 35 °C. If the unit is used in an extremely cold or hot place outside the operating temperature range, it may cause a malfunction.
- Do not place the unit where there is excessive oily smoke, steam, moisture or dust. It may cause a fire or electric shock.
- Do not install the unit in a dangerously unsuitable location. The unit may fall causing an injury.

- Do not subject the unit to a strong impact. If you apply a strong force to the unit, such as putting a heavy object on it, drop it, or step on it, it may cause injuries or a malfunction. Although the projection window is made of tempered glass, if it is strongly pushed or struck, it may break causing injuries.
- Take care not to drop the unit when moving it. If the unit falls, it may break or cause injuries.

On placement

- Do not place the unit in any places where there is excessive dust or cigarette smoke. Dust and cigarette tar adheres to components inside the unit (such as the projection window) causing a malfunction.
- Do not place the unit in any places where the temperature is extremely hot or cold, or the humidity is extremely high. Especially when there is strong sunshine or during the summer, the inside of a car can get quite hot, and a unit left in the car may deform or malfunction.
- Do not place the unit on an unstable surface. The unit may fall or topple over resulting in injuries.
- Do not place the unit where there is water. It may cause a fire or electric shock.
- Do not place/store the unit in a place exposed to direct sunlight or close to a heater. Heat may build up in the unit causing a fire.

On AC adaptor and cables

- Do not damage the power cord. It may cause a fire or electric shock.
- Be sure to use the supplied AC adaptor with the unit. If a different AC adaptor is used with the unit, it may cause a fire, electric shock or malfunction.
- Do not touch the power plug with wet hands. It may cause an electric shock.
- Before making connections with the AC adaptor and connection cables, turn off the unit and connected equipment, and unplug the power plugs from the wall outlet.

- Do not wrap the power cord or connection cable around the AC adaptor. It may cause the cord or cable to break.
- Before moving the unit, disconnect the power cord and connection cables. The cables may be damaged resulting in a fire or electric shock, or connected equipment may fall or topple over causing injuries.
- Insert the connector straight. If it is inserted at an angle, pins may make a short circuit causing a fire.

On fan noise

A fan is incorporated inside the projector to prevent overheating, and this makes a slight noise while turned on. This noise is not a malfunction. However, if there are any abnormal noises, consult qualified Sony personnel.

On light source maintenance

This unit uses a laser, therefore special caution and facilities are necessary for the inspection and maintenance of light source components. Be sure to consult qualified Sony personnel.

On cleaning

- Be sure to turn the unit off and unplug it from the wall outlet before cleaning.
- If the unit is rubbed hard with a dirty cloth, the unit may be scratched.
- If volatile liquids such as insecticide are sprinkled on the unit, or an item made of rubber or vinyl stays in physical contact with the unit for a long time, the unit may be affected or the surface color may fade.
- Do not touch the projection window with bare hands.
- To clean the surface of the projection window:
Gently wipe it with a soft cloth such as an eyeglass cleaning cloth. If there are stubborn stains, wipe them up with a cloth moistened with water. Never use alcohol, benzene, thinner, acidic cleaning agents, alkaline cleaning agents, abrasive cleaning agents, chemical dust cloths, and so on.
- To cleaning the exterior:
Gently wipe it with a soft cloth. If there are stubborn stains, wipe up the stains with a soft cloth which has been soaked in diluted neutral detergent and thoroughly wrung out, then wipe the

exterior again with a dry cloth. Do not use alcohol, benzene, thinner, and so on.

On projector

- Although this unit is manufactured using very high precision technology, there may be some permanent black or white pixels on the projected screen. Also, there may be striped unevenness in color or brightness. This is a result of the projector structure and is not a malfunction. The color balance of each projector unit varies; therefore, when multiple LCD projectors are used, the color reproduction among projectors may vary, even if they are of the same model.
- Depending on viewed content, primary colors such as red, blue, or green are visible when you move your eyes or under certain conditions; this is not a malfunction. It is caused by a "color breakup" phenomenon which is specific to the field-sequential color system adopted into the unit for displaying images. This phenomenon can be subdued by diminishing the contrast between the image and the backdrop, such as decreasing the brightness of the unit or increasing the brightness of the room.

On condensation

If the projector is moved suddenly from a cold to a warm place, or just after a room heater is turned on in a winter morning, condensation may occur on the surface or inside of the projector. If condensation occurs, leave the projector turned off until the condensation dissipates. If the projector is used while there is condensation, it may cause a malfunction.

On ventilation holes

- Do not block the ventilation holes (intake/exhaust). If the ventilation holes are blocked, heat will build up inside the unit, causing a fire or malfunction. To maintain good ventilation, observe the following:
 - Place the unit away from walls and objects.
 - Do not use a cover that blocks the ventilation holes.
 - Do not place the unit on a soft cloth, paper documents, thick carpet or small pieces of paper. They may be drawn in and block the intake holes.
- Do not bring your hand or object close to the exhaust holes. It may cause burns or deformation.

On projection window

- Do not look into the projection window. The light may damage your eyes.
- Do not obstruct the projection window. The light will heat the obstruction, which may cause deterioration, deformation, burns or fire.

Cautions about heat generation of the unit

- While using or charging the unit, the unit or AC adaptor may become hot; this is not a malfunction. If the unit temperature becomes excessively hot, it may automatically turn off for safety. In such a case, use it in a cooler place after the unit has cooled down.
- If the unit or AC adaptor becomes unusually hot, it may malfunction. Immediately turn the unit off and unplug the AC adaptor from the wall outlet, then consult qualified Sony personnel.
- Do not continue touching the unit in operation or the AC adaptor for a long time. Prolonged contact with the skin may result in burns. Even touching through clothing, prolonged contact may result in burns.
- Do not use the unit or AC adaptor covered by cloth or bedding. Heat will build up causing deformation, malfunction or a fire.

On charging

- Charge the unit in the ambient temperature of 5 °C to 35 °C. The unit may not charge sufficiently outside this temperature range.
- While charging or using the unit, the temperature of the unit may rise; this is not a malfunction.
- If you do not use the unit for a long time, charge it every six months to prevent battery degradation.
- When the unit has been left unused for a long time, the charging time may be longer.
- When the battery usage time drops to half of its original time, it may have reached the end of its life span. Consult qualified Sony personnel about the rechargeable battery replacement.

On AC power interruption

When the unit is turned off using the power button, the power supply to the unit is not completely stopped. To completely stop the power supply to the unit, unplug it from the wall outlet. Place the AC adaptor close to the wall outlet so that you can quickly unplug it when becoming aware of a problem.

Personal medical devices

Mobile devices / devices with radio transmitters may affect implanted medical equipment. Reduce risk of interference by keeping a minimum distance of 15 cm(6 inches) between the Sony product and the medical device. Turn off the device if you suspect interference. For use in proximity to personal medical devices, please consult a physician and the device manufacturer.

GPS/Location based functions

Some products provide GPS/Location based functions. Location determining functionality is provided "As is" and "With all faults". Sony does not make any representation or warranty as to the accuracy of such location information.

Use of location-based information by the device may not be uninterrupted or error free and may additionally be dependent on network service availability. Please note that functionality may be reduced or prevented in certain environments such as building interiors or areas adjacent to buildings.

Malware

Malware (short for malicious software) is software that can harm the device. Malware or harmful applications can include viruses, worms, spyware, and other unwanted programs. While the device does employ security measures to resist such efforts, Sony does not warrant or represent that the device will be impervious to the introduction of malware. You can however reduce the risk of malware attacks by using care when downloading content or accepting applications, refraining from opening or responding to messages from unknown sources, using trustworthy services to access the internet, and only downloading content to the device from known, reliable sources.

Accessories

Use only Sony branded original accessories and certified service partners. Sony does not test third-party accessories. Accessories may influence RF exposure, radio performance, loudness, electric safety and other areas. Third-party accessories and parts may pose a risk to your health or safety or decrease performance.

Disposal of Old Electrical and Electronic Equipment (Applicable in the European Union and other European countries with separate collection systems)

This symbol on the device or on its packaging indicates that this device shall not be treated as household waste. Instead it shall be handed over to the appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this device is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this device. The recycling of materials will help to conserve natural resources. For more detailed information about recycling of this device, please contact your local Civic office, your household waste disposal service, or the shop where you purchased the device.



Declaration of substances

When the device is operated under the conditions stated in the device documentation, the Environmental Protection Use Period (EUP) is 10 years.



Name and content of hazardous substances in EEP

Part Name	Hazardous substances					
	Lead (Pb)	Mercury (Hg)	Cadmium (Cd)	Hexavalent chromium (Cr(VI))	Polybrominated biphenyls (PBB)	Polybrominated diphenyl ethers (PBDE)
Device	X	0	0	0	0	0
Battery	X	0	0	0	0	0
Accessories and chargers	X	0	0	0	0	0

This form is prepared in accordance with the stipulations set forth in SJ/T 11364.

0: Indicates that this hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in GB/T 26572.

X: Indicates that this hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in GB/T 26572. (Currently there are no alternative technologies available.)

Memory card

If the device comes complete with a removable memory card, it is generally compatible with the device purchased but may not be compatible with other devices or the capabilities of their memory cards. Check other devices for compatibility before purchase or use. If the device is equipped with a memory card reader, check the memory card compatibility before purchase or use.

Memory cards are generally formatted prior to shipping. To reformat the memory card, use a compatible device. For details, refer to the operating instructions of the device or contact the relevant Sony Contact Center.

SIM card

If your device is equipped with a standard-sized SIM card slot, inserting an incompatible SIM card (for example, a micro SIM card, a micro SIM card with a non-Sony adapter, or a standard SIM card cut into a micro SIM card size) in the SIM card slot may damage your SIM card or your device permanently. Sony does not warrant and will not be responsible for any damage caused by use of incompatible or modified SIM cards.

Warning!

If the device requires an adapter for insertion into the device or another device, do not insert the card directly without the required adapter.

Precautions on memory card use

- Do not expose the memory card to moisture.
- Do not touch terminal connections with your hand or any metal object.
- Do not strike, bend, or drop the memory card.

- Do not attempt to disassemble or modify the memory card.
- Do not use or store the memory card in humid or corrosive locations or in excessive heat such as a closed car in summer, in direct sunlight or near a heater, etc.
- Do not press or bend the end of the memory card adapter with excessive force.
- Do not let dirt, dust, or foreign objects get into the insert port of any memory card adapter.
- Check you have inserted the memory card correctly.
- Insert the memory card as far as it will go into any memory card adapter needed. The memory card may not operate properly unless fully inserted.
- We recommend that you make a backup copy of important data. We are not responsible for any loss or damage to content you store on the memory card.
- Recorded data may be damaged or lost when you remove the memory card or memory card adapter, turn off the power while formatting, reading or writing data, or use the memory card in locations subject to static electricity or high electrical field emissions.

Protection of personal information

Erase personal data before disposing of the product. To delete data, perform a master reset. Deleting data from the memory of the device does not ensure that it cannot be recovered. Sony does not warrant against recovery of information and does not assume responsibility for disclosure of any information even after a master reset.

For Devices Supporting 3D Viewing capabilities

In viewing 3D images shot with this device, if applicable, on a 3D-compatible monitor, you may experience discomfort in the form of eye strain, fatigue, or nausea. To prevent these symptoms, we recommend that you take regular breaks. However, you need to determine for yourself the length and frequency of breaks you require, as they vary according to the individual. If you experience any type of discomfort, stop viewing the 3D images until you feel better, and consult a physician as necessary. Also refer to the operating instructions supplied with the device or software you have connected or are using with this device. Note that a child's eyesight is still at the development stage (particularly children below the age of 6). Consult a pediatrician or ophthalmologist before letting your child view 3D images, and make sure he/she observes the above precautions when viewing such images.

Loudness warning!

Avoid volume levels that may be harmful to your hearing.

For a device that contains a laser emitter and corresponding drive circuitry

Auto Focus Sensor using laser technology.

The laser output is designed to remain within Class 1 laser safety limits under all reasonably foreseeable conditions including single faults in compliance with IEC 60825-1:2014(third edition).

End user licence agreement

Software delivered with this device and its media is owned by Sony Mobile Communications Inc., and/or its affiliated companies and its suppliers and licensors. Sony grants you a non-exclusive limited licence to use the software solely in conjunction with the device on which it is installed or delivered. Ownership of the software is not sold, transferred or otherwise conveyed.

Do not use any means to discover the source code or any component of the software, reproduce and distribute the software, or modify the software. You are entitled to transfer rights and obligations to the software to a third party, solely together with the device with which you received the software, provided the third party agrees in writing to be bound by the terms of this Licence.

This licence exists throughout the useful life of this device. It can be terminated by transferring your rights to the device to a third party in writing.

Failure to comply with any of these terms and conditions will terminate the licence immediately.

Sony and its third party suppliers and licensors retain all rights, title and interest in and to the software. To the extent that the software contains material or code of a third party, such third parties shall be beneficiaries of these terms.

This licence is governed by the laws of Japan. When applicable, the foregoing applies to statutory consumer rights.

In the event software accompanying or provided in conjunction with your device is provided with additional terms and conditions, such provisions shall also govern your possession and usage of the software.

Export regulations

Export regulations: The device or software may be subject to import and export regulations of the European Union, the United States and other countries. You will comply with these applicable laws and regulations and will obtain and maintain any export and import license required for the delivery of goods to you under this Agreement. Without limiting the foregoing, and as an example, you will not knowingly export or re-export goods to destinations identified pursuant to Articles in Chapter II of European Council Regulation (EC) 428/2009 and specifically, and without limitation, you will also comply with U.S. government Export Administration Regulations ("EAR", 15 C.F.R. §§ 730-774, <http://www.bis.doc.gov/>) administered by Department of Commerce, Bureau of Industry and Security and economic sanctions regulations (30 C.F.R. §§ 500 et. seq., <http://www.treas.gov/offices/enforcement/ofac/>) administered by the U.S. Department of Treasury, Office of Foreign Assets Control.

Limited Warranty

Sony Mobile Communications Inc., 4-12-3 Higashi-Shinagawa, Shinagawa-ku, Tokyo 140-0002, Japan, or its local affiliated company, provides this Limited Warranty for your device, original accessory delivered with your device, and/or your computing product (hereinafter referred to as "Product").

Should your Product need warranty service, please return it to the dealer from whom it was purchased, or contact your local Sony Contact Center (national rates may apply) or visit www.sonymobile.com to get further information.

What we will do

If, during the warranty period, this Product fails to operate under normal use and service, due to defects in design, materials or workmanship, Sony authorised distributors or service partners, in the country/region* where you purchased the Product, will, at their option, either repair, replace or refund the purchase price of the Product in accordance with the terms and conditions stipulated herein.

Sony and its service partners reserve the right to charge a handling fee if a returned Product is found not to be under warranty according to the conditions below.

Please note that some of your personal settings, downloads and other information may be lost when your Sony Product is repaired or replaced. At present, Sony may be prevented by applicable law, other regulation or technical restrictions from making a backup copy of certain downloads. Sony does not take any responsibility for any lost information of any kind and will not reimburse you for any such loss. You should always make backup copies of all the information stored on your Sony Product such as downloads, calendar and contacts before handing in your Sony Product for repair or replacement.

Conditions

1. This Limited Warranty is valid only if the original proof of purchase for this Product issued by a Sony authorised dealer specifying the date of purchase and serial number**, is presented with the Product to be repaired or replaced. Sony reserves the right to refuse warranty service if this information has been removed or changed after the original purchase of the Product from the dealer.
2. If Sony repairs or replaces the Product, the repair for the defect concerned, or the replaced Product shall be warranted for the remaining time of the original warranty period or for ninety (90) days from the date of repair, whichever is longer. Repair or replacement may involve the use of functionally equivalent reconditioned units. Replaced parts or components will become the property of Sony.
3. This warranty does not cover any failure of the Product that is due to:
 - Normal wear and tear.
 - Use in environments where relevant IP rating limitations, if applicable, are exceeded (including liquid damage or the detection of liquid inside the device resulting from such use).
 - Misuse or failure to use in accordance with the Sony instructions for use and maintenance of the Product.

Nor does this warranty cover any failure of the Product due to accident, software or hardware modification or adjustment, or acts of God.

A rechargeable battery can be charged and discharged more than a hundred times. However, it will eventually wear out – this is not a defect and corresponds to normal wear and tear. When the talk-time or standby time is noticeably shorter, it is time to replace the battery. Sony recommends that you use only batteries and chargers approved by Sony.

Minor variations in brightness and colour may occur between devices. There may be tiny bright or dark dots on the display. It occurs when individual dots have malfunctioned and can not be adjusted. Two defective pixels are deemed acceptable.

Minor variations in camera image appearance may occur between devices. This is nothing uncommon and is not regarded as a defective camera module.

4. Since the cellular system on which the Product is to operate is provided by a carrier independent from Sony, Sony will not be responsible for the operation, availability, coverage, services or range of that system.
5. This warranty does not cover Product failures caused by installations, modifications, or repair or opening of the Product performed by a non-Sony authorised person.
6. The warranty does not cover Product failures which have been caused by use of accessories or other peripheral devices which are not Sony branded original accessories intended for use with the Product.
Sony disclaims any and all warranties, whether express or implied, for failures caused to the Product or peripheral devices as a result of viruses, trojan horses, spyware, or other malicious software. Sony strongly recommends that you install appropriate virus protection software on your Product and any peripheral devices connected to it, as available, and update it regularly, to better protect your device. It is understood, however, that such software will never fully protect your Product or its peripheral devices and Sony disclaims all warranties, whether express or implied, in case of failure by such antivirus software to fulfil its intended purpose.
7. Tampering with any of the seals on the Product will void the warranty.
8. THERE ARE NO EXPRESS WARRANTIES, WHETHER WRITTEN OR ORAL, OTHER THAN THIS LIMITED WARRANTY. ALL IMPLIED WARRANTIES, INCLUDING WITHOUT LIMITATION THE IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY. IN NO EVENT SHALL SONY OR ITS LICENSORS BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES OF ANY NATURE WHATSOEVER, INCLUDING BUT NOT LIMITED TO LOST PROFITS OR COMMERCIAL LOSS TO THE FULL EXTENT THOSE DAMAGES CAN BE DISCLAIMED BY LAW.

Some countries/states do not allow the exclusion or limitation of incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

The warranty provided does not affect the consumer's statutory rights under applicable legislation in force, nor the consumer's rights against the dealer arising from their sales / purchase contract.

Country specific terms

If you have purchased your Product in a country member of the European Economic Area (EEA) or in Switzerland or the Republic of Turkey, and such Product was intended for sale in the EEA or in Switzerland or in Turkey, you can have your Product serviced in any EEA country or in Switzerland or in Turkey, under the warranty conditions prevailing in the country in which you require servicing, provided that an identical Product is sold in such country by an authorised Sony distributor. To find out if your Product is sold in the country you are in, please call the local Sony Contact Center. Please observe that certain services may not be available outside the country of original purchase, for example, due to the fact that your Product may have an interior or exterior which is different from equivalent models sold in other countries. Please note in addition that it may sometimes not be possible to repair SIM-locked Products.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. If you purchased your product in Australia, you are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. For warranty service in Australia, please contact 1300 650 050 or Sony Service Centre, Unit 4 / 189 Woodville Road Villawood NSW 2163.

** In some countries/regions additional information (such as a valid warranty card) may be requested.

Trademarks, acknowledgements and copyright

© 2017-2018 Sony Mobile Communications Inc. and its affiliated entities. All rights reserved.

Xperia is a trademark or registered trademark of Sony Mobile Communications Inc.

Sony is a trademark or a registered trademark of Sony Corporation.

Bluetooth is a trademark or a registered trademark of Bluetooth SIG Inc. and any use of such mark by Sony is under license.

All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners.

Any rights not expressly granted herein are reserved. Visit www.sonymobile.com for more information.

