

OPENRUN


使用指南

S803




8000500142 (A0)

开关机




配对 ①




1. 在关机状态下, **持续按住“+”** 键5秒, 不要松手。
2. 直到信号灯**红色蓝色交替闪烁**再松手, 这时, 耳机进入配对状态。

配对 ②



3. 打开设备的**蓝牙**设置功能, 选择“OpenRun by Shokz”, 听到语音提醒**“已连接”**。


多功能键



有关更多详细信息, 请参阅以下内容
**Please refer to the following
for more details**

<https://www.shokz.com.cn/uploads/soft/20220101/OpenRun.pdf>

ON/OFF 開關機




開機：
Turn on the headphones

Press and hold the Power/Volume+ Button for 2 seconds until the LED Indicator flashes blue.
按住電源/音量+鍵2秒
直至藍燈閃爍

關機：
Turn off the headphones

Press and hold the Power/Volume+ Button for 3 seconds until the LED Indicator flashes red.
按住電源/音量+鍵3秒
直至紅燈閃爍


Pairing ① 配對



1. Start with OpenRun turned **off**.
2. Press and **hold** the **Volume+** Button for **5 seconds** or until the LED Indicator **flashes red and blue**.

- 1. 在關機狀態下開始操作。
- 2. 持續按住“+”鍵5秒，不要鬆手。直到信號燈紅色藍色交替閃爍再鬆手，這時，耳機進入配對狀態。


Pairing ② 配對




3. Open your device's **Bluetooth** settings and select "**OpenRun by Shokz**." Audrey will say "connected."

3.打開設備的**藍牙**設置功能，選擇“OpenRun by Shokz”，聽到語音提醒“已連接”。

Multifunction Button 多功能鍵



- 播放/暫停音樂**
Play/pause music
Click once
按一下
- 接聽電話**
Answer call
Click once
來電時按一下
- 掛斷電話**
End call
Click once
通話時按一下
- 上一首歌曲**
Previous song
Triple-click while music is playing
歌曲播放時按三下
- 下一首歌曲**
Next song
Double-click while music is playing
歌曲播放時按兩下



有關更多詳細資訊，請參閱以下內容
Please refer to the following for more details

<https://www.shokz.com.cn/uploads/soft/20220101/OpenRun.pdf>

ENGLISH



Storage and Maintenance

- Store the headphones in a cool, dry place. The working temperature should be 0~45°C(32~113°F). Working in a cold/hot environment, a highly humid area, or an extremely low air pressure may reduce the battery life.
- Keep the product away from heat sources, direct sunlight, combustible gas or other liquids.
- Keeping the charging port dry before connecting to the charger will reduce the risk of damage.
- The headphones can be used for daily cleaning, but it cannot be rinsed and soaked against the microphone hole, otherwise it may affect the performance of the microphone.
- Clean the headphones with a soft dry cloth.
- Do not charge right after exercising, in case there's sweat inside the charging port, which could lead to circuit burning while charging.
- After storage for a long period, please charge the headphones before using again.

Note
Design and specification are subject to change without notice. For the most up-to-date product information, please visit www.shokz.com.cn.

Hearing Loss

Listening with headphones at high volume may affect your hearing and the audio will be distorted.

Safety Warnings

- To avoid the risk of explosion, fire, or leakage from toxic chemicals, please do not disassemble the product or replace, deform, or mutilate the battery.
- The headphones might explode if the battery is improperly replaced. It shall only be replaced with a battery of the same type or of the equivalent performance.
- Do not expose the headphones to sunlight, fire or similar high temperature.
- Do not dissemble the headphones or subject the headphones to shock, squeeze and fire. Do not use the headphones if it swells up. Do not expose the headphones to high temperature.

FCC

FCC Caution
Any changes or modifications not expressly approved by the party responsible for compliance

could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the IC radio frequency (RF) Exposure rules. This equipment has very low levels of RF energy that is deemed to comply without testing of specific absorption rate (SAR).

Responsible party (contact for FCC matters only):
AfterShokz LLC.
3200 Gracie Kiltz Lane, Suite 400 Austin, TX 78758 USA

WEEE Declaration of Conformity

This WEEE logo means that this product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. For more information on disposal and recycling of this product, contact your local municipality, disposal service, or the shop where you bought this product.

Manufacturer Declarations

Warranty: Shokz Holding Limited gives a warranty of 12 months on this product. For the current warranty conditions, please visit our website at www.shokz.com.cn or contact your Shokz partner. Before putting the product into operation, please observe the respective country specific regulations.

繁體中文

存儲與維護

- 耳機應當存放在陰涼乾燥處，使用溫度在0~45°C。如在過冷、過熱或過度潮濕環境下使用，可能會縮短電池壽命。
- 請讓產品遠離熱源、陽光直射、可燃氣體或其他液體。
- 充電前保持充電口乾燥會降低耳機損壞風險
- 該耳機可用於日常清洗，但不能對著麥克風孔處沖洗和浸泡，否則對其麥克風的性能可能會產生影響。
- 請使用柔軟的乾布清潔耳機。
- 請不要在運動後立即充電，以防充電口內有汗水，這可能導致充電時電路燒毀。
- 長時間存放後，請在使用前再次充電。

注意
設計和規格若有變更，恕不另行通知。最新公司及產品資訊，請訪問www.shokz.com.cn

聽力損傷

過高音量下聽音樂可能會損傷您的聽力，音質也可能會失真。

安全警告

- 為了避免爆炸、火災或有毒化學品洩漏的危險，請不要自行拆解產品或更換、變形或破壞電池。
- 如果電池更換不當會有爆炸危險，只能用同樣類型或等效類型的電池來更換。
- 電池不得暴露在諸如日照、火烤或類似過熱環境。
- 禁止拆解、撞擊、擠壓或投入火中。若出現嚴重鼓脹，請勿繼續使用，請勿置於高溫環境中。

根據NCC LP0002低功率射頻器材技術規範_章節3.8.2

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。前述合法通信，指依電信管理法規定作業之無線電通信。低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

製造商聲明

保修: Shokz Holding Limited為該產品提供12個月的保修服務。有關當前的保修政策，請訪問我們的網站: www.shokz.com.cn 或聯繫向你出售產品的零售商。
在產品開始使用前，請遵守相關國家的具體規定。



廢電池請回收

**請適當處理廢舊電池，
遵守本地規章，
請勿將其焚化。**

简体中文

存储与维护

- 耳机应当存放在阴凉干燥处。工作温度在0~45°C。在过冷、过热或过度潮湿环境下工作，可能会缩短电池寿命。
- 请让产品远离热源、阳光直射、可燃气体或其他液体。
- 充电前保持充电口干燥会降低耳机损坏的风险
- 该耳机可用于日常清洗，但不能对着麦克风孔处冲洗和浸泡，否则对其麦克风的性能可能会产生影响。
- 请用柔软的干布清洁耳机。
- 请不要在运动后立即充电，以防充电口内有汗水，这可能导致充电时电路烧毁。
- 长时间存放后，请在使用前再次充电。

注意
设计和规格若有变更，恕不另行通知。最新公司及产品信息，请访问www.shokz.com.cn

听力损伤

过高音量下听音乐可能会损伤您的听力，声音也可能失真。

安全警示

- 为了避免爆炸、火灾或有毒化学品泄漏的危險，请不要自行拆解产品或更换、变形或破坏电池。
- 如果电池更换不当会有爆炸危险，只能用同样类型或等效类型的电池来更换。
- 电池不得暴露在诸如日照、火烤或类似过热环境。
- 禁止拆解、撞击、挤压或投入火中。若出现严重鼓胀，请勿继续使用，请勿置于高温环境中。

制造商声明

保修: 深圳市韶音科技有限公司为该产品提供12个月的保修服务。有关当前的保修条件，请访问我们的网站: www.shokz.com.cn 或联系向你出售产品的卖方。
在产品投入使用前，请遵守相关国家的具体规定。

中国大陆有害物质表

产品中有害物质的名称及含量						
部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr (VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
印刷线路板	×	○	○	○	○	○
金属部件	×	○	○	○	○	○
电池	×	○	○	○	○	○
塑料部件	○	○	○	○	○	○
线缆	×	○	○	○	○	○
本表格依据 SJ/T 11364 的规定编制。 ○ 表示该有害物质在该部件所有均质材料中的含量均在GB/T26572规定的限量要求以下。 × 表示该有害物质至少在该部件的某一均质材料中的含量超出GB/T26572规定的限量要求。						

