
USING THE MOUSE DOCK

1. Plug the charging cable from your computer's USB port to the mouse dock.




Cable not included

2. Insert the USB wireless dongle into your computer's USB port.



CHARGING MODE

You can use the mouse dock to replenish your mouse's battery and to extend the reach of your USB wireless dongle.



You can also connect to Razer Synapse and place your Razer mouse on the charging dock to view the mouse's current battery status.

Color	Battery Percentage	Effect
Red	<5%	Breathing
Orange	26%-50%	Breathing
Yellow	51%-75%	Breathing
Green	76%-99%	Breathing
Green	100%	Static

Please refer to the Online Master Guide at **support.razer.com** for in-depth instructions on how to configure and use your Razer Mouse Dock Chroma.

FRANÇAIS
Reportez-vous au mode d'emploi en ligne disponible à l'adresse **support.razer.com** pour obtenir des instructions détaillées sur la configuration et l'utilisation de votre Razer Mouse Dock Chroma.

DEUTSCH
Weitergehende Anweisungen zur Konfiguration und Verwendung deiner Razer Mouse Dock Chroma findest du im Online-Handbuch unter **support.razer.com.**

PORTUGUÊS (BR)
Consulte o Guia Principal Online em **support.razer.com** para conferir mais detalhes e instruções sobre como configurar e usar o Razer Mouse Dock Chroma.

ESPAÑOL
Consulta la Guía principal en línea en **support.razer.com** para encontrar instrucciones detalladas sobre la configuración y el uso de Razer Mouse Dock Chroma.

УССКИЙ
Обратитесь к разделу Online Master Guide (Главное интерактивное руководство) на веб-сайте **support.razer.com** для получения подробных инструкций по настройке и использованию Razer Mouse Dock Chroma.

POLSKI
Szczegółowe instrukcje na temat konfigurowania zestawu słuchawkowego Razer Mouse Dock Chroma i jego obsługi znajdziesz w Przewodniku podstawowym dostępnym online pod adresem **support.razer.com.**

УКРАЇНСЬКА
Детальні вказівки щодо налаштування та використання Razer Mouse Dock Chroma див. в Основному інтерактивному посібнику на веб-сайті **support.razer.com**.

TÜRKÇE
Razer Mouse Dock Chroma 'nızın yapılandırılıp kullanılması ile ilgili daha detaylı bilgi için lütfen **support.razer.com** adresindeki Online Kullanım Kılavuzuna başvurun.

繁體中文
請於 **support.razer.com** 參閱線上主指南，深入瞭解如何設定和使用 Razer Mouse Dock Chroma 的說明。

簡体中文
请参阅在线高级用户指南（位于 **support.razer.com/cn**），了解有关如何配置和使用Razer Mouse Dock Chroma。

日本語
Razer Mouse Dock Chroma の設定および使用の詳細な手順については、Online Master Guide **support.razer.com** を参照してください。

한국어
Razer Mouse Dock Chroma 의 구성 및 사용 방법에 관한 더 자세한 지침을 보려면 **support. razer.com**에서 온라인 마스터 가이드를 참조해 주십시오.

فيبرعلا
يلع تيرتسرلا ربع يعيبطلا ليلدلا يف ديزملا نم ديزتسا .**support.razer.com** عقوم ىلإ هدوجو ةنايص ديلقو ةنايص ليلد ىلإ عجرا Razer Mouse Dock Chroma ةيفيكو

SAFETY AND MAINTENANCE

SAFETY GUIDELINES

In order to achieve maximum safety while using your Razer Mouse Dock Chroma, we suggest that you adopt the following guidelines:

Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to **support.razer.com** for assistance. Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.

Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and/or switch off the device in order to let the temperature stabilize to an optimal level.

MAINTENANCE AND USE

The Razer Mouse Dock Chroma requires minimum maintenance to keep it in optimum condition. Once a month we recommend you unplug the device and clean it using a soft cloth or cotton swab to prevent dirt buildup. Do not use soap or harsh cleaning agents.

REGULATORY & COMPLIANCE INFORMATION

FCC NOTICE

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

For more information, refer to the online help system on **razer.com**
This device complies with Part 15 of the FCC Rules.
Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

NOTICE FOR CANADA

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

CANADIAN CLASS B STATEMENT: This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus as set out in the radio interference regulations of Industry Canada.
Le présent appareil numérique n'émet pas de bruits radioélectriques dépassant les limitesapplicables aux appareils numériques de Classe B prescrites dans le règlement sur le brouillage radioélectrique édicté par Industrie Canada.

AUSTRALIAN & NEW ZEALAND RCM COMPLIANCE

AUSTRALIAN CONSUMER LAW COMPLIANCE

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure. Please refer to **razer.com/warranty** for further details.

THE FOLLOWING LIMITED WARRANTY ONLY APPLIES TO AUSTRALIA

Limited Warranty. Razer warrants the Product to be free from defects in materials and workmanship (subject to the terms set forth herein) when used normally in accordance with the official documentation for the applicable Warranty Period from the date of retail purchase. If the Product is, or contains, a rechargeable battery, Razer does not provide any warranties for the battery life, as all rechargeable batteries can be expected to lose charging capacity over time and this is not considered a defect. Your actual battery life will vary depending on the conditions in which it is used.

Limited Warranty Period. You are eligible for Limited Warranty support for the following periods of time commencing upon the date of retail purchase of your Product ("Warranty Period"):

Razer Mouse Dock Chroma	2 Years

All new Products will have the Warranty Periods listed above, subject to local law. Certain "end of life", sell out or discontinued Products may have a shorter Warranty Period; this will be clearly marked at the time of purchase and the given Warranty Period will be stated at that time. Factory Refurbished Products will have a Warranty Period of 90 days. If you are uncertain whether your Product is eligible for Limited Warranty support, please contact our support team for clarification here.

Exclusions and Limitations. This Limited Warranty does not cover:

(a) software, including (without limitation), (i) the operating system and software added to the Razer-branded hardware products through our factory-integration system, (ii) third-party software, or (iii) the reloading of software, software configurations or any data files;
(b) non-Razer branded products and accessories, even if packaged and sold with the Product; problems with and/or damage to the Product caused by using non-Razer accessories, parts, or components;
(c) damage caused by service (including upgrades and expansions) performed by anyone who is not officially acting as an employee, representative or sub-contractor of Razer;
(d) claims arising from any unacceptable use or care of the Product, including (without limitation) misuse, abuse, negligence, unauthorized modification or repair, unauthorized commercial use or any operation of the Product outside Razer's recommended parameters;
(e) claims arising from external causes, including (without limitation), accidents, acts of God, liquid contact, fire or earthquake;
(f) Products with a serial number or date stamp that has been altered, obliterated or removed;
(g) Products for which Razer will not receive payment; or
(h) cosmetic damage and normal wear and tear, including (without limitation), scratches, dents and chips.

Razer does not warrant that the operation of the Product will be uninterrupted or error-free.

Remedies under this Limited Warranty. The benefits to the consumer given by this Limited Warranty are in addition to other rights and remedies of the consumer under a law in relation to the goods or services to which this Limited Warranty relates. If an eligible claim on the Limited Warranty is received by Razer within the applicable Warranty Period, Razer will (at its sole option) either: (a) repair the Product or the defective parts at no charge, using new or refurbished replacement parts; (b) provide online Razer Store vouchers of a value equivalent to the retail purchase price of the Product; or (c) exchange the Product with a Product that is new or which has been manufactured from new or serviceable used parts and is at least functionally equivalent to the original Product. Goods presented for repair may be replaced by refurbished goods of the same type rather than being repaired. Refurbished parts may be used to repair the goods. Razer reserves the sole right to determine whether a claim is eligible and/or whether the Product is defective. Where the Product is an "end of life" Product model, Razer may (at its sole option) exchange the Product with a functionally equivalent substitute model from Razer's current Product range. Razer has the sole option to provide any other type of remedy in addition to or in substitution of the aforesaid remedies. Repaired or exchanged Products shall be warranted free from defects for a period of ninety (90) days after date of repair or exchange (as the case may be), or for the remainder of the original Warranty Period, whichever is longer.

Remedies under Australian Consumer Law. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Entire Limited Warranty. No Razer supplier, dealer, agent, or employee is authorized to alter or extend the terms of this Limited Warranty or to make any representation whatsoever. Razer reserves the right to amend the terms of this Limited Warranty at any time without notice.

Help Resources. Before lodging a claim on the Limited Warranty, please review the online help resources at **support.razer.com**. If the Product is still not functioning properly after making use of these resources, please contact Razer through support.razer.com or your authorized distributor or dealer. You may be required to assist with the diagnosis process to verify and ascertain any issues which you may be facing with the Product. Service options, parts availability and response times may vary depending on the country in which the Limited Warranty claim is lodged.

How to make a Limited Warranty claim.
IF YOU PURCHASED THE PRODUCT FROM A RAZER RESELLER, PLEASE CONTACT THE RAZER RESELLER IN REGARDS TO YOUR LIMITED WARRANTY CLAIM.
If you are unable to return the Product to the Razer reseller for whatever reason, or if you have purchased the Product directly from Razer at **razer.com**, then please follow the steps:

a. Go to **support.razer.com/contact-support** to obtain a Return Merchandise Authorization Number ("RMA Number").
b. Note the RMA Number in a visible place on the outside of the Product's package.
c. Enclose a Valid Proof of Purchase inside the Product's package. Please visit **razer.com/warranty** for examples of a Valid Proof of Purchase.
d. Send the Product to the following address:
Razer (Asia-Pacific) Pte Ltd
Attention: Technical Support Department
RMA Number: [Please note your RMA number here]
514 Chai Chee Lane #07-05 Singapore 469029

DO NOT SEND RAZER ANY PRODUCT WITHOUT A VALID RMA NUMBER.
We advise that you select a method of shipping that is traceable (eg. UPS, DHL, FedEx). Any expense of claiming under this Limited Warranty will be borne by the person making the claim (including any shipping and handling charges in returning the Product to Razer, as well as any applicable customs, duties or taxes in relation to the claim). If the Product is validly returned under the terms of this Limited Warranty,

Razer will be responsible for postage expenses for shipping the Product back to you (but not any customs charges, duties, or taxes). You are responsible for ensuring that the Product is properly packaged and will bear the full risk of loss or damage for any Product that is returned improperly packaged. Risk of loss or damage in the returned Product only passes to Razer when the Product is received by Razer and Razer shall not be responsible for items lost in transit to us. In the event that the procedure herein is not followed, Razer reserves the right to accept the delivery of the Product on such terms that it may determine at its sole discretion.

Returns Not Covered by this Limited Warranty. If Razer receives a Product from you that does not meet the requirements of this Limited Warranty, including (but not limited to) a Product that (a) lacks a valid RMA Number, (b) is not accompanied by a valid Proof of Purchase, (c) is no longer covered under the Warranty Period, or (d) does not have a defect covered by this Limited Warranty, you may be responsible for an assessment fee, return shipping and handling fees, and other reasonable fees as may be required by Razer prior to the Product being returned to you.

General. This Limited Warranty applies only to the original purchaser of the Product and is non-transferable. This Limited Warranty is only valid in Australia. No Razer reseller, agent, distributor, or employee is authorized to make any modification, extension or addition to this Limited Warranty. If any term of this Limited Warranty is held to be illegal or unenforceable, the legality or enforceability of the remaining terms shall not be affected or impaired.

This Limited Warranty is being offered to you by:
Razer Inc.
9 Pasteur, Suite 100, Irvine, CA 92618, USA
Phone Number: +1(949) 655-8888
support.razer.com/contact-us

STATEMENT OF COMPLIANCE WITH EU DIRECTIVE

ENGLISH
STATEMENT OF COMPLIANCE WITH EU DIRECTIVE
Hereby, Razer (Europe) GmbH, declares that this Razer Mouse Dock Chroma is in compliance with the requirements and other relevant provisions of Directive 2014/30/EU and 2015/863/EU

FRENCH
DÉCLARATION DE CONFORMITÉ AVEC LES DIRECTIVES DE L'UNION EUROPÉENNE
Par la présente Razer (Europe) GmbH déclare que l'appareil Razer Mouse Dock Chroma est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 2014/30/EU et 2015/863/EU

DEUTSCH
EG-KONFORMITÄTSERKLÄRUNG
Hiermit erklärt Razer (Europe) GmbH, dass sich dieser/diese/dieses Razer Mouse Dock Chroma in Übereinstimmung mit den grundlegenden Anforderungen und den anderen relevanten Vorschriften der Richtlinie 2014/30/EU und 2015/863/EU befindet.

ESPAÑOL
DECLARACIÓN DE CONFORMIDAD CON LA DIRECTIVA DE LA UE
Por medio de la presente Razer (Europe) GmbH declara que el Razer Mouse Dock Chroma cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 2014/30/EU y 2015/863/EU

ITALIANO
DICHIARAZIONE DI CONFORMITA' CON LE DIRETTIVE EU
Con la presente Razer (Europe) GmbH dichiara che questo Razer Mouse Dock Chroma è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 2014/30/EU e 2015/863/EU

PORTUGUÊS
DIRECTIVA DA UE COM DECLARAÇÃO DE CONFORMIDADE.
Razer (Europe) GmbH declara que este Razer Mouse Dock Chroma está conforme com os requisitos essenciais e outras disposições da Directiva 2014/30/EU e 2015/863/EU

DANSK
ERKLÆRING OM OVERENSSTEMMELSE MED EU-DIREKTIV
Undertegnede Razer (Europe) GmbH erklærer herved, at følgende udstyr Razer Mouse Dock Chroma overholder de væsentlige krav og øvrige relevante krav i direktiv 2014/30/EU og 2015/863/EU

ΕΛΛΗΝΙΚΑ
ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ Razer (Europe) GmbH ΔΗΛΩΝΕΙ ΟΤΙ Razer Mouse Dock Chroma ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 2014/30/ΕΕ και 2015/863/ΕΕ

POLSKI
OŚWIADCZENIE O ZGODNOŚCI Z DYREKTYWĄ UE
Niniejszym Razer (Europe) GmbH oświadcza, ze Razer Mouse Dock Chroma jest zgodny z zasadniczymi wymogami oraz pozostałymi stosownymi postanowieniami Dyrektywy 2014/30/EU i 2015/863/EU

The full Declaration of Conformity can be requested via the following :
Company: Razer (Europe) GmbH
Address: Essener Bogen 23, 22419 Hamburg, Germany
E-mail: **compliance@razer.com**

NOTICE FOR KOREA EMI STATEMENT

식별부호 R-R-RAZ-RC30-030502

B급 기기 (가정용 방송통신기기)
이 기기는 가정용 (B급) 으로 전자파적합등록을 한 기기로서 주로 가정에서 사용하는 것을 목적으로 하며, 모든 지역에서 사용할 수 있습니다.

CUSTOMS UNION CERTIFICATION:

WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT INFORMATION

ENGLISH
Correct Disposal of This Product (Waste Electrical & Electronic Equipment)
(Applicable in the European Union and other European countries with separate collection systems) This marking shown on the product or its literature, indicates that it should not be disposed with other household wastes at the end of its working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product should not be mixed with other commercial wastes for disposal.

LEGALESE

COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION
©2020 Razer Inc. All rights reserved. Razer, the triple-headed snake logo, Razer logo, "For Gamers. By Gamers.", and "Powered by Razer Chroma" logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks and trade names are the property of their respective owners and other company and product names mentioned herein may be trademarks of their respective companies.

Razer Inc. ("Razer") may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this guide. Furnishing of this guide does not give you a license to any such copyright, trademark, patent or other intellectual property right.
The Razer Mouse Dock Chroma (the "Product") may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

LIMITED PRODUCT WARRANTY
For the latest and current terms of the Limited Product Warranty, please visit: **razer.com/warranty**.

LIMITATION OF LIABILITY
Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer's liability exceed the retail purchase price of the Product.

GENERAL
These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

Information correct at the time of printing
IPIG-RC30-030502-200709JC

RAZER
MOUSE DOCK CHROMA