

Jabra

GN9330e



English Guide for basic set-up and use
中文 基本安装和使用指南



Quick Start Guide





For detailed information about buttons and functions, please see Guide for additional functions.




有关按钮和功能的详细信息，请参阅《附加功能的指南》的其他功能。

English

- [1] Microphone
- [2] Boom arm
- [3] Speaker
- [4] Link indicator
- [5] Volume control with mute switch
- [6] Talkbutton
- [7] Ear hook
- [8] Base cover
- [9] Clear dial tone switch
- [10] Headset charge facility
- [11] Telephone cord port
- [12] Handset cord port
- [13] A/C power adapter port
- [14] Online indicator port (OLI)
- [15] AUX port for GN1000
- [16] Pairing button
- [17] Microphone Volume
- [18] Charge tower
- [19] Mute indicator
- [20] Battery indicator (4 diodes)
- [21] Base Talkbutton (with indicator)
- [22] A/C power cord
- [23] Telephone cord
- [24] Headband

中文

- [1] 麦克风
- [2] 话筒吊臂
- [3] 扬声器
- [4] 链接指示灯
- [5] 使用静音开关进行音量控制
- [6] 通话按钮
- [7] 耳勾
- [8] 机座盖子
- [9] 拨号音清晰度调节开关
- [10] 耳麦充电工具
- [11] 电话线端口
- [12] 听筒线端口
- [13] A/C 电源适配器端口
- [14] 在线指示灯端口
- [15] 用于 GN1000 的 AUX 端口
- [16] 配对按钮
- [17] 麦克风音量
- [18] 充电塔
- [19] 静音指示灯
- [20] 电池指示灯 (4 个二极管)
- [21] 机座通话按钮 (带有指示灯)
- [22] A/C 电源线
- [23] 电话线
- [24] 头夹





The number of lit battery indicator diodes shows level of charge, even with headset out of base.



耳麦不在机座上时，亮起的电池指示灯二极管的数目也可显示充电水平。



See Guide for additional functions for setting up the GN1000 and an external OLI.



请参阅《参考指南》，附加功能的指南 GN1000 和外部 OLI 的信息。

English

Setting up

[2.1] Unplug handset cord.

[2.2] Plug handset cord to base.

[2.3] Plug base's cord to telephone.

Note: If your telephone has a separate headset port, please refer to the "Guide for additional functions" for setting up and using this port.

Connecting to power

[2.4] Plug power adapter into base.

[2.5] Plug power adapter into electrical outlet.

► **Telephone button** will light.

Charging

[2.6] Place headset in base to charge.

All **Battery indicator** diodes will light for 1 sec.

[2.7] Charge headset for minimum 30 min. before use. A full charge takes 3 h.

中文

安装

[2.1] 拔下听筒线。

[2.2] 将听筒线插入机座。

[2.3] 将机座线插入电话。

注：如果电话有单独的耳麦端口，请参阅《附加功能的指南》，了解如何设置和使用此端口。

连接至电源

[2.4] 将电源适配器插入机座。

[2.5] 将电源适配器插入电源插座。

► 电话机指示灯亮起


充电

[2.6] 将耳麦放入机座中，进行充电。所有电池指示灯二极管将亮起 1 秒钟。

[2.7] 在使用耳麦之前至少将其充电 30 分钟。完全充电需要 3 个小时。


Setting up

安装



Charging

充电



See www.jabra.com for more about clear dial tone adjustment.

请参阅 www.jabra.com, 了解关于拨号音清晰度调节的详细信息。

English

Clear dial tone adjustment

[3.1] Put on headset.

[3.2] Lift handset and listen for dial tone in headset.

► If no/unclear dial tone is heard, continue adjustment to 3.3.

[3.3] Remove base cover and locate clear dial tone switch.

[3.4] Slide the switch (through A-G settings) until dial tone is clear. If dial tone is just as clear in position A as in position G, leave switch in position A.

Microphone volume setting

▲ This setting is critical for your voice to be heard clearly.

[3.5] Put on headset.

[3.6] Make a call to someone who will act as test person.

[3.7] Adjust microphone volume until your test person confirms your voice is at appropriate volume.

Adjusting speaker volume

[3.8] Push volume switch up/down to adjust transmit volume.

► Tones in headset indicate volume level.

中文

拨号音清晰度调节

[3.1] 戴上耳麦。

[3.2] 拿起听筒，听耳麦中的拨号音。

► 如果听不到拨号音或听到的拨号音不清晰，请继续按 3.3 调节。

[3.3] 取下机座盖，并找到拨号音清晰度调节开关。

[3.4] 将开关从 7 个档位 (A-G) 上逐一滑过，直到拨号音清晰为止。如果在位置 A 和在位置 G 处的拨号音清晰度相同，则将开关置于 A。

传送音量设置

▲ 要使对方清晰地听到您的声音，该设置很关键。

[3.5] 戴上耳麦。

[3.6] 向测试人员拨打电话。

[3.7] 调节 麦克风音量 调节器，直到测试人员确认您的音量合适为止。


调节扬声器音量

[3.8] 升/降音量开关以调节传送音量。

► 耳麦中的声音指出音量级别。


Clear dial tone adjustment

拨号音清晰度调节



Microphone volume setting

传送音量设置



Adjusting speaker volume

调节扬声器音量



You can also make/end calls remotely via telephone using GN1000. See Guide for additional functions for instructions.



也可以使用 GN1000 通过电话机远程拨打/挂断电话。请参阅《参考指南》，附加功能的指南。

English

Making calls

[4.1] Remove headset from base, or press headset's **talk button** if already wearing headset.

[4.2] Telephone indicator will start flashing.

[4.3] Lift telephone's handset and wait for dial tone.

[4.4] Dial desired number.

Ending calls

[4.5] Place telephone's handset.

[4.6] Place headset in base, or press headset's talk button.

Base talk button with indicator: Lit when power is on and flashing when link in headset is activated.

中文

通过电话机拨打电话

[4.1] 将耳麦从机座取下，或者按耳麦的通话按钮（如果已经戴上耳麦）。

[4.2] 电话指示灯开始闪烁。

[4.3] 拿起电话听筒并等待拨号音。

[4.4] 拨打需要的电话号码。

挂断电话




[4.5] 将电话听筒放回原位。

[4.6] 将耳麦放回机座中或按耳机的通话按键。

带有指示灯的基本通话按钮：通电时指示灯亮起，耳麦中的链接激活时指示灯闪烁。



Making calls

通过电话机拨打电话



Ending calls

挂断电话



English

Answering calls

[5.1] The telephone will ring.

[5.2] Remove headset from base, or press headset's **Talkbutton** if wearing headset.

[5.3] Lift telephone's handset.

► The call will be directed to headset.

Mute function

[5.4] Mute function is activated/deactivated by pressing the volume control's mute switch.

► When mute is activated, a tone in regular intervals is heard in headset and mute indicator on base lights.

Note: Mute function automatically deactivates when a call is terminated.

中文

接听电话

[5.1] 电话铃响起。

[5.2] 从机座上取下耳麦，或者按耳麦的通话按钮（如果已戴上耳麦）。

[5.3] 拿起电话听筒。

► 随后电话可直接传到耳麦。

静音功能



[5.4] 通过按下音量控制的静音开关可启用/停用静音功能。

► 启用静音时，将在耳麦中听到有规律的间隙性声音，而且机座上的静音指示灯将亮起。

注：终止电话时，将自动停用静音功能。



Answering calls

接听电话



Mute function

静音功能



For more information and technical specifications see Guide for additional functions on www.jabra.com/gn9330e/support

- Wearing styles
- Audio/visual indicators
- Remote handset lifting (RHL)
- Troubleshooting
- Installation on phones with headset port

有关详细信息和技术规范, 请参阅
www.jabra.com/gn9330e/support
上的附加功能的指南:

- 佩戴方式
- 音频/视频指示灯
- 远程听筒提举 (RHL)
- 故障排除
- 通过耳麦端口安装到电话上



GN Netcom Australia Pty Ltd

Unit 6, 20 Cato Street
Hawthorn East, Victoria 3123
Australia
Tel. +61 3 8823 9111
Fax. +61 3 8823 9199
help.au@jabra.com
www.jabra.com



GN Netcom Asia Ltd.

30/F, 88 Hing Fat Street
Causeway Bay
Hong Kong
Tel. +852 3550 9900
Fax. +852 3550 9933
help.hk@jabra.com
www.jabra.com

GN Netcom (Singapore) Pte Ltd.

16 Raffles Quay #20-04
Hong Leong Building (S) 048581
Singapore
Tel. +65 6542 4550
Fax. +65 6542 4551
help.sg@jabra.com
www.jabra.com

GN Communications Shanghai Co., Ltd.

Suite 2403
Zhongrong Hengrui International Plaza
620 Zhangyang Road
Shanghai 200122
P.R. China
Tel. +86 21 5836 3670
Fax. +86 21 5836 3671
help.cn@jabra.com
www.jabra.com