HTC Vive Pro Quickstart Guide



VR Expert
Demkaweg 11
3555HW, Utrecht

Info@vr-expert.nl
030 7116158

VREXPERT


HTC Vive Pro - Guide

VREXPERT

Hardware







In the box

- 1x HTC Vive Pro Headset
- 2x Controller 2.0
- 2x Lighthouses
- 1x Linkbox 2.0
- 1x DisplayPort Kabel
- 1x USB cable
- 1x Headset cable connector
- 1x Power cable
- 2x Power Adapters for controllers
- 2x Micro USB Cable
- 2x Power Adapter for Lighthouse
- 1x Sync cable
- 2x Lanyard

Before you start

- Do not allow the lenses to come in contact with periods of **direct sunlight**. This will permanently damage the screen and does not fall under warranty.

- Make sure your computer is compatible with the HTC Vive or you will not be able to start. You can check your compatibility here: https://www.vive.com/eu/support/vive/category_howto/how-to-check-if-pc-meets-system-requirements.html

HTC Vive Pro - Guide

VREXPERT

How to install

1. Start your computer.
2. Download and install the VIVE software. (https://www.vive.com/us/setup/)
3. Download and install Steam. (https://store.steampowered.com/about/)
4. Create a VIVE account and log in.
5. Create a Steam account and log in.
6. Download and install the Steam VR application from the Steam shop.
7. Install the Lighthouses by plugging in the power adapters.
8. Connect the Headset with linkbox via the headset cable connector (With the triangle markup).. Then connect the linkbox with the Computer through the corresponding cables.
    a. Put the USB-C Cable into a USB 3.0 port of the Computer and linkbox
    b. Insert the DisplayPort cable into the DisplayPort port on your computer's graphics card.
    c. Put the Power cable connect to the linkbox into the power socket.
9. Turn on the Linkbox by clicking on the blue button at the Linkbox
10. Connect the Controller by holding in the menu buttons. Pai
    a. Start Steam VR.
    b. Click on the hamburg icon in the Steam VR window.
    c. Go to devices.
    d. Go to "Pairing Controller".
    e. Follow the instructions.
11. If small exclamation marks appear on the icons in the SteamVR window:
    a. The device should have a software update available and you should update the device.
    b. Click on the hamburger icon.
    c. Go to devices.
    d. Go to "Actualise devices".
12. If the headset, controller and lighthouses are connected, follow the instructions in the device. .
13. You are ready to go - Enjoy the ride!.

Main Menu in the device

- *Taskbar of the menu. (in the middle of the screen)*
  Here you will find the most common applications like
  (Topsteamvr Apps - Environment- screenshots)

- *Sidebar. (On the left side of the screen)*
  Here you will find social events like friends.
  (Rooms- Recent apps and Steam apps)

HTC Vive Pro - Guide

VREXPERT

Controllers

- **Menu button**
  Press this button to start a shortcut menu. You will find the tutorial and settings here.
- **Trackpad**
  With the trackpad you will be able to select through the menu in the device
- **Menu button**
  This is the button for Steam. Here you will be able to search and download apps from Steam.
- **Trigger button**
  To confirm your choices and scale your room
- **Grip button**
  Choose another skin for your controller.


How to download applications from the HTC Vive store

- Click on the “Steam menu” button on your controller.
- Click on “Store” in the HTC Vive main menu.
- Search for the desired application in the store or search for it manually with the search function. (Navigate -> Search)
- Click on the application and then press download or buy.
- The application will then appear in your library.



VIVE PRO SPECS

Unprecedented presence with Hi-Res and 3D spatial audio
Stay immersed comfortably with higher display resolution, easy-to-use headset & cable design, and improved ergonomics
Chaperone technology
Free to move around wirelessly with VIVE Wireless Adapter*
*VIVE Wireless Adapter sold separately.



Headset Specs

Screen:	Dual AMOLED 3.5" diagonal
Resolution:	1440 x 1600 pixels per eye (2880 x 1600 pixels combined)
Refresh rate:	90 Hz
Field of view:	110 degrees
Audio:	Hi-Res certificate headset
	Hi-Res certificate headphone (removable)
	High impedance headphone support
Input:	Integrated microphones
Connections:	USB-C 3.0, DP 1.2, Bluetooth
Sensors:	SteamVR Tracking, G-sensor, gyroscope, proximity, IPD sensor
Ergonomics:	Eye relief with lens distance adjustment
	Adjustable IPD
	Adjustable headphone
	Adjustable headstrap

VIEWLISTIC Let's Collaborate

VIVE PRO HMD includes

- Headset
- 2 x Sensors
- 2 x Remotes
- Headset cable (attached)
- Face cushion (attached)
- Cleaning cloth
- Earphone hole cap (2)
- Documentaion
- Link box
- Power adapter
- DisplayPort™ cable
- USB 3.0 cable
- Mounting pad
- 2 x Sensors
- 2 x Remotes

Recommended Computer Specs

Processor: Intel® Core™ i5-4590 or AMD FX™ 8350, equivalent or better.

Graphics: NVDIA® GeForce® GTX1060 or AMD Radeon ™ RX480, equivalent or better. View the complete list >

Memory: 4 GB RAM or more

Video out: DisplayPort 1.2 or newer

USB ports: 1x USB 3.0 or newer port

Operating system: Windows® 8.1 or later, Windows® 10