Epicure Bamboo Digital Scale

Operating Instructions




PRODUCT SPECIFICATIONS

Product size	187 x 217 x 6 mm
Power	3x 1.5V AAA batteries
Display	LCD readout display
Max Capacity	5 kg/11 lb : 0.4 oz. 5000 ml/176 fluid oz.
Division	1 g/0.1 oz. 1 ml/0.1 fluid oz.

PRODUCT FEATURES

- Equipped with a four precision strain gauge sensors system
- Touch on/Auto off/Touch off
- Tare function
- Measure volume of water and milk
- Two weight units: g-lb:oz
- Two volume units: ml-fluid oz.
- Low battery/over-load indication

PRODUCT STRUCTURE



LCD DISPLAY FUNCTION



:negative value
:tare weight
ml : volume unit

g : weight unit
lb:oz: weight unit
fl'oz: volume unit



weight mode



milk volume mode



water volume mode

TO INSERT OR REPLACE BATTERY

1. On the base of the scale, gently remove the battery cover as per the arrow direction.
2. Insert 3x AAA batteries into the compartment, observing the polarity markings in the base.
3. After inserting the batteries, replace the battery cover and push the cover backward.

NOTE: Please be aware that the incorrect polarity may cause permanent damage to electronic parts.

BUTTON FUNCTIONS



Manual on/Manual off/Zero/Tare




Unit Conversion: g-lb:oz, ml-fl'oz
Mode Conversion: weight<->milk volume<->water volume

OPERATION

1. Before use, place the scale on a solid, level surface. Place any container or bowl you will use to hold your ingredients on the scale before operation.
2. Gently press the button to turn on the scale.
3. The LCD display will show its start routine as it powers on. Wait until the “0” is shown on the display.
4. Place the ingredients to be weighed on the scale (or in the bowl if required). The LCD will show the weight reading.
5. After weighing press the power button for three seconds to turn off the scale. Alternately, the scale will automatically power off in 2 minutes.

MODE CONVERSION


The scale features three weight modes. To measure different items, users can select required weight mode by pressing the “UNIT” button to change the unit of measurment, milk volume mode or water volume mode. At the left corner of the LCD screen you will see the unit of measurement. See above LCD Display functions.



UNIT CONVERSION

Choose between Metric (g, ml) and Imperial (lb:oz, fl'oz), users can select units from g to lb:oz or ml to fl'oz.

While the scale is on, select the required unit by pressing the power button for 3 seconds until the desired unit is shown, g/lb:oz or ml/fl'oz.



TARE FUNCTION

The tare Function allows you to weigh another item consecutively after weighing the first item without removing it from the scale.

1.  Gently touch the ⏻ button to turn on the scale.
2.  The scale LCD display will show its start routine of segment asit powers on.
3.  Wait until the "0" is shown on the display. Put the container on the scale platform.
4.  The LCD display will show the steady weight of the container.
5.  Touch the ⏻ button to clear the weight of the container (reset to zero).
6.  The lower-left corner will show icon T , it means the Tare function is activated.
7.  Add the ingredients into the container.
8.  The LCD will show the weight of the ingredients only. Repeat touching the ⏻ button to weight new different ingredients.

NEGATIVE VALUE

The display will show a negative value (see LCD functions) if a weight has been removed from the scale. Please press the power button to clear the negative value, the display will show “0” again.

ERROR INDICATION



The “Lo” symbol on the display indicates that the battery power is running low. Please replace battery.



The “Err” symbol on the display indicates that the scale is over-loaded. Please remove all items to avoid possible damage to the product.



The “un5f”symbol on the display indicates that the scale is not stable for weighing. Please follow operation instructions for usage.

CARE AND MAINTENANCE OF THE SCALE

- Place the scale on a solid level surface before use.
- Avoid hitting or dropping the scale otherwise damage may occur.
- Do not overload the scale or put heavy things on the scale when not use.
- Treat the scale with care as it is a highly precise electronic instrument.
- Do not immerse this product in water or any other liquid. Please keep dry surface.
- Clean the scale with a soft damp cloth, do not use chemicals or harsh abrasives.

BATTERY ADVICE

- If the scale is not to be used for long periods, it’s recommended to remove the battery to avoid damage to the scale due to possible battery leakage.
- Keep the battery our of reach of children.
- Do not overheat batteries
- Waste batteries should not disposed of with household waste.
- Please check with your local authority for battery recycling advice.