

Blueair Classic

用户手册 500/600 系列



中文 (简) | English

使用布鲁雅尔（Blueair）Classic 500 和 600 系列之前，请仔细阅读本用户手册。

注意：
这些型号可能有不同的当地版本。

目录

综述 4

设备概述 5

控制档位 5

安全信息 6

设备放置 8

开始 8

控制面板和触摸键 9

Blueair Friend 手机应用设置 10

更换滤网 11

保养和维护 13

滤网 14

滤网使用寿命换算表 15

售后服务指南 16

欢迎加入 Blueair 会员俱乐部 17

产品性能标贴 33

综述

Blueair 500/600 系列


布鲁雅尔（Blueair）500/600系列空气净化器共有二种型号，均配备了Wi-Fi连接功能。内置PM2.5、VOC、温度/湿度传感器。

可通过位于翻盖之下控制面板上的触摸键随时随地手动控制，或通过 Blueair Friend™ 手机应用远程控制空气净化器。


空气净化器还可根据内置传感器的空气质量读数自动进行调节。

有关如何搭配使用空气净化器和布鲁雅尔空气通™（Blueair Aware™）空气质量监测仪的更多信息，请参见布鲁雅尔空气通™（Blueair Aware™）用户手册和支持信息。

580i/680i 型号



设备概述



控制档位

请参阅下表查看控制空气净化机的不同方式

控制方式	580i/680i
通过控制面板上的触摸键手动控制	
通过 Blueair Friend 手机应用远程控制	
自动模式基于内置传感器的空气质量读数。该功能可通过控制面板上的触摸键或通过 Blueair Friend 手机应用启用	

建议在初始快速清洁、白天或空气严重污染时使用最高速度。建议在晚间时使用最低速度。

安全信息

布鲁雅尔（Blueair）500/600系列空气净化器是电器产品，请在使用前阅读安全说明并采取必要预防措施来降低火灾、触电或受伤的风险。**布鲁雅尔（Blueair）有限保修仅在遵照这些说明使用设备时适用。**



警告：表示危险情况，如果未避免，可能造成死亡或严重受伤。



注意：表示危险情况，如果未避免，可能造成轻度或中度受伤。

综述



- **警告：**为了避免危险，必须始终由制造商、服务代理商或类似有资质的人员更换损坏的电源线。
- 将 Blueair 空气净化器随机附送的接地电源线直接插入到合适的接地电源插座中。（请查看电器上的电压标签）
- 切勿以任何方式改动插头。

预期用途



- 注意：**请密切监督儿童，以免儿童因不当操作受到伤害。
- 本产品不适用于肢体功能、感觉功能、智力水平受限，或缺乏相关经验与知识的人员（包括儿童）使用。以上人员可在监护人的指导下使用本产品，监护人应对使用者的安全负责。

让您的Blueair空气净化器发挥极致功效

Blueair系统的使用十分简便。您只需确保这台空气净化器的规格适合房间大小，并遵照推荐的滤网更换时间表更换滤网即可。请记住：正如空调和加热器都有气流量的限值那样，每一套空气净化器也有其可以净化的空气量限值。请务必遵循以下的一般规律。

使用时请适当关闭窗户

在炎热的夏天，如果您打开窗户就不能期望空调高效地工作，因为您可以明显感觉到热空气的涌入和冷空气的流出。即使您无法看到受污染的空气涌入和洁净的空气流出，实际情况仍然是相同的。在使用空气净化器时请适当关闭窗户。（可根据需求适当留3-5厘米缝隙）

您还必须紧闭房门

正如您在寒冷冬季的夜晚可能将屋子的一部分密闭起来，以保持取暖设备更有效地运行那样，相对密闭的空间能使您的这套空气净化器获得最佳的运行效果。

建议每天24小时运行您的空气净化系统

为了获得最佳的效果，您应当每天24小时、每周7天持续运行这一台Blueair空气净化器。24小时不间断运行，就确保持续地为室内供应洁净、健康的空气。Blueair空气净化器旨在实现非常低的功率消耗；事实上，根据不同的型号和运行速度，Blueair空气净化器的能耗在特定条件下能耗与单个白炽灯泡相当。

设备放置



将净化机放置在空气可以自由进出并在净化机周围流通的地方。



切勿将设备放在暖气、壁炉或烤箱等热源附近。



切勿将净化机放在距离其它物体不足 6 英寸（15 厘米）之处。



切勿将设备放在潮湿区域如浴室、洗衣房等机器有可能接触到水的地方。



切勿将净化机直接放置或依靠在软性家具上，如床上用品或窗帘。



切勿将设备放在室外。


开始

连接空气净化器

遵循下列说明，将空气净化器与 Blueair Friend 手机应用连接，即可启用远程控制。

第 1 步

将固定式电源线插入三孔插座中。如果您所购产品的电源线是分离式的，请先将电源线牢固地完全插入位于净化机底部的插槽中，再将电源线的另一端插入三孔插座。



打开翻盖并按住 Wi-Fi 触摸键。当 Wi-Fi 符号开始闪烁时，空气净化器可与 Blueair Friend 手机应用配对。

第 2 步

从应用商店（Apple App Store 或腾讯应用宝）将 Blueair Friend 手机应用下载到智能手机上。

第 3 步

将净化机与 Blueair Friend 手机应用连接。启动应用并按照说明操作。

将空气净化器与 Blueair Friend 手机应用连接后，可使用手机应用远程控制净化机并更改设置。

Classic 580i/680i 控制面板触摸键



自动档

蓝色圆圈状态 - 净化机开机
灰色符号状态 - 自动档关闭
蓝色符号状态 - 自动档开启



VOC 指示器

蓝色状态 - 空气质量为优秀至轻度污染
橙色状态 - 空气质量为中度至重度污染

请参见 Blueair Friend 手机应用了解更多关于污染级别阈值的信息



PM2.5 指示器

蓝色状态 - 空气质量为优秀至轻度污染
橙色状态 - 空气质量为中度至重度污染

Blueair Friend 手机应用设置

请注意，必须将空气净化器添加到 Blueair Friend 手机应用才能通过手机应用控制下列设置：



控制档位

在 1、2 和 3 之间更改档位。



调节 LED 亮度

控制可见 LED 灯的亮度。



儿童锁

锁定净化机控制面板，启用后无法通过机身上的控制面板操作空气净化器。



自动模式

根据内置传感器（仅限“i”型号）或独立空气质量监测仪布鲁雅尔空气通™（Blueair Aware™）的读数自动控制净化机档位。（Sense+通用）



夜间模式

允许在特定时间启用/停用某些设置。

滤网更换-成套滤网更换

仅针对HEPASilent®多层渐进式粒子滤网及成套SmokeStop™除烟去味复合滤网

步骤1

拔出电源插头，然后取下机器顶部上盖




步骤2

取出位于顶部的滤网




步骤3

取出两侧滤网并清洁机身内部金属网格架




步骤4

分别将两个新滤网装入机身两侧，确认箭头朝上，黑色活性炭滤网面朝外



步骤5

将一个新滤网安放在机器顶部，确认黑色活性炭滤网面朝上



步骤6

将上盖正确安放在机器顶部



橙色状态 - 更换滤网后按住 5 秒以上重置。

温馨提示：内置滤网请勿拆包装纸盒/
新购滤网请拆除包装薄膜后使用，滤网摆放方向请仔细查看外包装提示信息。

滤网更换-部分滤网更换

仅针对500/600系列活性炭替换滤网


步骤1

请先拔出电源插头，然后取下机器顶部上盖




步骤2

取出位于顶部的滤网




步骤3

取出两侧滤网并清洁机身内部金属网格架




步骤4

取出SmokeStop™除烟去味复合滤网中活性炭滤网




步骤5

将全新活性炭滤网重新装入SmokeStop™复合滤网框中




步骤6

分别将两个新滤网装入机身两侧，确认箭头朝上，黑色活性炭滤网面朝外



步骤7

将一个新滤网安放在机器顶部，确认黑色活性炭滤网面朝上



步骤8

将上盖正确安放在机器顶部



橙色状态 - 更换滤网后按住 5 秒以上重置。

温馨提示：内置滤网请勿拆包装纸盒/
新购滤网请拆除包装薄膜后使用，滤网摆放方向请仔细查看外包装提示信息。

保养和维护

我们建议定期清洁以保持设备处于最佳状态。

更换滤网时

1. 取下后，擦净盖子的下表面。
2. 用配有软毛刷等配件的吸尘器从内部清洁进气口栅格。
3. 用配有软毛刷的吸尘器等清洁小进气口。

综述

1. 使用柔软干净的湿布擦拭净化机外部。
2. 切勿使用汽油、化学溶剂或腐蚀性物质清洁，因为这些物质可能会损坏表面。
3. 切勿让异物进入进风或出风口。这可能造成触电或损坏净化机。
4. 切勿尝试自己维修或调整布鲁雅尔（Blueair）净化机上的任何电气或机械功能。请联系当地经销商或布鲁雅尔（Blueair）了解保修信息。

帮助和支持


如果您对布鲁雅尔（Blueair）Classic 系列有任何疑问，请访问 www.blueair.cn 或联系当地布鲁雅尔（Blueair）经销商。

保修信息

布鲁雅尔（Blueair）有限保修仅在遵照本手册中的说明使用本净化机时适用。

前置滤网维护保养

- 用一块干净柔软的毛巾沾湿拧干后，擦拭前置滤网；
- 使用吸尘器清洁前置滤网；
- 可根据需求小心拆卸清洗，并在晾干后放置回原位。



滤网

获得专利的HEPASilent®技术，Blueair使这台空气净化机超静音运行。供货时随本机提供了一块复合型滤网，已安装在机内。建议不超过12个月。（具体更换周期视使用情况而定）





花粉



细菌/病毒



尘螨



宠物皮屑

HEPASilent®粒子型滤网，其中包含的一块颗粒物滤网，能够有效地清除粉尘、花粉、细菌、宠物皮屑、霉菌孢子和其它经空气传播的污染物颗粒。这种粒子型滤网是由聚丙烯材料制成的，它能以机械方式滤除经空气传播的固态污染物。为确保滤网发挥最大功效，固态污染物在经过离子室时已携带负电，可被滤网有效过滤。





花粉



细菌/病毒



尘螨



异味



宠物皮屑



二手烟



总挥发性有机物

SmokeStop™除烟去味复合滤网，包含一个复合型粒子与活性炭滤网，以清除诸如二手烟或其它VOCs（挥发性有机化合物，包括家用油漆和其它化学品）之类的气态污染物。滤网添加了活性炭之后，可能会影响风量和CADR（洁净空气输出率）。当第一次使用活性炭滤网时，您可能会不习惯初始气味，但这种味道很快会消散。（友情提示：开窗通风是解决室内气态污染物的最有效途径之一）





总挥发性有机物



异味



二手烟

活性炭滤网，能有效过滤气态污染物，例如包括甲醛、二氧化硫、二手烟、废气在内的多种挥发性有机化合物和异味。活性炭滤网可替换在SmokeStop™除烟去味复合型滤网中的活性炭滤网，便于客户延长整体滤网时效。当第一次使用活性炭滤网时，您可能会不习惯初始气味，但这种气味很快会消散。（友情提示：开窗通风是解决室内气态污染物的最有效途径之一）

为确保最佳的性能，Blueair建议：应当定期更换滤网，更换周期请参考附页-1，建议不超过12个月。（具体更换周期视使用情况而定）

在中国，Blueair提供便捷的滤网订购服务，您可以联系当地的经销商或Blueair公司了解详情。
重要事项：只能使用原厂生产的Blueair滤网，以确保您的这台设备的功能正常，并符合保修的要求。

滤网使用寿命换算表-I

当居室的换气率为0.6h⁻¹，将室内污染物维持在35µg/m³，达到12h后，净化机至少应处理的颗粒物质量，见表G.1。

单位为毫克

G.1	空气净化机的 颗粒物日均处理量	室外颗粒物质量浓度C _{out} (µg/m³)						
		100	150	200	250	300	350	400
空气净化机 使用面积 (m²)	10	6	13	20	26	33	40	47
	15	9	19	29	40	50	60	71
	20	12	25	39	53	67	81	94
	25	14	32	49	66	84	101	118
	30	17	38	59	79	100	121	142
	35	20	44	69	93	117	141	165
	40	23	51	78	106	134	161	189
	45	26	57	88	119	150	181	213
	50	29	63	98	132	167	202	236

注1：室外（大气环境）颗粒物的质量浓度近似采用当地官方公布的细颗粒物的质量浓度（环境空气质量指数）。
注2：表G.1的应用示例：如果，附录D测试出的净化机对颗粒物的累积净化量的区间分档为P3，净化机的使用面积为20m²，且室外污染物浓度为300µg/m³的情况下，表G.1对应的日均处理量为67mg，则净化机可工作（8000-12000）/67=（119-179）天，即大约为5个月左右，上述估算值是基于净化机的CADR初始值得出的，实际使用中，随着CADR衰减，净化机工作状态下的“平衡浓度”有可能高于GB/T 18883规定的室内污染物浓度水平要求。
注3：如果净化机每日工作时间小于或大于12h，应适当减小或增加表G.1中的数值。

净化机将室内甲醛维持在0.10mg/m³达到12h后，净化机至少应处理的甲醛质量，见表G.2。

单位为毫克

G.2	空气净化机的 甲醛日均处理量	室内甲醛的初始稳定浓度C _i (mg/m³)			
		0.15	0.2	0.25	0.3
空气净化机 使用面积 (m²)	10	9	17	26	35
	15	13	26	39	52
	20	17	35	52	69
	25	22	43	65	86
	30	26	52	78	104
	35	30	60	91	121
	40	35	69	104	138

注1：本表清单针对甲醛的释放量（释放速率）选取“较不利原则”。
注2：表G.2的应用示例：假设，附录E测试出的净化机对甲醛的累积净化量的区间分档为F3，净化机的使用面积为20m²，且室内本底浓度为0.2mg/m³，表G.2中对应的日均处理量为35mg，净化机可工作（1000-1500）/35=（28-42）天，或大约1个月左右。上述估算值是基于净化机的CADR初始值得出的，实际使用中，随着CADR衰减，净化机工作状态下的“平衡浓度”有可能高于GB/T 18883规定的室内污染物浓度水平要求。
注3：如果净化机每日工作时间小于或大于12h，应适当减小或增加表G.2中的数值。

售后服务指南

免费保修政策

1. 凡购买布鲁雅尔（Blueair）空气净化器580i、680i均可享受Blueair公司提供的整机保修5年，保修时间自购买发票开具日期起计算。

2. 免费保修条件：

- 能提供有效的购机发票或购机凭证；
- 能提供保修期内的《Blueair空气净化器保修卡》；
- 非人为原因造成的故障；
- 如无法提供有效购机凭证及保修卡，其购买日期按产品合格证上的出厂日期计算。

3. 非免费保修内容：

- 用户因电源电压不稳，不符合国家安全用电标准（AC220V+10%，50Hz）而造成损坏的；
- 因用户使用不当，保管不善而损坏的；
- 没有《Blueair空气净化器保修卡》和有效的购机凭证的；
- 《Blueair空气净化器保修卡》上的型号、机身号码与所维修空气净化机的产品规格标贴上的型号、机身号码不相符合的；
- 机器底部无完整中文标贴，内容包括产品型号、机身号码及制造商信息；
- 超过保修期的产品；
- 因不可抗力造成损坏的，例如：地震、洪水、火灾等。

4. 退换内容：

参照国家相关规定《部分商品修理更换退货责任规定》执行。

- 在7天内如果属产品质量问题，可以退、换货；
- 在15天内如果出现产品质量问题，可以换货。

5. 保修期内维修指引：

- 如果您购买的布鲁雅尔（Blueair）空气净化器出现故障，请致电Blueair全国统一客服热线400-006-9693；
- 产品维修后，如果故障未能彻底排除，您可以拒绝在《Blueair空气净化器维修记录表》上签名；
- 产品运转正常后，请您在《Blueair空气净化器维修记录表》上签名确认维修内容并提出宝贵意见。如果是企业单位用户，请加盖企业公章。

欢迎加入Blueair会员俱乐部

欢迎加入Blueair会员俱乐部

请您收到空气净化器后尽快通过以下方式获取延保服务，以延长有效的产品保修期。并在日后购买替换滤网时享受折扣优惠。



网上注册
www.blueair.cn
登录官网，自行按操作
步骤注册以获得相应延
保服务。



拨打400全国统一客服热线
400-006-9693
由客服输入唯一机身编码
进行注册得到客服确认
即可。



填写保修卡
将保修卡按要求填写完整，
并按指导寄回相应服务地址。



微信：
Blueair空气
净化机

Blueair中国
博露雅迹（上海）商贸有限公司
上海市徐汇区漕溪北路398汇智
大厦1005室
Email: info@blueair.cn
全国统一客服热线：400-006-9693

产品保修卡
Warranty Card

用户联
User's copy

姓名
Name

地址
Add

机器型号
Model

购买日期
Date of purchase

机身编号
Serial number

购买商场
Store purchased from

请在购买本公司产品时立即完整填写此保修卡，并妥善保管。
please complete the form and take care of it!
全国服务热线：400-006-9693

（有任何问题请联系当地经销商或Blueair中国区服务中心）
(Any questions please contact local distributors or Blueair China service center)

请沿此线撕开

产品保修卡
Warranty Card

存根联
For stock

姓名
Name

地址
Add

电话
Phone

机器型号
Model

购买日期
Date of purchase

邮箱
Email

机身编号
Serial number

购买商场
Store purchased from

请在购买本公司商品后立即完整填写此保修卡并通过以上方式注册您的商品。

Before using Blueair Classic 500 and 600 series, please read this user manual carefully.

Note:

There may be local variations of these models.

Contents

General	19
Overview of unit	20
Adjusting fan (air flow) speed	20
Safety information	21
Placing the unit	23
Getting started	23
Control panel and touch buttons	24
Blueair Friend mobile app settings	25
Replacing Filters	26
Care and Maintenance	28
Filters	29
Filters lifetime calculation	30
After-sales service guide	31
Welcome to join Blueair Membership club	32
Product performance label	33


General

Blueair 500/600 series

Blueair 500/600 series air purifiers are Wi-Fi enabled and are available in two models. The 580i/680i models have built-in sensors for PM2.5, VOC, temperature/humidity.

Adjustments to the air purifiers can be made manually anywhere and at any time, either via the touch buttons on the control panel located under the flip-up lid, or remotely via the Blueair Friend™ mobile app.


680i model



The air purifier can also be automatically regulated based on the air quality readings from the built-in sensors.

For more information on how to use your air purifier together with the Blueair Aware air quality monitor, please see the Blueair Aware owner's manual and the support information.

Overview of unit



Adjusting fan (air flow) speed

Please refer to the table below to see the different options available for controlling your air purifier.

Control options	680i
Manual control via touch buttons on control panel	
Remotely via the Blueair Friend mobile app.	
Automode based on air quality readings from the built in sensors. This function may be activated either via the touch button on the control panel or via the Blueair Friend mobile app.	

Maximum speed is recommended for fast initial cleaning, during the day or when the air is heavily polluted. Minimum speed is recommended for nighttime use.

Safety information

The Blueair 605 (505) and 680i air purifiers are electrical appliances. Please read the safety instructions before use and take the necessary precautions to reduce the risk of fire, electric shock or injury.

The Blueair Limited Warranty applies only if the unit is used according to these instructions.



WARNING: Indicates a hazardous situation that, if not avoided, could result in death or serious injury.



CAUTION: Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

General



WARNING: To avoid a hazard, a damaged supply cable must always be replaced by the manufacturer, service agent or similarly qualified person.

- Use the grounded power cable provided with your Blueair air purifier unit to plug directly into an appropriate, grounded electrical outlet. *(Refer to the rating label on your unit)*
- Do not alter the plug in any way.

Intended use



CAUTION: Supervise children to ensure that they do not play with the appliance.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Getting me most from your Blueair System

The Blueair system is easy to use. Make sure your unit is the right size for your room, and change the filters according to the recommended filter replacement schedule. Remember that, just as air conditioners and heaters have limits to the volume of air they can cool or heat, every air purification system has limits to the volume of air it can clean. Follow these common-sense guidelines.

Close Your Windows

You wouldn't throw open your windows on a hot summer day and expect your air conditioner to work efficiently, because you can feel the hot air coming in and the cool air going out. Even though you can't see the contaminated air coming in and the clean air going out, the same logic applies to your air purifier.

Close Your Doors

Just as you might seal off part of your house on a cold winter night to keep your heater working more efficiently, seal off the room in which your system is working for best results.

Run Your System 24 hours per Day

For the best results, run your Blueair unit 24 hours a day, 7 days a week. Round-the-clock operation ensures that a continuous supply of clean, filtered air constantly circulates throughout the room. Blueair systems are designed for phenomenally low power usage. In fact, it costs about the same to power a Blueair air purifier as it does to power a single light bulb, depending on the unit and the operating speed.

Placing the unit



Place the unit in a location where air can circulate freely in, out and around the unit.



Do not place the unit closer than 4" (10 cm) from another object.



Do not place the unit directly on or against soft furnishings such as bedding or linen.



Do not place the unit near sources of heat, such as radiators, fireplaces or ovens.



Do not place the unit near wet areas, such as bathrooms or laundry rooms where it may come into contact with water.



Do not place the unit outdoors



Getting started

Connecting your air purifier - 680i, 605 and 505

Follow the instructions below to connect your air purifier to your Blueair Friend mobile app. You can then enable remote control.

Step 1

Plug the fixed power cable into a grounded wall outlet. If you have a unit with a removable power cable, then plug the cable firmly and completely into the recessed power cable socket located at the bottom of the unit before plugging the other end of the power cable into a grounded wall outlet.



Open the flip-up lid and press the Wi-Fi touch button. When the Wi-Fi symbol starts to blink, the air purifier can be paired with the Blueair Friend mobile app.

Step 2

Download the Blueair Friend mobile app to your smartphone from your app store (Apple App Store or Google Play) Tencent App MKT.

Step 3

Connect your unit to your Blueair Friend mobile app. Start the app and follow the instructions.

After connecting your air purifier to the Blueair Friend mobile app, you can use the app to control the unit remotely and adjust settings.

Classic 580i/680i control panel touch buttons



Wi-Fi



FILTER



AUTO



VOC



PM 2.5



VOC indicator

Status blue - from excellent to moderate pollution levels

Status orange - from slight to high pollution levels

See Blueair Friend mobile app for further information regarding pollution and threshold levels.



Auto speed

Status circle blue - unit is on

Status symbol grey - Auto speed OFF

Status symbol blue - Auto speed ON



PM2.5 indicator

Status blue - from excellent to moderate pollution levels.

Status orange - from slight to high pollution levels

Blueair Friend mobile app settings

Please note that you must first add your air purifier unit to the Blueair Friend mobile app before you can control the following settings via the app:



Adjust airflow speed

Changes the fan speed between speed 1, 2 and 3.



Adjust LED intensity

Changes the LED intensity for those lamps that are visible.



Child lock

Regulates your ability to control the air purifier unit via the control panel on the unit.



Auto mode

Automatically controls the fan speed based on readings either from the built-in sensors ("i" models only), or from the external air quality monitor Blueair Aware.



Night mode

Allows the activation/deactivation of certain settings at specific times.

Replacing the complete set of filter

Only for HEPASilent® particle filter and complete set of SmokeStop™ combine filter

Step 1

Unplug the unit and lift the lid from the top off the unit.




Step 2

Remove the filter on top.



Step 3

Remove the filters on each side. Vacuum the grille from inside.



Step 4

Place the first and second replacement filters into the side slots. Ensure that the side with the words OUT/UP is turned toward the outer wall of the unit



Step 5

Place the third filter on top of the unit and ensure that the side with the words OUT/UP is facing upwards. Make sure that the carbon side is always facing out.



Step 6

Snap the lid back into place.



Status orange - replace filter and reset by pressing down for 5 seconds.

Replacing the partial filter

Only for 500/600 series Carbon Filter


Step 1

Unplug the unit and lift the lid off the unit.




Step 2

Remove the filter on top.




Step 3

Remove the filters on each side. Vacuum the grille from inside.




Step 4

Slide out the Carbon filter




Step 5

Slide in the new Carbon filter




Step 6

Place the first and second replacement filters into the side slots. Ensure that the side with the words OUT/UP is turned toward the outer wall of the unit



Step 7

Place the third filter on top of the unit and ensure that the side with the words OUT/UP is facing upwards. Make sure that the carbon side is always facing out.



Step 8

Snap the lid back into place.



Status orange - replace filter and reset by pressing down for 5 seconds.

Care and maintenance

We recommend routine cleaning in order to keep your unit in top condition.

When changing filters

1. Wipe clean the underside of the lid after removal.
2. Vacuum the air inlet grille from the inside using a soft brush and/or other suitable attachment.
3. Vacuum the small air inlets with a soft brush attachment.

General

1. Wipe the exterior of the unit with a soft, clean, damp cloth.
2. Never clean with gasoline, chemical solvents or corrosive material as these agents may damage the surface.
3. Do not allow foreign objects to enter the ventilation or exhaust openings. This may cause electric shock or damage the unit.
4. Do not try to repair or adjust any of the electrical or mechanical functions on your Blueair unit yourself. Contact your local dealer or Blueair for warranty information.

Help and support



If you have questions about **Blueair Classic series**, please visit **www.blueair.com** or contact your local Blueair retailer.

Warranty information

The Blueair Limited Warranty applies only if the unit is used according to the instructions in this manual.

Pre-filter Care and Maintenance

- Vacuum the pre-filter from the inside until clean finish.
- Wipe the pre-filter with a soft, clean, damp cloth.
- If too dirty, please remove the pre-filter carefully and wash by water, then put back to the position.



Filter

Patented HEPASilent® technology makes the Blueair Classic Series incredibly quiet. The unit comes with a SmokeStop™ filter already installed.




Pollen


Bacteria/Virus


Dust mite


Pet dander

Particle Filter. Includes a particle filter that removes dust, pollen, bacteria, pet dander, mold spores and other airborne particles. The particle filter is made of polypropylene, which mechanically filters out airborne particles. To maximize filter effectiveness, particles are negatively charged by the Blueair unit before reaching the filter.


Pollen


Bacteria/Virus


Dust mite


Odor


Pet dander


Smoke


VOC

SmokeStop™ Filter. Includes a combined particle and active carbon filter to remove gaseous pollutants such as cigarette and cigar smoke or other VOCs (volatile organic compounds, including household paints and other chemicals). Adding activated carbon to a filter may affect airflow and CADR. You may also notice a slight odor from the carbon when the filter is first used; this will quickly dissipate.


VOC


Odor


Smoke

Carbon Filter. It provides protection against gaseous contaminants such as formaldehyde, sulfur dioxide and volatile organic compounds.
(Open window is one of the most effective way to remove the gas pollutants.)

For optimal performance, Blueair recommends that you replace filters periodically. Refer to Appendix Page-1 for replacement schedule, which we suggest no longer than 12 months.

Blueair offers a convenient Filter Subscription Program in China. Contact your local dealer or Blueair for more information.
Important! Use only genuine Blueair filters to ensure proper function of your unit and to qualify for full warranty coverage.

Filters Lifetime Calculation Reference Tab

With the air exchange rate of 0.6h –1, the indoor pollutants are maintained at 35µg/m³, and after 12 hours. The minimum mass of particles that shall be treated by the air purifier can be found in Table G.1.

Unit: mg

G.1	Table G.1 Average daily treatment quantity of particle with air purifier	Outdoor particle mass concentration Cout (µg/m³)						
		100	150	200	250	300	350	400
Room size(m²)	10	6	13	20	26	33	40	47
	15	9	19	29	40	50	60	71
	20	12	25	39	53	67	81	94
	25	14	32	49	66	84	101	118
	30	17	38	59	79	100	121	142
	35	20	44	69	93	117	141	165
	40	23	51	78	106	134	161	189
	45	26	57	88	119	150	181	213
	50	29	63	98	132	167	202	236

Note 1: The officially published mass concentration of the fine particulate matter (Ambient Air Quality Index) is roughly adopted as mass concentration of outdoor (the ambient atmosphere) particles.
Note 2: An application example of Table G.1: For the range P3 of the air purifier for the particles' Cumulative Cleaning Mass(CCM) tested by Appendix D, with the room size of 20m² and mass concentration of outdoor pollutant 300µg/m³, 67 mg of daily treatment amount, then the unit can normally work for (8000-12000)/67= (119-179) days, or around 5 months. The above estimation is based on its initial value of CADR. However, during actual use, with the attenuation of CADR, the "average concentration" of the air purifier may be higher than the concentration level of indoor pollutant specified by GB/T 18883.
Note3: If the daily working duration of the unit is shorter or longer than 12 hours, the values in Table G.1 shall be appropriately decreased or increased.

With the indoor formaldehyde maintained at 0.1 mg/m³, and after 12 hours, the minimum mass of formaldehyde that shall be treated by the air purifier can be found in Table G.2.

Unit: mg

G.2	Table G.2 Average daily treatment quantity of formaldehyde with air purifier	Initial stable concentration of indoor formaldehyde C ₀ (mg/m³)			
		0.15	0.2	0.25	0.3
Room size(m²)	10	9	17	26	35
	15	13	26	39	52
	20	17	35	52	69
	25	22	43	65	86
	30	26	52	78	104
	35	30	60	91	121
	40	35	69	104	138

Note 1: This table adopts "Less favorable principle" to the formaldehyde release (release rate).
Note 2: An application example of Table G.2: For the range F3 of the air purifier for the particles' Cumulative Cleaning Mass (CCM) tested by Appendix E, with the room size of 20m² and background concentration of indoor pollutant 0.2mg/m³, 35mg of daily treatment amount corresponding to that in Table G.2, then the unit can normally work for (1000-1500)/(35)≈(28-42) days, or around 1 month. The above estimation is based on its initial value of CADR. However, during actual use, with the attenuation of CADR, the "average concentration" of the air purifier may be higher than the concentration level of indoor pollutant specified by GB/T 18883.
Note 3: If the daily working duration of the unit is shorter or longer than 12 hours, the values in Table G.2 shall be appropriately decreased or increased.

After-sales service guide

Warranty policy

1. All Blueair air purifier models, including 500/600 series are covered by five (5) year warranty of the whole unit, from the date of purchase as indicated on the relevant invoice.

2. Warranty conditions:

- Effective invoice or other Proof-of-Purchase can be provided;
- The Warranty Card for Blueair Air Purifier shall be in the warranty period;
- The cause of failure is not human factor(s) of users;
- If the effective Proof-of-Purchase and Warranty Card is not provided, the date of manufacturing on Product Qualification Certificate shall be deemed as the date of purchase.

3. Situations of repair with fees

- The damage is caused by unstable voltage of power supply, which does not comply with the National Safety Standard for electricity (AC 220V+10%, 50Hz);
- The damage is caused by the user's improper use or poor maintenance of the unit;
- The Warranty Card for Blueair Air Purifier or other effective Proof-of-Purchase is not provided;
- The Model or Serial Number on the Product Specification Label of the unit to be repaired is not consistent with that on the Warranty Card for Blueair Air Purifier;
- No complete Chinese Label at the bottom of the unit, which shall contain the product's model, Serial Number and manufacturer's information;
- The product has exceeded its warranty period;
- Damage due to for majeure, such as earthquake, flood, fire, etc.

4. Situations of return or exchange of products

Implemented according to relevant clauses of "Provisions for repair, return and exchange for some commodities".

- For any quality issues within 7 days of purchase, the unit is returnable or exchangeable;
- For any quality issues within 15 days of purchase, the unit is exchangeable.

5. Maintenance guidance within warranty period

- For any failure of your Blueair Air Purifier, please call Blueair Customer Service hotline at 400-006-9693;
- After service of the unit, if the failure is not completely eliminated, you may refuse to sign on the Maintenance Record Table of Blueair Air Purifier;
- After the product operates normally, please sign on the Maintenance Record Table of Blueair Air Purifier to confirm the service and provide your comments and/or suggestions. For enterprise users, please stamp official seal of the enter

Welcome to join Blueair Membership Club

Welcome to join Blueair Membership Club

After receiving your air purifier, please obtain the extended warranty service as soon as possible with the following way, so as to extend your limited warranty and to enjoy discount when purchasing filter for replacement in the future.



Online registration
www.blueair.cn

Please log on the official website and register as instructed, in order to extend your limited warranty.



Customer service hotline:
400-006-9603

The unique Serial Number entered for registration will be confirmed by Customer Service Center.



Fill in the Warranty Card

Please complete the Warranty Card as required, and mail it back to the relevant address as instructed.



WeChat:
Blueair Air Purifier

Blueair China
Blueair(Shanghai) Sales Co., Ltd
Room 1005, City Gateway, No. 398, North Caoxi Road, Xuhui District, Shanghai, China
Email: info@Blueair.cn
Customer service hotline:400-006-9693

Warranty Card

For clients keep

Name _____



Address _____

Model _____ Serial number _____

Date of purchase _____ Store purchased from _____

Please complete the form and take care of it!
(For any questions, please contact local distributors or Blueair China service center.)

Customer service hotline: 400-006-9693

请沿此线撕开

Warranty Card

For Mail

Name _____



Address _____

Phone _____ Email _____

Model _____ Serial number _____

Date of purchase _____ Store purchased from _____

After purchasing any commodities from our company, please complete the Warranty Card and register with the above way.



www.blueair.com



Blueair AB
Danderydsgatan 11
SE-114 26 Stockholm
Sweden
Tel: +46 8 679 45 00
Fax: +46 8 679 45
45info@blueair.se

Blueair (Shanghai)
Trading Co., Ltd.
Rm 1005 City Gatew
No. 398 North Caoxi Road Xuhui
Distr., Shanghai
Tel: +86 21 6091 0981
Fax: +86 21 6091 0989
info@blueair.cn

Blueair Inc.
Suite 1900
100 N LaSalle Street Chicago
IL 60602
Tel: +1 888 258 3247
Fax: +1 312 727 1153
info@blueair.com

Blueair India
Embassy of Sweden
Nyaya Marg
Chanakyapuri
New Delhi – 110021
Tel: +91 11 4606 7121
Fax: +91 11 4606 7120
india@blueair.se

www.blueair.cn

博露雅迹（上海）商贸有限公司
上海市徐汇区漕溪北路398号汇智大厦1005室
Email: info@blueair.cn
全国统一客服热线: 400-006-9693



微信:
Blueair空气净化器

900088_CL500-600_A_UM_Rev00