




零件清单

- A. 上弯管
- B. 上墙座
- C. 自攻螺钉
- D. 固定座
- E. 膨胀管
- F. 紧定螺钉
- G. 下直管
- H. 滑座
- I. 下墙座
- J. 提拉阀
- K. 进水管

Parts List

- A. Bended Tube
- B. Upper Cradle
- C. Self-tapping Screw
- D. Fixing Ring
- E. Screw Chassis
- F. Setting Screw
- G. Straight Tube
- H. Bracket
- I. Below Cradle
- J. Diverter
- K. Flexible Hose

安装前注意事项



警告: 在墙上钻任何孔时, 请确保在您准备钻孔的地方没有隐蔽的管道和线缆!

申明: 本公司保留更改产品结构不另行通知的权利。

安装注意事项:

1. 本产品已经出厂检测及调试, 请勿自行拆卸。
2. 安装前, 请务必先清除墙体预埋水管内的杂质及污泥, 以免影响出水功能。
3. 本产品的工作压力: 0.05MPa~0.6MPa, 推荐工作压力: 0.2MPa~0.5MPa。
4. 当您在钻孔和安装时请注意安全。


Precautions before installation

Warning: Please make sure there are no hidden service pipes or cables where you start to drill the wall.

Declare: We hereby reserve the rights to amend the specification without prior notification.

ATTENTIONS BEFORE INSTALLATION

1. The product has passed functionality tests before sale, please do not disassemble the product by yourself at will.
2. Clear your plumbing to avoid any debris from impacting on product performance.
3. The working pressure of this product is 0.05MPa~0.6MPa. The recommended working pressure is 0.2MPa~0.5MPa.
4. Be careful in your installation.




安装固定座:

1. 如图示, 标记并在墙壁上钻2个安装孔, 深度为35mm。
2. 在安装孔内分别打入膨胀管, 然后用自攻螺钉分别将上下固定座固定在墙上, 拧紧螺钉。

Install the fixing ring:

1. As left figure, mark the location of drilling on the wall. Drill two $\Phi 6\text{mm}$ holes in the wall. The depth of the holes should be 35mm.
2. Insert the screw chassis into the holes, then locate the fixing rings onto the wall with the Self-tapping screws. Tighten the screw on the wall.




组装管组件:

1. 拆下滑座。
2. 安装下墙座。
3. 重新套回滑座。
4. 上弯管套入上墙座。
5. 下直管组件旋入上墙座。
6. 锁紧紧定螺钉, 调整上、下墙座的方向使其保持一致。


Assemble the tubes:

1. Take out the bracket.
2. Assemble the below cradle.
3. Put the bracket back to the straight tube.
4. Insert the upper tube into the upper cradle.
5. Screw the lower straight tube into the upper cradle.
6. Lock tight the setting screws, then adjust the direction of upper and lower cradle to make them consistent.

3



4



安装管组件:

1. 松开下墙座内部的紧定螺钉, 调整下墙座的位置, 使上、下墙座之间的距离与两固定座之间距离保持一致, 然后拧紧。
2. 将上墙座和下墙座分别对准并套入墙上的固定座, 然后用内六角扳手依次拧紧上、下墙座底部的紧定螺钉, 确认安装稳定。

Install the shower bar:

1. Loosen setting screws, adjust the position of below cradle, to make the distance between upper and lower cradle and the two fixing ring to be consistent, then screw tight.
2. Insert the upper and lower cradle into fixing ring separately, and then screw tight the setting screws at the bottom of upper and lower cradle by hexangular wrench in turn, make sure the installation is stable.

安装其它卫浴配件(虚线产品仅供参考):

1. 在进水软管两端的接头内分别放入垫圈, 将进水软管的一端接在切换阀的接头上, 六角螺母的另一端与龙头出水口连接。
2. 安装后请检查各连接处是否连接紧密、管道是否有泄漏, 整体安装是否牢固。确定各部良好后, 可放水试用, 检查连接处是否漏水。

Install other bathroom accessories: (Dashed area for reference only)

1. Put the washer into two ends of the flexible hose connector, connect one side of the flexible hose to the diverter and the other end which is the hex nut to the water outlet connector.
2. Check up every step to ensure the stability and tightness to avoid any leaking before testing the shower spray.

切换阀的使用方法:

- 警告：**当您使用本产品进行淋浴时，请先开启冷水然后再开启热水，以免烫伤！

1. 为保持产品洁净，请定期清洁。
2. 先用清水或温和的液体清洁剂清洗，然后用清水冲洗，再用软棉布抹干。
3. 切勿使用任何具有酸性和研磨作用的清洁剂。
4. 切勿使用钢丝球等坚硬的物品清洗产品表面。

Usage of Diverter:

- Warning:** When you are showering, please turn on the cold water first, and then hot water to avoid scalding.

1. Keep the product clean with clean water or mild liquid detergent regularly.
2. Rinse with clean water, and wipe with soft cotton.
3. Acid or abrasive detergents are prohibited.
4. Steel ball or hard materials are prohibited.

