

SRP-270 SERIES



1 STATION PRINTER

Operator's Manual

All specifications are subjected to change without notice

Table of Contents

CHAPTER 1. UNPACKING	4
1-1. CHECKING THE CONTENTS OF THE PRINTER BOX.....	4
1-2. LOCATING THE PRINTER	4
1-3. FUNCTIONS.....	5
CHAPTER 2. CONNECTING THE CABLES	6
2-1. CONNECTING THE AC ADAPTER TO THE PRINTER.....	6
2-2. CONNECTING INTERFACE CABLE AND DRAWER	7
CHAPTER 3. INSTALLING THE ROLL PAPER.....	8
3-1. RIBBON CASSETTE INSTALLATION	8
3-2. ROLL PAPER INSTALLATION	9
CHAPTER 4. SETTING THE DIP SWITCHES.....	13
CHAPTER 5. HEXADECIMAL DUMPING.....	16
CHAPTER 6. THE SELF TEST	17
CHAPTER 7. CODE TABLE.....	18
CHAPTER 8. CONTROL COMMANDS LIST	25
APPENDIX A	29
CONNECTORS	29
Interface Connector.....	30
Drawer Connector	32
APPENDIX B	33
SPECIFICATION	33
APPENDIX C	34
REMOVING JAMMED PAPER	34

This is a “Table of Contents preview” for quality assurance

The full manual can be found at <http://the-checkout-tech.com/estore/catalog/>

We also offer free downloads, a free keyboard layout designer, cable diagrams, free help and support.

<http://the-checkout-tech.com> : *the biggest supplier of cash register and scale manuals on the net*