


STEP 1: Install the Batteries or Home Power Adapter

The Portable Speaker Dock can operate on either batteries or by using the Home Power Adapter if you are near an outlet.

To use your Portable Speaker Dock on-the-go:

- 1 Open the battery compartment on the bottom of the Portable Speaker Dock. Insert 8 C-cell alkaline batteries in the battery compartment.




- 2 Replace the battery cover.

TIP! When the battery life is getting low the power light will blink and your Portable Speaker Dock may not play.

TIP! It is not recommended to keep batteries in the Portable Speaker Dock for an extended length of time. Remove the batteries when not in use.

To use your Portable Speaker Dock with the Home Power Adapter:

- 1 Plug the Home Power Adapter into the connector labeled **DC POWER** at the rear of the Portable Speaker Dock.
- 2 Plug the other end of the Home Power Adapter into a standard wall outlet.




STEP 2: Install the Dock Adapter for Your Radio


Select the Dock Adapter for your Radio and install it into the Portable Speaker Dock. Turn the adapters over and locate the name imprinted on the underside of the adapter.




Radio Dock Adapter Underside




SIRIUS Radios



XM Radios (except XMp3 & XMp3i)




XMp3 & XMp3i Radios



STEP 3: Install the Indoor/Outdoor Home Antenna


- 1 Plug the antenna cable into the **antenna** connector at the left rear.
- 2 Wrap the antenna cable into the storage area.
- 3 Place the antenna into the storage area at the rear of the Portable Speaker Dock. Align the mounting holes on the bottom of the antenna with the 4 mounting brackets on the rear of the Portable Speaker Dock. Push the antenna over the mounting brackets and then slide the antenna down slightly to secure it in place.
- 4 Open the antenna clamshell so that the top of the antenna is facing the sky.



TIP! If you are using the Portable Speaker Dock indoors, consult the User Manual beginning on page 18 for instructions for indoor antenna placement.

STEP 4: Insert Radio and Turn On the Portable Speaker Dock

- 1 Be sure the Portable Speaker Dock is powered off.
- 2 Align the Radio with the Radio Dock Adapter.
- 3 Once aligned, gently press the Radio down so that it slides down Radio Dock Adapter and onto the connector until it is fully seated in the Portable Speaker Dock.
- 4 Press and hold the **Power button** on the top of the Portable Speaker Dock until the Power On light is on.
- 5 If your Radio did not power on, press the **Power button** on your Radio.




STEP 5: Adjust the Audio Level

If your Radio has a **Audio Level** or **Line Out Level** adjustment feature in the **Settings** menu when it's docked in the Portable Speaker Dock, you should set this level to the maximum volume that does not cause distorted sound. This will maximize the audio quality. Refer to the User Guide which accompanied your Radio for instructions on how to set the level.


Some Radios do not have this adjustment available when docked in the Portable Speaker Dock. These Radios set their level automatically to optimize the sound quality. No adjustment is necessary.

The installation is complete. Sit back and enjoy your favorite programming on SIRIUS|XM Radio!


Portable Speaker Dock Controls and Connections



What's in the Box?




SIRIUS|XM Portable Speaker Dock



Adapter 1 (SIRIUS Radios)




Adapter 2 (XM Radios)




Adapter 3 (XMP3 & XMP3i Radios)


Radio Dock Adapters




Indoor/Outdoor
Home Antenna



Home Power Adapter



Power Cord



Remote Control

Portable Speaker Dock
Quick Start Guide



sirius.com
xmradio.com

SIRIUS XM Radio Inc.
1221 Avenue of the Americas
New York, NY 10020

For XM Radio support call 1-800-XM-RADIO (800-967-2346)
For SIRIUS Radio support call 1-888-539-SIRIUS (7474)