

Replacement Parts & Accessories

Prices below include all Shipping & Handling charges within the USA. Available directly from GSI OUTDOORS.

To order with Visa & MasterCard call (509)928-9611

Full payment in advance by Check also accepted.

#73365-S	Lexan® Shot Cap- 1 fl. oz.	\$ 5.00
#73365-L/A	Sure Sealing Pour Through Lid Assembly <i>Includes- Shot, Lid & O-Ring- 3 pc.</i>	\$ 20.00
#73365-OP	O-Ring Lid/Pitcher Seal	\$ 3.00
#73365-P	Lexan® Pitcher- 1.5 Liter <i>Includes- Shot, Lid, O-Ring, Blade Assembly- 6 pc.</i>	\$35.00
#73365-B/A	Stainless Steel Blade Assembly <i>Includes- Blades, Base & O-Ring- 3 pc.</i>	\$10.00
#73365-OB	Blade Assembly O-Ring (pc.)	\$ 3.00
#73365-H	Ergonomic Hand Crank	\$15.00
#73365-C	3.5" C-Clamp	\$12.00

Mail your payment to-

GSI OUTDOORS 1023 S. Pines Road Spokane, WA 99206

Outdoor Cooking is what we're all about. . .

GSI Outdoors is proud to manufacture one of the largest selections of Outdoor Cookware available! Our selection continues to expand in our commitment to develop the finest quality products that perform for your particular outdoor experience.

Tested on expeditions world wide, our products excel for Camping, Backpacking, Paddle Sports & Mountaineering!


We're presenting many creative new designs that are excellent for your Camp, Boat, RV, Patio or up at the Mountain Cabin.

We welcome and appreciate your input and comments, as this insight makes the best products for your outdoor enjoyment.

Visit our website to see our entire product line!

gsioutdoors.com

PAGE 8



RECIPES & INSTRUCTIONS

Please read carefully before use!





Important Safeguards & Tips Please read carefully before use-

- Stainless Steel blades are sharp, please handle carefully
- Operate only with the lid, pitcher & base in the fully locked position
- To ensure stability use the C-Clamp on a dry, stable surface.
- Never put your hand or utensils inside the pitcher during operation.
- Do not immerse the Stainless Steel base in water
- Do not overload the blender, if operation becomes too difficult, you may need to add more liquid or remove some of the food/ice from the pitcher.
- Adult supervision is required if the Vortex Blender™ is used by or near children.
- Do not attempt to attach a power drill onto the Vortex™, or alter it's design in any way
- Hand wash pitcher, blade assembly, lid and shot cap in warm soapy water. Do not use abrasive pads to clean parts. Do not wash in dishwasher.

**Refer to Page 4 for
Quick Start Instructions**


Excellent for camping, tailgating, RV, Boat, Patio or Cabin

- Great for mixing healthy shakes, sauces or frozen drinks
- Goes anywhere- compact & lightweight!
- Unique Patent Pending design
- 1.5 liter Lexan® Pitcher & Shot Cap are virtually indestructible
- Exclusive "pour through" locking lid design
- Stainless Steel Base nests in Pitcher for compact storage
- Powerful two speed gear system crushes ice or works as a food processor
- Stainless Steel blade design creates an efficient vortex
- Wide base, with secure "C"-Clamp for stability

Features-

Here's what you should have-

1. Lexan® Shot Cap- 1 fl. oz.
2. Sure Sealing Pour Through Lid
3. O-Ring Lid/Pitcher Seal
4. Lexan® Pitcher- 1.5 Liter
5. Blade Assembly O-Ring
6. Stainless Steel Blade Assembly
7. Stainless Steel Base
8. Ergonomic Hand Crank
9. C-Clamp- 3.5"
10. Low Speed Location
11. High Speed Location





Quick Start Instructions for Frozen Drinks

Step 1-

Attach the C-Clamp to the Blender Base- the clamp locks securely up into the bottom of the base

Step 2-

After attaching the C-Clamp to the Blender Base, Securely tighten the base/clamp unit to a stable/dry surface

Step 3-

Attach pitcher to the base by turning clockwise into the base and locking it securely with the handle facing away from the Clamp side of the base. (3 possible positions)

Step 4-

Add liquids first, then food, fruit or ice into the pitcher (break up any large chunks of ice before adding)

Step 5-

Lock the Lid onto the Pitcher by turning clockwise

Step 6-

Start by turning the handle in the Top Position (Low Speed), for about 30 seconds (aprox. 55 revolutions) until the ice is crushed into smaller pieces

Note: you can crank from either left or right side of the handle. Forward and Reverse.

Step 7-

Move the handle to the Bottom Position (High Speed) and continue to crank until the mixture has reached desired consistency. If you happen to encounter any resistance, turn the handle back in the opposite direction a few strokes and continue forward when smooth.

Example: A n ice drink with 4 cups of ice, 2 cups of liquid can be blended in 30 seconds on top setting & 30 seconds on bottom setting.

Step 8-

To remove the pitcher, turn counter clockwise and lift off the base then remove the shot cap for serving.



Mountain Madness Margaritas

Start with the following for each Margarita desired-

6 fl. oz. Gold Tequila

4 oz Triple sec or Grand Mariner

2 fl. oz. Fresh lime juice

Add-

3 Cups Ice

Making the libation: Measure the fresh lime juice, tequila, and orange liqueur of choice into the pitcher of the Vortex™ Lexan® Blender.

Add in ice, and follow quick start instructions 6-8.

Tropical Temptation Banana Daiquiri

Start with the following for each Daiquiri desired-

6 fl. oz. Rum

6 fl. oz. Banana Liqueur

4 tablespoons Lemon juice

Add-

8 teaspoons Sugar

2 Bananas sliced in 1 in. pieces

4 Cups Ice

Making the libation: Measure the fresh lemon juice, rum, and banana liqueur of choice into the pitcher of the Vortex™ Lexan® Blender.

Add in ice, banana, sugar and follow quick start instructions 6-8.

Banana-Berry Summit Smoothie

Start with the following for each Smoothie desired-

16 fl. oz. Orange Juice

2 Bananas sliced in 1 in. pieces

2 Cups Frozen Berries

Add-

4 Cups Ice

Making the libation: Measure the orange juice, in the pitcher of the Vortex™ Lexan® Blender.

Add in banana, berries and ice, and follow quick start instructions 6-8.

Java Jolt Shake

Start with the following for each shake desired-

8 fl. oz. Coffee or espresso

8 fl. oz. Milk

2 Cups Vanilla Ice Cream, Ice Milk or Frozen Yogurt

Add-

4 Cups Ice

Making the libation: Measure the coffee and milk in the pitcher of the Vortex™ Lexan® Blender.

Add in ice cream and ice, then follow quick start instructions 6-8.

Recipes yield approximately four servings.