


Setup: At Home


- Use the home stand with the antenna, power, and audio cables for best results.
- Position the home antenna for best reception. You want at least two bars of signal strength.
- In some areas, no special positioning of the antenna is required, but if better reception is desired, you may take the following steps:
  1. Slowly rotate the antenna 360° until signal strength is maximized.
  2. Place the antenna in or near a southern-facing window.
  3. If you need to place the antenna at a location more than 25 feet away, XM offers an extension kit (model XM550FTANT at www.xmradio.com, click “Shop XM Radio”).



For more information see your user guide or install guide.


Setup: On the Go

- The included case is ideal for carrying your radio and listening to Live XM, recorded XM, or your MP3s.
- For best live reception on the go, try orienting the radio in various positions. Keep your hands and body clear of the antenna.
- In many situations the built-in antenna of your radio will provide excellent reception on the go. For jogging or carrying the radio in your pocket, we recommend using the Belkin Antenna Headphones for XM (model F5X002 available in retail stores or online at www.xmradio.com, click “Shop XM Radio”).




Setup: In Your Car\*

- Make sure you use the vehicle cradle for best live reception in your car.
- Use the cassette adapter for the best sound quality. If that isn’t possible, use the FM modulator by selecting an unused channel or weakest signal. You can choose from many frequencies (88.1 - 107.9) in the FM band.



Set your vehicle radio and your XM radio to the same frequency.


- In the rare situation when you can’t find a clear FM frequency or you experience interference, we recommend use of the optional Delphi FM Direct Adaptor (model SA10112 available at retail stores or online at www.shopdelphi.com).
- Use of the FM modulator outside the cradle without the vehicle antenna connected will hinder performance in the car. The XM vehicle antenna helps provide a clear signal when you use the FM modulator.



For more information see your user guide or install guide.

\*Optional car accessory kit required, sold separately.

quick tips guide



xm2go Satellite Radio with MP3

Recording Modes

Recording on the Go

- When recording on the go, ensure that you have at least two bars of signal strength on the main screen. This will help prevent accidental interruption of your recording if there is a fade in signal strength.
- To start your recording, press the **XM** button (⌂) and select “Record.” You can choose to record just the song currently playing or record the channel.
- To stop recording , press **XM** (⌂) → **Record** → **Stop Recording**.

**Shortcut:** To immediately start recording at any time, press and hold the **XM** (⌂) button until you see the “Recording...” message appear on the display.

Scheduling a Recording Session

- In order to schedule a recording, you must first have your radio in the home stand with the power adapter and XM antenna connected.
- Be sure you have at least two bars of signal strength.
- To set up your scheduled recording time, press **XM** (⌂) → **Record** → **Schedule Rec**.
- Choose “New Session.”


- Set the date, time, and channel of the scheduled recording then choose “OK.”
- When you want to listen to your recordings , press “MODE” to switch to “My Music” mode.



Playback Tips

Finding and Playing a Song

- All songs and tracks that are stored in your XM Radio are normally played in the order that they were recorded or transferred into your radio. You can also sort the selections by artist, category , or channel.
  1. While listening to recorded tracks in “My Music,” select **XM** (⌂) → **Find**.
  2. Choose how to view your stored music.



View all songs in chronological order.  
View songs by artist name, in alphabetical order.  
You can also view song lists by artists, by categories, by channels, or by recording sessions.

- To view all songs stored, select **XM** (⌂) → **Find** → **All Songs**.

**Shortcut:** As soon as you have highlighted a song, simply press the right arrow button to start playback.

Making a Playlist


- You can create one or more custom lists, called playlists. Each playlist is an index of songs that play in a certain order.
  1. To add a song to a playlist, first select a song using the up or down arrow buttons. The song may be a recorded XM track, an MP3, or a WMA track, including songs purchased through XM + Napster.
  2. Select **XM** (⌂) → **Edit Song** → **Add to Playlist**.
  3. You can choose to add the song to an existing playlist or to create a new playlist.

**Shortcut:** To add a song that you are currently hearing to a playlist, press and hold the **XM** button (⌂) , then select **Add to Playlist**.

**Warning:** Deleting songs from the “All Songs” list will **also** delete them from your playlist(s).

XM+Napster

Using XM+Napster, you can:

- Manage songs, playlists, and recording sessions
- Transfer MP3 and WMA files between your radio and your PC
- Explore and purchase music from XM+Napster’s enormous online store
- Listen to XM Radio Online
- Simply install the XM+Napster software on your PC using the included CD. Click on the library icon  to access your device.
- When you hear a song you like press, **XM** (⌂) → **Bookmark** → **Bookmark Only**.

- When you connect your radio to the PC, the bookmark will appear next to the song in the XM+Napster application so that you can easily select it for purchasing.

**Shortcut:** To bookmark the song that you are currently listening to in “My Music,” press and hold the **XM** button (⌂) , then select **Bookmark Song**. You can only bookmark live or recorded XM tracks, not MP3 or WMA tracks.

Additional Shortcuts

**Shortcut:** To lock the song you are currently listening to, press and hold the **XM** button (⌂) , then select **Lock Song**.

**Shortcut:** To delete the song that you are currently listening to in the “My Music” mode, press and hold the **XM** button (⌂) , then select **Delete**.

**Shortcut:** To delete multiple songs from “My Music,” select **XM** → **Organize** → **Songs**, then press the right arrow button to select the song you want to delete.

If you are having trouble:

- In the unlikely event that your radio is not responsive, hold down the power button for five seconds until the display goes blank. This action resets the radio.

Questions

For more information, see your radio’s user guide or contact XM Listener Care at 1.800.XM.RADIO (1.800.967.2346).

© 2006 XM Satellite Radio Inc.  
Delphi and related logos are trademarks of Delphi Corporation. Belkin and related logos are trademarks of Belkin Corporation. The XM name, XM2go and related logos are trademarks of XM Satellite Radio Inc.

