

DELPHI



**QUICK
START
GUIDE**



GET THERE ON TIME, EVERY TIME!

NAV200
PORTABLE GPS NAVIGATION

1 WARNINGS AND PRECAUTIONS.



WARNING

DANGER OF ACCIDENT

When using your Delphi NAV200 in a vehicle, it is your sole responsibility to install, secure and use the device in a manner that will not cause accidents, personal injury or property damage, or in any manner obstruct your view or interfere with operation of vehicle safety equipment.

The user of this product is solely responsible for observing safe driving practices. Do not operate your Delphi NAV200 while driving. Park the vehicle first. Do not use the navigation system or entertainment features if it presents a risk to you or any other person or if it is a distraction.

OBEDY ALL TRAFFIC LAWS

The user is solely responsible for obeying the local traffic laws and observing all road signs. Local traffic laws and actual traffic signs always have priority over the information and directions received from the navigation system. The navigation instructions might be inaccurate or incorrect due to detours or construction.

DELPHI DISCLAIMS ALL LIABILITY FOR ANY USE OF THIS PRODUCT IN A WAY THAT MAY CAUSE ACCIDENTS, DAMAGE, OR THAT MAY VIOLATE THE LAW.

SYSTEM CONTENTS

2

- 1.5 GB storage space.
- Preloaded with US and Canada maps.
- For more information on loading your music, movies and pictures to SD card, consult the full Owner's Manual.
- Additional SD cards can be purchased at many retailers.
- Delphi validated functionality on following cards Transcend, Kingmax, Kingston.

**NAV200 GPS
Receiver and Stylus**



**SD Card
(See information above)**



**Windshield and Dash
Mounts**






**In-Vehicle
Charging Cable**



**Owner's Kit - Includes
Quick Start Guide,
Owner's Manual on DVD Rom,
Customer Service Card**

NAV200 RECEIVER FEATURES.



MOUNTING THE NAV200

For best results when using the Suction Cup Mount make sure that your windshield is clean and dry.


1. Flip up the GPS Antenna.
2. Using the two tabs on the bottom of the cradle, locate the NAV200 and rotate rearward. While pushing in the two grey release buttons, continue rotation until unit is firmly seated in the cradle.
3. Release the two grey buttons. Reverse operation for unit removal.
4. Position suction cup firmly against windshield at desired location.
5. Flip the lever toward suction cup.
6. Unit is now secure for operation.

WARNING: To avoid personal injury, follow the safety guidelines and installation instructions provided so that the Delphi NAV200 does not obstruct the view of the driver, interfere with the operation of any airbags and safety features in the vehicle, or become airborne in the case of an accident. DO NOT attempt to install the Delphi NAV200 while driving.

1.



2.



3.



4.



5.



6.



NOTICE TO DRIVERS IN CALIFORNIA AND MINNESOTA: State law prohibits drivers in California and Minnesota from using suction mounts on their windshields. Other Delphi dashboard or friction mounting option should be used (see adhesive disk supplied in box). Delphi does not take any responsibility for any fines or damages that may be incurred as a result of disregarding this notice. (See California Vehicle Code Section 26708(a); Minnesota Statutes 2005, Section 169.71)

5 OPERATING THE NAV200

1. Your system comes with an SD card preloaded with USA and Canada maps. The card is in position and ready to use.
2. Turn the NAV200 on and wait for the Home Screen to appear.

There are eight options to choose from on the Home Screen. To activate any function displayed tap one of the icons with the Stylus or your finger.

NOTE: Adding music, movies or pictures requires a higher capacity SD card not included. See Owner's Manual for more complete instructions.



NAVI: Starts navigation functions.

MUSIC: Starts the music playback function that enables playing mp3 and wav files.

MOVIE: Starts the movie playback function that enables playing avi files.

PICTURE: Starts the picture function that enables viewing jpg, gif, and png files.

SETTINGS: Starts the screen/environment setting function.

W-CLOCK: Starts the world time function that enables viewing the time in different cities.

CALC: Starts the calculator function.

GAME: Starts the game function.



NAV200 Home Screen

NAVIGATION.



1. During initial start up, and on relaunch after closing the Navigation function via the Quit icon, the above message appears: Tap the I accept button. If you do not accept and you tap the I decline button, the software terminates.
2. When the Main Menu opens wait 3 seconds, tap Navigation.





3. Tap the Region entry field and select the country (or state, or province) of destination if it is not yet indicated. Tap Address.
4. Tap either City or ZIP. When tapping in city, after a few letters, a match may appear to select.
5. (a) Enter the destination street into the Street entry field. (b) If you know the house or business street number, enter into the No. field.
6. Enter the name of an intersection into the Intersection entry field if you want to define an intersection as the destination point. Tap Start Navigation.




7. Determine the route options, and tap start navigation. The software will determine the route.
8. The map screen opens. Your current position is indicated by a green arrow. The route is highlighted in orange.

When the received GPS signal is not sufficient, a message appears.

You have two possibilities:

1. Wait until navigation starts. This will happen as soon as the GPS reception is sufficient.
2. Tap  **Cancel** and restart navigation as soon as the reception of GPS signals is convenient. You may notice that by watching the GPS symbol on the screen it becomes **GPS ready**  when the reception is good.



NOTE: It can take 2-5 minutes for NAV200 system to capture GPS signal.

 **WARNING:** For your safety, program your Delphi NAV200 and enter information about your destination BEFORE you start your journey. Do not operate the Delphi NAV200 while driving.

MAP SCREEN



The Map Screen provides distances, directional arrows, route identification, and your speed. These, along with voice prompting will guide you to your destination. Should you deviate from the route, NAV200 will recalculate and provide new instructions.

See full Owner's Manual for detailed information on all map functions.

MUSIC SCREEN

Music Player plays mp3 and wav files.



Time Played/Total Time

Current Status

Play/Pause

Fast Backward

Mute (by toggle)

Stop

Fast Forward

Selecting a Play Interval

NOTE: Adding music, movies or pictures requires a higher capacity SD card not included.

MOVIE SCREEN

Movie Player plays avi files.



Time Played/Total Time

Mute (by toggle)

Selecting a Play Interval

File in Play

Fast Backward

Play/Pause

Fast Forward

Switch to the Play List Screen.


WARNING: For your safety, DO NOT operate the Delphi NAV200's entertainment features while driving. Movie and music (MP3) playing, picture showing, world clock and calculator are intended for use ONLY while you are not driving your vehicle.

PICTURE VIEWER

Picture Viewer displays jpg, gif and png files.

Remaining Battery

File Name



Current File Index/Total Number of Files Read

Previous

Next

Slideshow

Switch to Picture View List Screen



Current File Index/Total Number of Files Read

Scroll Up

Scroll Down

View/Play

Cancel

NOTE: Adding music, movies or pictures requires a higher capacity SD card not included.

WORLD CLOCK



Allows you to check the current time of any city in the world.

NOTE:
Receiver must have GPS signal to work properly.

CALCULATOR



GAME

