

EPSON

LX300

Page 1 of 5

	PART	DESC	QTY	STANDARD
100	1018194	HOUSING ASSY. LOWER	1	
101	1018196	INSULATOR	1	
102	1018197	INSULATOR	2	
103	1018212	SHIELD PLATE	1	
104	1021961	COVER ASSY. PRINTER	1	
105	1016265	ROLLER DRIVEN	2	
106	1016266	HOLDER ROLLER DRIVEN	2	
107	1016268	COMPRESSION SPRING 73	2	
108	1018204	COVER ROLLER DRIVEN	2	
109	1018205	EDGE GUIDE ASSY.	1	
110	1018199	HOUSING UPPER	1	
111	1018200	SHEET PANEL	1	
112	1018894	LOGO PLATE	1	
113	1018214	KNOB	1	
114	1018210	COVER BOTTOM	1	
115	1018211	COVER CONNECTOR CS	1	
116	1018213	SHIELD PLATE I/F	1	
117	1018297	GROUNDING PLATE	2	
118	1019833	LABEL POSITION	1	
119	B070200411	HEXAGON NUT	1	M4
120	1006901	C.B.C-LAMITITE	1	M3X8
121	1018296	SHAFT HOUSING LOWER	3	
122	1015457	SHAFT HOUSING LOWER	1	
123	B045800115	C.B.(O) SCREW	1	M4X8
124	B310204311	C.B.B. SCREW	8	M3X8
125	B310204411	C.B.B. SCREW	1	M3X10
126	B310206411	C.B.B. SCREW	4	M4X12
127	1012989	C.B.USCA C	7	M3X8 F/ZN
128	1018287	JACK SOCKET	2	FOR EUR.,S.E.ASIA,OCEANIA
128	1018288	JACK SOCKET	2	FOR USA
129	1019830	C.F.P-TITE SCREW 2.6X8 F/ZN	2	
131	1012990	C.B.USCA C(S-P1)	1	M3X10 F/ZN
132	1019310	GUIDE STACKER	2	
133	1019482	STACKER	1	
135	1018459	COVER HEAT SINK	1	
200	2012918	BOARD ASSY. MAIN	1	WITHOUT E1
E1	2014574	P-ROM TCN00	1	1M BIT
250	2012921	BOARD ASSY. I/F	1	
300	2012919	BOARD ASSY. POWER SUPPLY	1	FOR 120V
300	2012920	BOARD ASSY. POWER SUPPLY	1	FOR 220V/240V
400	2002364	POWER CABLE (VD31303SA-10A)	1	220V
401	2006741	POWER CABLE (BS31303SA-SR-10A)	1	240V
402	2010468	AC CABLE	1	240V
403	2002365	POWER CABLE VD00303SA-10A	1	220V
403	2008768	POWER CABLE	1	FOR EHK
330	2012927	WIRE HARNESS	1	
410	2012930	POWER CABLE ASSY.	1	
411	2014029	POWER CABLE ASSY.	1	
412	2012926	WIRE HARNESS	1	
500	2013202	PRINTER MECH M-3G10-000	1	USA,S.E.ASIA,OCEANIA
500	2013203	PRINTER MECH M-3G10-001	1	EUROPE W/O 558-575
501	1018153	FRAME LEFT	1	
502	1018167	FRAME RIGHT	1	
503	2012999	MOTOR PF	1	

EPSON

LX300

Page 2 of 5


REF	PART	DESC	QTY	STANDARD
504	2014283	DETECTOR LEAF B1	2	0,0V,0A,
505	2014535	HARNESS TR	1	
506	1018184	LEVER G ADJUST	1	
507	1018168	COMPRESSIONSPRING 200	1	
508	F334005270	TRACTOR REDUCTION GEAR	1	
509	F359002020	PAPER FEED REDUCTION GEAR	1	
510	B310204311	C.B.B. SCREW	1	M3X8
511	B100153090	PLAIN WASHER	1	5.2X0.3X10
512	1018154	LEVER ASSY. PLANETARY	1	
513	1018174	PAPER GUIDE UPPER	1	
514	1018175	ROLLER PF DRIVEN	4	
515	1018170	PAPER GUIDE LOWER	1	
516	1018176	PAPER GUIDE SUPPORT	1	
517	1018145	FRAME BASE	1	
518	1018157	SPUR GEAR 13.2	1	
519	1018158	COMBINATION GEAR 5.1 16.2	2	
520	1018159	RATCHET RD	1	
521	1018164	COVER RD	1	
522	F333051020	TIMING BELT	1	
523	F333051060	BELT TENSION SPRING	1	
524	1018160	PULLEY ASSY. DRIVEN	1	
525	2012998	MOTOR CR	1	
526	1015038	PULLEY DRIVE	1	
527	F336051030	BELT PULLEY FLANGE	1	
528	F333051080	PLAIN WASHER	1	3.2X0.5X7
529	B150350111	RETAINING RING	1	TYPE-E(2,3)
530	1018180	CARRIAGE ASSY.	1	
531	1018182	GROUNDING PLATE HEAD	1	
532	1018183	SHAFT ASSY. CR GUIDE	1	
533	1018185	GROUNDING PLATE SHAFT CR	1	
534	1011120	OIL PAD	1	
535	2013199	DETECTOR PE	1	0,0V,0A,
536	1018178	PLATEN	1	
537	1008995	BUSHING 11	2	
538	B100166990	PLAIN WASHER	1	11.3X0.5X16.5
539	B150301111	RETAINING RING	2	TYPE-E(8)
540	1008637	U-TYPE 11.2X0.13X16S/NA	1	
541	1018191	GROUNDING WIRE PLATEN	1	
542	2013002	CABLE HEAD	1	
543	1018192	SHEET CABLE HEAD	1	
544	1018248	RIBBON MASK	1	
545	2014534	HARNESS HP	1	
546	2014536	HARNESS PE	1	
549	1018252	HEAT INSULATOR	1	
550	1018324	SHEET FRAME BASE	1	
551	1018169	LEVER DISENGAGE	1	
552	1012841	BUSHING PARALLEL ADJUST	2	
553	1018172	SHAFT FRICTION	1	
554	1008636	GEAR 34	1	
555	1018179	SPURGESR 25	1	
556	B310104611	C.P.B SCREW	1	M3X14
557	1018171	COMPRESSION SPRING 800	2	
558	1016186	COMPRESSION SPRING 500	2	

Page 3 of 5

[illegible]

EPSON
LX300


Page 4 of 5



LX300 EXPLODED DIAGRAM
FIG. 1
PAGE 4 OF 5

EPSON LX300

Page 5 of 5



LX300 EXPLODED DIAGRAM
FIG. 2
PAGE 5 OF 5

EPSON

LX300

Page 6 of 5

EPSON

SPARES AND SERVICE

You may copy short extracts from this document for identification purposes only. Complete sections can be purchased from Epson (UK) Ltd., spares wholesalers.

Ensure that the full part number is quoted in all communications with Epson and all Epson appointed wholesalers.


If a list is found to be inaccurate please contact in writing:

**The Spares Department
Epson (UK) Ltd.
Campus 100
Maylands Avenue
Hemel Hempstead
Herts.
HP2 7TJ**

Fax (01442) 227324



EPSON (UK) LTD. 1990



EXPLODED DIAGRAM FOR LX-300 (I)

