

User Guide

Mini Bluetooth Headset

MODEL: HB200M



Table of Contents

Thank You	3
Safety Guidelines	3-5
Introducing the HB200M	5-6
What Your Headset Can Do	6
Specifications	7
GETTING STARTED	7
Turning Your Headset On & OFF	7-8
Pairing it with Your Phone	7-8
Wear It How You Like It	9
Left or Right Ear Use	9
Adjusting Earplug	10
Wearing the Headset as a Pendant	10
Charging your Headset	11
Answer a Call	12
End a Call	12
Make a Call	12
Reject a Call*	12
Activate Voice Dialing*	12
Redial Last Number*	12
Adjust Sound and Volume	13
Call Waiting and Placing a Call on Hold*	13
What the Lights Mean	14
Using the HB200M with Two Mobile Phones	15
Troubleshooting	
Taking Care of Your Headset	17
Glossary	17-18

Thank You

Thank you for purchasing the Hisense HB200M Bluetooth® Headset. We hope you enjoy it! This instruction manual will get you started and ready to make the most of your headset.

WARNING!

Headsets are capable of delivering sounds at loud volumes and high pitched tones. Exposure to such sounds can result in permanent hearing loss or damage. The volume level may vary based on conditions such as the phone you are using, its reception and volume settings, and the environment. Please read the safety guidelines below prior to using this headset.

Safety Guidelines

- Prior to using this product follow these steps:
 Before putting on the headset, turn the volume
 control to its lowest level, put the headset on,
 and then slowly adjust the volume control to a
 comfortable level.
- During the use of this product:
 Keep the volume at the lowest level possible and
 avoid using the headset in noisy environments
 where you may be inclined to turn up the volume.
 If increased volume is necessary, adjust the volume

control slowly, and if you experience any discomfort or ringing in your ears, immediately discontinue use and consult a physician.

With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.

Using the headset while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions. Check your local laws. Use caution while using your headset when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the headset from your ear area or turning off your headset will keep you from being distracted, so as to avoid accident or injury.

3. Keep out of reach of children:

The plastic bags the product and its parts are wrapped in are not toys for children. The bags themselves or the many small parts they contain may cause choking if ingested.

 Never try to dismantle the product yourself. None of the internal components can be replaced or repaired by users.

Only authorized dealers or service centers may open the product. If any parts of your product require replacement for any reason, including normal wear and tear or breakage, contact your dealer. Avoid exposing the product to rain or other liquids. Dispose of the product according to local standards and regulations.


Do not use the Headset in environments where there is a danger of ignition of flammable gases.

The headset is equipped with a magnetic pendant. The magnet in the pendant can harm other electronic devices. handle the magnetic pendant with care and keep away from electronic devices such as speakers, TV, LCD screens Etc.

Introducing the HB200M

- 1. Microphone
- 2. Multi-Function Button (MFB)
- Pairing Button press and hold for 5 sec to put headset into pairing mode
- · Answer/End Button
- Press to turn headset on (blue and red lights flash for 1sec)
- Press and hold to turn headset off (blue and red lights flash for 1sec and then power will shut down)
- Press to answer or end a call
- 3. LED Light
- 4. Charging Socket

Far Hook



What Your Headset Can Do

Your Hisense HB200S lets you do the following:

- Answer Calls
- End Calls
- Reject Calls*
- Voice Dialing*
- Last Number Redialing*
- Call Waiting*
- Put Call on Hold*
- * Phone Dependent

Specifications

- Up to 5.5 Hours talk time/Standby Time up to 150 hours
- Rechargeable battery with charging option from AC power supply or PC via USB cable
- Weight: 7.5 gr.
- Operating range up to 10 meters (approx. 33 feet)
- Headset and hands-free Bluetooth profiles
- Bluetooth Specification (see glossary) version 2.1

GETTING STARTED

The Hisense HB200M is easy to operate.

Turning your headset on and off

To turn on your headset press and hold the MFB for 5 seconds. Release the button when the indicator lights flash (both blue and red lights) once.

Note: blue led light indicates that the headset is connected to a mobile phone. When the headset is powered on but is not connected to any Bluetooth device, the red indiction light will keep on flashing.

To turn off your headset, press and hold the MFB for 5 seconds. Release when the indicator lights flash once (both red and blue lights) and then off again together with an indication tone

The MFB (multi function button) on the headset performs different functions depending on how long you press it.

Pairing with Your Phone or Other Device

Before using your Hisense HB200M, you need to pair it with your mobile phone.

- 1. Make sure that the headset is turned off
- Hold the headset's MFB for 8 seconds till the blue and red indication light flash alternatively, meaning that the headset has entered into pairing mode.
- Activate Bluetooth function of the mobile phone to search for Bluetooth devices (please refer to the phone's manual).
- Set your Bluetooth phone to 'discover' the Hisense HB200M.
 - follow your phone's instruction guide. This usually involves going to a 'setup,' 'connect' or 'Bluetooth' menu on your phone and selecting the option to 'discover' or 'add' a Bluetooth device.
 - * (See example from a typical mobile phone).



- 5. Your phone will find the Hisense HB200M.
- 6. Your phone will then ask if you want to pair with it. Accept by pressing 'Yes' or 'OK' on the phone and confirm with the passkey or PIN = 0000 (4 zeros). Your phone will confirm when pairing is complete.

In case of unsuccessful pairing, repeat steps 1 to 6.

Wear It How You Like It

Left or Right Ear Use

The Hisense HB200M is ready to wear on your right ear. If you prefer the left, gently remove the ear hook and rotate to fit left ear.



Adjusting the Ear Bud

- 1. The in-ear bud is assembled by default. You can change different ear bud sizes according.
- Rotate the in-ear bud clockwise or counter clockwise about 45 degrees to remove the ear bud, then replace with desired ear bud.





Wearing the Headset as a Pendant

Use the supplied magnetic clip, you can attach the headset using the metal part around the charging socket, it will connect easily to the magnet of the pendant.



Charging Port

CAUTION

The Magnetic Clip is delicate and doesn't hold the headset tight. Handle with Care!! Do not use the Magnetic Clip for sport or other activities that can cause the headset to fall down.

STRONG MAGNET!

It can be harmful to pacemaker wearers and others with medical implants. Stay clear! Keep tools and other metal objects away. To avoid damage, keep magnetic media such as memory disks/chips, credit cards and tapes away.

Charging Your Headset

Make sure that your Hisense HB200S headset is fully charged before first use. Use the AC adaptor to charge from a power socket, or charge directly from your PC with the USB cable provided.

Connect your headset to the AC $\,$

adaptor or USB cable After connecting to the power source. The red LED light will blink twice and then solid red, your headset is charging. After charging ends the LED color will turn from red to solid blue.

Charging Socket Port

10

How to...

Answer a Call

Press the MFB on your headset to answer a call.

End a Call

Press the MFB to end an active call.

Make a Call

When you make a call from your mobile phone, the call will (subject to phone settings) automatically transfer to your headset. If your phone does not allow this feature, press on the Hisense HB200M's MFB to transfer the call to the headset.

Reject a Call*

Press the MFB for approximately 2 seconds when the phone rings to reject an incoming call. Depending on your phone settings, the person who called you will either be forwarded to your voice mail or hear a busy signal.

Activate Voice Dialing*

Press the MFB once. Wait for the beep and then announce the name you wish to call For best results, record the voice-dialing tag through your headset. Please consult your phone's user manual for more information about using this feature.

Redial Last Number*

Press the MFB twice when the headset is on and not in use.

Adjust Sound and Volume

Volume adjustment can be done by the volume control in your mobile phone, we canceled the volume button on the headset in order to reduce the size of the HB200M.

Call Waiting and Placing a Call on Hold*

This lets you put a call on hold during a conversation and answer a waiting call.

Press the MFB twice to put the active call on hold and answer the waiting call.

Press the MFB twice to switch between the two calls. Press the MFB to end the active conversation.

• Functions marked with * are dependent on your phone supporting these features.

Check your phone's user manual for further information.

Hisense 🖔

What the Lights Mean

	What you see	What does this mean about your headset
When headset is connected to charger	Red light flashes twice and then on continuously	Charging
	Solid Blue	Charging completed
When headset is not connected to charger	Red and Blue light flashes alternativly	Pairing
	Blue light flashes 3 times quickly	Connected or standby
	Red light flashes 3 times quickly	Awaiting for connection
	In connection or standby mode, red light flashes 3 times quickly	Low battery alert

Using the HB200M with 2 Mobile Phones

Hisense HB200M is capable of having two mobile phones connected to the headset at the same time. This will give you the freedom of having only one headset to operate both your mobile phones and the operation of the functions in the headset functions as described above.

How to pair a second mobile phone

- Turn off Bluetooth function of the first connected phone temporarily
- 2. Launch the pairing steps (the same pairing steps as in the first phone) for the second mobile phone;
- 3. After the second phone is paired, turn off the Bluetooth headset, then turn on the first paired phone's Bluetooth function.
- 4. Restart the headset. The headset will connect to both phones automatically.

NOTE: Last Number Redial will dial the number from the last outgoing call, independent of the mobile phones, and the Voice Dialing function only will work on the last paired mobile phone.

Troubleshooting

I hear crackling noises

For the best audio quality, always wear your headset on the same side of the body as your mobile phone.

I cannot hear anything in my headset

Increase the volume on the mobile phone.

Ensure that the headset is paired with the phone.

Make sure that the phone is connected to the headset – if it does not either connect from the phone's Bluetooth menu or by pressing the MFB, follow the pairing procedure.

I have pairing problems even though my phone indicates otherwise

You may have deleted your headset pairing connection in your mobile phone.

Follow the pairing instructions in page 8.

Will the Hisense HB200M work with other Bluetooth equipment?

The Hisense HB200M is designed to work with Bluetooth mobile phones. It can also work with other Bluetooth devices that are compliant with Bluetooth version 2.1 and support a headset and/or hands-free profile.

Taking Care of Your Headset

- Always store the Hisense HB200M with the power off and safely protected.
- Avoid storage at extreme temperatures (above 45°C/113°F – including direct sunlight – or below -10°C/14°F). This can shorten battery life and may affect operation. High temperatures may also degrade performance.
- Do not expose the Hisense HB200M to rain or other liquids.

Glossary

Bluetooth

The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Hisense is under license. Other trademarks and trade names are those of their respective owners.

- Bluetooth is a radio technology that connects devices, such as mobile phones and headsets, without wires or cords over a short distance (approx. 30 feet). Get more information at www.bluetooth.com.
- Bluetooth profiles are the different ways that Bluetooth devices communicate with other devices.

Bluetooth phones support either the headset profile, the hands-free profile or both. In order to support a certain profile, a phone manufacturer must implement certain mandatory features within the phone's software.

- 3. **Pairing** creates a unique and encrypted link between two Bluetooth devices and lets them communicate with each other. Bluetooth devices will not work if the devices have not been paired successfully.
- 4. Passkey or PIN is a code that you enter on your mobile phone to pair it with your Hisense HB200M. This makes your phone and the Hisense HB200M recognize each other and automatically work together.
- Standby mode is when the Hisense HB200M is passively waiting for a call. When you 'end' a call on your mobile phone, the headset goes into standby mode.



Dispose of the product according to local standards and regulations or local laws.

