



Hisense

User Guide

Stereo Bluetooth Headset

MODEL: HB400C



Table of Contents

Thank You	3
Safety Guidelines	4-5
Introducing the HB400C	6
What Your Headset Can Do	7
Specifications	8
GETTING STARTED	8
Charging your Headset	8
Turning Your Headset On and Off	9
Pairing it with your phone	9-10
Wearing Your HB400C Headset	11
How to	11
Answer a Call	11
End a Call	11
Make a Call	11
Reject a Call*	11
Activate Voice Dialing*	12
Redial Last Number*	12
Adjust Sound and Volume	12
How to Play Music in Stereo	13
What the Lights and Tones Mean	14
Troubleshooting	15-16
Taking Care of Your Headset	17
Glossary	17-19

Thank you

Thank you for purchasing the Hisense HB400C Stereo Bluetooth® Headset. We hope you enjoy it! This instruction manual will get you started and ready to make the most of your headset.

The HB400C is a Bluetooth stereo headset, designed to use with mobile phones, PC's with Bluetooth transmitter, PDA's or other audio devices equipped with Bluetooth transmitters.

The HB400C support the following profiles

A2DP: Advanced Audio Distribution Profile

AVRCP: Audio/Video Remote Control Profile

HSP: Headset Profile

HFP: Hands free Profile

Note – the use of the AVRCP profile allows you to control the audio device from the headset buttons, is subject to the support of the audio device in this profile

WARNING

Use of this headset with both ears covered while driving is not permitted in certain states.

WARNING!

Headsets are capable of delivering sounds at loud volumes and high pitched tones. Exposure to such sounds can result in permanent hearing loss damage. The volume level may vary based on conditions such as the phone you are using, its reception and volume settings, and the environment. Please read the safety guidelines below prior to using this headset.

Safety guidelines

1. Prior to using this product follow these steps:
Before putting on the headset, turn the volume control to its lowest level, Put the headset on, and then slowly adjust the volume control to a comfortable level.
2. During the use of this product:
Keep the volume at the lowest level possible and avoid using the headset in noisy environments where you may be inclined to turn up the volume; If increased volume is necessary, adjust the volume control slowly; and if you experience any discomfort or ringing in your ears, immediately discontinue use and consult a physician.
With continued use at high volume, your ears may become accustomed to the sound level, which may result in permanent damage to your hearing without any noticeable discomfort.


Using the headset while operating a motor vehicle, motorcycle, watercraft or bicycle may be dangerous, and is illegal in some jurisdictions. Check your local laws. Use caution while using your headset when you are engaging in any activity that requires your full attention. While engaging in any such activity, removing the headset from your ear area or turning off your headset will keep you from being distracted, so as to avoid accident or injury.

3. Keep out of reach of children:
The plastic bags the product and its parts are wrapped in are not toys for children. The bags themselves or the many small parts they contain may cause choking if ingested.
4. Never try to dismantle the product yourself. None of the internal components can be replaced or repaired by users.
Only authorized dealers or service centers may open the product. If any parts of your product require maintenance for any reason, including normal wear and tear or breakage, contact your dealer.
Avoid exposing the product to rain or other liquids.
Dispose of the product according to local standards and regulations.

Do not use the Headset in environments where there is a danger of ignition of flammable gases.

Introducing the HB400C

1. Clip
2. Volume Up (+) / Next Track (➤)
3. Multi-Function Button (MFB)
 - Turn On or Turn Off the Headset
 - Pairing Button
 - Answer/End Button
 - Play / Pause Music
4. Stereo Output Jack (3.5 mm) / Charging Port
5. Microphone
6. Volume Down (-) / Previous Track (⏮)
7. Indicator Light



What Your Headset Can Do

Your Hisense HB400C lets you do the following:

- Answer Calls
- End Calls
- Reject Calls*
- Voice Dialing*
- Last Number Redialing*
- Call Waiting*

* Phone dependent

In addition you can use the HB400C headset for listening to music. When doing so you will be able to enjoy the following features:

- Pause/Play
- Navigate to next track / navigate to previous track

*Device depended

Specifications

- Up to 6 Hours TalkTime/ Listening to Music: Up to 6 Hours
- Standby Time Up to 160 Hours
- Rechargeable battery with charging option from AC power supply or PC via USB cable
- Weight 12 grams
- Operating range up to 10 meters (approx. 33 feet)
- A2DP, AVCRP, Headset and hands-free Bluetooth profiles
- Bluetooth specification (see glossary) version 2.1

GETTING STARTED

Charging your Headset

Make sure that the Hisense HB400C headset is fully charged for 3 hours before first use.

Use the AC adaptor to charge from a power socket, or charge directly from your PC with the USB cable provided. Connect your headset to the AC adaptor or USB cable.

When the indicator light is solid red, your headset is charging. When the lights turn off the headset is fully charge.

Turning Your Headset On and Off

To turn on your headset, press and hold the MFB for 5 seconds.

To turn off your headset, press and hold the MFB for 5 seconds.

Notice: If the headset has not connected to a Bluetooth device for 30 minutes, the headset will turn off automatically, in order to save power.


Pairing with Your Phone or Other Device

Before you use the Hisense HB400C, you need to pair it with your mobile phone or other audio device with Bluetooth transmitter.

put your headset into pairing mode

1. make sure that your Bluetooth headset is turned off
2. Press and Hold the headset's MFB for 8 seconds till the blue and red indication light flash alternatively, meaning that the headset has entered into pairing mode;
3. Activate Bluetooth function of the mobile phone or other device to search for Bluetooth devices (please refer to the phone/device manual);

4. Set your Bluetooth phone to 'discover' the Hisense HB400C
HB400C
Follow your phone's instruction guide. This usually involves going to a 'setup,' 'connect' or 'Bluetooth' menu on your phone and selecting the option to 'discover' or 'add' a Bluetooth device. * (See example from a typical mobile phone).



5. Your phone will find the Hisense HB400C
6. Your phone will then ask if you want to pair with it. Accept by pressing 'Yes' or 'OK' on the phone and confirm with the passkey or PIN = 0000 (4 zeros). Your phone will confirm when pairing is complete.

In case of unsuccessful pairing, repeat steps 1 to 5

Wearing Your HB400C Headset

The HB400C is clip designed Bluetooth headset, you can wear it on the shoulder collapsible or frock pocket etc.

You can use a mono headset in one ear or stereo headset in both ears to listen to music.



How to...

Answer a Call

Press the MFB on your headset to answer a call.

End a Call

Press the MFB to end an active call.

Make a Call

When you make a call from your mobile phone, the call will (subject to phone settings) automatically transfer to your headset.

Reject a Call*

Press the MFB for approximately 3 seconds following an indication tone. Depending on your phone settings, the person who called you will either be forwarded to your voice mail or hear a busy signal.

Activate Voice Dialing*

Press the MFB, wait for the beep and then announce the name you wish to call.

For best results, record the voice-dialing tag through your headset. Please consult your phone's user manual for more information about using this feature.

Redial Last Number*

Press the MFB for 3 seconds, when the headset is on and not use.

Adjust Sound and Volume

During conversation or music listening, press several times on the volume up (+) or volume down (-) to adjust the volume.

- Functions marked with * are dependent on your phone supporting these features.

Check your phone's user manual for further information

How to Play Music in Stereo

Your HB400C headset realizes its full potential when connected via Bluetooth to a Bluetooth stereo device. The buttons on the both sides of your HB400C are used for navigating through the songs. They work when the device you have connected to supports the Bluetooth remote control (AVRCP) profile. (See Glossary page 18).

Start Play

Start the music using the controllers on your music device

Answer a Call when Playing Music*

Press the MFB to pause the music and the call will be connected. The music will resume after the call has ended (depending on the device supporting this feature).

Skip One Track Forward

Press for 3 seconds the volume (+) button.

Skip One Track Back

Press for 3 seconds the volume (-) button.

Note:

In some mobile phones, while playing music, the music will transmit to the speaker of mobile phone.

In order to send the music to the headset you have to choose "transmit the sound through Bluetooth" in the "setting" of music play interface, and then choose "HB400C" in the device list.

What the Lights and Tones Mean

	What you see	What does this mean about your headset
When headset is connected to charger	Solid red	Charging
	Red LED turns off	Charging completed
When headset is NOT connected to charger	Red and blue LED flash alternately	Pairing
	Blue LED flash every 3 seconds.	Standby mode (connected with the Bluetooth device)
	Blue LED flash every 8 seconds.	Standby mode (connected with the Bluetooth device)
	Red LED flash every 5 seconds.	Low Battery

What you hear	What does this mean about your headset
During a conversation 2 tones every 5 seconds	Microphone is muted
Short tone every 20 seconds	Low battery

Troubleshooting

I hear crackling noises

Bluetooth is a radio technology, which means it is sensitive to objects between the headset and the connected device. It is designed for the headset and the connected device to be used within 10 meters (33 feet) of each other, with no major objects in the way (walls, etc.).

I cannot hear anything in the headset

Increase the volume in the headset.

Ensure that the headset is paired to a device that is playing.

Make sure your phone is connected to the headset by checking the phone's menu or by tapping the MFB.

I have pairing problems

You may have deleted the pairing connection in your mobile phone. Follow the pairing instructions in page 9.

I have problems streaming in stereo from another device (PC, MP3-player etc.)

Make sure the other device supports Bluetooth 1.1 or 1.2 and that the Advanced Audio

Distribution Profile (A2DP) is active, or it will not work. Please consult the other device's manual for how to pair to a headset.

I can hear stereo but the music control buttons do not work

The connected device must support the Bluetooth profile for remote control, AVRCP, to make the music control buttons work. Try to re-connect.

I cannot use reject call, redial or voice dialing

These features are dependent on the ability of your phone to support a hands-free profile. Please consult your phone's manual for details.

Will it be possible to listen to radio on my phone with the HB400C?

Being able to listen to radio via Bluetooth depends on your phone. Most of the mobile phones currently on the market require a corded headset that uses the cord as an antenna.

Taking Care of Your Headset

- Always store the Hisense HB400C with the power off and safely protected.
- Avoid storage at extreme temperatures (above 45°C/113°F – including direct sunlight – or below -10°C/14°F). This can shorten battery life and may affect operation. High temperatures may also degrade performance.
- Do not expose the Hisense HB400C to rain or other liquids.

Glossary**Bluetooth**

The Bluetooth® trademark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by Hisense is under license. Other trademarks and trade names are those of their respective owners.

1. **Bluetooth** is a radio technology that connects devices, such as mobile phones and headsets, without wires or cords over a short distance (approx. 30 feet). Get more information at www.bluetooth.com.
2. **Bluetooth** profiles are the different ways that Bluetooth devices communicate with other devices.

Bluetooth phones support either the headset profile, the hands-free profile or both. In order to support a certain profile, a phone manufacturer must implement certain mandatory features within the phone's software.

3. **Pairing** creates a unique and encrypted link between two Bluetooth devices and lets them communicate with each other. Bluetooth devices will not work if the devices have not been paired successfully.
4. **Passkey or PIN** is a code that you enter on your mobile phone to pair it with your Hisense HB400C. This makes your phone and the Hisense HB400C recognize each other and automatically work together.
5. **Standby Mode** is when the Hisense HB400C is passively waiting for a call. When you 'end' a call on your mobile phone, the headset goes into standby mode.
6. **A2DP (Advanced Audio Distribution Profile)** is a Bluetooth profile that enables stereo sound. Both the headset and the device it connects to must support A2DP in order to hear A2DP sound in the headset.
7. **AVRCP (Audio Video Remote Control Profile)** is a Bluetooth profile that enables remote control of the device that the headset is connected to. Both the headset and the device it connects to must support AVRCP in order for AVRCP to work.



Dispose of the product according to local standards and regulations or local laws.

