
3M MP8630/8640 Multimedia Projector Quick Setup Instructions

Cable Connections: Always turn power off when making any cable connections.



© 3M 1997 78-6970-7971-9

3M MP8630/8640 Multimedia Projector Quick Setup Instructions

Projector Packout





Multimedia Projector Remote Control Transmitter (batteries included)







(with dip switch



3-Conductor ideo/Audio Cal


M)

Video Cable IS-Video mini DIN4-pi


Packout Items not shown:

- PS/2 mouse cable
- ADB mouse cable
- Serial mouse cable
- Stereo mini-jack

Remote Control Transmitter



Projector Controls



Projector Start Up Procedure

- 1. With all power off, connect cables from projector to input devices.
- 2. Press the projector power switch (1) to the "ON" postion.
- 3. Slide lens shutter (2) to the open position.
- 4. Press the STANDBY/On button (3).
- 5. Raise or lower front projector feet to adjust image height.
- 6. Press the ZOOM button (4) to adjust the image size to fit the screen. If needed, move projector closer or further from projection screen.
- 7. Press the FOCUS button (5) to adjust the image focus.
- 8. Turn on all connected equipment.
- 9. Press the INPUT button (6) on projector or INPUT SELECT-Video or RGB (6) on remote to select signal source.

Projector Shutdown Procedure

1. Press and hold STANDBY/ON button (3) for 3-5 seconds. (The lamp turns off, the fan motor continues to run)

⚠ Caution

Do not turn off the projector power before pressing the STANDBY/ON button. The fan motor will run for about 1 minute and cool the projector.

- 2. After fan stops, press main power switch (1) to "OFF".
- 3. Close the lens shutter (2) to protect lens.
- 4. Disconnect cables.