


3M

MP8746/MP8747 Multimedia Projector Quick Start Guide



Important Notice

Before using this product, you must evaluate it and determine if it is suitable for your intended application. You assume all risks and liability associated with such use.

Warranty; Limited Remedy; Limited Liability.


This product will be free from defects in material and manufacture as of the date of purchase. 3M MAKES NO OTHER WARRANTIES INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. If this product is defective within the warranty period stated above, your exclusive remedy shall be, at 3M's option, to replace or repair the 3M product or refund the purchase price of the 3M product. Except where prohibited by law, 3M will not be liable for any loss or damage arising from this 3M product, whether direct, indirect, special, incidental or consequential regardless of the legal theory asserted.

3M

Visual Systems Division


6801 River Place Blvd.
Austin, TX 78726-9000
800/328-1371-3573
www.3M.com/meetings

Printed in USA
© 3M IPC 2000 78-6970-9052-6 Rev.A




Start-up Procedure

PC & Mac Connection




Standby/Power Buttons

1




Wait 5 Seconds



00:00:00



00:00:05




2



Hold button for 3 seconds

00:00:00





00:00:03




Shutdown Procedure

1



2


00:00:00




00:01:00



00:00:30



= 00:01:30



Power