# Optical Drive, 20-inch Replacement Instructions


Follow the instructions in this sheet carefully. Failure to follow these instructions could damage your equipment and void its warranty.

Note: Online instructions are available at http://www.apple.com/support/doityourself/.

#### **Tools Required**

- Use the screwdriver provided, or a Phillips #2 screwdriver, preferably with a magnetized tip
- · Screw tray or equivalent to hold the screws

#### **Part Location**




## **Important Things to Know**

- 1. All customer removable screws are brass colored. Do not remove screws unless they are brass colored, or you will void your warranty.
- 2. A magnetized "L"-shaped Phillips screwdriver is included with the replacement part.
- 3. Ground yourself when working on the computer. The procedure will show you how to ground yourself.
- 4. Keep drinks and other liquids away from the area you are working on the iMac.

#### **Opening the Computer**

Note: These instructions cover the iMac G5 (20-inch) models. The models may look slightly different from one shown in the illustration; however, the following procedure applies to both models.

- 1. Turn off your computer by choosing Shut Down from the Apple ( ) menu.
- 2. Disconnect all cables, and unplug the power cord from your computer.



3. Place a soft, clean towel or cloth on the desk or surface. Hold the sides of the computer and slowly lay the computer face down as shown.



 Locate the three silver case screws circled below. You may have to lift the stand to locate the middle case screw. Note: These screws are captive; they are part of the display/bezel assembly and cannot be removed.

Using the tool provided, or a Phillips #2 screwdriver, loosen the three captive screws. Turn the screws to the left until they stop turning. **Don't force the screws once they stop turning**.



5. Holding the back cover by the metal foot, tilt the cover up and lift it off the computer. Set the back cover aside.




## **Removing the Optical Drive**

1. Ground yourself. Touch the metal surface (as shown below) on the inside of the computer to discharge any static electricity.

Warning: Always discharge static electricity before you touch any parts or install any components inside the computer. To avoid generating static electricity, do not walk around the room until you have finished installing the part and closed the computer.




2. Locate the optical drive in the top left corner.




3. Using the tool provided, or a Phillips #2 screwdriver, remove the four optical drive screws circled below. Set the screws aside.





4. Pull the optical drive tab straight up and then to the right. Set the optical drive aside.




5. Return this optical drive to Apple in the packaging provided.

# **Installing the Replacement Optical Drive**


1. Remove the replacement optical drive from its packaging.

2. Slide the optical drive into place (#1) and press down (#2) near the tab to reconnect the drive.



#### 3. Replace the four optical drive screws.





# **Closing the Computer**

1. Replace the cover so that the slots on the top edge of the cover mate with the tabs on the display housing.




2. Lower and press the cover into place until it fits snugly on the computer.



3. Tighten the case screws by turning them clockwise.



4. Reconnect the power cord while the computer is face down and then position the computer in the upright position. Turn on the computer.



#### **Apple Computer, Inc.**

© 2005 Apple Computer, Inc. All rights reserved.

This document is protected under U.S. Copyright Law and International Treaties, and no part of this document may be reproduced in any form without written permission from Apple.

Apple is not responsible for typographical, printing, or inadvertent errors.

Apple Computer, Inc.
1 Infinite Loop
Cupertino, CA 95014-2084
USA
+ 1 408 996 1010
http://www.apple.com

Apple, the Apple logo, iMac, Mac, Macintosh, and the Mac logo are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.