

USB Storage Media

Operating Instructions

操作說明

操作说明

USM256J/USM512J/
USM1GJ/USM2GJ



MICROVAULT™

© 2006 Sony Corporation Printed in Taiwan

English

WARNING

Keep away from children. If swallowed, promptly see a doctor.

To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

When Using USB Storage Media for the First Time (Installing the Device Driver)

When running Windows 98/98SE

You must install a device driver. Visit the following URL to download and install the device driver.

<http://www.sony.net/Products/Media/Microvault/>

When running Windows Vista, Windows XP, Windows 2000, Windows Me, or Mac OS 9.0 and higher

Ordinarily, the device driver is installed automatically when you connect the Micro Vault.

However, with some USB 2.0 cards or boards, you may need to initiate installation manually.

Follow the instructions displayed on the screen to search for a suitable driver.

For Customers in Asia Pacific Region

For MICRO VAULT™ USB Storage Media only

Limited warranty for Customer in Asia Pacific region.

If this product proves defective in workmanship or materials when used in accordance with the guidelines and conditions presented in the instruction manual, Sony will replace this product with an equivalent product free of charge within 1 year after purchase date. This warranty is subject to the conditions indicated herein. Sony shall not be liable for loss or damage to data stored in the product howsoever caused.

NOTE: "FOR YOUR PROTECTION"

Please retain your original sales receipt to receive warranty coverage. For more information on Sony Authorized Service Centers, please access the 'Support Network' section in the following web site.

<http://www.css.ap.sony.com/>

Basic Operation

Note:
 • Please remove the Micro Vault properly following the procedure described in this manual. Otherwise, data may not be recorded correctly.
 • If the USB port connector is not easily accessible, you can use a USB hub to attach the Micro Vault to the USB port connector on your computer.

Setup

Slide the button on the Micro Vault while pressing it down to extend the USB connector and connect it to a USB port on the computer.

When running Windows Vista, Windows XP, Windows 2000, Windows Me, or Windows 98/98SE

Once the Micro Vault is connected to the computer, the drive icon for the Micro Vault device appears. (The drive name varies, depending on your computer system.)

You can now copy and save data on the Micro Vault by dragging files and folders on the drive icon, just as you would when copying data to a hard disk or to a floppy disk.

An Important Notice for Windows 98, Windows 98SE and Windows Me Users

Microsoft Corporation finished the support for Windows 98, Windows 98SE and Windows Me on July 11th, 2006.

We confirmed the software that we provide on the website can work under these OSs, but we may not be able to provide upgrade programs or support for these OSs since Microsoft retired public and technical support of these OSs.

We would appreciate your kind understanding.

When running Mac OS 9.0 and higher

Once the Micro Vault is connected to the computer, the drive icon for the Micro Vault device appears. You can now copy and save data on the Micro Vault by dragging files and folders on the drive icon, just as you would when copying data to a hard disk or to a floppy disk.

* Mac OS 10.0x is not supported.

Meanings of the Indicator Light

When the Micro Vault is in use, the indicator light indicates its status as follows.

Indicator Light Status	Meaning
Off	Standby
On	Data transfer in progress (Do not remove the Micro Vault while the indicator light is flashing.)

Disconnection

When running Windows Vista, Windows XP, Windows 2000 or Windows Me

Double-click (Safely Remove Hardware) in the task tray in the lower right portion of the screen. In the window that appears, select the name of the device that is to be removed, then click the Stop button. When the Stop a Hardware Device screen appears, make sure that the correct information is displayed, and then click the OK button. When the "Safe to Remove Hardware" message appears, you may remove the Micro Vault. (The icon and messages that appear may vary depending on the version of the OS.) When running Windows Vista, you can also select "Safely Remove Hardware" by right-clicking the Micro Vault drive icon in Explorer or My Computer.

When removing the Micro Vault while Virtual Expander is running, be sure to end the program first by right-clicking the Virtual Expander icon in the task tray and selecting "End" from the menu that appears.

When running Windows 98/98SE

After confirming that the Micro Vault is in standby mode, disconnect the Micro Vault.

When running Mac OS 9.0 and higher

Drag the Micro Vault icon to the Trash. After confirming that the Micro Vault is in standby mode, disconnect the Micro Vault.

About Micro Vault Virtual Expander software

- This software is pre-installed in the Micro Vault.
- This is compression software originally designed for the Micro Vault. For more details on its use, see the README file stored in the Micro Vault.
- The compression ratio will differ depending on the file.
- Files that have already been compressed by Virtual Expander and files of 2 KB or less are saved unchanged, without being compressed.
- If the software becomes unstable during use, visit the following URL to download the latest version. Only products with Micro Vault Virtual Expander installed at the time of purchase can download from this Web site.

<http://www.sony.net/Products/Media/Microvault/>

- Supported OS: Windows XP (SP1 and higher), Windows 2000 (SP3 and higher)

Notes on Use

- When formatting the device, use the format software which you can download from the website. To avoid any changes of the specifications, do not format the device in any other way.
- The Micro Vault may not function correctly if it is connected to the computer when the computer is started up, restarted, or restored from sleep mode. Always disconnect the Micro Vault from the computer before performing any of these operations.
- The Micro Vault has a hole for attaching a strap or a ring. However, a hook-shaped metal object (such as a key holder) should not be attached to this hole, because it may cause damage to the Micro Vault.
- Do not place the unit in locations that are:
 - extremely hot or cold
 - very humid
 - exposed to corrosive gases
 - Cleaning
- Clean the unit with a soft, dry cloth or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of solvent, such as alcohol or benzene, which may damage the finish.

It is strongly recommended that you periodically back up the data written on the unit.

Sony Corporation assumes no liability for any damage or loss of data that may occur.

Precautions for Transfer and Disposal

If data stored on the Micro Vault is deleted or reformatted using the standard methods, the data only appears to be removed on a superficial level, and it may be possible for someone to retrieve and reuse the data by means of special software.

To avoid information leaks and other problems of this sort, it is recommended that you use commercially available software designed to completely remove all data from the Micro Vault.

- Micro Vault is a trademark of Sony Corporation.
- Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and other countries.
- Mac and Macintosh are trademarks of Apple Computer, Inc., registered in the U.S. and other countries.
- Other system names and product names that appear in this manual are registered trademarks or trademarks of their respective owners. Note that the ™ and ® symbols are not used in this manual.

- Our product warranty is limited only to the USB storage media itself, when used normally in accordance with these operating instructions and with the accessories that were included with this unit in the specified or recommended system environment. Services provided by the Company, such as user support, are also subject to these restrictions.
- The Company cannot accept liability for damage or loss resulting from the use of this unit, or for any claim from a third party.
- The Company cannot accept any liability for problems with your computer or other hardware arising from the use of this product; the suitability of this product for specific hardware, software, or peripherals; operating conflicts with other installed software; data loss; or other accidental or unavoidable damages.
- The Company cannot accept any liability for financial damages, lost profits, claims from third parties, etc., arising from the use of the software provided with this unit.
- The software specifications may be subject to change without notice.

中文

警告

請將本品放在兒童接觸不到的地方。如果吞食，立即請醫生救治。

為減少火災或觸電的危險，請勿將本裝置暴露在雨中或潮濕環境中。

為防止觸電，請勿打開機蓋。維修只能由有資格的人員進行。

用戶記錄

型號和序號位於本產品的側面。請在此處的空白處記錄下系序號。致電Sony客戶資訊中心時請參考該型號和系序號。

型號：USM256J, USM512J, USM1GJ, USM2GJ

序號：

當第一次使用 USB 儲存媒體時 (安裝設備驅動程式)

當運行 Windows 98/98SE 時

您必須安裝設備驅動程式。請訪問以下 URL，下載並安裝設備驅動程式。

<http://www.sony.net/Products/Media/Microvault/>

當運行 Windows Vista, Windows XP, Windows 2000, Windows Me 或 Mac OS 9.0 及其以上版本時

一般來說，當 Micro Vault 連接到電腦上時，自動安裝設備驅動程式。但是，對某些 USB 2.0 卡或接口板，可能需要手動進行起始安裝。請按螢幕上顯示的說明，搜索合適的驅動程式。

資訊為亞太地區顧客

僅適用於 MICRO VAULT™ USB 儲存媒體

亞太地區客戶有限保固

依說明手冊所述各項指示與條件使用之下，本產品的製造與材質若有瑕疵，自購買日起一年內，Sony 將免費為客戶更換相當的產品。本項保固僅適用於此處所述之有限保固條款。本產品內所儲存資料若有任何毀損，Sony 恒不擔負任何責任。

備註：「為保護您的權益」

請妥善保存您的原始購買單據，以利取得產品固保。有關Sony Authorized Service Centers(授權服務中心)的詳盡資訊，請進入下列網站的「Support Network」(支援網路)區：
<http://www.css.ap.sony.com/>

基本操作

註：

- 請按本手冊中介紹的步驟正確刪除 Micro Vault。否則不能正確錄製資料。
- 如果很難直接連上 USB 端口連接器，可以使用 USB 集線器把 Micro Vault 連到電腦上的 USB 端口連接器上。

設定

按住並滑動 Micro Vault 上的按鈕，伸出 USB 連接器並將它連接到電腦的 USB 端口連接器上。

當運行 Windows Vista、Windows XP、Windows 2000、Windows Me 或 Windows 98/98SE 時
 一旦 Micro Vault 連上電腦，Micro Vault 設備的驅動器圖示即出現。(驅動器名稱取決於電腦系統)現在，可以通過把檔案和資料夾拖到 Micro Vault 驅動器圖示上來將資料拷貝和保存到 Micro Vault 上，如同拷貝資料到硬碟或軟碟上的操作。

針對 Windows 98、Windows 98SE 和 Windows Me 用戶的重要通知。

微軟公司於 2006 年 7 月 11 日起停止對 Windows 98、Windows 98SE 和 Windows Me 系統的支持。我們確定在網站上提供的軟件能在這些操作系統下使用，但是由於微軟公司停止對這些操作系統的技術支持，我們不能保證提供升級程序或繼續支持這些操作系統。敬請諒解。

當運行 Mac OS 9.0 及其以上版本時

一旦 Micro Vault 連上電腦，Micro Vault 設備的驅動器圖示即出現。現在，可以通過把檔案和資料夾拖到 Micro Vault 驅動器圖示上來將資料拷貝和保存到 Micro Vault 上，如同拷貝資料到硬碟或軟碟上的操作。

* Mac OS 10.0x 不支持。

指示燈的意義

當 Micro Vault 正在使用時，指示燈顯示狀態如下。

指示燈狀態	意義
關	待機
開	正在傳輸資料（指示燈閃爍時，不要取下 Micro Vault）

取出

當運行 Windows Vista, Windows XP, Windows 2000 或 Windows Me 時

雙擊螢幕右下方任務欄上的 (安全取下硬體)。在出現的窗口中，選擇要取下設備的名稱，然後單擊 [Stop] 按鈕。當 [Stop a Hardware Device] 螢幕出現時，確認顯示資訊正確，然後單擊 OK 按鈕。當 "Safe to Remove Hardware" 訊息出現時，便可以取下 Micro Vault。

(顯示的圖示和訊息可能因作業系統的版本而異。)

運行 Windows Vista 時，也可以右鍵按一下資源管理器或我的電腦當中的 Micro Vault 驅動器圖示來選擇 "Safe to Remove Hardware"。

如果在運行 Virtual Expander 時取下 Micro Vault，請務必先右鍵按一下任務欄當中的 Virtual Expander 圖示，然後再從出現的選單中選擇 "END" 來結束程式。

當運行 Windows 98/98SE 時

確認 Micro Vault 處於待機狀態後，取出 Micro Vault。

當運行 Mac OS 9.0 及其以上版本時

把 Micro Vault 圖示拖到資源回收筒。確認 Micro Vault 處於待機狀態後，取出 Micro Vault。

關於 Micro Vault Virtual Expander 軟體

- 本軟體預裝在 Micro Vault 上。
- 本壓縮軟體專用於 Micro Vault。使用詳情請參閱儲存在 Micro Vault 內的 README 檔案。
- 壓縮率因檔案而異。
- 已經由 Virtual Expander 壓縮過的檔案和容量為 2 KB 以下的檔案將原樣保存，不再進行壓縮。
- 如果在使用期間軟體變得不穩定，請訪問以下 URL，下載最新版本。只有在購買時安裝了 Micro Vault Virtual Expander 的產品才可從該網站上下载。

<http://www.sony.net/Products/Media/Microvault/>

- 支持的作業系統：Windows XP (SP1 或更高)、Windows 2000 (SP3 或更高)

使用注意事項

- 當格式化設備時，請使用您從網站下載的格式化軟體。為避免改變產品規格，請勿以其他方式格式化設備。
- 當電腦啓動、重新啓動或從睡眠模式恢復時，如果把 Micro Vault 連到電腦上，Micro Vault 可能無法正常工作。在進行這些操作前，務必從電腦上取出 Micro Vault。
- Micro Vault 上有一小孔用來帶子或環。但是，鉤狀的金屬物 (如鑰匙扣) 不能裝到此孔內，否則可能損壞 Micro Vault。
- 不要將本機放在以下位置：
 - 非常冷或熱的地方
 - 非常潮濕的地方
 - 有腐蝕性氣體的地方
 - 清潔
- 用軟的乾布或稍沾上中性洗潔溶液的軟布清潔本機。
 不要使用任何種類的溶劑，如酒精或苯，它們可能損壞表面。

強烈建議您將本品上寫入的資料定期備份。

Sony 公司對任何可能發生的資料損壞或丟失概不負責。

傳輸和處理注意事項

如果使用標準方法刪除 Micro Vault 上儲存的資料或重新格式化 Micro Vault，這些資料僅僅是表面上被刪除，藉助於某些特殊軟體，用戶有可能恢復並重新使用這些資料。如要避免資訊泄漏和其他此類問題發生，建議您使用能夠徹底將全部資料從 Micro Vault 上刪除的市售軟體。

- Micro Vault 是 Sony 公司的商標。
- Microsoft 和 Windows 是 Microsoft 公司在美國和其他國家的註冊商標。
- Mac 和 Macintosh 是 Apple Computer 公司的商標，已在美國和其他國家註冊。
- 出現在本手冊中的其他系統名稱和產品名稱是它們各自所有者的註冊商標或商標。注意，本手冊不使用™ 和 ® 符號。

- 我們的產品擔保僅限於 USB 介質本身，且要遵守這些操作說明，使用本機附帶的附件，在指定或推薦的系統環境下正常使用。本公司提供的服務，如用戶支持，也受這些限制。
- 本公司對因使用本機導致的損害或損失，或任何第三方的索賠不承擔責任。
- 本公司對下列情況不承擔任何責任：由於使用本產品導致您的電腦或其他硬體出現的問題；本產品對特定硬體、軟體或外設的適應性；和安裝的其他軟體產生操作衝突；資料損失；或其他意外或不可避免的損害。
- 本公司對因使用隨本機附帶的軟體而產生的財務損失、利潤損失、第三方的索賠等不承擔任何責任。
- 軟體規格如有變動，恕不通知。

中文

警告

請將本品放在兒童接觸不到的地方。如果吞食，立即請醫生救急。

為減少火災或觸電的危險，請勿將本裝置暴露在雨中或潮濕環境中。

為防止觸電，請勿打開機蓋。維修只能由有資格的人員進行。

用戶記錄

型號和序列號位於本產品的側面。請在此處的空白處記錄下序列號。致電 Sony 客戶信息中心時請參考該型號和序列號。

型號: USM256J, USM512J, USM1GJ, USM2GJ

序列號: _____

对中国地区用户质量保证

如果你对该产品有任何问题，可致电客户信息中心，中国地区电话: 8008209000; 或发电子邮件至: ccc@sony.com.cn

我们对该产品的质量保证期为一年（质量保证期自购买日期起计算，请务必妥善保存发票，在获取免费更换或退款的服务时需出示该发票的原件，否则无法享受该项质量保证服务）。如果在此期间经我公司确认产品确实存在因原材料或制造工艺问题而导致的质量缺陷，我们将提供免费更换或按原发票面额全额退款的质量保证服务。（注：此质量保证的最终解释权归索尼（中国）有限公司公司所有）。

有关更换或退货服务详呈，请致电客户信息中心或参阅索尼中国网页

<http://www.sony.com.cn> (Micro Vault 部分)

当第一次使用 USB 存储介质时（安装设备驱动程序）

当运行 Windows 98/98SE 时

您必须安装设备驱动程序。请访问以下 URL，下载并安装设备驱动程序。

<http://www.sony.net/Products/Media/Microvault/>

当运行 Windows Vista, Windows XP, Windows 2000, Windows Me 或 Mac OS 9.0 及其以上版本时

一般来说，当 Micro Vault 连接到计算机上时，自动安装设备驱动程序。但是，对某些 USB 2.0 卡或接口板，可能需要手动进行起始安装。请按屏幕上显示的说明，搜索合适的驱动程序。

基本操作

注：

- 请按本手册中介绍的步骤正确删除 Micro Vault。否则不能正确录制数据。
- 如果很难直接连上 USB 端口连接器，可以使用 USB 集线器把 Micro Vault 连到电脑上的 USB 端口连接器上。

设置

按住并滑动 Micro Vault 上的按钮，伸出 USB 连接器并将它连接到计算机的 USB 端口连接器上。

当运行 Windows Vista、Windows XP、Windows 2000、Windows Me 或 Windows 98/98SE 时

一旦 Micro Vault 连上计算机，Micro Vault 设备的驱动器图标即出现。（驱动器名称取决于计算机系统）

现在，可以通过把文件和文件夹拖到 Micro Vault 驱动器图标上来将数据复制和保存到 Micro Vault 上，如同复制数据到硬盘或软盘上的操作。

针对 Windows 98、Windows 98SE 和 Windows Me 用户的重要通知。

微软公司于 2006 年 7 月 11 日起停止对 Windows 98、Windows 98SE 和 Windows Me 系统的支持。我们确定在网站上提供的软件能在这些操作系统下使用，但是由于微软公司停止对这些操作系统的技术支持，我们不能保证提供升级程序或继续支持这些操作系统。

敬请谅解。

当运行 Mac OS 9.0 及其以上版本时

一旦 Micro Vault 连上计算机，Micro Vault 设备的驱动器图标即出现。现在，可以通过把文件和文件夹拖到 Micro Vault 驱动器图标上来将数据复制和保存到 Micro Vault 上，如同复制数据到硬盘或软盘上的操作。

* Mac OS 10.0x 不支持。

指示灯的意义

当 Micro Vault 正在使用时，指示灯显示状态如下。

指示灯状态	意义
关	待机
开	正在传输数据（指示灯闪烁时，不要取下 Micro Vault）

断开

当运行 Windows Vista、Windows XP、Windows 2000 或 Windows Me 时

双击屏幕右下方任务栏上的 (安全卸下硬件)。在出现的窗口中，选择要取下设备的名称，然后单击 [Stop] 按钮。当 [Stop a Hardware Device] 屏幕出现时，确认显示信息正确，然后单击 OK 按钮。

当 “Safe to Remove Hardware” 讯息出现时，便可以取下 Micro Vault。

(显示的图标和讯息可能因操作系统的版本而异。)

运行 Windows Vista 时，也可以右键单击资源管理器或我的电脑当中的 Micro Vault 驱动器图标来选择 “Safely Remove Hardware”。

如果在运行 Virtual Expander 时取下 Micro Vault，请务必先右键单击任务栏当中的 Virtual Expander 图标，然后再从出现的菜单中选择 “END” 来结束程序。

当运行 Windows 98/98SE 时

确认 Micro Vault 处于待机状态后，断开 Micro Vault。

当运行 Mac OS 9.0 及其以上版本时

把 Micro Vault 图标拖到回收站。确认 Micro Vault 处于待机状态后，断开 Micro Vault。

关于 Micro Vault Virtual Expander 软件

- 本软件预装在 Micro Vault 上。
- 本压缩软件专用于 Micro Vault。使用详情请参阅存储在 Micro Vault 内的 README 文件。
- 压缩率因文件而异。
- 已经由 Virtual Expander 压缩过的文件和容量为 2 KB 以下的文件将原样保存，不再进行压缩。
- 如果在使用期间软件变得不稳定，请访问以下 URL，下载最新版本。只有在购买时安装了 Micro Vault Virtual Expander 的产品才可从该网站上下载。

<http://www.sony.net/Products/Media/Microvault/>
<http://sony.com.cn>
<http://www.sonystyle.com.cn/minisite/mv>

- 支持的操作系统: Windows XP (SP1 或更高)、Windows 2000 (SP3 或更高)

使用注意事项

- 当格式化设备时，请使用您从网站上下载的格式化软件。为避免改变产品规格，请勿以其他方式格式化设备。
- 当计算机启动、重新启动或从睡眠模式恢复时，如果把 Micro Vault 连到计算机上，Micro Vault 可能无法正常工作。在进行这些操作前，务必从计算机上断开 Micro Vault。
- Micro Vault 上有一小孔用来系带子或环。但是，钩状的金属物（如钥匙扣）不能装到此孔内，否则可能损坏 Micro Vault。
- 不要将本机放在以下位置：
 - 非常冷或热的地方
 - 非常潮湿的地方
 - 有腐蚀性气体的地方
 - 清洁
- 用软的干布或稍沾上中性洗洁溶液的软布清洁本机。
不要使用任何种类的溶剂，如酒精或苯，它们可能损坏表面。

强烈建议您将本品上写入的数据定期备份。

索尼公司对任何可能发生的数据损坏或丢失概不负责。

传输和处理注意事项

如果使用标准方法删除 Micro Vault 上存储的数据或重新格式化 Micro Vault，这些数据仅仅是表面上被删除，借助于某些特殊软件，用户有可能恢复并重新使用这些数据。如要避免信息泄漏和其它此类问题发生，建议您使用能够彻底将全部数据从 Micro Vault 上删除的市售软件。

- Micro Vault 是索尼公司的商标。
- Microsoft 和 Windows 是 Microsoft 公司在美国和其他国家的注册商标。
- Mac 和 Macintosh 是 Apple Computer 公司的商标，已在美国和其它国家注册。
- 出现在本手册中的其它系统名称和产品名称是它们各自所有者的注册商标或商标。注意，本手册不使用™ 和 ® 符号。

- 我们的产品担保仅限于 USB 介质本身，且要遵守这些操作说明：使用本机附带的附件，在指定或推荐的系统环境下正常使用。本公司提供的服务，如用户支持，也受这些限制。
- 本公司对因使用本机导致的损害或损失，或任何第三方的索赔不承担责任。
- 本公司对下列情况不承担任何责任：由于使用本产品导致您的计算机或其它硬件出现的问题；本产品对特定硬件、软件或外设的适应性；和安装的其它软件产生操作冲突；数据损失；或其它意外或不可避免的损害。
- 本公司对因使用随本机附带的软件而产生的财务损失、利润损失、第三方的索赔等不承担任何责任。
- 软件规格如有变动，恕不通知。

* 以上内容和中国法律规定不符之处，以中国法律为准。

产品名称: MV 随身存
型号: USM256J, USM512J, USM1GJ, USM2GJ
制造商: 索尼公司

进口商: 索尼(中国)有限公司
进口商地址: 北京市朝阳区东三环北路霞光里 18 号佳程大厦 A 座 25 层

产地: 台湾

Specifications

Interface:	Hi-Speed USB (USB2.0)*
Port type:	Type A USB port
Power supply:	USB bus power (no external power supply)
Compatible OSs:	Windows Vista Home Basic/Premium, Business, Enterprise, Ultimate, Starter, Windows XP Professional/Home Edition, Windows 2000 Professional, Windows Me, Windows 98**, Windows 98SE**, Mac OS 9.0x/9.1x/9.2x, Mac OS 10.1 to 10.4.7***
Capacity:	256 MB, 512 MB, 1 GB, 2 GB (Actual usable capacity is somewhat less than the amount shown on the device.)

Operating temperature range: 0 to 35 °C (32 to 95 °F)
Operating humidity range: 10 to 90% (with no condensation)

Storage temperature range: -20 to 60 °C (-4 to 140 °F)

Storage humidity range: 10 to 90% (with no condensation)

External dimensions: Approximately 17.7 × 8.3 × 67 mm

Weight: Approximately 10 g

Accessories: Main Unit, Operating Instructions

* USB 2.0 接口可能不被支持，取决于您使用的电脑和操作系统。如果这是情况，使用 USB 1.1 接口。

** 设备驱动程序须从网上下载。

*** Mac OS 10.0x 不支持。

<http://www.sony.net/Products/Media/Microvault/>

<http://www.mediabysony.com/>

<http://www.sony-asia.com/microvault/>

<http://www.sony.com.cn>

<http://www.sonystyle.com.cn>

Design and specifications are subject to change without notice.

产品规格

串行接口:	USB2.0 高速 *
端口类型:	A 类 USB 端口
电源:	USB 总线供电，无须其它供电
兼容的操作系统:	Windows Vista 家庭版/加强版、商用版、Enterprise、Ultimate、Starter、Windows XP 专业版/家庭版、Windows 2000 专业版、Windows Me、Windows 98**、Windows 98SE**、Mac OS 9.0x/9.1x/9.2x、Mac OS 10.1-10.4.7***
容量:	256 MB, 512 MB, 1 GB, 2 GB (实际可使用的容量会比设备上标明的数值有所减少。)
工作环境温度要求:	摄氏 0 °C-35 °C (华氏 32 °F-95 °F)
工作环境湿度要求:	10%-90% 相对湿度
存放环境温度要求:	摄氏 -20 °C-60 °C (华氏 -4 °F-140 °F)
存放环境湿度要求:	10%-90% 相对湿度
外观尺寸:	大约 17.7 毫米 × 8.3 毫米 × 67 毫米
重量:	大约 10 克
附件:	主件，使用说明书

* 由于您使用的电脑和操作系统的原因，USB2.0 接口可能不被支持，如有上诉情况，请使用 USB1.1 接口。

** 设备驱动程序须从网上下载。

*** Mac OS 10.0x 不支持。

<http://www.sony.net/Products/Media/Microvault/>

<http://www.mediabysony.com/>

<http://www.sony-asia.com/microvault/>

<http://www.sony.com.cn>

<http://www.sonystyle.com.cn>

设计和规格若有改动，恕不另行通知。