



這份《快速啟動指南》的目的，是在協助您快速的架設並使用您的電視。有關安裝及安全注意事項的詳盡資訊，請務必參閱隨附的《使用手冊》。

前視圖




後視圖




連接各式接線

連接天線/有線電視/影音設備/電腦



連接電源轉換器




- 依照圖示連接電源線與電源轉換器。
- 將電源轉換器接頭插入電視后面板的 DC-IN 輸入插座。
- 將電源線另一端的三蕊插頭插入電源插座。

開始操作


觀賞無線或有線電視

- 開啓電視。
- 按下電視的 **SOURCE** 按鈕，選擇「電視」。
- 按下 **MENU** 按鈕，開啓主選單。
- 利用**頻道選擇**(或遙控器的▲/▼)按鈕，選擇「電視」設定。
- 按下 + 或 - (或遙控器的▶或◀) 按鈕，進入「電視」。
- 利用**頻道選擇**(或遙控器的▲/▼)按鈕，選擇「一般/有線電視」。
- 按下 + 或 - (或遙控器的▶或◀) 按鈕選擇無線或有線電視。




選擇 AV1 ~ AV5

- 請確定您的電視已開啓，同時已連接如 DVD 播放機的裝置。
- 按電視的 **SOURCE** 按鈕選擇其他訊號源。電視螢幕上會出現電視頻道碼, PC, 或AV1 ~ AV5。



調整主選單設定值

按 **MENU** 按鈕進入選單。利用遙控器上的**方向鍵**，以調整設定。




HANNSpree

Quick Start Guide


ST63-23A1 23" Liquid Crystal Display TV

This Quick Start Guide is designed to help you set up and start using your LCD TV. Refer to the User's Manual for more detailed installation and safety instructions.

Front View




Rear View




Making Connections

Connecting to Antenna/Cable TV/AV Devices/Computer




Connecting the Power Adapter



Getting Started


Watching Broadcast or Cable TV

1. Turn on your LCD TV.
2. Press the **SOURCE** button to select "TV".
3. Press the **MENU** button to open the OSD menu.
4. Use CH▲ or CH▼ (or ▲/▼ on the remote control) to select "TV".
5. Press + (or ► on the remote control) to enter the "TV" MENU.
6. Use CH▲ or CH▼ (or ▲/▼ on the remote control) to select "TV/CATV".
7. Press + or - (or ►/◀ on the remote control) to select TV (broadcast TV) or CATV (cable TV).



Selecting AV1 - AV5

1. Make sure your TV is turned on and a device such as a DVD player is connected.
2. Press the **SOURCE** button to select different source signals. The channel number, PC, or AV1 ~ AV5 appears on the screen.



Adjusting OSD Settings

Press the **MENU** button to open the OSD menus. Use the arrow buttons on the remote control to adjust settings.

