

XAircraft DIY X4/X8 配件安装说明书


XAircraft DIY X4/X8 Parts Assembly

www.cnhelicopter.com


编号含义 The Meaning of Number

DIY-XF-F4004


袋编号或小袋编号 物品编号
Packet Number or Product Number
Sub Packet Number




设备承载板安装 Device Mounting Plate Assembly




X650起落架安装 X650 Landing Gear Assembly



起落架安装步骤 Landing Gear Assembly STEPS




步骤1 Step1
先扣入一边的挂载杆，扣入时注意用力，避免损坏。
Assemble one side. DO NOT OVER-EXERT TO AVOID DAMAGE.



步骤2 Step2
弯曲起落架，将另一边也扣入挂载杆。弯曲时注意用力，以免损坏起落架。as shown in the figure, and assemble it.

电池固定板安装 Battery Mount Assembly




步骤1 Step1
先扣入一边的挂载杆，扣入时注意用力，以免损坏挂载固定件。
Assemble one side of hanger. DO NOT OVER-EXERT TO AVOID DAMAGE.

步骤2 Step2
使挂载固定件变形，并将其压入挂载杆。注意用力避免损坏挂载固定件。Assemble the other side of hanger as shown in the figure. DO NOT OVER-EXERT TO AVOID DAMAGE.


电机固定板安装
Motor Mounting Plate Installation

建议DIY用户配置22系列电机(如2212)、10寸螺旋桨及10A以上电调，或购买XAircraft提供的动力部件。
DIY users can use 22 serial motor(e.g. 2212), 10inch blade and >10A ESC, or use the power unit provided by XAircraft.


X4 电机安装示例
X4 Motor Installation Example




X8 电机安装示例
X8 Motor Installation Example



X450起落架安装
X450 Landing Gear Assembly



航向球安装
Heading Ball Assembly



零件清单 Parts List

袋编号 Pack No.	编号 Product No.	名称	Part Name	数量 Qty
DIY-XF	F5001	X4/X8机身上板	X4/X8 Fuselage Upper Plate	1
	F5002	X4/X8机身下板	X4/X8 Fuselage Lower Plate	1
	F3005	电池板	Battery Mounting Plate	1
	L1010	扎带	Fastener	2
	F3006	电机固定板	Motor Mounting Plate	8
	F4004	设备承载板	Device Mounting Plate	1
	F4005	机身臂	Frame Arm	4
	F4006	X450 Pro起落架	X450 Pro Landing Gear	4
	L3005	X650 Value起落架	X650 Value Landing Gear	2
	L3001	起落架横杆	Landing Gear Skid Pipe	2
	L3002	挂载杆 (含管塞)	Load Mounting Pipe(with Cork)	2
	F3010	挂载固定件	Load Hanger	2
	L3003	挂载杆固定件	Load Mounting Pipe Mount	4
	L3004	挂载固定胶	Load Mounting Pipe Fixer	4
	F4007	航向球	Heading Ball	1
	F4008	航向连杆	Heading Ball Rod	1
M(DIY)	M6001	M2.5x6 圆头内六角螺丝	M2.5x6 Socket Screw	66
	M6002	M3x6 圆头内六角螺丝	M3x6 Socket Screw	16
	M4003	M3x8 尼螺丝	M3x8 Nylon Screw	4
	M4005	M3 尼龙螺母	M3 Nylon Nut	4
	M4004	M3x12 尼龙支柱	M3x12 Nylon Pillar	12
		附赠包1	Steel Screw Pack	1
		附赠包2	Nylon Screw Pack	1


XAircraft DIY Hexa 配件安装说明书

XAircraft DIY Hexa Parts Assembly

编号含义 The Meaning of Number

DIY-HF-F4004


袋编号或小袋编号 物品编号
Packet Number or Product Number
Sub Packet Number



X650起落架安装


X650 Landing Gear Assembly

www.cnchicopter.com




设备承载板安装

Device Mounting Plate Assembly




起落架安装步骤

Landing Gear Assembly STEPS




步骤1 Step1
先扣入一边的挂载杆，扣入时注意用力，避免损坏。
Assemble one side. DO NOT OVER-EXERT TO AVOID DAMAGE.



步骤2 Step2
弯曲起落架，将另一边也扣入挂载杆。弯曲时注意用力，以免损坏起落架。
Bend the other side of landing gear as shown in the figure, and assemble it.

电池固定板安装

Battery Mount Assembly




步骤1 Step1
先扣入一边的挂载杆，扣入时注意用力，以免损坏挂载固定件。
Assemble one side of hanger.
DO NOT OVER-EXERT TO AVOID DAMAGE.


步骤2 Step2
使挂载固定件变形，并将其压入挂载杆。注意用力避免损坏挂载固定件。Assemble the other side of hanger as shown in the figure.
DO NOT OVER-EXERT TO AVOID DAMAGE.

电机固定板安装
Motor Mounting Plate Installation

建议DIY用户配置22系列电机(如2212)、10寸螺旋桨及10A以上电调，或购买XAircraft提供的动力部件。
DIY users can use 22 serial motor(e.g. 2212), 10inch blade and >10A ESC, or use the power unit provided by XAircraft.



安装时，注意电机固定板与无刷电机的安装孔距。
Notice the hole distance of motor and motor mounting plate.



零件清单 Parts List

袋编号 Pack No.	编号 Product No.	名称	Part Name	数量 Qty
DIY-HF	F6001	X6机身上板	X6 Fuselage Upper Plate	1
	F6002	X6机身下板	X6 Fuselage Lower Plate	1
	F3005	电池板	Battery Mounting Plate	1
	L1010	扎带	Fastener	2
	F3006	电机固定板	Motor Mounting Plate	6
	F4004	设备承载板	Device Mounting Plate	1
	F4005	机身臂	Frame Arm	6
	F4006	X450 Pro起落架	X450 Pro Landing Gear	6
	L3005	X650 Value起落架	X650 Value Landing Gear	2
	L3001	起落架横杆	Landing Gear Skid Pipe	2
	L3002	挂载杆（含管塞）	Load Mounting Pipe(with Cork)	2
	F3010	挂载固定件	Load Hanger	2
	L3003	挂载杆固定件	Load Mounting Pipe Mount	4
	L3004	挂载固定胶	Load Mounting Pipe Fixer	4
	F4007	航向球	Heading Ball	1
	F4008	航向连杆	Heading Ball Rod	1
M(DIY)	M6001	M2.5×6 圆头内六角螺丝	M2.5×6 Socket Screw	66
	M6002	M3×6 圆头内六角螺丝	M3×6 Socket Screw	16
	M4003	M3×8 尼螺丝	M3×8 Nylon Screw	4
	M4005	M3 尼龙螺母	M3 Nylon Nut	4
	M4004	M3×12 尼龙支柱	M3×12 Nylon Pillar	12
		附赠包1	Steel Screw Pack	1
		附赠包2	Nylon Screw Pack	1