

Start Here

Don't forget to register the TV at www.Panasonic.com/register

To start over: Unplug TV power for 3 minutes.

1 "Click"

II Select one

Not HD | Good | Best

Component | HDMI

--- not included ---

Connect

Cable Box (HD) or Satellite Receiver (HD)

2

Language

English | Español | Français

Select OK

Please select your viewing environment

Home Use | Store Presentation

Select "Home Use" when using this TV in your home.

Select OK RETURN

3

First time setup

Language

Clock

ANT/Cable setup

Input labels

Select OK RETURN

Language

Language | English

Change RETURN

4

First time setup

Language

Clock

ANT/Cable setup

Input labels

Select OK RETURN

ANT/Cable setup

ANT in | Not used

Auto program

5

First time setup

Language

Clock

ANT/Cable setup

Input labels

Select OK RETURN

Label your Connected devices

Input labels

Component 1

Component 2

HDMI 1 | CABLE

HDMI 2

HDMI 3

Video 1

Video 2

6

Select

Input Select

1 TV

2 Component 1

3 Component 2

4 HDMI 1 | CABLE

5 HDMI 2

6 HDMI 3

7 Video 1

8 Video 2

Select OK RETURN

Only when using Antenna or Cable without a box


1. Connect

2. ANT in | Cable or Antenna

3. Run Auto program

To watch digital channels, use the "-" button: (example: 4 - 1)

TQD2A19010 · Printed in U.S.A. · Impreso en los Estados Unidos



Viera Concierge

Welcome!

As a Panasonic flat panel TV owner you are now entitled to a variety of free privileges that will make owning your new television even more of a pleasure. It's our way to give you the experience and peace of mind you expect from Panasonic.

Panasonic VIERA Concierge adds value to your premium TV experience with services like:

EXPERT TOLL-FREE HOTLINE AND LIVE WEB CHAT SUPPORT FROM PANASONIC'S NATIONALLY RECOGNIZED CUSTOMER SUPPORT CENTER

IN-HOME PRIORITY SERVICE SCHEDULING AND FOLLOW-UP IF YOUR TELEVISION EVER NEEDS TO BE SERVICED (USUALLY FIXED IN ABOUT TWO DAYS)

COMPLIMENTARY LOANER TVs AVAILABLE FOR IN-WARRANTY REPAIRS BY CONTACTING PANASONIC.

For more information or to get support: call

1-877-95VIERA
(1-877-958-4372)

or visit

VIERAConcierge.com



The Panasonic Customer Call Center is recognized by Purdue University as a "Center of Excellence".

VIERA Concierge Program not available in US territories. Priority Service Scheduling and TV Loaners not available in Alaska and Hawaii. Program details subject to change.

Empezar Aquí

No olvide registrarse en www.Panasonic.com/register/Spanish

Para empezar de nuevo: Desconecte el cable de CA por 3 minutos.

1 "Clic"

II Seleccione Uno

No HD | Bueno | Mejor

Componente | HDMI

--- no incluidos ---

Conecte

Caja de Cable (HD) o Receptor de Satélite (HD)

2

Idioma

English | Español | Français

Selección OK

Por favor seleccione el ambiente de uso

Uso en Hogar | Exhibición | Monstrador

Seleccione "Uso en Hogar" cuando utilice el TV en su hogar.

Selección OK RETURN

3

Ajuste inicial

Idioma

Reloj

Ajuste ANT/Cable

Títulos de entradas

Selección OK RETURN

Idioma

Idioma | Español

Cambiar RETURN

4

Ajuste inicial

Idioma

Reloj

Ajuste ANT/Cable

Títulos de entradas

Selección OK RETURN

Ajuste ANT/Cable

Entrada ANT | No utilizado

Programa auto

5

Ajuste inicial

Idioma

Reloj

Ajuste ANT/Cable

Títulos de entradas

Selección OK RETURN

Nombre sus dispositivos conectados

Títulos de entradas

Componente 1

Componente 2

HDMI 1 | CABLE

HDMI 2

HDMI 3

Video 1

Video 2

6

Seleccionar

Seleccionar entrada

1 TV

2 Componente 1

3 Componente 2

4 HDMI 1 | CABLE

5 HDMI 2

6 HDMI 3

7 Video 1

8 Video 2

Selección OK RETURN

Solo cuando use una Antena o Cable sin la caja

1. Conecte

2. Entrada ANT | Cable o Antena

3. Corra Programa Auto

Para ver un canal digital, utilice el botón "-": (ejemplo: 4 - 1)



• www.Panasonic.com/VIERASupport

• Connections.Panasonic.com



USA 1-(877) 95VIERA (1-877-958-4372)

Mon-Fri 9am - 9pm (EST) Lunes-Viernes
Sat-Sun 10am - 7pm (EST) Sábado-Domingo

Panasonic ideas for life