

45-0888-0000



Mouse Adapters

These adapters make it possible to connect a serial mouse to your IBM PS/2® computer.

Serial Mouse to PS/2, DB9 (M)/MD6 (M) 6"
Cat. No. 45-0888-0000

These adapters make it possible to connect a Serial Mouse to a MAC® computer.

45-0574-0000



MAC® Mouse to IBM® AT, DB9 (M)/MD8 (F)
Cat. No. 45-0574-0000

45-0578-0000



Serial Mouse to PS/2, DB9 (M)/MD6 (M)
Cat. No. 45-0578-0000

45-0577-0000



Serial Mouse to MAC®, DB9 (M)/MD8 (F)
Cat. No. 45-0577-0000

45-0579-0000



PS/2 Mouse to IBM® AT, DB9 (F)/MD6 (F)
Cat. No. 45-0579-0000

DATA SWITCHES


- No power required
- Fully shielded metal case with no-mar feet
- Hard wired rotary switch with all connector pins wired

"D-Sub" Type Manual Switches

The switches are intended to be used for switching low current data signals. All pins are wired through the switch. These switches can be used on either serial or parallel applications.

*Complies with IEEE 1284 Standards

64-2001-0000



Manual Data Switch, DB25 A/B
Cat. No. 64-2001-0000

Manual Data Switch, DB25 A/B/C
Cat. No. 45-2002-0000

Manual Data Switch, DB25 A/B/C/D
Cat. No. 45-2005-0000

Manual Data Switch, DB25 A/B/C/D/E
Cat. No. 45-2006-0000

Manual Data Switch, DB25 "X" (Cross Wired)
Cat. No. 45-2008-0000

Manual Bi-Directional Data Switch, DB25 A/B
***Cat. No. 45-2220-0000**

Manual Bi-Directional Data Switch, DB25 A/B/C/D
***Cat. No. 45-2221-0000**

45-2046-0000



Manual Data Switch, DB15 A/B
Cat. No. 45-2045-0000

Manual Data Switch, DB15 A/B/C
Cat. No. 45-2046-0000

Manual Data Switch, DB15 A/B/C/D
Cat. No. 45-2047-0000

45-2036-0000



Manual Data Switch, DB9 A/B
Cat. No. 45-2030-0000

Manual Data Switch, DB9 A/B/C/D
Cat. No. 45-2035-0000

Manual Data Switch, DB9 "X"
Cat. No. 45-2036-0000