



## User Guide for Android 2.3 (Gingerbread)

Thank you for choosing the Pantech Crossover, our latest smartphone. The Pantech Crossover has many features designed to enhance your mobile experience. With its unique, stylish design and QWERTY keypad, you will enjoy the entire Crossover experience.

This User Guide contains important and useful information that will maximize your familiarity with all that the Pantech Crossover has to offer.

# Important Safety Information

---

## Safety information

The following list shows how to maintain your mobile phone and precautions to take as you use the device.

- Keep your mobile phone and its accessories out of the reach of children and pets.
- Maintain your mobile phone in dry conditions and keep it within normal operating temperatures. It may be damaged at temperatures higher than 55°C/131°F or lower than -20°C/-4°F.
- Do not dry your phone in a microwave oven. Sparks may occur and cause an explosion or fire.
- Do not use or store your mobile phone in dusty, dirty areas.
- Do not disassemble your mobile phone.
- Do not drop or cause severe impact to your mobile phone.
- Do not clean your mobile phone with chemical products, cleaning solvents or detergents.
- Contact your dealer immediately if your mobile phone does not work properly.
- Use only authorized batteries, battery chargers and accessories. Any malfunction or damage caused by the use of unauthorized batteries, battery chargers and accessories will void the limited product warranty.
- Ensure that the battery and the battery charger do not come in contact with conductive objects.
- For optimal performance, use cases and accessories that do not contain magnets.

## Safety precautions


The following list shows precautions to keep your device as you use it.

- Using a mobile phone while driving is prohibited.
- Using a mobile phone while driving can distract your attention and cause an accident. Always switch your phone off to drive safely.
- In an emergency, use a hands-free device built into your car or pull over in a safe place first.
- Check local laws and regulations and comply with them, with regard to the prohibition of mobile phone use while driving.

## Switch off in restricted areas

Always switch your phone off in areas where mobile phone use is restricted.

## Switch off in an aircraft

Always switch your phone off or select the airplane mode (Press , tap **Settings** > **Wireless & networks** > **Airplane mode**) when you are in an aircraft. Electromagnetic waves emitted by your phone may affect the electronic navigation equipment in the aircraft.

## Switch off in hospitals and near medical equipment

Always switch your phone off in hospitals and obey their regulations. Switch your phone off when using medical equipment for private purposes. Always consult with the medical equipment's manufacturer or an expert regarding phone use near the medical equipment.

## Switch off in dangerous areas

Always switch your phone off in areas where explosive or dangerous materials (e.g. fuels or chemical products) are located and obey relevant instructions or signals. Do not insert or remove your mobile phone's battery in such areas.

## Install a hands-free device in a safe location

Install a hands-free device away from the steering wheel and airbag expansion areas. Otherwise you can be injured in a car accident.

## Keep away from other electronic devices

Mobile phones emit electromagnetic waves that may affect nearby electronic devices. After switching on your phone, do not place it close to other electronic goods.

## About the battery usage

Your phone is powered by a Lithium Ion (Li-Ion) battery. In other words, you can recharge your battery while some charge remains without reducing your phone's autonomy due to the "battery memory effect."


- Do not use a damaged battery or charger.
- Do not disassemble, open crush, bend, deform, puncture or shred the battery.
- Do not modify or remanufacture, insert foreign objects into the battery, immerse or expose to water or other liquids, expose to fire, explosion or other hazard.
- Do not put your battery in contact with conductive objects.
- Dispose of and recycle used batteries in accordance with local regulations. Do not dispose of batteries by burning; they may explode.

- Do not use an unauthorized charger or battery.
- Use the battery only for the device for which it is specified.
- Use the battery with a charging device that has been qualified for the device per this standard. Use of an unqualified battery or charger may present a risk of fire, explosion, leakage, or other hazard.
- Do not short circuit a battery or allow metallic conductive objects to contact battery terminals.
- Replace the battery only with another battery that has been qualified with the device per this standard, IEEE-Std-1725-2006.
- Children should be supervised when they use the battery.
- Avoid dropping the phone or the battery. If the phone or the battery is dropped, especially on a hard surface, and the user suspects damage, take it to a service center for inspection.
- Use your battery for the specified purpose only.
- The closer you move to your network's base station, the longer you can use your phone because less battery power is required for connection.
- The battery recharging time varies depending on the remaining battery capacity and the battery and charger type.
- Battery life inevitably shortens over time.
- Since overcharging may shorten battery life, remove the phone from its charger once it is fully charged. Unplug the charger once charging is complete. Leaving the battery in hot or cold places, especially inside a car in summer or winter, may reduce its capacity and life.
- To prevent injury or burns, ensure that no metal objects come into contact with the + and - terminals of the battery.

## Basic instructions


### Useful tips

To understand information contained in this user guide, please keep in mind the following:


- It is assumed that you start operating applications of Crossover from the Applications screen.
- 1. Tap  from the home screen to access the Applications screen.
- 2. Flick the screen up or down and run the application you want to use.





Main home screen



Applications menu screen

- Words in bold fonts refer to the relevant action on the screen. For example, “**Create New contact**” for instruction on creating new contact means that you have to tap .
- Words in all capital letters refer to hard keys of Crossover. For example, LOCK/PWR indicates the lock/power key on the top right of the handset that locks the screen or turns on/off power.

- The symbol “>” refers to the next action. For example, “Press , tap **Settings** > **Language & keyboard**” means that you should press , tap **Settings** first and **Language & keyboard** next.
- Applications menu refers to the screen where all applications of Crossover appear.
- Home screen refers to the screen that appears first when you unlock the screen.
- Idle mode refers to the status when you stay on the home screen ready to run an application.
- Channels through which you can share your items, e.g. contacts and pictures, increase as you subscribe to a service. For example, if you sign up for Facebook or Twitter, you can also share your information with others through Facebook or Twitter.

### About Google accounts

It is recommended that you have a Google account to use some applications provided by Google, e.g. Calendar, Latitude, Play Store, Talk and Gmail of Crossover. For more information on setting up a Google account, refer to Activating Crossover on page 16.

# AT&T Applications Overview

---

## Using AT&T applications

Enjoy applications provided by AT&T.



**AT&T FamilyMap:** Allows you to locate your family members on the map



**AT&T Navigator:** Helps find your way to the destination and locate restaurants and more



**YPmobile:** Helps search for local businesses or map any location



**Contacts:** Recovers your contacts and manages your contacts online



**Live TV:** Provides dozens of TV channels and hundreds of shows including sports, breaking news, kids shows and music entertainment



**AT&T Mark the Spot:** Allows you to submit AT&T's Network Operations problems or difficulties



**myAT&T:** Helps subscribe services and make payments for the bill



**AT&T Code Scanner:** Allows you to scan QR or Data matrix Mobile Barcodes in magazines, stores or on online



**AllSport GPS:** Record time, speed, calories burned and distance travelled

# Table of contents

---

## Important Safety Information .....2

Safety information ..... 2

Safety precautions..... 2

About the battery usage ..... 3

Basic instructions..... 4

## AT&T Applications Overview .....5

Using AT&T applications..... 5

## 1. Getting Started ..... 9

### Getting Started.....10

Inside the package ..... 10

Installing the SIM/USIM card..... 10

Installing the microSD card..... 10

Inserting the battery ..... 11

Charging the battery ..... 11

Turning Crossover on/off ..... 12

Unlocking the screen ..... 12

Locking the screen ..... 12

Product overview ..... 13

Gripping Crossover..... 16

Activating Crossover ..... 16

Using the touch screen ..... 17

Understanding the home screen..... 18

Customizing the home screen..... 20

## 2. Communication .....23

### Communication ..... 24

Calling..... 24

Messaging..... 26

Receiving and sending emails..... 30

Using Gmail..... 31

Using Twitter ..... 32

Using Facebook..... 33

Using the Social Net widget..... 34

S-Board ..... 34

Google Talk ..... 35

## 3. Entertainment .....37

### Entertainment ..... 38

Using the camera..... 38

Using the gallery ..... 41

Listening to music ..... 42

Enjoying YouTube..... 44

## 4. Personal Information ..... 46

### Personal Information..... 47

Managing contacts ..... 47

Using the calendar ..... 48

Creating a memo ..... 49

Using voice memo ..... 50

**5. Documents ..... 52****Documents ..... 53**

Viewing documents ..... 53

**6. Web ..... 55****Web ..... 56**

Accessing the Internet ..... 56

Shopping in the Play Store ..... 58

Using Google Maps ..... 59

Using Places ..... 59

Using Latitude ..... 60

Searching with Google ..... 62

News &amp; Weather ..... 63

**7. Connectivity ..... 64****Connectivity ..... 65**

Using a Wi-Fi network ..... 65

Connecting to a 3G network ..... 66

Using Bluetooth ..... 66

Making Crossover a modem ..... 67

**8. Storage ..... 69****Storage ..... 70**

Managing the memory card ..... 70

Connecting to a PC ..... 70

Using Crossover as Mass Storage ..... 71

Transferring files through Media Transfer ..... 71

**9. Tools ..... 72****Tools ..... 73**

Clock Tools ..... 73

Alarm/Clock ..... 74

Calculator ..... 75

Converter ..... 75

Sketch Pad ..... 76

Voice Dialer ..... 77

Voice Search ..... 77

Compass ..... 78

Navigation ..... 79

Weather ..... 80

Stocks ..... 81

RSS Reader ..... 83

Table of contents

---


**10. Settings ..... 84**  
**Settings ..... 85**  
Personalize .....85  
Wireless & networks.....85  
Call settings..... 86  
Sound.....87  
Display ..... 88  
Location & security ..... 88  
Applications ..... 90  
Accounts & sync ..... 91  
Privacy ..... 91  
Storage..... 91  
Language & keyboard.....92  
Voice input & output .....93  
Accessibility ..... 94  
Date & time ..... 94  
AT&T software update ..... 94  
About phone..... 94  
Resetting Crossover .....95

**Appendix ..... 96**  
**Appendix ..... 97**  
How to upgrade the Android Operating System .....97  
PC Suite ..... 98  
Troubleshooting checklist..... 98  
Specifications ..... 99  
FCC Hearing-Aid Compatibility Regulations for Wireless Devices 99  
FCC Regulatory Compliance ..... 100  
Warranty .....101  
Legal notice .....103  
Index .....104



# 1

## Getting Started



Inside the package  
Installing the SIM/USIM card  
Installing the microSD card  
Inserting the battery  
Charging the battery  
Turning Crossover on/off  
Unlocking the screen  
Locking the screen  
Product overview  
Gripping Crossover  
Activating Crossover  
Using the touch screen  
Understanding the home screen  
Customizing the home screen

**PANTECH**  
CROSS)OVER™



# Getting Started

Follow the outlined steps that should be taken first before using Crossover.


## Inside the package

The package should contain the following items:

- Handset
- Battery
- MicroSD card
- Adapter
- Getting Started CD
- USB cable

## Installing the SIM/USIM card

1. Press and hold the latch and slide it to remove the battery cover.
2. Insert the SIM/USIM card into the slot. Ensure that the gold contacts of the card go against the metal contacts of Crossover.
3. Close the battery cover by sliding it up until you hear “click.”




## About the SIM/USIM card

When you subscribe to the network operator, you receive the Subscriber Identity Module (SIM) card or the Universal Subscriber Identity Module (USIM) card that contains your registration information, PIN code, etc. You should keep it secure and handle carefully. Do not bend, scratch or expose it to moisture. Avoid static electricity.

## Installing the microSD card

1. Press and hold the latch and slide it to remove the battery cover.
2. Insert the microSD card into the slot. Ensure that the gold contacts of the card go against the metal contacts of Crossover.
3. Close the battery cover by sliding it up until you hear “click.”




## About the microSD card

A microSD card is a removable flash memory card where you can save data. Save pictures and contacts, and download applications to the SD card. You can expand the external memory up to 32GB.


It is recommended that you format the microSD card before using Crossover. For more information, refer to page 70.

## Inserting the battery


1. Press and hold the latch and slide it to remove the battery cover.
2. Align the gold contacts on the battery with the contacts located at the top of the battery compartment on the phone.
3. Press the battery down until it lays flat in the compartment.
4. Close the battery cover by sliding it up until you hear “click.”



### Correct method of inserting the battery



### Correct method of installing the battery cover




## About the battery

Crossover uses a Lithium Ion (Li-Ion) battery. Make sure to use the authorized battery and charger only. Maximum hours to use the battery might vary depending on service types offered by the service provider and temperatures. For more details, inquire at your nearest dealer.

- ① **Note** The Li-Ion battery can be recharged while some charge remains without reducing your phone's autonomy due to the “battery memory effect” inherent in those technologies.

## Charging the battery


1. Open the protective cover on the right side of Crossover and connect the charger adapter to the USB connector of Crossover.



- ① **Note** Make sure to align the connector as indicated in the image. Otherwise, the charging connector will be damaged and the battery will not be charged.

## Getting Started

2. Disconnect the charger from Crossover when the battery is fully charged.



## Turning Crossover on/off

### To turn on Crossover,



1. Press and hold the LOCK/PWR key for a few seconds.
2. Unlock the screen.

### To turn Crossover off,


1. Press and hold the LOCK/PWR key.
2. Tap **Power off**.
3. Tap **OK**.

## Unlocking the screen

The screen is locked by default when you turn on power. To unlock the screen,

1. Press the LOCK/PWR key,  or .
2. Drag the arrow symbol diagonally.
3. Draw a pattern if the screen is protected by pattern lock. Enter a PIN or a password if the screen is locked by a PIN or a password.

For more information on screen lock, refer to **Location & security** in Settings on page 88.



## Locking the screen


Lock the screen to protect information in Crossover or save the usage of the battery.

To lock the screen, press the LOCK/PWR key.

## Product overview


### Touch mode

#### Front view



Key	Function
<b>FUNCTION</b>	Adds or deletes application shortcuts
<b>BACK</b>	Ends an application; returns to the previous menu
<b>MENU</b>	Displays options available; turns on the screen; rearranges the home screen
<b>LOCK/PWR</b>	Locks the screen; turns on/off Crossover



#### Rear view



Key	Function
<b>SEARCH</b>	Searches through the Internet; searches applications, contacts and messages that are saved
<b>HOME</b>	Moves to the Home screen; turns on the screen; manages applications that are running

① **Note** Make sure not to cover the proximity sensor with the LCD protection film. If the sensor is covered, you might experience difficulties using the touch screen.

Side view




Hard keys from the touch mode

Key	Function
<b>VOLUME</b>	Adjusts all sound volumes; adjusts the ring mode

Key	Function
<b>USB connector</b>	Connects Crossover and your PC via the USB cable
<b>CAMERA</b>	Turns on the camera; takes a picture
<b>Internal antenna</b>	Receives data from other parties

## QWERTY keypad




### Hard keys from QWERTY keypad

Key	Function
<b>[A] - [Z]</b>	Enters the corresponding letter
<b>ALT + [A]</b>	Enters the secondary character (numbers, symbols) on the left of each key
<b>ALT + ALT + [A]</b>	Continuously enters secondary characters
<b>ALT + Sym</b>	Enters symbols other than those in the keypad
<b>[↑] + [A]</b>	Enters the capital letter for the key

Key	Function
<b>[↑] + [↑] + [A]</b>	Continuously enters capital letters
<b>Sym</b>	Enters a space
<b>[↑] [↓] [←] [→]</b>	Moves the cursor; moves to the next field
<b>[↵]</b>	Moves to the next line of text
<b>[X]</b>	Deletes the character to the left of the cursor

### Gripping Crossover

Hold Crossover in the right position for a call as indicated below:



- Make sure not to block the internal antenna embedded in Crossover. Check the location of the antenna on the illustration on page 13.
- Metal accessories can affect the quality of calls.

### Activating Crossover

Go through the following steps when you turn on Crossover for the first time.

#### Learning how to use Crossover


1. Press and hold the LOCK/PWR key to turn on Crossover.
2. Tap the android logo on the screen.
3. Select and tap a language for Crossover and tap **Next**.
4. Tap either **Mobile network or Wi-Fi** or **Wi-Fi only**, for Internet connection and tap **Next**.


5. Tap **Connect to Wi-Fi network > Next** if you want to establish a connection to the Wi-Fi network. Or tap **Next** if you want to connect to the network later.
  6. Select and tap an available Wi-Fi network if you have tapped **Connect to Wi-Fi network > Next** in step 5. Follow the necessary steps to connect to the Wi-Fi network. For more information, refer to page 85.
  7. Check the mobile network or Wi-Fi network and tap **Next**.
  8. Tap **See location in applications (such as Maps) using wireless networks** to Use Google location, tap **Agree** for Location consent, and tap **Next**.
  9. Tap **Google account** if you want to set up a Google account and follow the necessary steps, or just tap **Next**. For more information on creating a Google account, refer to the next section.
  10. Check how to unlock screen and tap **Skip**.
  11. Check how to use the function key and tap **Next**.
  12. Tap **Tap here to start typing** in the middle of the screen if you want to learn how to use the onscreen keyboard and follow the instructions. Or you can tap **Skip** and learn it later.
  13. Tap **Sync now** for AT&T Address Book sync. You should insert a SIM/USIM card in Crossover. Tap **Skip** if you want to sync later and tap **OK**.
- ① **Note** You can do all of these steps later by tapping **Tutorial**.



## Creating a Google account

After finishing learning how to use Crossover:

1. Press , tap **Settings > Accounts & sync > Add account**.
  2. Tap **Google > Next > Create**.
  3. Enter your first name, last name and user name for the account, and tap **Next**. The user name should be 6–30 characters long. You can select an alternative.
  4. Tap **Next > Connect to Wi-Fi** if you have not connected Crossover to the Wi-Fi network and follow the instructions.
  5. Enter a password and enter it again to confirm. You should enter at least 8 characters.
  6. Tap **Next**.
  7. Select and tap a security question and enter an answer.
  8. Enter a secondary email address and tap **Create**.
  9. Tap **I agree, Next** for the Google Terms of Service.
  10. Tap **Try again** if your password is too weak for a password or contains invalid characters.
  11. Repeat the steps 5 to 9.
  12. Type the characters that appear on screen and tap **Next**.
  13. Tap **Sync Contacts** if you want to synchronize your contacts. Tap **Sync Gmail** if you want to synchronize Gmail.
  14. Tap **Finish setup**.
- ① **Note** Steps for connecting to Wi-Fi network and Google location service might not appear if you have already done with them.



## Using the touch screen

Run an application or perform functions with the touch screen. The following finger actions help you easily understand how to use the touch screen and Crossover.

**Tap:** Tap once to access a menu or an option.

**Double-tap:** Tap an item twice.

**Drag:** Tap and hold your finger on an item and move it without losing contact with the screen.

**Flick:** Place a finger on the screen and move the screen up, down / left, right.

**Pinch:** Place two fingers on the screen and move them apart to zoom in a picture, a document or a web page, or move them together to zoom out.

**Select and tap:** Tap one in the list of options available.

**Press and hold:** Press a key for a few seconds.

① **Note** Use one finger at a time except when you deal with a picture or a document. Crossover will not recognize it when you use more than two fingers at the same time.

### ⚠ CAUTION

- Do not use sharp tools that can scratch the touch screen.
- Do not allow the touch screen to come in contact with water or chemicals. The touch screen may malfunction in humid conditions or in chemicals.
- Do not sit on Crossover. The touch screen can be damaged.

## Getting Started

### Understanding the home screen

Home screen is the starting point to use applications. Access shortcuts, widgets or folders, and display a wallpaper according to your preference.



Portrait view



Landscape view

① **Note** The screen changes to the landscape mode if you open the QWERTY keyboard.



#### Icons of the home screen

Icon	Description
	Makes calls
	Opens messaging
	Accesses the Internet
	Opens Applications menu

### Navigating the home screen

Crossover provides five different screens where you can place items according to your preference.

















1. Flick the screen from the left to the right or vice versa.
2. Tap a desired application or widget to run.











Sample home screens




#### Screen indicators


Icon	Description
	Connected to a Wi-Fi network
	An alarm has been set.
	Sync in progress
	TTY is active.
	The GPS is active.
	There is a message that is not sent.


Icon	Description
	New voicemail
	Bluetooth is connected.
	Bluetooth is active but not connected to other device.
	A file is ready to be delivered from other device.
	Portable Wi-Fi hotspot is active.
	USB tethering is active.
	USB tethering or Portable Wi-Fi hotspot is not active.
	The speakerphone is active.
	Strength of signal: The bar becomes bigger when the signal is strong.
	Airplane mode is active.
	There is no signal.
	A call is under way.
	There is a call on hold.
	There is a missed call.
	Strength of battery: The more green, the more it is charged.
	The battery is charging.

Icon	Description
	There is an upcoming event.
	Music is being played.
	There is no SIM/USIM card.
	The phone vibrates when there is an incoming call.
	The other party cannot listen to you during a call.
	The phone doesn't ring when there is an incoming call.
	The memory disk is full.
	There is an error.

## Managing running applications

1. Press and hold  while you are using an application. Applications that are running in the background appear.
2. Select and tap an application in the screen if you want to resume your work with the application.
3. Tap  if you want to end the application by force and tap **Yes**. Press  and tap **Close all** > **Yes** if you want to stop all applications at once that are running.





- ① **Note** Make sure to press  and move to the home screen if you want to finish using an application. Otherwise, the application continues to run and will take memory and consume battery.

# Customizing the home screen

## Adding a shortcut


1. Press and hold on an empty space on the home screen.
2. Tap **Shortcuts**.
3. Select and tap an item among those that can be added as a shortcut.
4. Select and tap a shortcut among those in the list.



- ① **Note** You can also make a shortcut of an application by pressing and holding the application in applications menu.


## Adding a widget


1. Press and hold an empty space on the screen.
2. Tap **Widgets**.
3. Tap either **Android Widgets** or **Pantech Widgets**.
4. Select and tap a widget among those in the list.




- ① **Note** Make sure to secure enough room on the screen for a widget. Depending on the type of the widget, you have to delete another widget or shortcut or rearrange them.

## Creating a wallpaper from the Gallery

1. Press and hold an empty space on the home screen and tap **Wallpapers**, or press  in idle mode and tap **Wallpaper**.
2. Tap **Gallery**.
3. Select and tap a picture and adjust the size.
4. Tap **Save**.


- ① **Note** If you want to create a live wallpaper, tap **Wallpaper > Live wallpapers**, select a wallpaper and tap **Set wallpaper**. Please remember that **Maps** consumes the battery relatively quickly. Even if you select wallpaper other than Maps, it is recommended that you save the battery consumption by tapping **Force stop** (Press , tap **Settings > Applications > Manage applications > Maps**).

## Deleting a shortcut or a widget from the home screen



1. Press and hold a shortcut or widget you want to delete.
2. Drag it to the trash bin  on the bottom of the screen and release it.






## Changing the theme of the home screen

1. Press  in idle mode and tap **Themes**. The User theme (Unsaved) is selected by default.
2. Select and tap a theme for the home screen among contextual themes and tap **Done**.
3. Tap **Yes** in the saving theme screen, enter the name of the user theme and tap **Done**. The home screen appears under the new name.

## Deleting the user theme from home screen

1. Press  in idle mode and tap **Themes**.
2. Select and tap one of the user themes on the top of the screen.
3. Press  and tap **Delete**.
4. Tap the trash bin next to the user theme to delete and tap **Done**.

## Changing the order of screens

1. Press and hold  in idle mode.
2. Press and hold a screen and drag it to the new position.
3. Tap a screen or press  or  if you want to go back to the home screen.

## Adding a shortcut for the function key


1. Press **FUNCTION** and tap **Add/Delete**.
2. Select and tap an application to add for the function key, and tap **Done**. Applications that you have selected appear. Tap an application if you want to run it.

## Deleting a shortcut from the function key

1. Press **FUNCTION** and tap **Add/Delete**.
2. Tap and deselect an application to delete from the function key, and tap **Done**.

## Checking Easy Settings and Notifications

Easy Settings help manage a few important functions easily and check ongoing events.

1. Tap on the top of the home screen and drag it down, or press  in idle mode and tap **Notifications**.
2. Tap an icon in Easy Setting that you want to run. The icon turns orange when the function is on.
3. Tap an ongoing event message if you want to run the relevant application.
4. Tap **Clear** if you want to remove notifications in the bar.






Opening Easy Setting






Checking Notifications


## Viewing Applications

1. Tap  in idle mode.
2. Press  and tap **List View** if you want to see applications in the order of alphabet. In the list view, press  and tap **Grid View** if you want to see applications at a glance.


## Rearranging Applications

1. Tap  in idle mode.
2. Press  and tap **Rearrange** while in the Grid View.
3. Press and hold an application and drag it to its new location and tap **Done**. If you want to undo your changes, tap **Cancel** or press  and tap **Reset**.

## Selecting the language

1. Press , tap **Settings** > **Language & keyboard** > **Select language**.
  2. Select and tap a language that you want to use for Crossover.
- ① **Note** It is recommended to set the language option first before using other functions.

## Managing Applications

1. Tap  in idle mode.
2. Tap **Manage apps**.
3. Select and tap an application to manage.

# 2

## Communication

- Calling
- Messaging
- Receiving and sending emails
- Using Gmail
- Using Twitter
- Using Facebook
- Using the Social Net widget
- S-Board
- Google Talk





**PANTECH**  
CROSS)OVER™



# Communication


## Calling

### Making a call


1. Tap .
2. Enter the area code and the phone number. Tap  to delete the previous number. Press and hold  to delete the whole number.
3. Tap .

### Answering and ending a call

1. Drag **Answer** to the right to answer the call.
2. Tap **End** to end a call during the conversation. After ending a call, its summary is shortly displayed.



### Adjusting the volume

1. Press the volume key **+** to increase the volume during a call. Press the volume key **-** to decrease the volume during a call.
- ① **Note** Press the volume key in idle mode if you want to adjust the ringer volume. If you want to set it to the vibration mode, press the volume key all the way down until the mode  appears.

### Holding and unholding a call


1. Tap **Hold** during a call. The party will hear nothing.
2. Tap **Unhold** to resume the call.
3. Tap **End** to finish the call.



### Swapping a call for a multiparty call

1. Tap **Add call** during a call. The first party will hear a waiting sound.
2. Tap **Swap** to change the calling party.
3. Tap **End** to finish the call.

### Making a conference call

1. Tap .
2. Enter the area code and the phone number.
3. Tap **Add call** to invite a third party to the call.
4. Tap **Merge calls** to let all the parties to participate in the conversation.






## Checking your voice mail

1. Tap .
2. Press and hold **1** on the keypad.

① **Note** The screen moves to the voice mail contact editing screen if the number has not been designated for the voice mail.



## Making a call from the Address Book

1. Tap .
2. Tap **Contacts**, select and tap a contact to call.
3. Tap **Call home**, **Call mobile** or **Call work** according to your preferences.



## Making an emergency call

1. Tap **Emergency call** when the screen is locked.
2. Dial 911 or other numbers for emergency calls.

## Checking missed calls



1. Tap .
2. Tap **Call log** and check missed calls.
3. Select and tap a number to call back.
4. Tap  if you want to make a call to the number.

## Checking the call history

1. Tap .
2. Tap **Call log**.
3. Select and tap a contact to see.
4. Tap  if you want to make a call to the contact.

① **Note** The displayed call time is not equal to the call charge.

## Saving a new contact

1. Tap .
2. Enter a telephone number.
3. Press  and tap **Add to contacts**.
4. Tap **Create new contact**.
5. Enter necessary information of the contact and tap **Save**.

## Talking through the speaker

1. Tap **Speaker** during a call. A white bar appears under **Speaker** when the function is on.
2. Tap **Speaker** if you want to stop using the function.


## Talking through the Bluetooth

1. Tap **Bluetooth** during a call. A white bar appears under **Bluetooth** when the function is on.
  2. Tap **Bluetooth** if you want to stop using the function.
- ① **Note** Refer to the relevant manual of the Bluetooth headset for more information.




## Muting the phone


1. Tap **Mute** during a call. A white bar appears under **Mute** when the function is on.
2. Tap **Mute** if you want to turn off the function.

### Adding a call

1. Tap **Add call** to make a call to another party during a call with a party.
  2. Enter the telephone number and tap .
- ① **Note** The current call is held when you make a call with another party.


### Using the Yellow Pages

1. Tap .
2. Tap  > **Local Search**.
3. Tap **Change** and enter the location if you want to change the location.
4. Select and tap a business name that you want to see from each category, or enter a business name and tap .




## Messaging

### Sending a new message

1. Tap **Messaging** from the applications menu.
2. Tap **New message**.
3. Enter the recipient's number. Tap  tap **Contact** or **Group** and tap a contact.
4. Enter a message.
5. Tap **Send**.






① **Note** A failed message remains in the list. If you want to delete it, press and hold the message and tap **Delete**.


### Entering a message using voice

1. Tap **Messaging** from the applications menu.
2. Tap **New Message** and tap in the body of the text.
3. Tap  in the virtual keyboard and speak your message.
4. Tap **Send**.


### Entering a message using the keyboard

Use different keyboard settings for different characters.


1. Tap **Messaging** from the applications menu.
2. Tap **New message** and tap in the body of the text.
3. Tap  to select and enter letters for the message.
  - When  is selected, the next letter entered is capitalized.
  - When  is selected, all letters entered are capitalized.
4. Tap  if you want to enter a number or/and common symbols. Tap  if you want to enter complicated symbols.



Capital letters



Numbers and  
common symbols



Complicated  
symbols


## Creating a message using Swype

1. Tap **Messaging** from the applications menu.
2. Tap **New message** and tap on the empty space for the message.
3. Press and hold in the message field.
4. Tap **Input method > Swype**. It is selected by default.
5. Drag your finger on the screen and enter the message.


① **Note** If you want to change the text input method, press and hold on the screen and tap **Input method > Android keyboard**.

## About Swype


Swype is a fast and easy way to enter a message. For example, drag your finger on the screen keyboard as shown and input "Dear."





## Setting Swype options

1. Press and hold  and tap **Preferences**.
2. Tap **Word suggestion** if you want to see predicted words while you enter a message.
  - Tap **Auto-correction** if you want the entered text to be automatically corrected when you press the space bar.
  - Tap **Show suggested word** if you want to see a suggested word for every text you enter.




## Deleting messages

1. Tap **Messaging** from the applications menu.
2. Press  and tap **Delete**.
3. Select and tap the trash bin next to the conversation(s) to remove.
4. Tap **Done**.



## Forwarding messages

1. Tap **Messaging** from the applications menu.
2. Press and hold a message that you want to deliver.
3. Tap  **Forward**.
4. Enter the recipient's number or tap .
5. Enter a message in the message field.
6. Tap **Send**.



## Sending a message using a Quick Text

1. Tap **Messaging** from the applications menu.
2. Press .
3. Tap **Quick text** and select and tap a message.
4. Press .
5. Tap **Send message**.
6. Enter the recipient's number or tap , select and tap a contact.
7. Tap **Send**.



### Adding a Quick Text

1. Tap **Messaging** from the applications menu.
2. Press  and tap **Quick text**.
3. Press  and tap **Add new**.
4. Enter a quick text.
5. Tap **Save**.


### Adding a template

1. Tap **Messaging** from the applications menu.
2. Press  and tap **Templates**.
3. Press  and tap **Add new**.
4. Enter the recipient's number and the message.
5. Tap **Save**.

### Sending a message using a template


1. Tap **Messaging** from the applications menu.
2. Press , tap **Templates** and select a template.
3. Press  and tap **Send message**.
4. Type a message in the message field.
5. Tap **Send**.

### Attaching pictures to a message


1. Tap **Messaging** from the applications menu.
2. Tap **New message**.
3. Enter the recipient's number.
4. Type a message in the message field.
5. Press  and tap **Attach > Picture**.

6. Tap **Take a picture, Gallery, Sketch Pad** or **Handy Memo (Drawing)**.
7. Select and tap a picture to attach.
8. Tap **Send**.


### Attaching locations

1. Tap **Messaging** from the applications menu.
2. Tap **New message**.
3. Enter the recipient's number.
4. Enter a message in the message field.
5. Press  and tap **Attach > Location**.
6. Tap either **Searching for GPS signal** or **Find on map**.
7. Place the indicator on the map and tap **Done**.
8. Tap either **Address** or **Google Maps Web link**.
9. Tap **Send**.


### Setting storage limits

1. Tap **Messaging** from the applications menu.
  2. Press  and tap **Settings > Delete old messages** if you want old messages to be deleted when the storage limit is reached.
  3. Tap **Text message limit**, set the maximum number of messages and tap **Set**.
  4. Tap **Multimedia message limit**, set the maximum number of messages and tap **Set**. Make sure to delete old messages before setting the maximum number of messages.
- ① **Note** Make sure to secure enough internal memory space: you might experience difficulties receiving or sending messages when the memory space is low.



## Setting a signature

1. Tap **Messaging** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Edit signature**.
4. Enter a signature and tap **Save**.
5. Tap **Signature auto-append** if you want to add your signature automatically, and tap either **Manual/off** or **Append on Compose** and tap **OK**.

## Checking used space

1. Tap **Messaging** from the applications menu.
2. Press  and tap **More**.
3. Tap **Used space**. You can see the number of the messages that you have saved. Used space only appears as a menu option if you have saved messages.


## Searching messages

1. Tap **Messaging** from the applications menu.
2. Press  and tap **More**.
3. Tap **Search**.
4. Enter a word to search for in messages and tap .


## Viewing received messages

1. Tap **Messaging** from the applications menu.
2. Select and tap a message to read. Unread messages are displayed in bold fonts.


## Replying to a received message

1. Tap **Messaging** from the applications menu.
2. Select a message to reply to.
3. Press  and tap **Reply**.
4. Enter a message.
5. Tap **Send**.


## Text message settings

1. Tap **Messaging** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Manage SIM card messages** if you want to manage messages that are stored in the SIM card.

## Multimedia message settings

1. Tap **Messaging** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Auto-retrieve** if you want to retrieve messages automatically. It is selected by default.
4. Tap **Extra settings** and adjust settings as you prefer.

## Setting notifications

1. Tap **Messaging** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Notifications** if you want to see in the status bar when a message is delivered. It is selected by default.
4. Tap **Select ringtone** and select and tap a ringtone for incoming messages, and tap **OK**.
5. Tap **Vibrate** and tap **Always**, **Only when silent** or **Never**, and tap **OK**.



# Receiving and sending emails

## Setting up an email account

1. Tap **Email** from the applications menu.
2. Enter your email address and password for the first use.
3. Tap either **Manual setup** or **Next**.
  - If you tap **Manual setup**, tap **POP3**, **IMAP** or **Exchange**, set the necessary options and tap **Next**.
4. Give a name for the account.
5. Give your name that will be displayed on the outgoing messages.
6. Tap **Done**.

① **Note** The screen varies depending on the email service provider.


## Adding a new email account

1. Tap **Email** from the applications menu.
2. Press  and tap **More > Accounts**.
3. Press  and tap **Add account**.
4. Follow the steps to set up an email account.


## Viewing incoming messages

1. Tap **Email** from the applications menu.
  2. Select and tap an account, and tap a message you want to check.
- ① **Note** Make sure to secure enough internal memory space: you might experience difficulties receiving or sending emails when the memory space is low.


## Sending an email

1. Tap **Email** from the applications menu.
2. Tap **Compose mail**.
  - ① **Note** If you have added more than two email accounts, the first one is designated as the primary account for sending an email.
3. Enter the recipient's email address, or tap  and select and tap the contact.
4. Enter the subject of the email and the message.
5. Tap **Send**.


## Adding attachments to an email

1. Press  in the composed message and tap **Attach**.
2. Tap an item you want to attach among **Pictures**, **Videos**, **Audio**, **vCard**, **vCalendar**, **Documents**, and **Location**.
3. Tap **Send** when you are finished.


## Designating emails as favorites

1. Tap **Email** from the applications menu.
2. In the Inbox screen, press  and tap **Star**.
3. Select and tap the message and tap **Done**. A red star icon appears next to the message.


## Marking emails as read

1. Tap **Email** from the applications menu.
2. Press  and tap **Read/Unread** in the Inbox screen.
3. Select and tap the message to display it as read.
4. Tap **Read**. The title of the message is displayed in regular type.

## Removing the email account

1. Tap **Email** from the applications menu.
2. Press  and tap **More > Accounts** in the Inbox screen.
3. Press and hold the account that you want to remove.
4. Tap **Remove account > OK**.

## Email settings

1. Tap **Email** from the applications menu.
2. Tap an account.
3. Press  and tap **More > Account settings**.
4. Tap **Inbox check frequency**, set the time interval to check email and tap **OK**.
5. Tap **Default account** if you want to set the email account as the basic account by default.

## Using Gmail


### Adding a Gmail account

1. Tap **Gmail** from the applications menu.
  2. Tap **Next**.
  3. Tap **Sign in** if you have a Gmail account.
  4. Enter your user name and password.
  5. Tap **Sign in**.
- ① **Note** For more information on adding a Gmail account, refer to Creating a Gmail account on page 17.




## Reading incoming messages

1. Tap **Gmail** from the applications menu.
2. Select and tap the message to read.
3. Tap **Archive** if you want to preserve the message in a separate folder.
4. Tap **Delete** if you want to delete the message.


① **Note** You can read messages by label. Press  in the Inbox screen and tap **Go to labels**.




## Sending an email through Gmail

1. Tap **Gmail** from the applications menu.
2. Press  and tap **Compose**.
3. Enter the recipient's email address, the subject and the message.
4. Tap  or press  and tap **Send**.

## Designating emails as spam

1. Tap **Gmail** from the applications menu.
2. Select and tap an email.
3. Press  and tap **More**.
4. Tap **Report spam** if you want to report the email and put it away from your inbox.

### Setting Gmail options




1. Tap **Gmail** from the applications menu.
2. Press  and tap **More > Settings > General preferences**.
3. Adjust the following setting options.
  - **Message Actions**: Sets to show message actions outside of a message's header among **Always show**, **Only show in portrait**, and **Don't show**.
  - **Clear search history**: Removes all the search history.
  - **Clear "Show pictures"**: Restores the default setting for all senders in order not to show pictures on a mail automatically.

## Using Twitter


### Joining in Twitter

1. Tap **Twitter** from the applications menu.
2. Tap **Sign In**, enter Username or email address and password, and tap **Sign In** again. If you do not have an account, tap **Sign Up** and follow the necessary steps.

### Posting Tweet


1. Tap **Twitter** from the applications menu.
2. Tap  on the top of the screen.
3. Enter a message in the box.
4. Tap , and select and tap a picture from your gallery if you want to attach a picture for the message. You can take a photo right away by tapping  and running the camera.
5. Tap **Tweet**.

### Sending messages


1. Tap **Twitter** from the applications menu.
2. Tap  on the top of the screen.
3. Enter a message in the box.
4. Tap **@**.
5. Tap the check box next to the recipient you want to send to and tap **OK**.
6. Tap **Tweet**.




## Searching Tweets or people

1. Tap **Twitter** from the applications menu.
2. Tap **Connect** > **Enter @ name or full name**.
3. Type the keyword in the box and tap . You can also tap one of keywords that appear below the box.

## Adjusting settings for sync

1. Tap **Twitter** from the applications menu.
2. Press  and tap **Settings**.
3. Tap your account.
4. Tap **Sync data** if you want to synchronize data about the people you are following to Contacts of Crossover.
5. Tap **Sync interval**, select and tap the time for refreshing Tweets.

## Adjusting settings for notifications

1. Tap **Twitter** from the applications menu.
2. Press  and tap **Settings**.
3. Tap your account and adjust the following setting options.
  - **Vibrate**: Sets the vibrate mode for an incoming notification.
  - **Ringtone**: Assigns a ringtone for notifications.
  - **Notification light**: Sets to pulse light for notifications.

## Using Facebook




### Accessing Facebook

1. Tap **Facebook** from the applications menu.
2. Enter your email address and password. If you don't have the account, tap **Sign Up for Facebook** and follow the necessary steps.
3. Tap **Login**.
4. Select and tap an option for syncing and tap **Done** to complete the process.



### Posting messages

1. Tap **Facebook** from the applications menu.
2. Tap **Status** on the top left side of the screen and enter your message, and tap **Post**.

### Sending messages


1. Tap **Facebook** from the applications menu.
2. Tap  and tap **Messages**.
3. Tap .
4. Enter the recipient's name, or tap , select and tap the check box next to the recipient you want and tap **Done**.
5. Enter the subject and contents of the message.
6. Tap **Send**.

### Adjusting settings

1. Tap **Facebook** from the applications menu.
2. Press  and tap **Settings**. If there are new feeds, press  first.
3. Tap **Refresh interval** and set the frequency for refreshing.
4. Tap **Messages** if you want to see when a new message arrives. The check box is selected by default.
5. Tap **Friend requests** if you want to see when a friend wants to add you on Facebook. The check box is selected by default.

### Using the Social Net widget

1. Press and hold an empty space on the home screen.
2. Tap **Widgets**.
3. Tap **Pantech Widgets > Social Net**.
4. Select and tap a style.
5. Tap the widget on the screen and log in to Twitter, Facebook or MySpace. When updated, the relevant icon changes color.




### About the Social Net widget

The Social Net widget helps use the social networking services easily. Check updates in Twitter, MySpace or Facebook at a glance and post your messages.



## S-Board

Form a group with your friends through S-Board and share contents and logs that you have created using Crossover. You can use S-Board in the landscape mode only.



### Forming a group

1. Tap **S-Board** from the applications menu. The screen changes to landscape mode by default.
2. Tap **Create New**.
3. Tap **Add Photo**, select and tap a picture from the Gallery.
4. Enter the name of the group.
5. Enter the name or phone number of a member that you want to add to the group. You can also add by tapping  selecting and tapping a contact, and tapping **Done**.
6. Tap **Next** on the top of the screen.
7. Enter a message in the empty space and tap **Done**.
8. Tap **Send**.


### Editing a group

1. Tap **S-Board** from the applications menu.
2. Press  and tap **Edit group**.
3. Tap **Photo**, select and tap a picture from the Gallery.
4. Change the name of the group.
5. Tap  if you want to set the group as your favorite. The icon turns orange when it is selected.
6. Tap **Done**.


## Adding members to a group

1. Tap **S-Board** from the applications menu.
2. Press  and tap **Add members**.
3. Enter the name or phone number of a member to add to the group. You can also add by tapping  selecting and tapping a contact, and tapping **Done**.
4. Tap **Next** on the top of the screen.
5. Enter a message in the empty space and tap **Send**.

## Deleting members from a group

1. Tap **S-Board** from the applications menu.
2. Press  and tap **Delete members**.
3. Select and tap a member you want to remove.
4. Tap **Next** on the top of the screen.
5. Enter a message in the empty space and tap **Send**.


## Deleting a group

1. Tap **S-Board** from the applications menu.
2. Press  and tap **Delete group**.
3. Tap **Yes**.
4. Enter a message in the empty space and tap **Send**.

## Sharing media

1. Tap **S-Board** from the applications menu.
2. Tap **Contents** on the top left of the screen.
3. Tap a content icon.
4. Select content from a corresponding application.
5. Move the attached icon.
6. Resize the icon if it is resizable.
7. Tap **Share**.

## Deleting logs


1. Tap **S-Board** from the applications menu.
2. Tap **Logs**.
3. Press  and tap **Delete Logs**.
4. Select and tap logs you want to remove.
5. Tap **Done**.

## Google Talk


### Setting your status

1. Tap **Talk** from the applications menu.
2. Tap on the top of the screen where your Gmail address is displayed.
3. Tap the status bar on the top of the screen.
4. Tap **Available**, **Busy** or **Invisible**.




① **Note** The status message will not be displayed if your status is Invisible.

5. Enter the status message.
6. Tap  if you want to insert a photo.
7. Select and tap a picture from your gallery, adjust the size of the picture and tap **Save**.
8. Tap **Done**. Your status is displayed at the top of the screen.


### Inviting a friend to chat

1. Tap **Talk** from the applications menu.
2. Press  and tap **Add friend**.
3. Enter the user name of the friend you want to add.
4. Tap **Send invitation**.


### Chatting with friends

1. Tap **Talk** from the applications menu.
2. Select and tap one of friends that appear on the screen.
3. Enter a message and tap **Send**.
4. Press  and tap **Add to chat** if you want another friend to join the conversation.
5. Press  and tap **More > Insert smiley**, and select and tap one.
6. Press  and tap **End chat** if you want to stop chatting with your friend.

### Managing your friends list

1. Tap **Talk** from the applications menu.
2. Press  and tap **More**.
3. Tap **Invites**. You can check pending invitations.

### Setting the talk environment

1. Tap **Talk** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Automatically sign in** if you want to remain signed-in for Talk.
4. Tap **Mobile indicator** if you want your friends to see that you are on a mobile device.
5. Tap **IM notifications** if you want to see notifications in the status bar when a new IM arrives.

# 3

## Entertainment

Using the camera  
Using the gallery  
Listening to music  
Enjoying YouTube

PANTECH  
CROSS)OVER™





# Entertainment


Crossover offers a variety of tools for entertainment purposes.

## Using the camera


Take pictures and record videos with the built-in camera. They can be saved and sent via multimedia messages.

### Taking pictures

1. Tap **Camera** from the applications menu or press the CAMERA key for a few seconds. The screen changes to landscape mode by default.
2. Tap on the screen and select options if necessary. Option buttons disappear in a few seconds.
3. Focus on the object and tap  or press the CAMERA key. The picture is saved automatically.
4. Tap **Share**, **Set as** or **Delete**, and take the necessary steps.
5. Press the CAMERA key or  if you want to take another picture.





Selecting options





Focusing on the object

① **Note** The screen moves to applications menu if you do not touch the screen or run the camera for two minutes.

### Adding special effects




1. Tap on the screen or press  while in the camera mode.
2. Tap  and select special effects.
3. Tap **Done**.

### Taking pictures using shot modes

1. Tap on the screen or press  while in the camera mode.
2. Tap .
3. Tap **Multi Shot**, **Division Shot**, or **Polaroid**, and take the necessary steps.

① **Note** Various shot modes are available only when the resolution is 640x480.



### Adjusting brightness

1. Tap on the screen or press  while in the camera mode.
2. Tap .
3. Drag  to the left to reduce brightness, or to the right to increase brightness.

### Zooming in/out









1. Tap on the screen or press  while in the camera mode.
2. Tap .
3. Drag  to the left to zoom out, or to the right to zoom in.

### Changing settings


1. Tap on the screen or press  while in the camera mode.
2. Tap .
3. Tap **Resolution** and adjust the resolution from 640x480 to 2048x1536.

4. Tap **Shutter Sound** if you want to make sound when taking a picture. The check box is selected by default.
5. Tap **Focus mode**, and tap **Auto**, **Infinity** or **Macro**.
6. Tap **Store location** if you want to take a picture with geo-information.

### Camera menu options


Icon	Name	Description
	Shutter	Takes a picture
	Function	Adds special effects: White Balance, Filter; and sets timer
	Shot	Selects shot modes: Single Shot, Multi Shot, Polaroid, Division Shot
	Brightness	Adjusts brightness
	Zoom	Zooms the object in or out
	Album	Views saved pictures
	Setting	Changes settings: Resolution, Shutter Sound, Focus mode, Store location
	Video mode	Changes to the camcorder mode

### Sharing pictures


1. Tap on the screen and tap  while in the camera mode, or tap **Gallery** in applications menu.
2. Press and hold a picture to share. If you want to share all pictures, tap **Select All**. You can also select a few pictures.
3. Tap **Share**.
4. Tap **Facebook**, **Bluetooth**, **Twitter**, **Picasa**, **Email**, **Gmail** or

**Messaging**. If you select more than one pictures, **Bluetooth**, **Picasa**, **Email**, **Gmail** and **Messaging** are available.


### Cropping a picture

1. Tap on the screen and tap  while in the camera mode or tap **Gallery** in applications menu.
2. Select and tap a picture to crop.
3. Tap **Menu > More > Crop**.
4. Adjust the size of the picture and tap **Save**.


### Setting a picture as wallpaper

1. Tap on the screen and tap  while in the camera mode or tap **Gallery** in applications menu.
2. Select and tap a picture to set as wallpaper.
3. Tap **Menu > More > Set as > Wallpaper**.
4. Adjust the size of the picture and tap **Save**.

### Assigning a picture to a contact





1. Tap on the screen and tap  while in the camera mode or tap **Gallery** in applications menu.
2. Select and tap a picture to assign to a contact.
3. Tap **Menu > More > Set as > Contact icon**.
4. Select and tap a contact to set the picture for its icon.
5. Adjust the size of the picture and tap **Save**.

### Deleting pictures

1. Tap  while in the camera mode or tap **Gallery** in applications menu.
2. Press and hold a picture to delete. If you want to delete all pictures, tap **Select All**. You can also select a few pictures.

3. Tap **Delete > Confirm Delete**.

## Recording videos

1. Tap **Camcorder** from the applications menu. The screen changes to landscape mode by default.
2. Tap on the screen and select options if necessary. Option buttons disappear in a few seconds.
3. Focus on the object and press . Press  if you want to cancel recording.
4. Tap  to stop recording.
5. Tap **Share**, **Play** or **Delete**, and take the necessary steps.
6. Press the CAMERA key or  if you want to record another video.





Selecting options





Recording a video

① **Note** The screen moves to Applications if you do not touch the screen or run an application for two minutes.



## Recording videos for a certain period of time

1. Tap on the screen while in the camcorder mode.
2. Tap  and tap **Duration**.
3. Select and tap a time duration and tap **Done**.
4. Tap . The video will record for the selected duration.


## Adjusting brightness

1. Tap on the screen while in the camcorder mode.
2. Tap .
3. Drag  to the left to reduce brightness, or to the right to increase brightness.




## Zooming in/out

1. Tap on the screen while in the camcorder mode.
2. Tap .
3. Drag  to the left to zoom out, or to the right to zoom in.





## Changing settings

1. Tap on the screen while in the camcorder mode.
2. Tap .
3. Tap **Resolution** and adjust the resolution from 176x144(MMS) to 800x480.
4. Tap **Video Encoder** and tap **MPEG4** or **H.264** if you want to change the video encoder.
5. Tap **Shutter Sound** if you want to make a sound when taking a video. The check box is selected by default.


## Camcorder menu options

Icon	Name	Description
	Video	Records a video
	Function	Uses functions: White Balance, Filter, Duration
	Brightness	Adjusts brightness



Icon	Name	Description
	Zoom	Zooms the object in or out
	Album	Views saved videos
	Settings	Changes settings: Resolution, Shutter Sound, Video Encoder
	Camera mode	Changes to the camera mode

## Sharing videos

1. Tap on the screen and tap  while in the camcorder mode, or tap **Gallery** in applications menu.
2. Tap on the first video on the screen.
3. Press and hold a video to share. If you want to share all videos, tap **Select All**. You can also select a few videos.
4. Tap **Share**.
5. Tap **Facebook**, **Bluetooth**, **YouTube**, **Email**, **Gmail** or **Messaging**. If you select more than one videos, **Bluetooth**, **YouTube**, **Email**, **Gmail** and **Messaging** are available.




Selecting a video



Sharing a video

## Deleting videos

1. Tap on the screen and tap  while in the camcorder mode or tap **Gallery** in applications menu.
2. Tap on the first video on the screen.
3. Press and hold a video to delete. If you want to delete all videos, tap **Select All**. You can also select a few videos.
4. Tap **Delete** > **Confirm Delete**.


## Using the gallery


### Viewing pictures

1. Tap **Gallery** from the applications menu.
2. Select and tap a picture to view.
3. Tap the image on the screen to zoom in or out. Double-tap on the screen to zoom in to the maximum.
4. Flick the screen to the left or right if you want to see other pictures.


① **Note** Functions of the gallery disappear in a few seconds. Tap on the screen if you want to see functions available.

### Viewing videos

1. Tap **Gallery** from the applications menu.
2. Select a video to view. An item with  is a video.
3. Tap **Movies** or **Video Player** to run the video. You can choose a default application to open videos.
4. Tap on the screen to pause, fast-forward or rewind the video.



Video Player



Movies

## Video Player icons

Icon	Name	Description
	Play	Plays the video
	Pause	Pauses the video
	Fast-forward	Fast-forwards the video
	Rewind	Rewinds the video

## Video Player settings

1. Press while a video is playing through **Video Player**.
2. Tap **Settings**.
3. Tap **Always landscape mode** if you want to see videos in the landscape mode all the time. The check box is selected by default.
4. Tap **Full screen mode** if you want to see videos in the full screen mode all the time.
5. Tap **Sound effect**, select and tap an effect from the 3D sounds and equalizer, and tap **Done**.

## Viewing pictures in a slideshow


1. Tap **Gallery** from the applications menu.
2. Select and tap the pictures that you want to view in a slideshow.
3. Tap **Slideshow**.
4. Tap on the screen if you want to stop the slideshow.
5. Tap on the screen and tap **Slideshow** if you want to resume the slideshow.

## Listening to music

Enjoy music on Crossover. Make sure to insert a microSD card to transfer music to Crossover and listen to it.









## Playing music

1. Tap **Music Player** from the applications menu.
2. Select and tap a file from the list sorted by the alphabetic order. Files that Crossover offers include MP3, AAC, AAC+, eAAC+ and WMA.
3. Tap **Play All** to listen to all files.




- ① **Note** Press and hold the artist name, album title or song if you want to search for related information with **Music**, **Web**, or **YouTube**.


## Music Player icons

Icon	Description
	Pauses and plays a file
	Moves to the next/previous file Fast-forwards or rewinds the file if you press and hold
	Shuffles files (blue); shuffle is off (white)
	Does not repeat the file
	Repeats all files
	Repeats current file only
	Shows the list of files that are being played
	Rates the file

## Adding sound effects

1. Tap **Music Player** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Sound effect**.
4. Select sound effects according to your preferences.
5. Tap **Done**.

## Creating a playlist

1. Tap **Music Player** from the applications menu.
2. Tap **Songs > Playlists**.
3. Tap **Add new playlist** or press  and tap **New Playlist**.
4. Enter the name of the playlist and tap **Done**.


## Adding songs to a playlist

1. Tap **Music Player** from the applications menu.
2. Tap **Songs > Playlists**.
3. Press and hold the playlist you would like to add songs to and tap **Add tracks**.
4. Select and tap the check box next to the song(s) that you want to add to the playlist.
5. Tap **Add**.

## Removing songs from a playlist

1. Tap **Music Player** from the applications menu.
2. Tap **Songs > Playlists** on the top of the screen.
3. Press and hold a playlist and tap **Remove tracks**.
4. Select and tap the trash bin next to the song(s) to remove. You cannot remove a song that is playing.
5. Tap **Done**.

## Music Player Settings

1. Tap **Music Player** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Shuffle** if you want to shuffle the songs in the playlist.
4. Tap **Repeat** and tap **Repeat all**, **Repeat single track** or **Repeat off**.
5. Tap **Shake gesture** if you want to listen to the previous or next track simply by shaking Crossover to the left or right.

## Viewing information

1. Tap **Music Player** from the applications menu.
2. Press and hold a file to see information.
3. Tap **Properties**.
4. Scroll up or down to view information.

## Sorting files by type

1. Tap **Music Player** from the applications menu.
2. Tap **Songs** on the top of the screen and select the option you would like to sort by. **Songs** is set up by default.

## Rating a file

1. Tap **Music Player** from the applications menu.
2. Select and tap a file to rate.
3. Tap ★★ while the file is playing and rate from one to five stars.

## Deleting files

1. Tap **Music Player** from the applications menu.
2. Press ≡ and tap **Delete**.
3. Tap 🗑️ on the file to delete. When selected, the icon turns green.
4. Tap **Done**.

## Enjoying YouTube

### Watching videos

1. Tap **YouTube** from the applications menu.
2. Select and tap a video to watch.
3. Double-tap the screen to watch the video in full screen.



### Uploading videos

1. Tap **YouTube** from the applications menu.
2. Press ≡ and tap **Upload**.
3. Select and tap a video to upload.
4. Set a title for the video and tap **Upload**.


### Creating a YouTube account

1. Tap **YouTube** from the applications menu.
2. Press ≡ and tap **My Channel > Add account**.
3. Tap **Next** and follow the next steps to create an account.


### Sharing videos

1. Tap **YouTube** from the applications menu.
2. Select and tap a video to share.
3. Tap 📲 on the top of the screen.
4. Tap **Bluetooth, Email, Facebook, Gmail, Messaging** or **Twitter**. Channels might vary depending on the video type.

## Viewing my account information

1. Tap **YouTube** from the applications menu.
2. Press  and tap **My Channel**.
3. Tap your Google account. You can tap **Add account** and add an account for YouTube.
4. Tap each item for your account including **Uploads**, **Playlists** and **Subscriptions**.

## YouTube Settings

1. Tap **YouTube** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **High quality on mobile** if you want to watch high-quality videos.
4. Tap **Caption font size** and select and tap the font size if you want to adjust the size of the font.
5. Tap **Uploads** if you want to set your network preference for upload.
6. Tap **Clear search history** if you want to remove search history from the search box and tap **OK**.
7. Tap **SafeSearch filtering** if you want to block videos that contain restricted content, and select and tap the filtering option.

# 4

## Personal Information

Managing contacts  
Using the calendar  
Creating a memo  
Using voice memo

PANTECH  
CROSS)OVER™



# Personal Information

---




This chapter explains how to manage contacts and to communicate via memos.

## Managing contacts

### Viewing contacts information

1. Tap **Contacts** from the applications menu.
2. Select and tap a contact for more information.

### Creating contacts

1. Tap **Contacts** from the applications menu.
  2. Press  and tap **New contact**.
  3. Enter related information and tap **Save**.
- ① **Note** You can create a contact by entering the telephone number first. Tap  enter a telephone number, press  and tap **Add to contacts > Create new contact**.


### Editing contacts

1. Tap **Contacts** from the applications menu.
2. Press and hold a contact to edit, and tap **Edit**.
3. Edit information and tap **Save**.


### Deleting contacts

1. Tap **Contacts** from the applications menu.
2. Press and hold a contact to delete and tap **Delete**.
3. Tap **Yes**.


## Importing/Exporting contacts information

1. Tap **Contacts** from the applications menu.
2. Press  and tap **More > Import/Export**.
3. Tap **Import contacts**, **Export contacts**, or **Share visible contacts**.
  - Tap **Phone, SIM** or your account if you tapped **Import contacts**.
  - Tap **OK** if you want to export your contact list to the SD card, if you tapped **Export contacts**.
  - Tap **Bluetooth, Email, Gmail** or **Messaging** if you tapped **Share visible contacts**. Follow the next steps to share contacts.
4. Tap **OK**.


## Searching contacts information

1. Tap **Contacts** from the applications menu.
2. Press  and tap **Search**.
3. Enter the name of contact. The search result appears instantly.

## Setting up AT&T Address Book

1. Tap **Contacts** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **AT&T Address Book > OK**. Your contacts are backed up to your AT&T Address Book and changes to contacts are automatically saved.

## Setting display options

1. Tap **Contacts** from the applications menu.
2. Press  and tap **Display options**.

## Personal Information

3. Tap **Only contacts with phones** if you want to see only contacts with phone numbers.
4. Tap **Sort list by** and tap either **First name** or **Last name**.
5. Tap **View contact names as**, and tap **First name first** or **Last name first**.
6. Tap your Google account, select and tap the category for system group.
7. Tap **Done** when you are finished.


## Sharing contact details

1. Tap **Contacts** from the applications menu.
2. Press and hold a contact to share and tap **Share**.
3. Tap **Bluetooth**, **Email**, **Gmail** or **Messaging**.

## Setting contact options

1. Tap **Contacts** from the applications menu.
  2. Press and hold a contact, and tap **Options**.
- ① **Note** For a SIM contact, **Options** is not available.
3. Tap **Ringtone**, select and tap a ringtone for the contact and tap **OK**.
  4. Tap **Incoming calls** if you want to send incoming calls from the contact to voicemail directly.

## Managing accounts and sync

1. Tap **Contacts** from the applications menu.
2. Press  and tap **More > Accounts**.
3. Tap **Background data** to allow applications to retrieve data at any time.

4. Tap **Auto-sync** if you want to sync data automatically.
5. Tap **Add account** if you want to add an account and follow the next steps for creating accounts.


## Adding to favorite contacts

1. Tap **Contacts** from the applications menu.
  2. Press and hold a contact to add to favorites, and tap **Add to favorites**. A orange star appears next to the contact.
- ① **Note** For a SIM contact, **Add to favorites** is not available.
3. Tap **Favorites** on the top of the screen if you want to see added favorite contacts.


## Using the calendar

Manage your schedule with the calendar. Make sure to have a Google account. For details on Google account, refer to page 17.

## Creating an event




1. Tap **Calendar** from the applications menu.
2. Tap a day in the calendar.
3. Press and hold the time that you want to add an event to and tap **New event**.
4. Enter necessary information. Press  and tap **Show extra options** if you need more options.
5. Tap **Done**.

- ① **Note** You can also create an event by pressing  and tapping **More > New event**.





## Viewing the calendar

1. Tap **Calendar** from the applications menu.
2. Tap a day that you want to view events for the day. A blue dot indicates an event for a day.
3. Press  and tap **Week** or **Month** if you want to see events for a weekly or monthly basis.
4. Press  and tap **Today** if you want to view events for today.
5. Press  and tap **Agenda** if you want to see events in the text mode.






Monthly view




Agenda


## Calendar icons


Icon	Description
	Today
	Day with events
	Highlighted day

## Setting reminders

1. Tap **Calendar** from the applications menu.
2. Press  and tap **More > Settings**.
3. Tap **Set alerts & notifications** and select and tap an option if you want to change the notification method.
4. Tap **Select ringtone** if you want to set a specific ringtone for calendar reminders, and select and tap one.

## Editing events

1. Tap **Calendar** from the applications menu.
2. Tap the day that you want to edit events.
3. Press the event that you want to edit.
4. Press  and tap **Edit event**.
5. Edit the details and tap **Done**.



Editing an event


## Creating a memo


Create a memo with your finger, the keypad or your voice. Make sure to insert a microSD card to use the memo.

## Creating a text memo


1. Tap **Handy Memo** from the applications menu.
2. Enter a memo. If there are saved memos, tap **Create new > Text memo**.
3. Tap **Save**.

### Drawing a handy memo

1. Tap **Handy Memo** from the applications menu.
2. Draw a memo with your finger. If there are saved memos, tap **Create new > Hand drawing memo**.
3. Tap  to select effects.
4. Adjust the thickness of the pencil and the eraser.
5. Tap **Save**.



Adding effects

- ① **Note** The screen for entering a text memo appears first if there are no memos saved. Press  and tap **Hand drawing memo** if you want to change the memo type.

### Editing a memo

1. Tap **Handy Memo** from the applications menu.
2. Press and hold a memo to edit and tap **Edit**.
3. Edit the memo and tap **Save**.

### Sharing a memo

1. Tap **Handy Memo** from the applications menu.
2. Press and hold a memo to share, and tap **Share**.
3. Tap **Bluetooth, Facebook, Email, Gmail, Messaging, Picasa, or Twitter**. Channels might vary depending on the memo type.



### Deleting a memo



1. Tap **Handy Memo** from the applications menu.
2. Press and hold a memo to delete, and tap **Delete**.
3. Tap **Yes**.


### Using voice memo

Record a memo using Crossover.


### Recording Voice Memo

1. Tap **Voice Memo** from the applications menu.
2. Tap  to start recording your voice.
3. Tap  to stop recording your voice.

- ① **Note** Once you have recorded a voice memo, the screen to play it appears. Tap  to replay the recorded voice memo. Press  if you want to record a new voice memo.





Ready to record




Recording starts


## Listening to recorded voices

1. Tap **Voice Memo** from the applications menu.
2. Press  and tap **Open**.
3. Select and tap a memo to listen.
4. Tap .


## Sharing a voice memo

1. Tap **Voice Memo** from the applications menu.
2. Press  and tap **Open**.
3. Press and hold a memo to share, and tap **Share**.
4. Tap **Bluetooth**, **Email**, **Gmail** or **Messaging**.

## Setting a memo as a ringtone

1. Tap **Voice Memo** from the applications menu.
2. Press  and tap **Open**.
3. Press and hold a memo to use as a ringtone, and tap **Set as Ringtone**.

## Deleting a voice memo

1. Tap **Voice Memo** from the applications menu.
2. Press  and tap **Open**.
3. Press and hold a memo to delete, and tap **Delete > Yes**.

# 5

## Documents

Viewing documents

PANTECH  
CROSS)OVER™










# Documents

## Viewing documents




Read Microsoft Office documents that are stored in a variety of formats in Crosscover.


### Reading documents

1. Tap **Document Viewer** from the applications menu.
2. Select and tap a folder where you have stored documents.
3. Select and tap a document to read.
4. Tap anywhere on the screen while a document is open.
5. Tap  and tap  to zoom in the document or tap  to zoom out in landscape mode. Drag  downwards or upwards to zoom in or out in portrait mode. You can also zoom in the document by pinching your fingers apart, and zoom out by pinching your fingers together.
6. Tap  if you want to fit the document to width.
7. Tap  if you want to fit the document to height.








## Searching for words in a document

1. Tap **Document Viewer** from the applications menu.
2. Open a document.
3. Press  and tap **Word Search**.
4. Enter a word to search for and tap  in the virtual keyboard.
5. Tap  to see the word that you have searched for in the next sentence or page.
6. Tap **Done** if you want to stop searching for the word.



## Moving to a page in a document

1. Tap **Document Viewer** from the applications menu.
2. Open a document.
3. Tap  to move to the previous page. Tap  to move to the next page.
4. Press  and tap **Go to Page**.
5. Enter the page to go and tap .



### Sharing documents

1. Tap **Document Viewer** from the applications menu.
2. Select and tap a folder where you have stored documents.
3. Press and hold a document to share, and tap **Share**.
4. Tap **Bluetooth, Facebook, Gmail, Messaging, or Twitter**.  
Channels might vary depending on the document type.

### Deleting documents

1. Tap **Document Viewer** from the applications menu.
2. Select and tap a folder where you have stored documents.
3. Press and hold a document to delete, and tap **Delete > Yes**.

### Renaming documents

1. Tap **Document Viewer** from the applications menu.
2. Select and tap a folder where you have stored documents.
3. Press and hold a document to rename, and tap **Rename**.
4. Enter the new name and tap **Save**.

# 6

## Web

Accessing the Internet  
Shopping in the Play Store  
Using Google Maps  
Using Places  
Using Latitude  
Searching with Google  
News & Weather

PANTECH  
CROSSOVER™






# Web

This chapter introduces useful applications that you can use through the Internet. Make sure to connect Crossover to a 3G or Wi-Fi network.


## Accessing the Internet

### Searching for information in the Internet


1. Tap **Web** from the applications menu.
2. Tap on the search box and type the keyword using the virtual keyboard.
3. Tap **Go** or tap  in the virtual keyboard.
4. Pinch two fingers apart on the screen if you want to zoom in the web page. You will not zoom in some web pages to the maximum if they are optimized for mobile devices.
5. Press  and tap **Back** or **Forward** if you want to visit the previous or next web page again.





### Changing the home page

1. Tap **Web** from the applications menu.
2. Press  and tap **More**.
3. Tap **Settings** > **Set home page**.
4. Enter a new URL if you want to change the home page, and tap **OK**.
5. Tap **Use current page** if you want to use the current page as the home page.



### Using voice search

1. Tap **Web** from the applications menu.
2. Tap on the search box and tap  next to the address bar.
3. Speak a keyword as clearly as you can.
4. Select and tap the web page in the search result.

### Refreshing a page

1. Tap  to refresh the page.
2. Tap  to stop refreshing the page.


### Visiting a new page


1. Tap **Web** from the applications menu.
2. Tap the address bar and enter a new URL.
3. Tap  next to the address bar or tap  in the virtual keyboard.

### Opening a new window

1. Tap **Web** from the applications menu.
2. Press  and tap **New window**. Another window appears.

### Managing many windows


1. Tap **Web** from the applications menu.
2. Press  and tap **Windows**.
3. Select and tap a window on the bottom of the screen that you want to see.
4. Tap on the screen. You can see the window in full screen view.






## Adding bookmarks

1. Tap **Web** from the applications menu.
2. Press **≡** and tap **Bookmarks** while you are visiting a web page.
3. Tap **★ Add** on the top of the screen.
4. Enter the name and location of the website and tap **OK**.



Bookmarks



Adding a bookmark

## Viewing browser history

1. Tap **Web** from the applications menu.
2. Press **≡** and tap **Bookmarks**.
3. Tap **Most visited** if you want to see web pages that you visit the most. Tap the star icon next to the website if you want to add it to bookmarks.
4. Tap **History** if you want to see past browsing activity. Press **≡** and tap **Clear history** if you want to delete the browsing history.

## Setting the display options

1. Tap **Web** from the applications menu.
2. Press **≡** and tap **More > Settings**.
3. Tap **Text size**, select and tap your preferred text size.
4. Tap **Default zoom**, select and tap your preferred zoom mode.
5. Tap **Block pop-up windows** if you want to prevent pop-up windows from appearing. The check box is selected by default.

## Setting privacy options


1. Tap **Web** from the applications menu.
2. Press **≡** and tap **More**.
3. Tap **Settings**.
4. Tap **Clear cache > OK** if you want to delete content and database locally cached.
5. Tap **Clear all cookie data > OK** if you want to delete all cookie data.
6. Tap **Clear form data > OK** if you want to delete all form data.

## Shopping in the Play Store

Download useful applications from the Play Store and use them for your purposes.




### Downloading applications

1. Tap **Play Store** from the applications menu.
2. Tap **Yes** and follow the necessary steps for adding a Google account if you do not have a Google account.
3. Tap **Accept** on the Play Store Terms of Service if you are accessing the Play Store for the first time.
4. Flick the screen to the left or right.
5. Select and tap an application.
6. Tap **Install** > **Accept & download** for free applications. Tap the price and follow the necessary steps for paid applications.




Installing an application


### Searching applications

1. Tap **Play Store** from the applications menu.
2. Tap  and enter the name or the keyword of the application that you want to install and tap  or .
3. Select and tap the application and install it.


### Running downloaded applications

1. Tap on the top of the home screen, drag the notifications down.
2. Tap the application that you have downloaded from the Play Store.  indicates that an application is completely downloaded. You can also run the application in the Applications screen.

### Deleting applications from the Play Store

1. Tap **Play Store** from the applications menu.
2. Press  and tap **My Apps**.
3. Select and tap the application to delete.
4. Tap **Uninstall** > **OK**.



### Deleting applications from Settings



1. Press  tap **Settings** from the Home screen.
2. Tap **Applications** > **Manage applications**.
3. Select and tap an application to delete.
4. Tap **Uninstall** > **OK**.
5. Tap **OK**.

## Using Google Maps



Google Maps offers useful information based on your region. Make sure to connect Crossover to a Wi-Fi or 3G network. If you turn on the GPS function, you can obtain more accurate information.

### Finding places

1. Tap **Maps**. You can see your current location on the map.
- ① **Note** Make sure to connect to wireless networks or GPS satellites by tapping **Settings > Location & security** and tapping either **Use wireless networks** or **Use GPS satellites**.
2. Tap on the search box and type the keyword using the virtual keyboard and tap  or .
3. Select and tap the location that you want to see, and check the related information.




### Zooming in and out of the map



1. Tap  to zoom in the map. Or you can place your fingers on the screen and pinch them apart.
2. Tap  to zoom out of the map. Or you can place your fingers on the screen and pinch them together.

① **Note** You can double-tap the screen to zoom in the map.

### Finding directions

1. Tap **Maps** from the applications menu.
2. Press  and tap **Directions**.
3. Enter the name of the place you want to visit.
4. Decide whether you want to go to the end point by car, public transportation or foot.
5. Tap **Get directions**.

### Finding the current location on the map


1. Tap **Maps** from the applications menu.
2. Tap . Your location is indicated as .

## Using Places


### Finding places

1. Tap **Places** from the applications menu.
2. Enter a keyword in the search box, or tap **Restaurants, Cafes, Bars, or Attractions**.
3. Select and tap a place in the search results.
- ① **Note** If you want to sort the result by distance or ratings by customers, tap **Distance**, **Rating**, **Open now**, or **Price**. in the search results.

## Viewing places at a glance

1. Tap **Places** from the applications menu.
2. Select and tap a category.
3. Tap . You can see related places in the map.

## Adding a category for places

1. Tap **Places** from the applications menu.
2. Press  and tap **Add a search**. Then, enter a category to add. The category appears on the screen.


## Adding starred places

1. Tap **Places** from the applications menu.
2. Select and tap a category.
3. Select and tap a place that you want to see.
4. Tap the star icon for each place. When selected, the icon turns yellow.


## Using Latitude

Share your location with your friends or check those of your friends. Make sure to have a Google account to use Latitude.


## Joining Latitude

1. Tap **Latitude** from the applications menu.
2. Tap **OK** for the tip on the updated map.
3. Tap **Allow & Share** if you allow your location to be informed to your friends. The Latitude screen appears shortly where your personal information is displayed.
4. Press  if you want to see your location in the map.

## Adding friends from contacts

1. Tap **Latitude** from the applications menu.
2. Press  and tap **Add friends**.
3. Tap **Select from Contacts**.
4. Select and tap the contact you want to add as your friend and tap **Done**.
- ① **Note** All contacts are displayed by default. If you want to classify contacts, tap **All Contacts** on the top of the screen, and select and tap a category of contacts.
5. Tap **Yes** if you want to send sharing requests.

## Adding friends from email addresses

1. Tap **Latitude** from the applications menu.
2. Press  and tap **Add friends**.
3. Tap **Add via email address**.
4. Enter the email address of your friend and tap **Add friends**.
5. Tap **Yes** if you want to send sharing requests.

## Accepting invitation from friends

1. Tap **Latitude** from the applications menu.
2. Tap **1 new sharing request** on the top of the screen.
3. Tap **Accept and share back**. You can see the location of your friend shortly below.




## Managing friends

1. Tap **Latitude** from the applications menu.
2. Tap one of the friends who are on Stable location section in the screen.
3. Tap **Ping for check in** and select and tap the time interval for refreshing locations.
4. Tap **Sharing options**, and select and tap an option.
5. Tap **Remove this friend** and tap **OK** if you want to remove the friend from Latitude.

## Checking personal settings

1. Tap **Latitude** from the applications menu.
2. Tap your name on the top of the screen. You can see your name, Gmail account and your current location.
3. Tap **Change your photo**, tap either **Take a photo** or **Pick from gallery**, and change your photo.



## Adjusting privacy settings

1. Tap **Latitude** from the applications menu.
2. Press **≡** and tap **Location reporting > Location reporting**.
3. Tap **Detect your location**, **Set your location** or **Do not update your location** for a location reporting. Detect your location is selected by default.
4. Tap **Enable location history** if you want to store your locations in the past and visualize them on the Latitude website.
5. Tap **Sign out of Latitude** if you do not want to use Latitude. If you want to join Latitude again, press **≡** and tap **More > Join Latitude**.

① **Note** For more information on the map, refer to Using Google Maps on page 59.

## Searching with Google

### Searching for information with Google

1. Tap **Google Search**, or press **Q** in idle mode.
2. Enter a keyword in the search box and tap **🔍** or **➔**. You can also tap **🗣️** and say it on the phone.

### Setting search options

1. Tap **Google Search** from the applications menu.
2. Press **☰** and tap **Search settings**.
3. Tap **Google search**.
4. Tap **Show web suggestions** if you want to see suggestions from Google as you search through Google. The check box is selected by default.
5. Tap **Use My Location** if you allow your location to be used for Google search results.

### Selecting items that can be searched

1. Tap **Google Search** from the applications menu.
2. Press **☰** and tap **Search settings**.
3. Tap **Searchable items**.
4. Select and tap items you want to include for the search result.

### Managing search history

1. Tap **Google Search** from the applications menu.
2. Press **☰** and tap **Search settings**.
3. Tap **Google search > Manage search history**.


4. Enter the email address and password for your Google account.
5. Select and tap search history in the list and tap **Remove** if you want to remove the search history.

## News & Weather

News and Weather offers news in various fields and weather information in your region.

### Viewing weather information

1. Tap **News & Weather** from the applications menu. Information on your current region for the moment is provided by default.
2. Tap on the weather information in the middle of the screen if you want to check the weather forecast throughout the day.
3. Tap on the chart and drag the vertical bar on the screen to the left or right if you want to see weather information for a certain time of the day.




Weekly weather forecast




Daily weather forecast

## Selecting weather settings

1. Tap **News & Weather** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Weather settings**.
4. Tap **Use my location** if you want to see information of your region automatically.
5. Tap **Use metric** if you want to change the unit for weather information.


## Changing my location

1. Tap **News & Weather** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Weather settings**.
4. Deselect **Use my location**.
5. Tap **Set location** and enter the name or postal code of a city you want.


## Reading news articles

1. Tap **News & Weather** from the applications menu.
2. Tap **Top Stories** on the top of the screen.
3. Select and tap an article if you want to see the full story.
4. Flick the screen to the left or right if you want to see articles by category.


## Customizing news topics

1. Tap **News & Weather** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **News settings > Select news topics**.
4. Select and tap the topic you want to see. Tap it again if you want to delete the topic.

## Adding news topics

1. Tap **News & Weather** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **News settings > Select news topics**.
4. Tap **Custom topic**, enter the title and tap **OK**. You can see articles related to the title.

## Setting refresh options

1. Tap **News & Weather** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Refresh settings**.
4. Tap **Auto-refresh** if you want to update weather and news automatically. The check box is selected by default.
5. Tap **Refresh interval**, select and tap an interval to refresh.

# 7

## Connectivity

Using a Wi-Fi network  
Connecting to a 3G network  
Using Bluetooth  
Making Crossover a modem

PANTECH  
CROSS)OVER™







# Connectivity

This chapter introduces useful tips on how to connect to the network available that enables applications of Crossover to run.

## Using a Wi-Fi network

### Connecting to a Wi-Fi network



1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Wi-Fi settings**.
3. Tap **Wi-Fi** to activate the technology.
4. Select and tap a network. You should enter the password if the network is secured.  indicates a secured Wi-Fi network.
5. Tap **Connect**. Once the network is remembered, Crossover will automatically connect to it when in range.




Activating Wi-Fi




Connecting to a Wi-Fi network

① **Note** The icon next to each network indicates the strength of the signal. For example,  indicates the signal is poor while  indicates the signal is strong.



### About network notifications

You are informed by default when a Wi-Fi network is available around you. The message  in the status bar indicates a network is available. Tap **Network notification** in the Wi-Fi settings if you do not want to be informed the availability of the network.


### Setting Wi-Fi networks

1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Wi-Fi settings**.
3. Tap **Wi-Fi** to activate the technology.
4. Tap **Automatic connection** if you want Crossover to connect to AT&T Wi-Fi network automatically.
5. Tap **WPS button connection** if you want to establish a new wireless connection using the Wi-Fi Protected Setup (WPS). You should press WPS button on your Wi-Fi access point within two minutes.


### Using the Easy Setting

1. Tap on the top of the home screen and drag it down, or press  in idle mode and tap **Notifications**.
2. Tap  in Easy Setting. The icon turns orange when the function is on.


### Searching for Wi-Fi networks

1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Wi-Fi settings**.
3. Tap **Wi-Fi** to activate the technology. Crossover scans networks automatically every six seconds. The newly found networks appear on the bottom of the list.

### Adding a Wi-Fi network

1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Wi-Fi settings**.
3. Tap **Wi-Fi** to activate the technology.
4. Tap **Add Wi-Fi network**.
5. Enter Network SSID and select the security type among **Open**, **WEP**, **WPA/WPA2 PSK** and **802.1x EAP**. Aside from **Open**, you must enter a password for the network.
6. Tap **Save**.

### Disconnecting to a Wi-Fi network

1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Wi-Fi settings**.
3. Tap the network that is connected to Crossover.
4. Tap **Forget** to disconnect with the network.

① **Note** You can also disconnect to the Wi-Fi network by pressing and holding the network and tapping **Forget network**.

### Connecting to a 3G network

Use 3G (or EDGE if available) to connect Crossover to the Internet and exchange multimedia messages. You will need a data plan to access a 3G network.

3G settings are already preconfigured on Crossover, and it is ready to use 3G services. Please do not change the settings: this may cause services to stop working.

① **Note** Using 3G loads Internet data faster in some cases, but may decrease battery performance. If you are making a lot of phone calls, you may want to turn 3G function off to extend battery performance.


### Using Bluetooth


Bluetooth technology enables wireless connections between electronic devices. Using this technology, you can send images, text, and business cards.

With Bluetooth technology, Crossover provides:


- Connection to hands-free devices.
- Connection to electronic devices.

### Pairing with devices

1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Bluetooth settings**.
3. Tap **Bluetooth** to activate the technology.
4. Tap **Scan for devices**.
5. Select and tap a device from the list.
6. Tap **Pair** to connect to and pair with the device.





Scanning devices




Requesting pairing

## Using the Easy Setting

1. Tap on the top of the home screen and drag it down, or press  in idle mode and tap **Notifications**.
2. Tap  in Easy Setting. The icon turns orange when the function is on.


## Bluetooth settings

1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Bluetooth settings**.
3. Tap **Bluetooth** to activate the technology.
4. Tap **Discoverable** if you want to let other people pair their devices with Crossover. The status lasts for 120 seconds.
5. Tap **Discoverable timeout** if you want to set the time that Crossover will be discovered, tap the timeout and tap **OK**.

## Sharing a picture using Bluetooth

1. Tap **Gallery** from the applications menu.
2. Select and tap a picture to share.
3. Tap **Menu > Share > Bluetooth**.
4. Select and tap a device among those paired with Crossover. The other party will receive a message to accept the file.


## Renaming the device

1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Bluetooth settings**.
3. Tap **Bluetooth** to activate the technology.
4. Tap **Device name** and enter a new name.
5. Tap **OK**.

## Making Crossover a modem


Crossover provides other devices with an Internet connection by becoming a Wi-Fi hotspot.

## Activating the USB Tethering


1. Connect Crossover with an electronic device using the USB cable.
2. Press , tap **Settings** from the Home screen.
3. Tap **Wireless & networks > Tethering & portable hotspot**.
4. Tap **USB tethering** to activate the technology. The electronic device that is connected to Crossover can now access the Internet.

① **Note** You cannot use a few applications that require Internet connection while using the tethering technology.

## Becoming a portable Wi-Fi hotspot

1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Tethering & portable hotspot**.
3. Tap **Portable Wi-Fi hotspot**. Crossover can offer the Internet connection to other devices around you.

## Setting options for portable Wi-Fi hotspot

1. Press , tap **Settings** from the Home screen.
2. Tap **Wireless & networks > Tethering & portable hotspot**.
3. Tap **Portable Wi-Fi hotspot settings > Configure Wi-Fi hotspot**.
4. Enter a name for Network SSID. Tap **Hide SSID** if you want to hide the SSID.

5. Tap **WPA2(AES)**, **WPA(TKIP)**, **WPA/WPA2 mixed**, or **Open** for Security and enter password if you want to allow limited devices to access the Internet through Crossover, and tap **Save**.



Selecting security options



Wi-Fi hotspot for Open

# 8

## Storage

Managing the memory card  
Connecting to a PC  
Using Crossover as Mass Storage  
Transferring files through Media  
Transfer

PANTECH  
CROSS)OVER™




# Storage

The microSD card offers useful functions including mass storage and media file transfer.


## Managing the memory card

You should manage the microSD card carefully. If you do not follow the steps described below to manage the memory card, you can incur serious damage to the card.


### Viewing available memory

1. Press , tap **Settings** from the Home screen.
2. Tap **Storage**.
3. Flick the screen and check the status of the SD card and internal phone storage.

### Unmounting the SD Card

1. Press , tap **Settings** from the Home screen.
  2. Tap **Storage > Unmount SD card > OK**.
  3. Press and hold the LOCK/PWR key.
  4. Tap **Power off > OK**.
  5. Open the battery cover.
  6. Remove the battery.
  7. Remove the SD card.
- ① **Note** If you want to mount the SD card, tap **Storage > Mount SD card**.


### Formatting the microSD card

1. Press , tap **Settings** from the Home screen.
2. Tap **Storage > Unmount SD card > OK**.
3. Tap **Erase SD card > Erase SD Card > Erase everything**.

## Connecting to a PC


Synchronize files and exchange data with a computer using the PC data cable. Keep in mind that you cannot transfer media files if you turn on the USB debugging mode (**Settings > Applications > Development > USB debugging > OK**).

### Selecting the USB mode

1. Press , tap **Settings** from the Home screen.
2. Tap **Storage > USB Mode**. If you have turned on the USB debugging function, tap **OK** to turn it off.
3. Select and tap a USB mode.
  - Tap **Media Transfer > OK** if you want to transfer media files between Crossover and your PC when they are connected.
  - Tap **Mass storage > OK** if you want to save mass files in Crossover.
  - Tap **Ask on connection > OK** if you want to select the USB mode whenever Crossover is connected.
4. Connect the USB cable to Crossover.
5. Connect the other end of the cable to your computer.



## Turning on/off the USB mode in the Easy Setting

1. Connect Crossover to your computer using the USB cable.
2. Tap on the top of the home screen and drag it down, or press  in idle mode and tap **Notifications**.
3. Tap **USB connected > Turn on USB storage**. Keep in mind that you can use this function only when you have selected the USB mass storage mode.
4. Tap **OK**.

① **Note** Tap **Turn off USB storage** in the notifications screen if you want to turn off the function, and tap **Turn off USB storage**.




## Transferring files through Media Transfer

Transfer media files between your computer and the microSD card in Crossover. Once you have turned on the MTP connection, media files are collected through Windows Media Player™.

### Transferring files

1. Set the USB mode for Media Transfer.
2. Select files to transfer from Crossover or your PC.
3. Transfer files to your PC or Crossover.



## Using Crossover as Mass Storage

Copy files between your computer and the microSD card in Crossover. In the mass storage mode, a few applications—Handy Memo, Voice Memo, Sketch Pad, Music Player, Camera, Camcorder, Document Viewer—that need the microSD card will not run.

### Copying files

1. Set the USB mode for mass storage.
2. Select and copy files to transfer from Crossover.
3. Paste files to your PC.

# 9

## Tools

Clock Tools  
Alarm/Clock  
Calculator  
Converter  
Sketch Pad  
Voice Dialer  
Voice Search  
Compass  
Navigation  
Weather  
Stocks  
RSS Reader

PANTECH  
CROSS)OVER™





# Tools


Crossover offers a variety of tools that help you live a convenient life.

## Clock Tools

Clock Tools offers the current time in major cities and time zones around the world. World time is displayed first by default.

### Viewing the world time

1. Tap **Clock Tools** from the applications menu.
2. Tap **Add new city** and enter the name of a city. Type the first letter and you can find the city more easily.
3. Select and tap the city.



### Rearranging the order of cities

1. Tap **Clock Tools** from the applications menu.
2. Press and tap **Rearrange**.
3. Select a city to relocate and drag up or down to rearrange the order.
4. Tap **Done**.

### Deleting a city

1. Tap **Clock Tools** from the applications menu.
2. Press and tap **Delete**.
3. Select and tap the trash icon next to the city to delete.
4. Tap **Done**.

① **Note** You can delete a city by pressing and holding it and tapping **Delete > Yes**.

### Using the timer

1. Tap **Clock Tools** from the applications menu.
2. Tap **Timer**.
3. Press and tap **Set** for setting the time.
4. Set the hour, minute and second and tap **Done**.
5. Tap **Start**.




① **Note** You can reset the time by tapping **Reset** while the timer is running.

### Using the stopwatch

1. Tap **Clock Tools** from the applications menu.
2. Tap **Stopwatch**.
3. Tap **Lap > Lap** on the top of the screen and tap **Start**. This function is used when you want to measure time that takes to run for a certain distance.

4. Tap **Lap** > **Split** on the top of the screen and tap **Start**. This function is used when you want to measure the accumulated time.
5. Tap **Reset** to restart the stopwatch.



Lapping time




Splitting time

## Alarm/Clock


Clock helps set the alarm and see basic information on your region including time and weather. Desk clock is provided by default.

### Adding a new alarm

1. Tap **Alarm/Clock** from the applications menu.
2. Tap **Add alarm**.
3. Enter the hour and the minute and tap **Set**.
4. Adjust settings for alarm and tap **Done**. You will see a green bar under the set alarm.



Desk Clock




Adding an alarm

### Changing an alarm

1. Tap **Alarm/Clock** from the applications menu.
2. Select and tap the alarm time to change.
3. Adjust settings and tap **Done**.


### Deactivating an alarm

1. Tap **Alarm/Clock** from the applications menu.
2. Tap  of the alarm to deactivate. A green bar indicates that the alarm is on. The color disappears when the alarm is turned off.

### Deleting an alarm

1. Tap **Alarm/Clock** from the applications menu.
2. Press and hold the alarm to delete, and tap **Delete alarm**.
3. Tap **OK**.

## Setting an alarm

1. Tap **Alarm/Clock** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Alarm in silent mode** if you want to play the alarm even when Crossover is in silent mode. The check box is selected by default.
4. Tap **Alarm volume** if you want to adjust the volume, set the volume and tap **OK**.
5. Tap **Snooze duration** if you want to adjust the snooze duration, select and tap the duration and tap **OK**.
6. Tap **Side button behavior** if you want to assign an action for the volume key and the camera key to take during an alarm, select and tap the option and tap **OK**.

## Calculator

Perform basic mathematical calculations with the calculator in Crossover.


### Doing calculations

1. Tap **Calculator** from the applications menu.
2. Enter a number and tap a mathematical sign you want to use.
3. Tap **C** to delete a number and hold **C** to delete the whole number.





① **Note** You can calculate numbers up to six decimal places.


## Saving a calculation

1. Tap **Calculator** from the applications menu.
2. Press  during a calculation.
3. Tap **Save** and enter the file name. The date of the day appears on the screen by default.
4. Tap **Done**.

### Editing a saved calculation

1. Tap **Calculator** from the applications menu.
2. Press  and tap **List**.
3. Select and tap a calculation to edit.
4. Tap the result and edit it.
5. Press  and tap **Save**.



### Deleting a calculation

1. Tap **Calculator** from the applications menu.
2. Press  and tap **List**.
3. Press and hold the calculation to delete, and tap **Delete**.
4. Tap **Yes**.

## Converter


Converter helps convert values for length, volume, weight, temperature, area and speed.

### Converting values

1. Tap **Converter** from the applications menu.
2. Select a unit type. Length is selected by default. Change the unit type by tapping  or .

## Tools

3. Tap on the box below the unit type, and apply original value.
4. Select the original unit by dragging the wheel in the middle of the screen.
5. Select a target unit. The changed value promptly appears below.



### Resetting a conversion

1. Tap **Converter** from the applications menu.
2. Press during a conversion and tap **Reset**.


## Sketch Pad

Sketch a drawing and share it with your friends.

### Creating a drawing

1. Tap **Sketch Pad** from the applications menu.
2. Tap **Create new** if there are saved drawings. The sketch board appears first if there are no saved drawings.
3. Sketch a drawing and tap to open options for special effects.

4. Select the size and color of the brush and the size of the eraser.
5. Press and tap **Background** to select an image you want to set as background of the drawing.
6. Tap **Save**.
7. Enter the file name. A file name cannot contain any of the following characters: \ / : \* ? " < > |.
8. Tap **Save**. You can see the saved drawing.



### Sketch Pad icons

Icon	Description
	Sets the size of the brush
	Sets the color of the brush
	Sets the size of the eraser
	Undo the previous drawing
	Redoes the previous drawing
	Moves the canvas

### Deleting a drawing

1. Tap **Sketch Pad** from the applications menu.
2. Press and hold the drawing to delete, and tap **Delete**.
3. Tap **Yes**.

## Editing a drawing

1. Tap **Sketch Pad** from the applications menu.
2. Press and hold the drawing to edit, and tap **Edit**.
3. Edit the drawing and tap **Save**.



## Saving to the Gallery

1. Tap **Sketch Pad** from the applications menu.
2. Press and hold the drawing to save to the gallery, and tap **Save to gallery**.

## Sharing a drawing

1. Tap **Sketch Pad** from the applications menu.
2. Press and hold the drawing to share, and tap **Share**.
3. Tap **Bluetooth**, **Facebook**, **Gmail**, **Messaging**, **Picasa** or **Twitter**.

## Changing the view mode

1. Tap **Sketch Pad** from the applications menu.
2. Press  and tap **Thumbnail view** if you want to see drawings only.
3. Press  and tap **List view**. You can see the file name and file format of the drawings.

## Voice Dialer

Perform functions by speaking on the phone.

### Searching for a contact


1. Tap **Voice Dialer** from the applications menu.
2. Say a contact's name, e.g. Mike, on the mic.
3. Tap on the message or **OK**. For example, if you have said "Mike," **Call Mike on mobile** will appear on the screen.



## Voice Search

Search the Internet by speaking on the phone.

1. Tap **Voice Search** or press and hold **Q**.
2. Say a keyword on the mic.
3. Select and tap the result. Speak again when no matches are found for the keyword.



Voice search




Search results

## Compass

Compass helps you find your location using the speed and the distance of your moving. Turn on the GPS function to use.

### Setting the way point


1. Tap **Compass** from the applications menu.
2. Press  and tap **Search Way Point** or just tap **No Way Point** on the top of the screen.
3. Type the way point name in the box and select and tap the way point. You can see the distance and the direction from the current location.

① **Note** When there is interference on the compass, keep it away from the interfering items or wave Crossover in a figure 8 motion.





### Moving toward the way point


1. Tap **Start** after you set the way point and start moving. The moving track begins to be recorded.
2. Tap **Pause** if you stop recording temporarily. Tap **Resume** if you want to resume recording.
3. Tap **Stop** if you want to end recording.
4. Tap **Yes** if you want to export data. The data is saved in the external memory card.

① **Note** You might experience difficulties using the compass if you are indoors or near metal materials.




### Reviewing the moving track



1. Tap **Compass** from the applications menu.
2. Press  and tap **Map View**.  indicates your current location on the map.
3. Tap **Start**. The marker  on the map starts moving.
4. Tap  and move it up if you want to zoom in the map. Move it down if you want to zoom out the map.



### Creating I'mark


1. Tap **Compass** from the applications menu.
2. Press  and tap **Add to I'mark**.
3. Enter the name, latitude, longitude, proximate range and comment and tap **Save**.

## Deleting I'mark

1. Tap **Compass** from the applications menu.
2. Press  and tap **I'mark list**.
3. Press  and tap **Delete**.
4. Select and tap the I'mark to delete.
5. Tap **Done**.

① **Note** You can delete a I'mark by pressing and holding the I'mark in the list and tapping **Delete**.


## Adding a photo for I'mark

1. Tap **Compass** from the applications menu.
2. Press  and tap **Add photo**.
3. Tap **Take a photo** if you want to take a picture.
4. Tap **Picture** if you want to add a photo from your gallery.

## Navigation


### Searching for the destination by voice


1. Tap **Navigation** from the applications menu.
2. Tap **Speak Destination** and speak your destination toward Crossover.
3. Select and tap a destination in the list when there are many possible destinations.



① **Note** You can also search the destination by typing it or selecting in the contacts.



## Finding directions using Google Maps

1. Tap **Maps** from the applications menu.
2. Press  and tap **Directions**.
3. Enter the name of the end point.
4. Tap a method and tap **Get directions**.
5. Select and tap a place in the results.





① **Note** For more information on Google Maps, refer to Using Google Maps on page 59.


## Setting the end point manually

1. Tap **Maps** from the applications menu.
2. Press  and tap **Directions**.
3. Tap  to the right of End point.
4. Tap **Point on map** if you want to set the end point manually.
5. Tap a point on the map.
6. Tap **Tap to select this point**.
7. Tap a method and tap **Get directions**.

① **Note** You can also set your location following the same process.

## Checking the traffic conditions

1. Press  and tap **Route Info** while Navigation is running.
2. Flick the screen along the suggested route to the destination. Depending on the traffic conditions, the road appears in green (good), yellow (congested) or red (jammed).
3. Tap  and tap the route if you want to set an alternative route.




## Weather

### Adding a new city

1. Tap **Weather** from the applications menu.
2. Tap **Add new city**.
3. Enter the name of the city you want, or flick the screen upwards and tap one. Weather information of the city appears on the list.



### Viewing weather information

1. Tap **Weather** from the applications menu.
2. Select and tap a city in the list you want to see.
3. Flick the screen to the left to see forecasted weather information of the city. Or press  and tap **Forecast**.

4. Tap **Update** to view updated information.






Current weather





Weather forecast


### Changing the temperature unit

1. Tap **Weather** from the applications menu.
2. Press  and tap **Settings**.
3. Tap  or . The temperature changes from Fahrenheit to Celsius or vice versa.

### Rearranging the order of cities

1. Tap **Weather** from the applications menu.
2. Press  and tap **Rearrange**.
3. Select a city and drag  up or down to move the city.
4. Tap **Done**.

### Deleting a city

1. Tap **Weather** from the applications menu.
2. Press  and tap **Delete**.
3. Select and tap the trash icon next to the city to delete.
4. Tap **Done**.



## Stocks

Check the current stock market conditions and establish your investment strategy with Crossover. Stocks is in synch with Google Finance by default.


### Checking the current stock market conditions

1. Tap **Stocks** from the applications menu. You can see the overall stock market conditions for the moment.
  2. Select and tap an index in the list. The fluctuation of the index for one day is displayed by default.
  3. Tap **Prev** or **Next** above the graph in the middle of the screen if you want to adjust the period of the fluctuation.
- ① **Note** You can also change the period by tapping the graph and select and tap one from one day to the maximum when data is available.




Market	
Dow	11,671.88
(INDEXDJX.DJI)	0.3% +34.43
S&P 500	1,274.48
(INDEXSPL.INX)	0.37% +4.73
NASDAQ	2,716.83
(INDEXNASDAQ.DXC)	0.33% +9.53
ShangHai	2,820.69
(SHAS000001)	0.34% +15.21
NIKKEI 225	10,566.87
(INDEXNIKKEI.N225)	0.33% +36.19
Hang Seng Index	23,760.34
(INDEXHANGSENG.HSI)	0.0% +0.00
FTSE 100	6,014.03
(INDEXFTSE.FTSE)	0.31% +17.7
BSE Sensex	19,196.34

The overall market conditions




Detailed information



### Renaming the stock market index

1. Tap **Stocks** from the applications menu.
  2. Press and hold an index to rename and tap **Rename**.
  3. Enter a new name of the index and tap **OK**.
- ① **Note** You can also rename an index by pressing  and tapping **Edit**, selecting and tapping an index to rename.



### Deleting the stock market index


1. Tap **Stocks** from the applications menu.
2. Press and hold an index to delete and tap **Delete**.




- ① **Note** You can also delete an index by pressing  and tapping **Edit**, selecting and tapping  next to an index to delete. The trash bin appears in front of the index. Then, tap the trash bin.

### Adding the stock market index




1. Tap **Stocks** from the applications menu.
2. Press  and tap **Edit**.
3. Tap on the box in the bottom of the screen, enter the name of the index and tap .



### Sharing the stock market information


1. Tap **Stocks** from the applications menu.
2. Select and tap an index to see the relevant information.
3. Press  and tap **Share**.
4. Tap **Bluetooth**, **Facebook**, **Gmail**, **Messaging** or **Twitter**.

### Adjusting the alert




1. Tap **Stocks** from the applications menu.
2. Select and tap an index to receive the alert.
3. Press  and tap **Alert**.
4. Enter the value for Above and tap ; enter the value for Below and tap .



### Setting the alert

1. Tap **Stocks** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Ringtone**, and select and tap a ringtone for the alert and tap **OK**.
4. Tap **Check interval**, and select and tap the refresh period.
5. Tap **Check time**, adjust the time for checking stock market indexes and tap **OK**.


### Writing notes

1. Tap **Stocks** from the applications menu.
2. Select and tap an index to write notes.
3. Press  and tap **Notes**.
4. Tap on the screen and enter a message.
5. Press  if you want to check the notes. Press  again and you can see the note on the bottom of the screen.

### Viewing related news articles

1. Tap **Stocks** from the applications menu.
2. Select and tap an index to see the relevant news.
3. Flick the screen downwards, and select and tap an article to see.

### Adjusting the appearance

1. Tap **Stocks** from the applications menu.
2. Press  and tap **Settings**.
3. Tap **Sort**, and select and tap the sorting order for the stock market indexes.
4. Tap **Default Chart**, and select and tap the refresh period. The comparing period of the graph for each index changes accordingly.



### Adding the Stocks widget

1. Press and hold the empty space of the screen.
2. Tap **Widgets**.
3. Tap **Android Widgets > Stocks**.
4. Select and tap a market in the portfolio list and tap **Save**. You can see the stock market indexes on the home screen.


## RSS Reader

RSS Reader helps check updated news from various sources.


### Creating channels

1. Tap **RSS Reader** from the applications menu.
  2. Tap **All channels > Add Channel**. If you have already subscribed to channels, Tap **RSS Reader > All channels**, and press  and tap **Add channel**.
  3. Tap **URL**, **Google Reader** or **Recommendation**.
    - Tap **URL** and enter the title and URL of the channel, tap **Category**, select the relevant category and tap **Save**. If there is no category you want, tap **Create New** and create a category.
    - Tap **Google Reader**, select and tap a channel, and tap **Add**.
- ① **Note** Make sure to register your Google account first by tapping **RSS Reader**, pressing  and tapping **Settings > Google Account**.
- Tap **Recommendation**, select and tap a category you want to add, and select and tap a channel and tap **Done**.


### Managing categories

1. Tap **RSS Reader** from the applications menu.
2. Tap **Categories**.
3. Press  and tap **Edit category**.
4. Select and tap a category, enter a new name and tap **Save**.
5. Tap **Create New** if you want to make a new category, enter the name of the category and tap **Save**.

### Viewing new feeds

1. Tap **RSS Reader**.
2. Tap **New feeds**.
3. Press  and tap **Update**.
4. Select and tap updated new feeds to read.

### Setting options

1. Tap **RSS Reader**.
2. Press  and tap **Settings**.
3. Tap **Automatic Update**, select the interval of updating feeds and tap **OK**.
4. Tap **Automatic Delete** and select the timing to delete feeds automatically, and tap **OK**.
5. Tap **Limited Update Size**, select the size of updated feeds, and tap **OK**.

# 10


## Settings

Personalize  
Wireless & networks  
Call settings  
Sound  
Display  
Location & security  
Applications  
Accounts & sync  
Privacy  
Storage  
Language & keyboard  
Voice input & output  
Accessibility  
Date & time  
AT&T software update  
About phone  
Resetting Crossover

PANTECH  
CROSS)OVER™




# Settings


This chapter explains how to change the settings of Crossover. Access the settings from Applications or simply do it from the home screen by pressing  and tapping **Settings**.


## Personalize

### Setting and managing home screen themes

1. Press , tap **Settings > Personalize > Themes**.
2. Select a predefined theme or a user saved theme that you want to apply to the home screen.
3. Tap **Done**. The selected theme will be applied to the home screen.


### Setting home wallpaper

1. Press , tap **Settings > Personalize > Home Wallpaper**.
2. Tap **Gallery**, **Live wallpapers** or **Wallpapers**.
3. Select an image you want to use as wallpaper and tap **Save** or **Set wallpaper**.


① **Note** Please remember that Maps consumes the battery relatively quickly. Even if you select wallpaper other than **Maps**, it is recommended that you save the battery consumption by tapping **Force stop** (Press , tap **Settings > Applications > Manage applications > All > Maps**).

## Wireless & networks


### Setting Airplane mode

1. Press , tap **Settings > Wireless & networks > Airplane mode**. If you turn on Airplane mode, Wi-Fi, Bluetooth and GPS functions are turned off at once. However, you can turn on each function for your preference.
2. Tap **Airplane mode** again to reactivate other functions.


### Setting Wi-Fi networks

1. Press , tap **Settings > Wireless & networks**.
2. Tap **Wi-Fi settings** to manage the wireless network. Refer to page 65 for more information.


### Setting Bluetooth

1. Press , tap **Settings > Wireless & networks**.
2. Tap **Bluetooth settings** to manage the wireless technology option. Refer to page 67 for more information.



### Setting Tethering and portable hotspots

1. Press , tap **Settings > Wireless & networks > Tethering & portable hotspot**.
2. Tap **USB tethering** to provide Internet connection to other devices. You should connect Crossover with your other device through the USB cable.
3. Tap **Portable Wi-Fi hotspot** to make Crossover a portable Wi-Fi hotspot. Refer to page "Becoming a portable Wi-Fi hotspot" on page 67 for more information.

### Setting VPN settings


1. Press , tap **Settings > Wireless & networks > VPN settings > Add VPN**.
2. Tap **Add PPTP VPN, Add L2TP VPN, Add L2TP/IPSec PSK VPN** or **Add L2TP/IPSec CRT VPN**.
3. Set up the network by entering necessary information.

### Setting mobile networks



1. Press , tap **Settings > Wireless & networks > Mobile networks**.
  2. Tap **Data Services** to allow access to data over mobile network.
  3. Tap **International Data Roaming** to connect to data services when roaming and tap **OK**.
- ① **Note** You may incur significant roaming charges.
4. Tap **Access Point Names** and tap the point name to edit it. Press  and tap **New APN** if you want to add an APN.
  5. Tap **Network operators** and select a network provider.

## Call settings


### Managing fixed dialing numbers

1. Press , tap **Settings > Call settings > Fixed Dialing Numbers**.
2. Tap **Enable FDN, Change PIN2** or **FDN list**.
3. Enter the necessary information.


### Setting your voicemail

1. Press , tap **Settings > Call settings > Voicemail settings > Voicemail number**.
2. Enter the voicemail number or tap  and select a contact to designate as the voicemail number and tap **OK**.
3. Tap **OK**.


### Setting Auto Redial

1. Press , tap **Settings > Call settings > Auto Redial**.


### Setting TTY mode

1. Press , tap **Settings > Call settings > TTY mode**.
2. Tap **TTY Off, TTY Full, TTY HCO** or **TTY VCO**.
3. Tap **OK**.


### Setting DTMF Tones

1. Press , tap **Settings > Call settings > DTMF Tones**.
2. Tap **Normal** or **Long**.
3. Tap **OK**.


### Setting Caller ID

1. Press , tap **Settings > Call settings > Caller ID**.
2. Tap **Network default, Hide number** or **Show number**.
3. Tap **OK**.

### Setting Call forwarding


1. Press , tap **Settings > Call settings > Call forwarding**.
2. Tap **Always forward, Forward when busy, Forward when unanswered** or **Forward when unreachable**.

## Setting Call waiting


1. Press , tap **Settings > Call settings > Call waiting > Call waiting**.

## Sound


### Setting silent mode


1. Press , tap **Settings > Sound > Silent mode**. All other functions except the media volume and alarms are silenced if you select this option.
2. Tap **Silent mode** again to activate all functions.

### Setting to vibrate


1. Press , tap **Settings > Sound > Vibrate**.
2. Tap **Always, Never, Only in Silent mode** or **Only when not in Silent mode**.
3. Tap **OK**.

### Setting volume


1. Press , tap **Settings > Sound > Volume**. Make sure to deselect **Silent mode**.
2. Adjust the volume for ringtone, media and alarm. Tap **Use Incoming call volume for notifications** if you want to use this function. Otherwise, deselect it and adjust the volume for notifications.
3. Tap **OK**.




## Setting phone ringtone

1. Press , tap **Settings > Sound > Phone ringtone**.
2. Select and tap a ringtone in the list.
3. Tap **OK**.


## Setting notification ringtone

1. Press , tap **Settings > Sound > Notification ringtone**.
2. Select and tap a ringtone for notifications.
3. Tap **OK**.

## Setting feedback options



1. Press , tap **Settings > Sound**.
2. Tap **Audible touch tones** if you want to play tones when using the dial pad. It is selected by default.
3. Tap **Audible selection** if you want to play sound when making selection on the screen.
4. Tap **Screen lock sounds** if you want to play sound when locking and unlocking the screen.
5. Tap **Haptic feedback** if you want Crossover to vibrate when you press soft keys. It is selected by default.

## Setting Sound effect


1. Press , tap **Settings > Sound > NASH Sound Effect**.
2. Select and tap an effect from 3D sounds and equalizers. You can choose the user set.
3. Tap **Done**.

### Display


#### Setting brightness

1. Press , tap **Settings > Display > Brightness**.
2. Drag  to the right to increase the brightness. Drag it to the left to decrease the brightness.
3. Tap **OK**.


#### Setting auto-rotate screen

1. Press , tap **Settings > Display > Auto-rotate screen** if you want to make the screen rotate automatically when you move Crossover horizontally or vertically.

#### Setting animation options


1. Press , tap **Settings > Display > Animation**.
2. Tap **No animations**, **Some animations** or **All animations**.
3. Tap **OK**.

#### Setting screen timeout


1. Press , tap **Settings > Display > Screen timeout**.
2. Select and tap the time interval to turn off the screen.
3. Tap **OK**.


### Location & security

#### Setting my location


1. Press , tap **Settings > Location & security > Use wireless networks**.
2. Tap **Agree** to allow Google's location service to collect anonymous location data.
3. Tap **Use GPS satellites** if you want to find street-level locations.

#### Setting screen lock with a pattern key

1. Press , tap **Settings > Location & security > Set up screen lock > Pattern**.
  2. Read "Securing your phone" page and tap **Next**.
  3. Watch how to set up the pattern and tap **Next**.
- ① **Note** Steps 2–3 appear only when you set up the pattern lock for the first time.
4. Drag your pattern on the screen and tap **Continue**. Make sure to connect the pattern with at least four dots. Tap **Retry** and draw another pattern if you want to set up one.
  5. Tap **Continue**.
  6. Drag the pattern again and tap **Confirm**.



Setting the pattern lock



Unlocking the pattern lock



- ① **Note** If you fail to drag the correct pattern to unlock the screen for five consecutive times, you have to wait for 30 seconds before you can try it again. If you forget your pattern lock, tap **Forgot pattern**, enter your account name and password for Google and create a new pattern lock. However, **Forgot pattern** will not appear if you have no Google account for Crossover.

## Forgot your password for Google account?

If you have forgotten your password for Google account, reset it at the Google website.

1. Open your web browser on your computer and go to <https://www.google.com/accounts/recovery>.
2. Enter the email address or username that you use to sign in to your Google account and click **Submit**.
3. Enter the characters that you see on the screen and click **Continue**.
4. Select an option about recovering your account and click **Continue**.
5. Take necessary steps for each option:
  - Enter the answer for security questions if you have selected **Answer your security question**. This option will not be available if you have signed in to your Google account within last five days.
  - Check your email account you provided when you created your Google Account and follow the instructions if you have selected Email to \*\*\*\*\*@\*\*\*\*.
  - Fill in the form for Google Accounts Help if you have selected **I no longer have access to these**, and click **Submit** on the bottom of the window.


- ① **Note** Do not select **Text message to \*\*\*\*\*30**: You cannot receive a code to reset your password on your mobile phone.

## Setting screen lock with a password

1. Press **≡**, tap **Settings > Location & security > Set up screen lock > Password**.
2. Enter your password and tap **OK**. The password should be at least 4 characters.
3. Enter the password again to confirm.
4. Tap **OK**.



Setting the password lock



Unlocking the password lock


- ① **Note** Press **≡**, tap **Settings > Location & security > Visible passwords** if you want to see passwords as you type.

## Setting screen lock with a PIN


1. Press **≡**, tap **Settings > Location & security > Set up screen lock > PIN**.
2. Enter numbers as PIN and tap **Continue**. The PIN should be at least 4 characters.
3. Enter the numbers again to confirm.
4. Tap **OK**.




Setting PIN



Entering PIN


- ① **Note** Press , tap **Settings > Location & security > Change screen lock** if you do not want to set up an additional process to unlock the screen.

### Setting SIM card lock

1. Press , tap **Settings > Location & security > Set up SIM card lock**.
2. Tap **Lock SIM card** and enter the SIM PIN if you want to require a PIN to use the phone. The check box is selected by default.
3. Tap **Change SIM PIN** and enter the old SIM PIN and a new SIM PIN if you want to change the SIM PIN.




### Setting the credential storage password


1. Press , tap **Settings > Location & security > Set password**.
2. Enter a new password and enter it again to confirm.
3. Tap **OK**.

## Applications


### Setting keyboard shortcuts for applications

1. Press , tap **Settings > Applications > Quick launch**.
2. Select an application for the shortcut.


### Managing applications

1. Press , tap **Settings > Applications > Manage applications > Downloaded**.
2. Tap an application and tap **Force stop** if you want to stop its operation by force. Tap **Uninstall** if you want to uninstall the application.
3. Tap **Running** on the top of the screen and tap an application to manage its operation.


### Viewing running services and applications

1. Press , tap **Settings > Applications > Running services**.
2. Tap a service or an application to stop its operation or to edit its options.
3. Tap **Force stop** if you want to stop its operation.

## Debugging USB


1. Press , tap **Settings > Applications > Development**.
2. Tap **USB debugging** to allow the debug mode when the USB cable is connected.
3. Read and tap **OK** on the USB debugging information page.

## Allowing installation of unknown applications


1. Press , tap **Settings > Applications**.
2. Tap **Unknown sources** to allow non-market applications to be installed on Crossover.

## Accounts & sync


### Managing background data

1. Press , tap **Settings > Accounts & sync**.
2. Tap **Background data** if you want to sync, send and receive data any time.

### Allowing background data to sync automatically


1. Press , tap **Settings > Accounts & sync**.
2. Tap **Auto-sync** if you want to sync data automatically.

### Adding an account


1. Press , tap **Settings > Accounts & sync**.
2. Tap **Add account**.
3. Select and tap an account type, and follow the necessary steps for creating an account.

## Privacy

### Backing up data


1. Press , tap **Settings > Privacy**.
2. Tap **Back up my data** if you want to back up your data.
3. Tap **Automatic restore** if you want to restore backed-up data for an application.

### Resetting Crossover


1. Press , tap **Settings > Privacy**.
2. Tap **Factory data reset** if you want to erase all data from the phone.
3. Tap **Reset phone**.
4. Tap **Erase everything**.

## Storage

### Selecting the USB mode


1. Press , tap **Settings > Storage**.
2. Tap **USB Mode**. If you turn on the USB debugging function, tap **OK** to turn it off.
3. Tap **Media Transfer**, **Mass storage** or **Ask on connection**, tap **OK**, and follow the relevant steps.

### Viewing the status of space


1. Press , tap **Settings > Storage**. The status of space available for Crossover is displayed.
2. Tap **Unmount SD card > OK** if you want to remove the SD card from Crossover safely. Tap **Mount SD card** if you want to mount the card.

## Language & keyboard



### Selecting the language

1. Press , tap **Settings > Language & keyboard > Select language**.
2. Select and tap a language to use for Crossover.


### Setting Swipe

1. Press , tap **Settings > Language & keyboard > Swipe**.
2. Tap **Preferences** and adjust settings as you prefer.
  - Tap **Auto-spacing** if you want space to be entered between words automatically.
  - Tap **Show complete trace** if you want to see the path of every word.
  - Tap **Word suggestion** if you want to see predicted words as you type.
  - Tap **Speed vs. accuracy**, drag the bar to the left or right if you want to adjust the response speed and tap **OK**.


### Setting the Android keyboard

1. Press , tap **Settings > Language & keyboard > Android keyboard**.
2. Tap **Vibrate on keypress** if you want Crossover to vibrate when you press soft keys.
3. Tap **Voice input** if you want to change the method for voice input. Tap **On main keyboard**, **On symbols keyboard** or **Off** and tap **OK**.
4. Tap **Input languages**, select and tap the language for the keyboard and press .



### Setting the Android keyboard word suggestion

1. Press , tap **Settings > Language & keyboard > Android keyboard**.
2. Tap **Quick fixes** if you want to correct commonly typed mistakes. The check box is selected by default.
3. Tap **Show suggestions** if you want to see suggestions while you type. The check box is selected by default.

### Setting the device keyboard

1. Press , tap **Settings > Language & keyboard > Built-in keyboard**.
2. Tap **Auto-replace** if you want to correct mistyped words. The check box is selected by default.
3. Tap **Auto-cap** if you want to capitalize the first letter in a sentence. The check box is selected by default.
4. Tap **Auto-punctuate** if you want to enter “.” automatically by pressing space key twice. The check box is selected by default.


## Managing the user dictionary

1. Press , tap **Settings > Language & keyboard > User dictionary**.
2. Press  and tap **Add**.
3. Enter the name of the dictionary in the box and tap **OK**.


## Voice input & output

Text-to-speech helps listen to a text file by transforming it to a speech file.

### Setting input options


1. Press , tap **Settings > Voice input & output > Voice recognizer settings**.
2. Tap **Language**, select and tap a language that will be used for the input language.
3. Tap **SafeSearch**, and tap **Off**, **Moderate** or **Strict** for filtering input language.
4. Tap **Block offensive words** if you want to hide recognized offensive voice results. The check box is selected by default.

### Setting output options

1. Press , tap **Settings > Voice input & output > Text-to-speech settings**.
2. Tap **Listen to an example** if you want to listen to an example.
3. Tap **Install voice data** that is required for speech synthesis.
4. Select and tap related application from the Play Store and install it. Voice is offered when you finish installing the application.
5. Tap **Always use my settings** when you want make your settings the default settings for Crossover.
6. Tap **Speech rate**, select and tap an option, and tap **OK**.
7. Tap **Language**, select and tap a language, and tap **OK**.


### Accessibility

#### Setting the accessibility option


1. Press , tap **Settings > Accessibility**.
2. Tap **OK** in the No accessibility related applications found screen.
3. Select and tap related application from the Play Store and install it.
4. Tap **Accessibility** when you finish installing the application.
5. Tap **Power button ends call** if you want to end a call by pressing the LOCK/PWR key.

### Date & time


#### Allowing date and time to be set automatically

1. Press , tap **Settings > Date & time**.
  2. Tap **Automatic**.
- ① **Note** Set date, Select time zone and Set time will not work if you tap **Automatic**.


#### Setting the date

1. Press , tap **Settings > Date & time > Set date**.
2. Enter month, day and year for Crossover.
3. Tap **Set**.


#### Setting the time zone

1. Press , tap **Settings > Date & time > Select time zone**.
2. Select and tap a time zone in the list.

### Setting time


1. Press , tap **Settings > Date & time > Set time**.
2. Enter the minute and the hour.
3. Tap **Set**.

### Selecting date format

1. Press , tap **Settings > Date & time > Select date format**.
2. Select a preferred date format.
3. Tap **OK**.


### AT&T software update

#### Checking for AT&T software updates


1. Press , tap **Settings > AT&T software update**.
2. Tap **Check for updates > Continue**.

### About phone


#### Checking the status of the phone

1. Press , tap **Settings > About phone**.
2. Tap **Status** if you want to check the current status of the phone, including battery status, battery level and my phone number.


#### Checking battery use

1. Press , tap **Settings > About phone**.
2. Tap **Battery use** if you want to check how the battery is being used.

## Seeing legal information

1. Press , tap **Settings > About phone**.
2. Tap **Legal information** if you want to see the open source licenses and Google's legal information.

## Learning how to use Crossover

1. Press , tap **Settings > About phone**.
  2. Tap **System tutorial** if you want to see how to use Crossover.
- ① **Note** Make sure to set Swype as the default keyboard. Refer to Language & keyboard for more information on setting Swype.
3. Follow the onscreen instructions.

## Resetting Crossover

Solve repeated problems by resetting Crossover. Make sure to turn off Crossover first to protect information and software in Crossover.

1. Remove the battery cover and battery without turning off Crossover.
2. Insert the battery to Crossover right away.
3. Turn on Crossover.

# Appendix

How to upgrade the Android  
Operating System  
PC Suite  
Troubleshooting checklist  
Specifications  
FCC Hearing-Aid Compatibility  
Regulations for Wireless Devices  
FCC Regulatory Compliance  
Warranty  
Legal notice  
Index

**PANTECH**  
CROSS)OVER™






# Appendix


---

## To update software


You can update your software without visiting the nearest dealer.

1. Press , tap **Settings > AT&T software update**.
  2. Tap **Check for updates** to check whether you need to update the software.
- ① **Note** After downloading the software, the device will ask you whether to update the software now. If you choose to update the software now, it will restart the handset. If you postpone updating the software, you can select between 1 hour, 4 hours or 8 hours in Options. After selecting the updating time, you will be sent back to standby mode. If you go to Software Update while you postpone the process, tap **Continue Update**.

## To view the version of software

1. Press , tap **Settings > About phone**.
2. Scroll down to see the version of software.

## How to upgrade the Android Operating System

1. Press , tap **Settings > About phone** in the Crossover, and check the Android version. If the version starts with 2.2, the OS needs to be upgraded to the latest.
2. Visit [http://pantechusa.com/support/crossover\\_p8000](http://pantechusa.com/support/crossover_p8000) from your PC.
3. Click **VIEW** next to Crossover Upgrade to Gingerbread to upgrade Pantech Crossover to Android Gingerbread OS.

4. Please write your e-mail address to download Android Gingerbread OS on your PC.
5. Unpack the ZIP file "P8000\_Sideload\_Tool\_OS\_upgrade."
6. Install the file, "P8000\_Sideload\_Tool\_OS\_upgrade." If you need further assistance to upgrade OS, please refer to below category which is "How to install."

### ① CAUTION

- Do not disconnect the USB data cable or turn the power off during the update process.
- All data in the Crossover will be deleted when the OS is updated. If you have not backed up your personal data, run the Pantech PC Suite and keep your data in a separate storage.

To locate Pantech technical support in the U.S. & Canada:

Call (800) 962-8622 or send an email to [HandsetHelp@Pantech.com](mailto:HandsetHelp@Pantech.com). Or refer to the tips included in Pantech Crossover OS Upgrade Tool.

### PC Suite

PC suite is a Windows-based program that allows you to easily manage personal data and multimedia files by connecting your phone to a PC. The application can be downloaded at <http://www.pantechusa.com>.

#### System requirements

- Microsoft Windows XP family, Windows7 and Vista
- Minimum 100MB of free disk space
- Interface devices such as USB or Wi-Fi for connection with the phone

#### PC Suite features:

- PC Suite launcher
- Application Management
- Data Backup & Restore
- File Management
- Multimedia Management
- Outlook Sync

### Troubleshooting checklist

**When audio quality is poor:** End a call and try again.

**When the other party cannot hear you speaking:**

Your phone may be set to MUTE. Disable the MUTE function. Or your hand may be covering the microphone.

**When battery life is shorter than usual:**

This may happen when you are in an area with low signal strength. Turn off your phone when it is not in use. Change the battery when battery energy is exhausted.

**When you cannot turn on your phone:**

Make sure your battery is charged. Check to see if your phone works while recharging the battery.

**When you are unable to send a message:**

Either you are not registered to receive an SMS service, or you may be in an area where your network service provider cannot provide such a service.

**When you are unable to make a call:**

Your phone may be set to “fixed dial.” Cancel the “fixed dial” function.

**When you are unable to charge the battery:**

This may be the result of one of the following three cases.

1. Your charger may be out of order. Contact your nearest dealer.
2. You may be attempting to use the phone in an overly hot/cold temperature. Try changing the charging environment.
3. Your battery may have not been connected to the charger properly. Check the connector.

**When you are unable to input data into your Address Book:**

Your Address Book memory may be full. Delete some entries from your Address Book.

**When you are unable to select a certain function:**

You may not have subscribed to that function, or your network service provider may be in an area where such service cannot be provided. Contact your local service provider.

**When you are unable to receive a call:**

Your phone may be set to “Call forwarding”. Cancel the “Call forwarding” function.

## Specifications

### Design

Touch QWERTY Slider

### Displays

262k colors TFT with 3.1" display 320\*480 (HVGA) pixels in resolution

### Melodies

MP3, AAC, AAC+, eAAC+ and WMA

### Camera

#### Integrated 3M CMOS Camera with AF (Auto Focus)

- Resolution up to 2048 x 1536 (3,145,728 pixels)
- Video Encoding up to 24f/s; decoding up to 30f/s
- Photo album and video album

### Dimensions & Weight

- Weight: 148.5g/5.23oz (with battery cell)
- Dimensions: 113 x 58 x 14.35mm (4.45" x 2.28" x 0.56")

### Power Management (Performance)

Battery Type	Capacity	Standby Time	Talk Time
Standard Lithium-Ion (Li-ion)	1500 mAh	250hours	3hours

### Operating Frequency

- GSM/GPRS/EDGE 850/900/1800/1900 MHz, UMTS/HSDPA 850/1900/2100 MHz networks in North America, South America, Europe, Africa, and Asia-Pacific where these networks are supported.
- Automatic band switching

## FCC Hearing-Aid Compatibility Regulations for Wireless Devices

On July 10, 2003, the U.S. Federal Communications Commission (FCC) Report and Order in WT Docket 01-309 modified the exception of wireless phones under the Hearing Aid Compatibility Act of 1988 (HAC Act) to require digital wireless phones be compatible with hearing-aids. The intent of the HAC Act is to ensure reasonable access to telecommunications services for persons with hearing disabilities.

While some wireless phones are used near some hearing devices (hearing aids and cochlear implants), users may detect a buzzing, humming, or whining noise. Some hearing devices are more immune than others to this interference noise, and phones also vary in the amount of interference they generate.

The wireless telephone industry has developed a rating system for wireless phones, to assist hearing device users find phones that may be compatible with their hearing devices. Not all phones have been rated. Phones that are rated have the rating on their boxes or a label located on the boxes.

The ratings are not guarantees. Results will vary depending on the user's hearing device and hearing loss. If your hearing device happens to be vulnerable to interference, you may not be able to use a rated phone successfully. Trying out the phone with your hearing device is the best way to evaluate it for your personal needs.

- **M-Ratings:** Phones rated M3 or M4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. M4 is the better/higher of the two ratings.
- **T-Ratings:** Phones rated T3 or T4 meet FCC requirements and are likely to generate less interference to hearing devices than phones that are not labeled. T4 is the better/higher of the two ratings.

higher of the two ratings.

Hearing devices may also be rated. Your hearing device manufacturer or hearing health professional may help you find this rating. Higher ratings mean that the hearing device is relatively immune to interference noise. The hearing aid and wireless phone rating values are then added together. A sum of 5 is considered acceptable for normal use. A sum of 6 is considered for best use.



In the above example, if a hearing aid meets the M2 level rating and the wireless phone meets the M3 level rating, the sum of the two values equals M5. This is synonymous for T ratings. This should provide the hearing aid user with “normal usage” while using their hearing aid with the particular wireless phone. “Normal usage” in this context is defined as a signal quality that is acceptable for normal operation.

The M mark is intended to be synonymous with the U mark. The T mark is intended to be synonymous with the UT mark. The M and T marks are recommended by the Alliance for Telecommunications Industries Solutions (ATIS). The U and UT marks are referenced in Section 20.19 of the FCC Rules. The HAC rating and measurement procedure are described in the American National Standards Institute (ANSI) C63.19 standard.

To ensure that the Hearing Aid Compatibility rating for your phone is maintained, secondary transmitters such as Bluetooth and WLAN components must be disabled during a call. See page 66 for instructions to disable these components.

## FCC Regulatory Compliance

### FCC Regulatory Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Your mobile device is a low power radio transmitter and receiver. When it is ON, it receives and also sends out radio frequency (RF) signals. In August 1996, the Federal Communications Commission (FCC) adopted RF exposure guidelines with safety levels for mobile devices. Those guidelines are consistent with safety standards previously set by both U.S. and international standards bodies: American National Standard Institute (ANSI), National Council of Radiation Protection and Measurements (NCRP), and International Commission on Non-Ionizing Radiation Protection (ICNRP). Those standards were based on comprehensive and periodic evaluations of the relevant scientific literature. The design of your phone complies with the FCC guidelines and is applicable.

### Statement according to FCC part 15.105

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by

turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## Statement according to FCC part 15.21

Modifications not expressly approved by this company could void the user's authority to operate the equipment.

## RF exposure FCC

For body worn operation, to maintain compliance with FCC RF exposure guidelines, use only accessories that contain no metallic components and provide a separation distance of 20 mm (0.6 inches) to the body. Use of other accessories may violate FCC RF exposure guidelines and should be avoided.

This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter.

## Health and Safety Information FCC

This EUT has been shown to be capable of compliance for localized specific absorption rate (SAR) for uncontrolled environment/general population exposure limits specified in ANSI/IEEE Std. C95.1-1992 and had been tested in accordance with the measurement procedures specified in FCC/OET Bulletin 65 Supplement C (2001) and IEEE Std. 1528-2003 Ministry of Health (Canada), Safety Code 6. The standards include a substantial safety margin designed to assure

the safety of all persons, regardless of age and health. The exposure standard for wireless mobile phones employs a unit of measurement known as the Specific Absorption Rate, or SAR. The SAR limit set by the FCC is 1.6W/kg.\*

\* In the U.S. and Canada, the SAR limit for mobile phones used by the public is 1.6 watts/kg (W/kg) averaged over one gram of tissue. The standard incorporates a substantial margin of safety to give additional protection for the public and to account for any variations in.

\*\* This device contains 1800 MHz GSM functions that are not operational in U.S. Territories; this filing is applicable only for 850 MHz GSM and 1900 MHz PCS operations.

## Warranty

### Protect Your Warranty

Read your Warranty carefully, with the special consideration to paragraph seven of the Limited Warranty for your unit:

"Warranty does not apply to... or to any product or part thereof which has suffered through alteration... mishandling, misuse, neglect or accident."

Many companies are making look alike accessories and in some cases, promoting that their products are equal to or better than the Pantech product. Be careful. Some of these products may not be compatible to use with your Pantech product and may damage the unit or cause it to malfunction.

If service is required on your unit and it is determined that a non-Pantech accessory has created the problem with your unit, the Warranty will not apply. In addition, if the unit has already suffered irreversible damage by the reason of a non-compatible accessory, the Warranty will be voided. To protect your warranty, use only compatible accessories which cannot

damage or interfere with the functioning of your Pantech product.

### 12-Month Limited Warranty

Pantech Wireless, Inc. (the Company) warrants to the original retail purchaser of this Pantech handheld portable cellular telephone, that should this product or any part thereof during normal consumer usage and conditions, be proven defective in material or workmanship that results in product failure within the first twelve (12) months period from the date of purchase, such defect(s) will be repaired or replaced (with new or rebuilt parts) at the Company's option, without charge for parts or labor directly related to the defect(s).

The antenna, keypad, display, rechargeable battery and battery charger, if included, are similarly warranted for twelve (12) months from date of purchase. This Warranty extends only to consumers who purchase the product in the United States or Canada and it is not transferable or assignable.

### This warranty does not apply to:

- (a) Products subjected to abnormal use or conditions, accident, mishandling, neglect, unauthorized alteration, misuse, improper installation or repair or improper storage;
- (b) Products whose mechanical serial number or electronic serial number has been removed, altered or defaced
- (c) Damage from exposure to moisture, humidity, excessive temperatures or extreme environmental conditions;
- (d) Damage resulting from connection to, or use of any accessory or other product not approved or authorized by the Company;
- (e) Defects in appearance, cosmetic, decorative or structural items such as framing and non-operative parts;
- (f) Products damaged from external causes such as fire, flooding, dirt, sand, weather conditions, battery leakage,

blown fuse, theft or improper usage of any electrical source.

The Company disclaims liability for removal or reinstallation of the product, for geographic coverage, for inadequate signal reception by the antenna or for communications range or operation of the cellular system as a whole.

To obtain repairs or replacement within the terms of this Warranty, the product should be delivered with proof of Warranty coverage (e.g. dated bill of sale), the consumer's return address, daytime phone number and/ or fax number and complete description of the problem, transportation prepaid, to the Company by calling the number listed below or to the place of purchase for repair or replacement processing.

To locate Pantech Authorized Service Center, call: (800) 962-8622 or email [HandsetHelp@Pantech.com](mailto:HandsetHelp@Pantech.com). Please have the following information available when you send the phone in for repair:

- A valid original Proof of Purchase
- Return address
- Daytime phone number or fax number
- Model number
- IMEI number (Look for the 15-digit IMEI number behind the battery of the device.)
- Complete description of the problem
- Transportation prepaid

### Other Warranty Program

You may have other warranty program with your purchase, such as warranty exchange. If so, please refer to equipment package or the original point of sale.

- THE EXTENT OF THE COMPANY'S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE

COMPANY'S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY.

ANY ACTION FOR BREACH OF ANY WARRANTY MUST BE BROUGHT WITHIN A PERIOD OF 18 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY SPECIAL CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. THE COMPANY SHALL NOT BE LIABLE FOR THE DELAY IN RENDERING SERVICE UNDER THIS WARRANTY OR LOSS OF USE DURING THE TIME THE PRODUCT IS BEING REPAIRED OR REPLACED.

No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product.

Some states or provinces do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitation or exclusions may not apply to you. This Warranty gives you specific legal rights, and you may also have other rights which vary from state to state or province to province.

For technical support in the U.S. & Canada, call (800) 962-8622. Or email us to [HandsetHelp@Pantech.com](mailto:HandsetHelp@Pantech.com). Or visit the web site at [www.pantechusa.com](http://www.pantechusa.com).

For all other inquiries, write to:

PANTECH WIRELESS, INC. 5607 Glenridge Dr. Suite 500  
Atlanta, GA 30342, USA.

## Legal notice

Bluetooth is a trademark of Bluetooth SIG, Inc. Wi-Fi is a trademark of the Wi-Fi Alliance. Google, YouTube, Picasa, Gmail, Google Maps and Play Store are trademarks of Google, Inc.

### Index

3G 56, 59, 66

#### A

Accessibility 94

Accounts & sync 17, 91

Airplane mode 2, 85

Alarm/Clock 74-75

Applications 13, 16, 18-19, 22, 38-41, 57

Ask on connection 70, 91

AT&T Address Book 16, 47

AT&T software update 94, 97

Auto Redial 86

Automatic 83, 91, 94

Auto-replace 92

#### B

Background data 48, 91

Battery use 94

Bluetooth 19, 25, 66-67, 85, 99, 102

Bookmark 57

Brightness 38-40, 88

#### C

Calculator 75

Calendar 48-49

Call forwarding 86

Call log 25

Call waiting 87

Caller ID 86

Camcorder 39-40, 71

Camera 14, 38-41, 75, 98

Clock Tools 73

Connectivity 65

Contacts 4-5, 17, 25, 47-48, 60

Converter 75-76

#### D

Date format 94

Date & time 94

Display 47, 88, 98

Document Viewer 53, 54, 71

DTMF Tones 86

#### E

Email 17, 30-31

Erase everything 70, 91

#### F

Facebook 33-34

Factory data reset 91

FCC Hearing-Aid Compatibility Regulations for  
Wireless Devices 98

FCC Regulatory Compliance 99

Fixed dialing numbers 86

Force stop 90

FUNCTION 13, 21

#### G

Gallery 20, 32, 34, 39, 41-42, 61, 67, 77

Gmail 17, 31, 32, 35, 61

Google Search 62

GPS satellites 59, 88

#### H

Handy Memo 28, 49-50, 71

Home screen 13, 18-21, 34, 85

#### K

Keyboard 4, 16, 22, 26, 90, 92

#### L

Language & keyboard 22, 92-93, 95

Latitude 60-61

Legal information 95

Legal notice 102

Lithium Ion (Li-Ion) battery 3, 11

Location & security 12, 59, 88-90

Locations 28, 61, 88

LOCK/PWR 4, 12-13, 16, 70, 94



**M**

Maps 16, 20, 28, 59, 61, 79, 85  
Mass Storage 70-71, 91  
Media Transfer 70-71, 91  
Messaging 18, 26-29  
MicroSD card 10, 42, 49, 70-71  
Mobile networks 86  
Modem 67  
Mount SD card 70, 92  
Music Player 42-44

**N**

NASH Sound Effect 87  
Navigation 79  
News & Weather 62-63  
Notifications 21, 29, 33, 58, 65, 71

**P**

Password 12, 17, 30, 31-33, 62, 65-66, 68, 89-90  
Pattern lock 12, 88-89  
PC 14, 70-71, 97  
Personalize 85  
PIN 12, 89-90  
Places 59-60  
Play Store 58, 93  
Playlists 43, 45  
Power button ends call 94

Privacy 57, 61, 91

**Q**

Quick fixes 92

**R**

Reset phone 91  
Ringtone 33, 51, 87  
RSS Reader 83

**S**

Safety information 2, 100  
Safety precautions 2  
S-Board 34-35  
Screen lock 12, 87-89  
Screen timeout 88  
SD card & phone storage 70  
Set date 94  
Setting 28-33, 35, 39, 47  
Shortcuts 13, 18, 20, 90  
Silent mode 75, 87  
SIM card 10, 16, 19, 29, 90  
Sketch Pad 71, 76-77  
Social Net 34  
Sound 14, 24, 38, 42, 87  
Speech rate 93  
Stopwatch 73-74

Swype 27, 92, 95

System tutorial 95

**T**

Talk 35-36  
Tethering & portable hotspot 67, 85  
Text-to-speech 93  
Timer 39, 73  
Time zone 73, 94  
Touch screen 13, 17  
Trash bin 21, 27, 43, 81  
TTY mode 86  
Tutorial 16

**U**

Uninstall 58, 90  
Unmount SD card 70, 92  
USB debugging 70, 90-91  
Use My Location 62-63  
User dictionary 93

**V**

Vibrate 29, 33, 87  
Voice input & output 93  
Voicemail 18, 48, 86  
Voice Memo 50-51, 71  
Voice Search 56, 77

## Appendix

---

Volume 14, 24, 75, 87

VPN 86

### W

Wallpaper 18, 20, 39, 85

Warranty 101-102

Weather 62-63, 74, 80

Web 56-57

Widget 18, 20-21, 34, 82

Wi-Fi 16-18, 56, 59, 65-68, 85, 97, 101

Wireless & networks 2, 65-67, 85-86

World time 73

### Y

YouTube 44-45

### Z

Zoom 17, 38-41, 53, 56-57, 59, 78