

E-TON

PARTS LIST MANUAL




EXL 150

CONTENTS

PARTS ITEM	
01	CRANK CASE, L COVER, SPINDLE ASSY.
02	CRANK SHAFT, PISTON, CYLINDER, TENSIONER
03	OIL PUMP, STARTING MOTOR
04	RIGHT CRANK CASE COVER, GENERATOR
05	COVER HEAD, HEAD, CAM SHAFT, VALVE
06	FAN COVER, SHROUD
07	DRIVEN RULLEY (CVT)
08	TRANSMISSION
09	GEAR SHAFT LEVER, SAFETY SWITCH
10	AIR CLEANER
11	CARBURETOR
12	OIL COOLER
13	ENGINE
14	MUFFLER
15	FRAME
16	FENDER
17	SWING ARM
18	SEAT
19	FUEL TANK
20	SUSPENSION
21	FRONT WHEEL
22	REAR WHEEL
23	FRONT BRAKE SYSTEM
24	REAR BRAKE SYSTEM
25	HANDLE BAR
26	BUMPER, FOOTREST
27	REAR WHEEL AXLE
28	STEERING
29	ELECTRICAL EQUIPMENT
30	PACKING CASE,EXTERNAL
NOTE : Not for sales*表示不售服、Not available N/A表示不適用	

曲軸箱，曲軸箱蓋，腳起動組
曲柄，活塞，汽缸，拉力桿
機油pump，起動馬達
右曲軸箱蓋，發電機
汽缸頭蓋，汽缸頭，凸輪軸，閥門
風扇蓋，引擎罩蓋
CVT驅動皮帶輪
傳動系
變檔桿，安全開關
空氣濾清器
化油器
機油冷卻管組
引擎
排氣管
車架
擋泥板
A 臂
座墊
汽油箱
避震器
前輪
後輪
前煞車系統
後煞車系統
手把
保護桿，置腳踏板
後輪軸
轉向系統
電裝品
包裝外箱


1. CRANK CASE 、 L COVER 、 SPINDLE ASSY



ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
1		CRANK CASE, L COVER, SPINDLE ASSY.								
1-1	A1200-V30-0900	CRANK CASE L	1	左曲軸箱組						
1-2	I6100-62030	BEARING, BALL ,RADIAL	1	NO:013 滾珠軸承						
1-3	I6100-62020	BEARING, BALL ,RADIAL	1	NO:014 滾珠軸承						
1-4	I6100-62043	BEARING, BALL, RADIAL	1	NO:012 滾珠軸承						
1-5	B3411-V30-9000	SHAFT DRIVE(13T)	1	驅動軸						
1-6	I1202-A04-0000	OIL SEAL (20×32×6)	1	油封 (20×32×6)						
1-7	I4510-20000	CIRCLIP EX	1	NO:010 C型扣環						
1-8	I4608-09424	O-RING	1	NO:012 O型環						
1-9	I6150-62000-10	BEARING, BALL, RADIAL	1	NO:035 滾珠軸承						
1-10	A1103-V30-0000	RUBBER BUSH ENGINE	4	懸吊橡膠						
1-11	A8255-V30-0000	BOSS (A)	1	襯套(A)						
1-12	I4301-08140	KNOCK PIN	2	NO:008 定位銷						
1-13	I0032-08208-0H	STUD BOLT (B)	2	NO:005 汽缸螺栓(B)						
1-14	I0031-08200-0H	STUD BOLT (A)	2	NO:007 汽缸螺栓(A)						
1-15	A1100-V30-0900	CRANK CASE COMP RIGHT	1	右曲軸箱組(油冷)						
1-16	I6001-06050-0H	BOLT HEXAGON HEAD	2	NO:005 六角帶頭螺栓						
1-17	I1201-A04-9000	OIL SEAL (19.8×30.5)	1	油封 (19.8×30.5)						
1-18	I4608-10720	O-RING	1	NO:025 O型環						
1-19	I4608-06017	O-RING	2	NO:031 O型環						
1-20	A1207-A14-0001	PLATE CRANK CASE L	1	左曲軸箱板						
1-21	I6001-06020-0H	BOLT HEXAGON HEAD	2	NO:001 六角帶頭螺栓						
1-22	I4104-12120	WASHER	2	NO:049 平墊圈						
1-23	I2800-12015-0C	DRAIN PLUG BOLT	2	NO:002 洩油塞頭螺栓						
1-24	B4305-V30-0000	SCREW FIXING	1	檔位固定螺栓						
1-25	I4104-14210	WASHER	1	NO:057 平墊圈						
1-26	B4306-V30-0000	SPRING FIXED CATCH	1	檔位固定彈簧						
1-27	B4307-V30-0000	BALL BEARING	1	鋼珠						
1-28	A1206-V30-0000	CONNECTER TUBE BREATHER	1	排水管接頭						
1-29	A7232-V30-0000	DRAIN TUBE	1	排水管						
1-30	A1192-A08-0000	GASKET CRANK CASE	1	曲軸箱墊片						


ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
1		CRANK CASE, L COVER, SPINDLE ASSY.								
1-31	I4104-10010	WASHER	1	NO:058 平墊圈						
1-32	C5750-V30-0000	NEUTRAL SWITCH COMP	1	空檔接點開關組						
*1-32-1	C5752-V30-0000	NEUTRAL SWITCH CONNECTER	1	空檔開關接頭						
*1-32-2	I3500-04006	SCREW, CROSS RECESS HEAD	1	圓頭十字螺絲						
*1-32-3	C5751-V30-0000	WIRING COMP	1	接線組						
1-33	I4301-10140	KNOCK PIN	2	NO:009 定位銷						
1-34	A1341-V30-0300	COVER L SIDE	1	左曲軸箱側蓋						
1-35	A1395-V30-0000	GASKET L COVER	1	左曲軸箱側蓋墊片						
1-36	I6001-06040-0C	BOLT, HEXAGON HEAD	7	NO:024 六角帶頭螺栓						
1-37	I6001-06040-0H	BOLT, HEXAGON HEAD	1	NO:004 六角帶頭螺栓						
1-38	B825A-V30-0000	SPINDLE ASSY. KICK STARTER	1	起動軸總成						
1-38-1	B8250-A14-0001	SPINDLE COMP KICK STARTER	1	起動軸組						
1-38-2	B8281-A14-0000	SPG KICK STARTER	1	起動桿彈簧						
1-38-3	B8253-V30-0000	BOSS KICK SPINDLE	1	起動軸襯套						
1-38-4	I4608-13824A	O-RING	1	NO:046 O型環						
1-39	I4104-14520A	WASHER	1	NO:025 平墊圈						
1-40	I4510-14000	CIRCLIP EX 14mm	1	NO:002 C型扣環						
1-41	B823A-A14-0001	GEAR ASSY .STARTER IDLE	1	起動惰輪總成						
*1-41-1	B8230-A14-0001	GEAR COMP KICK DRIVEN	1	起動惰齒輪組						
*1-41-2	B8223-A14-0000	SPG KICK DRIVEN GEAR	1	起動摩擦彈簧						
1-42	I4102-10505	WASHER	1	NO:052 平墊圈						
1-43	B8300-V30-9000	ARM ASSY. KICK STARTER	1	起動桿組						
1-44	I5701-06035-0C	BOLT , HEXAGON HEAD	1	NO:012 六角帶頭螺栓						
1-45	I4104-06515A	WASHER	1	NO:085 平墊圈						
1-46	I6001-06012-0H	BOLT , HEXAGON HEAD	1	NO:030 六角帶頭螺栓						
1-47	A1106-A00-0000	CONNECTER TUBE BREATHER	1	呼吸管接頭						
1-48	A1221-V30-0000	TUBE BREATHER	1	呼吸管						
1-49	A1382-E1A-9000	CLAMPER BRAKE CABLE	1	煞車導線夾						

2. CRANK SHAFT 、 PISTON 、 CYLINDER 、 TENSIONER




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
2		CRANKSHAFT, PISTON, CYLINDER, TENSIONER								
2-1	A3000-V30-0001	CRANK SHAFT COMP	1	曲柄軸組						
2-1-1	I4401-25046	WOOD RUFF KEY	2	NO:001 半圓鍵						
2-2	I4601-15000	CLIP,PISTON PIN 15mm	2	NO:001 活塞銷扣環						
2-3	A3111-A08-0000	PIN,PISTON	1	活塞銷						
2-4	A3101-A08-0000	PISTON	1	活塞						
2-5	A3011-A08-0000	RING SET,PISTON	1	活塞環組						
*2-5-1	A3121-A08-0000	RING PISTON TOP	1	第一活塞環						
*2-5-2	A3131-A08-0000	RING PISTON 2ND	1	第二活塞環						
*2-5-3	A3141-A08-0000	RING PISTON OIL	1	刮油活塞環						
2-6	I4301-10140	PIN DOWEL	2	NO:009 定位銷						
2-7	A2191-A08-0000	GASKET CYLINDER	1	汽缸墊片						
2-8	A2100-A08-0000	CYLINDER COMP	1	汽缸						
2-9	I5801-06012-0C	BOLT, HEXAGON HEAD	1	NO:022 六角帶頭螺栓						
2-10	I4104-06512	WASHER	1	NO:043 平墊圈						
2-11	I4301-06240	KNOCK PIN	1	NO:012 定位銷						
2-12	A4510-A04-0000	GUIDE TENSION CAM CHAIN	1	鏈條張力導板						
2-13	A4610-A04-0000	GUIDE CAM CHAIN	1	鏈條導板						
2-14	A4401-A07-0000	CHAIN CAM	1	凸輪軸驅動鏈條						
2-15	I3700-06005	SCREW, OVAL TAP	1	NO:001 扁圓頭十字螺絲						
2-16	I6001-06020-0H	BOLT, HEXAGON HEAD	2	NO:001 六角帶頭螺栓						
2-17	I4608-09515	O-RING	1	NO:019 O型環						
2-18	A4520-A04-0000	LIFTER ASSY .TENSIONER	1	鏈條調整器組						
2-19	A4523-A04-0000	GASKET TENSIONER LIFTER	1	鏈條調整器墊片						

3. OIL PUMP 、STARING MOTOR




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
3		OIL PUMP, STARTING MOTOR								
3-1	A5100-A07-0000	PUMP ASSY. OIL	1	機油泵總成						
*3-1-1	I3500-03010-0G	SCREW,CROSS RECESS HEAD (3×10)	1	NO:001圓頭十字螺絲3×10						
*3-1-2	A5116-A04-0000	PLATE OIL PUMP	1	機油泵底板						
*3-1-3	A5331-A07-0000	ROTOR OIL PUMP INNER	1	機油泵內轉子						
*3-1-4	A5332-A07-0000	ROTOR OIL PUMP OUTER	1	機油泵外轉子						
*3-1-5	I4303-04065	KNOCK PIN	1	NO:006 定位銷						
*3-1-6	A5101-A07-0000	BODY OIL PUMP	1	機油泵本體						
*3-1-7	A5132-A04-0000	SHAFT OIL PUMP	1	機油泵軸						
3-2	I3600-06030-0H	SCREW, CROSS RECESS HEAD	2	NO:003 平頭十字螺絲						
3-3	A5133-A04-0000	SPROCKET OIL PUMP DRIVEN	1	機油泵被驅動鏈輪						
3-4	I4050-0600G	NUT FLANGE 6 mm	1	凸緣螺帽 6 mm						
3-5	A5141-A04-0000	CHAIN OIL PUMP	1	機油泵驅動鏈條						
3-6	A5711-A04-0000	SEPARATOR OIL	1	分油器						
3-7	I6001-06012-0H	BOLT, HEXAGON HEAD	2	NO:030 六角帶頭螺栓						
3-8	C1200-V30-0000	MOTOR START COMP	1	起動馬達組						
*3-8-1	I1309-24031	O-RING (24.4×3.1)	1	O型環24.4×3.1						
*3-8-2	I3892-04006-08	SCREW WASH (4×6)	2	螺絲附墊圈4×6						
3-8-3	C1221-A04-0000	CARBON BRUSH	2	碳刷						
3-9	I6001-06016-0C	BOLT, HEXAGON HEAD	2	NO:029 六角帶頭螺栓						
3-10	B8102-A04-0000	SHAFT STARTER REDUCTION GEAR	1	起動減速齒輪軸						
3-11	B8101-A04-0000	GEAR STARTER REDUCTION	1	起動減速齒輪						
3-12	I0231-A04-0000	NUT LOCK	1	鎖緊螺帽						
3-13	B812A-A04-0000	OUTER ASSY .STARTING CLUTCH	1	單向傳動器總成						
*3-13-1	B8125-A04-0000	FLANGE STARTING CLUTCH	1	起動離合器凸緣						
*3-13-2	B8124-A04-0000	CAP STARTING CLUTCH ROLLER SPRING	3	滾子彈簧蓋						
*3-13-3	I6220-A0100	ROLLER	3	NO:003 滾筒						
*3-13-4	B8127-A04-0000	SPRING STARTING CLUTCH ROLLER	3	滾子彈簧						
*3-13-5	B8120-A04-0000	BODY COMP CLUTCH OUTER	1	單向傳動器本體組						
*-3-13-6	I0001-06012	BOLT, SOCKET PAN 6×12	3	圓頭承窩螺栓						
*-3-13-7	I4303-05060	KNOCK PIN	1	NO:005 定位銷						
*-3-13-8	I1110-2832168	BEARING, NEEDLE	1	NO:012滾針軸承						
3-14	B8110-A04-0000	GEAR COMP STARTING CLUTCH	1	起動離合器齒輪組						
3-15	I4104-22225	WASHER	1	NO:047 平墊圈						

4. RIGHT CRANK CASE COVER 、 GENERATOR





ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
4		RIGHT CRANK CASE COVER, GENERATOR								
4-1	I4301-08140	KNOCK PIN	2	NO:008 定位銷						
4-2	I1201-A04-9000	OIL SEAL (19.8×30×5)	1	油封(19.8×30×5)						
4-3	A1394-A04-0000	GASKET R CRANK CASE COVER	1	右曲軸箱蓋墊片						
4-4	A1331-V30-0900	COVER R SIDE	1	右曲軸箱側蓋						
4-5	A5650-A04-0000	GAUGE ASSY. OIL LEVEL	1	機油尺組						
*4-5-1	A5651-A04-0000	GAUGE OIL LEVEL	1	機油尺						
*4-5-2	I4608-12625	O-RING (18×3.5)	1	NO:020 O型環						
4-6	A5421-A00-0000	SCREEN,OIL FILTER	1	濾油網						
4-7	A5426-A04-0000	SPRING OIL FILTER SCREEN	1	濾網彈簧						
4-8	A2360-A04-0001	HOLE CAP TAPPET ASSY.	1	調整塞頭組						
*4-8-1	A2361-A04-0000	CAP TAPPET ADJUSTING HOLE	1	調整塞頭						
*4-8-2	I4608-30832	O-RING	1	NO:017 O型環						
4-9	C2961-A04-0000	CLAMPER A.C.G GENERATOR	1	A.C.G線夾						
4-10	I6001-06040-0C	BOLT, HEXAGON HEAD	1	NO:024 六角帶頭螺栓						
4-11	I6001-06110-0C	BOLT , HEXAGON HEAD	1	NO:026 六角帶頭螺栓						
4-12	I6001-06100-0H	BOLT , HEXAGON HEAD	1	NO:010 六角帶頭螺栓						
4-13	I6001-06032-0H	BOLT , HEXAGON HEAD	1	NO:009 六角帶頭螺栓						
4-14	I6001-06095-0C	BOLT , HEXAGON HEAD	4	NO:025 六角帶頭螺栓						
4-15	C1120-V30-9000	STARTER COMP(CDI)	1	定子線圈						
4-16	C1110-V30-0000	FLYWHEEL COMP	1	飛輪組						
4-17	I3412-05014-0H	BOLT, HEXAGON HEAD WASHER	2	NO:001 六角螺栓+波形墊圈						
4-18	I6001-06020-0H	BOLT, HEXAGON HEAD	2	NO:001 六角帶頭螺栓						
4-19	I4104-12522	WASHER	1	NO:046 平墊圈						
4-20	I4050-12110-0H	NUT, HEXAGON HEAD 12mm	1	NO:001 六角帶頭螺帽						
4-21	A9510-A04-0000	FAN COMP COOLING	1	冷卻風扇組						
4-22	I6001-06018-0H	BOLT, HEXAGON HEAD (6×18)	4	NO:007 六角帶頭螺栓						

5. HEAD COVER 、 HEAD 、 CAM SHAFT 、 VALVE




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
5		COVER HEAD, HEAD, CAM SHAFT, VALVE								
5-1	I4301-10140	DOWEL PIN (10×14)	4	NO:009定位銷						
5-2	A2251-A08-0000	GASKET CYLINDER HEAD	1	汽缸頭墊片						
5-3	A220A-A08-9000	HEAD CYLINDER ASS'Y	1	汽缸頭總成						
5-3-1	A2200-A08-0001	HEAD COMP CYLINDER	1	汽缸頭組						
*5-3-1-1	I4608-09016	O-RING	2	NO:018 O型環						
*5-3-1-2	A2237-A04-0000	GUIDE IN VALVE	1	進氣閥導管						
*5-3-1-3	A2245-A04-0000	GUIDE EX VALVE	1	排氣閥導管						
5-3-2	A4721-A08-0000	VALVE EXHAUST	1	排氣閥						
5-3-3	A4711-A08-0000	VALVE INLET	1	進氣閥						
5-3-4	I2900-06016-0A	STUD BOLT	2	NO:003 螺樁						
5-3-5	I2900-06050-0A	STUD BOLT	2	NO:001 螺樁						
5-3-6	I8000-V30-0000	SPARK PLUG (CR7HSA)	1	火星塞CR7HSA						
5-3-7	A4781-A04-0000	COTTER VALVE	4	鍍鍵						
5-3-8	A4771-A04-0000	RETAINER VALVE SPG	2	閥彈簧固定片						
5-3-9	A4761-A07-0000	SPG VALVE INNER	2	閥門彈簧(內)						
5-3-10	A4751-A07-0000	SPG VALVE OUTER	2	閥門彈簧(外)						
5-3-11	I4104-16508	SEAT VALVE SPG OUTER	2	NO:071平墊圈						
5-3-12	A2209-A04-0000	SEAL VALVE STEM	2	閥頭油封						
5-4	I0012-A04-0000	SCREW TAPPET ADJUSTING	2	間隙調整螺絲						
5-5	A4431-A07-0001	ARM VALVE ROCKER	2	進氣搖臂						
5-6	A4450-A04-0000	SHAFT COMP IN ROCKET ARM	1	進氣閥搖臂軸組						
5-7	I6001-06100-0H	BOLT,HEXAGON HEAD	2	NO:010 六角帶頭螺栓						
5-8	A4452-A04-0000	SHAFT EX ROCKET ARM	1	排氣閥搖臂軸						
5-9	A6201-A04-0000	GASKET CARB INSULATOR	1	隔熱板墊片						
5-10	A6211-A04-0000	INSULATOR CARB	1	化油器隔熱板						
5-11	A711A-V30-0000	PIPE ASSY. INLET	1	化油器接頭總成						
*5-11-1	A7256-V30-0000	BAND INSULATOR	1	連接管固定帶						
*5-11-2	A7110-A07-0000	PIPE COMP INLET	1	化油器接頭組						
*5-11-3	I4608-27020	O-RING	1	NO:016 O型環						
5-12	I4050-0600G	NUT FLANGE 6mm(c)	2	螺帽6mm						
5-13	I4101-08523	WASHER	4	NO:054 平墊圈						
5-14	I4050-08075-0H	NUT,HEXAGON HEAD	4	NO:002 六角帶頭螺帽						
5-15	A2211-A04-0000	HOLDER SHAFT	1	凸輪軸座						
5-16	A230A-A04-0000	COVER ASSY. HEAD	1	汽缸頭蓋總成						
*5-16-1	A2301-A04-0001	COVER HEAD	1	汽缸頭蓋						
5-16-2	A2391-A04-0000	GASKET COVER HEAD CYLINDER	1	汽缸頭蓋墊片						
*5-16-3	A2305-A04-0000	JOINT COMP BREATHER	1	接頭組						
5-17	I6001-06025-0C	BOLT, HEXAGON HEAD	4	NO:022 六角帶頭螺栓						
5-18	A4150-A04-0000	PLATE COMP STOPPER	1	制止片組						
5-19	A8291-A04-0000	GASKET EXHAUST PIPE	1	排氣管墊片						
5-20	A4100-A07-0001	SHAFT COMP CAM	1	凸輪軸組						
5-21	I4001-050K0	NUT, HEXAGON HEAD	2	NO:007 六角螺帽						

6. FAN COVER , SHROUD



ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
6		FAN COVER, SHROUD								
6-1	A9620-A07-0001	SHROUD COMP A	1	罩蓋A組						
*6-1-1	A9621-A07-0000	SHROUD A	1	罩蓋(A)						
*6-1-2	A9625-A04-0000	SEAL SHROUD A	1	密封墊圈(A)						
6-2	A963A-V30-0001	HROUD B ASSY	1	罩蓋B總成						
*6-2-1	A9630-V30-0000	SHROUD COMP B	1	罩蓋B組						
*6-2-2	A9635-A04-0000	SEAL SHROUD B	1	密封墊圈(B)						
*6-2-3	A1384-V30-0000	CLAMPER BREATHER TUBE	1	通氣管夾						
*6-2-4	A9633-A04-0000	GROMMET SHROUD(B)	1	索環 (B)						
6-3	A961A-V30-0000	COVER ASSY. FAN	1	冷卻風扇罩總成						
*6-3-1	A9610-V30-0000	COVER COMP FAN	1	冷卻風扇罩組						
6-3-2	G0529-A04-0000	GROMMEET B SIDE PANEL	1	橡皮塞						
*6-3-3	A9615-A04-0000	DUCT CARBURETOR COOLING	1	化油器冷卻導管						
6-3-4	H7541-V30-0000	LABEL OIL CAP	1	機油油量標籤						
*6-3-5	G0529-V30-0000	GROMMET SHROUD	1	橡皮塞						
*6-3-6	A9616-V30-0000	DUCT INLET	1	進氣導管						
*6-3-7	I3902-304B0	SELF-TAPPING SCREW	3	圓頭十字自攻螺絲						
*6-3-8	I4101-04508	WASHER	3	平墊圈						
6-4	I3904-316B0	BOLT, HEXAGON HEAD	2	NO:001 六角帶頭十字自攻螺絲						
6-5	I3500-05025-0G	SCREW PAN	2	NO:009 圓頭十字螺絲						
6-6	A1385-V30-0000	CLAMPER CARB DRAIN TUBE	1	溢油管夾						
6-7	I6001-06025-0C	BOLT , HEXAGON HEAD	3	NO:022 六角帶頭螺栓						

7. DRIVEN PULLEY (CVT)




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
7		DRIVEN PULLEY (CVT)		驅動皮帶輪						
7-1	I4050-12110-0H	NUT, HEXAGON HEAD	2	NO:001六角帶頭螺帽						
7-2	B301A-V30-0000	PULLEY ASSY. DRIVEN	1	CVT從動輪總成						
	B301A-V30-9000	PULLEY ASSY. DRIVEN	1	CVT從動輪總成						
*7-2-1	B2101-A04-0000	OUTER CLUTCH	1	離合器外殼						
	B2101-A04-9000	OUTER CLUTCH	1	離合器外殼						
*7-2-2	I0202-A04-0000	NUT SPECIAL 28 mm	1	特殊螺帽28 mm						
	I0202-A04-9000	NUT SPECIAL 28 mm	1	特殊螺帽28 mm						
7-2-3	B2300-V30-0000	PLATE ASSY. DRIVEN	1	離合器組						
*7-2-3-1	B2350-A04-0000	PLATE COMP DRIVE	1	離合器壓板組						
*7-2-3-2	B2804-A04-0000	ROLLER CLUTCH	3	離合器滾柱						
*7-2-3-3	B2401-A04-0000	SPRING CLUTCH	3	離合器彈簧						
*7-2-3-4	B2530-V30-0000	WEIGHT SET CLUTCH	1	離合器配重						
*7-2-3-5	B2361-A04-0000	PLATE CLUTCH SIDE	1	離合器側板						
*7-2-3-6	I0605-A04-0000	CIR CLIP 7 mm	3	環夾7 mm						
*7-2-4	B3238-A04-0000	COLLAR SPRING	1	彈簧襯環						
*7-2-5	B3233-A08-0000	SPRING DRIVER FACE	1	CVT彈簧						
*7-2-6	B3237-A04-0000	COLLAR SEAL	1	油封套筒						
*7-2-7	I1351-A04-0000	O-RING	2	O型環						

ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
7		DRIVEN PULLEY (CVT)		驅動皮帶輪						
*7-2-8	I1211-A04-0000	SEAL DRIVEN FACE (34×41×4)	2	油封						
*7-2-9	B3225-A04-0000	PIN GUIDE	3	CVT從動輪銷						
*7-2-10	B3226-A04-0000	ROLLER	3	滾柱						
*7-2-11	B3220-A04-0000	FACE COMP MOVABLE DRIVEN	1	C.V.T被動輪組						
*7-2-12	B3200-A04-0000	FACE COMP DRIVEN	1	CVT從動輪組						
*7-2-12-1	B3210-A04-0000	FACE DRIVEN	1	從動皮帶盤						
*7-2-12-2	I1002-A04-69020	BEARING BALL REDIAL 6902U	1	軸承 6902U						
*7-2-12-3	I4520-28000	CIRCLIP EX	1	NO:001 C型扣環						
*7-2-12-4	I1001-A04-0000	BEARING NEEDLE 20×29×18	1	滾針軸承						
7-3	B3100-A07-0000	BELT DRIVE	1	驅動皮帶						
7-4		CANCEL,PREARRANGE		取消預留						
7-5	I4104-15023	WASHER	1	NO:019 平墊圈						
7-6	B2102-A14-0000	FACE DRIVE	1	CVT風扇						
7-7	B2105-A04-0000	BOSS DRIVE FACE	1	襯套						
7-8	B2110-A08-0000	FACE ASSY. MOVABLE DRIVE	1	主動輪總成(前CVT)						
*7-8-1	I4601-28000	CLIP, PISTON PIN 28 mm	2	NO:004活塞銷扣環						
7-8-2	B2112-A04-0000	BOSS FACE MOVABLE DRIVE	1	C.V.T主動輪套筒						
*7-8-3	B2111-A04-0000	FASE COMP MOVABLE DRIVE	1	C.V.T 主動輪						


ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
7		DRIVEN PULLEY (CVT)		驅動皮帶輪						
7-8-4	B2121-A08-0000	ROLLER SET WEIGHT	6	配重滾子						
7-8-5	B2132-A04-0000	PIECE SLIDE	3	C.V.T滑槽片						
7-8-6	B2131-A04-0000	PLATE RAMP	1	C.V.T滾柱導板						
7-9	B8211-A14-0002	RATCHET KICK STARTER	1	起動棘輪						
7-10	I4104-15104	WASHER	1	NO:083 平墊圈						
7-11	B3240-V30-0000	DISK CLUTCH FRICTON COMP	1	摩擦片組						
7-11-1	B3241-V30-0000	STOPPER PUMP	1	固定座						
7-11-2	B3242-V30-0000	STOPPER	1	蓋板						
7-11-3	B3243-V30-0000	CLUTCCH	6	彈簧						
7-11-4	B3244-V30-0000	BRAKE LINING	6	來令塊						
7-11-5	I3501-V30-0000	SCREW BUTTON HEAD CAP	3	圓頭內六角螺絲						
7-11-6	I3502-V30-0000	SCREW BUTTON HEAD CAP	3	圓頭內六角螺絲						

8. TRANSMISSION




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
8		TRANSMISSION		傳動系						
8-1	B1300-V30-0900	COVER MISSION	1	齒輪箱蓋						
8-2	B3430-V30-0000	SHAFT FINAL COMP	1	最終軸組						
8-3	I1130-304217	BEARING NEEDLE	1	NO:020 滾針軸承						
8-4	I1201-V30-0000	OIL SEAL (30×40×5)	1	油封 (30×40×5)						
8-5	I6150-62053-10	BRG BALL RADIAL	1	NO:036 滾珠軸承						
8-6	I4104-25210	WASHER	1	NO:060 平墊圈						
8-7	I4510-25000	CIRCLIP	1	NO:008 C型扣環						
8-8	I4520-52000	CIRCLIP	1	NO:003 C型扣環						
8-9	B3801-V30-8000	SPROCKET DRIVE(15T)	1	傳動鏈輪(15T)						
8-10	B3811-V30-0000	PLATE FIXING	1	鏈輪固定片						
8-11	I2201-06010-0C	BOLT, HEXAGON HEAD	2	NO:012 六角螺絲						
8-12	B3420-V30-9000	COUNTER SHAFT COMP	1	中間軸組						
*8-12-1	B3421-V30-0000	SHAFT COUNTER (15T)	1	中間軸						
*8-12-2	B3422-V30-9000	GEAR COUNTER (41T)	1	中間齒輪(41T)						
8-13	I6100-63020	BEARING, BALL, RADIAL	1	NO:034 滾珠軸承						
8-14	B3250-V30-9000	SHAFT GEAR SHIFT COMP	1	變檔軸組						
*8-14-1	B3213-V30-0001	COLLAR SHAFT	1	軸套						
*8-14-2	I4104-15110	WASHER	2	NO:062 平墊圈						
*8-14-3	B3440-V30-0000	SPUR GEAR ASSY (36T)	1	正檔齒輪組 (36T)						
*8-14-3-1	B3441-V30-9000	SPUR GEAR (36T)	1	正檔齒輪(36T)						
*8-14-3-2	B8113-V30-9000	COLLAR SHAFT	1	銅襯套						
*8-14-4	B3481-V30-0000	RATCHET SHIFT	1	變檔棘輪						
*8-14-5	I4510-22000	CIRCLIP EX	1	NO:007 C型扣環						
*8-14-6	I0454-22030	WASHER B SPINE	1	NO:007 栓槽墊圈						
*8-14-7	B3460-V30-0000	GEAR COMP REVERSE	1	倒檔齒輪組						
*8-14-7-1	B3461-V30-0000	GEAR REVERSE	1	倒檔齒輪						
*8-14-7-2	I1130-223013	BEARING, NEEDLE	1	NO:021 滾針軸承						
*8-14-8	I4104-22010	WASHER	1	NO:061 平墊圈						
*8-14-9	B3251-V30-9000	SHAFT MAIN TRANSMISSION	1	主傳動軸(17T)						
*8-14-10	I4540-15000	CIRCLIP	1	NO:004 C型固定環						
*8-14-11	I4104-15010A	WASHER	1	NO:082 平墊圈						
8-15	I6100-62043	BEARING, BALL, RADIAL	1	NO:012 滾珠軸承						
8-16	B4231-V30-0000	FORK SHIFT	1	換檔叉片						
8-17	B4241-V30-0000	SHAFT GEAR SHIFT	1	換檔叉軸						
8-18	B4300-V30-0000	DRUM COMP GEAR SHIFT	1	換檔鼓組						
*8-18-1	B4301-V30-0000	DRUM GEAR SHIFT	1	換檔鼓						
*8-18-2	B4302-V30-0000	GEAR DRUM GEAR SHIFT	1	換檔鼓齒輪						
*8-18-3	I4104-13110	WASHER	1	NO:063 平墊圈						
*8-18-4	B4303-V30-0000	SPRING GEAR SHIFT RETURN	1	換檔鼓彈簧						
*8-18-5	B4304-V30-0000	COLLAR SHAFT	1	軸套						
8-19	B461A-V30-0000	SPINDLE ASSY SHIFT	1	換檔器總成						
*8-19-1	B4610-V30-0000	SPINDLE COMP SHIFT	1	換檔器組						
*8-19-2	I4540-1201A	CIRCLIP	2	NO:003 E型扣環						
8-20	I4301-10140	KNOCK PIN	2	NO:009 定位銷						

9. GEAR SHAFT LEVER 、 SAFETY SWITCH




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
9		GEAR SHAFT LEVER, SAFETY SWITCH		變檔桿，安全開關						
9-1	B4640-V30-0001	SHAFT COMP ROD	1	變檔桿組						
*9-1-1	B4641-V30-0001	ROD SHIFT	1	變檔桿						
*9-1-2	B4642-V30-0000	HANDLE PLASTICS	1	變檔把手						
*9-1-3	I3600-06020-0G	SCREW FLAT	1	NO:002平頭十字螺絲						
9-2	I3892-05016-0C	SCREW WASHER	2	NO:005 圓頭十字螺絲+波形墊圈						
9-3	B1395-V30-0000	GASKET MISSION COVER	1	齒輪箱蓋墊片						
9-4	C2963-A09-0000	CLAMPER PULSER CORD	1	線夾						
9-5	B4622-V30-0000	FIXED SUPPORT CATCH	1	檔位固定座						
9-6	B4643-V30-0000	FIXED SUPPORT ROD COMP SHIFT	1	變檔桿固定座						
9-7	I4104-08515	WASHER	2	NO:064 平墊圈						
9-8	B4644-V30-0000	SPRING ROD SHIFT	1	變檔桿彈簧						
9-9	I4201-46195	SPLIT PIN	1	NO:002 開口銷						
9-10	B4645-V30-0000	PIN ROD SHIFT	1	變檔桿銷						
9-11	I5701-06025-0C	BOLT , HEXAGON HEAD	1	NO:011 六角帶頭螺栓						
9-12	I1206-A00-0000	OIL SEAL (14×28×7)	1	油封 (14×28×7)						
9-13	I5801-06012-0C	BOLT, HEXAGON HEAD	2	NO:022 六角帶頭螺栓						
9-14	I2800-12015-0C	DRAIN PLUG BOLT	1	NO:002 洩油塞頭螺栓						
9-15	I4104-12120	WASHER	1	NO:049 平墊圈						
9-16	B4624-V30-0000	SPRING TRANSMISSION PLANK	1	傳動板彈簧						
9-17	B4623-V30-0000	PLATE TRANSMISSION	1	傳動板						
9-18	I5701-06010-0C	BOLT , HEXAGON HEAD	1	NO:027 六角帶頭螺栓						
9-19	I5701-06040-0C	BOLT , HEXAGON HEAD	10	NO:013 六角帶頭螺栓						
9-20	A8254-V30-0000	BOSS (B)	2	襯套40mm						
9-21	A1103-V30-0000	RUBBER BUSH ENGINE HANGER	2	懸吊橡膠襯套						
9-22	C510A-V30-0000	SAFETY SWITCH ASSY.	1	安全開關組						
9-23	A1332-A09-0000	GAUGE OIL LEVEL	1	油門視窗						

10. AIR CLEANER




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
10		AIR CLEANER		空氣濾清器						
10-1	A720A-V30-0001	AIR CLEANER ASSY .	1	空氣濾清器總成						
*10-1-1	A7230-V30-0001	CASE AIR CLEANER	1	空氣濾清器箱						
*10-1-2	A7214-A11-0000	SEAL AIR CLEANER COVER	2	空氣濾清器蓋油封						
10-1-3	A7205-A12-0000	FILTER PAPER ASSY.	1	濾紙總成						
*10-1-4	A7231-V30-0001	COVER AIR CLEANER	1	空氣濾清器蓋						
*10-1-5	A7256-A04-0000	BAND AIR CLEANER CONNECTING TUBE	1	連接管固定帶						
*10-1-6	I3903-320B0	SELF-TAPPING SCREW (φ5×20)	4	NO:007自攻螺絲						
*10-1-7	I3903-430B0	SELF-TAPPING SCREW (φ5×32)	2	NO:008自攻螺絲						
*10-1-8	A7253-V30-0000	AIR CLEANER CONNECTING TUBE	1	連接管						
*10-1-9	A7364-A11-0000	B TUBE BERATHER	1	通氣管 (B)						
*10-1-10	A7233-V30-0000	BAND CONNECTIOG TUBE	1	連接管固定片						
*10-1-11	I3903-310B0	TAPPING SCREW PAN	1	NO:006 圓頭十字自攻螺絲						
10-2	A736A-V30-9001	GAS WASTE RECOVERY	1	曲軸箱廢氣回收器						
10-3	I5701-06025-0C	BOLT , HEXAGON HEAD (M6×25)	2	NO:011 六角帶頭螺栓						

11. CARBURETOR




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
11		CARBURETOR								
11-1	A610A-V30-0000	CARBURETOR ASSY.	1	化油器總成						
11-1-1	A6100-V30-A001	MAINTENANCE KIT 1	1	化油器小修包1						
*11-1-1-1	KAB73710	THROTTLE VALVE SPRING	1	活塞彈簧						
*11-1-1-2	KAB43610	CLIP	1	彈簧承座						
*11-1-1-3	KAB40G04	AIR ADJUSTING SCREW ASSY.	1	油氣栓總成						
*11-1-1-4	KAB73010	SLOW JET (*35)	1	低速噴嘴 (*35)						
*11-1-1-5	KAB73110	NEEDLE JET HOLDER (*SG5A)	1	主霧化管(*SG5A)						
*11-1-1-6	KAB42910	NEEDLE JET	1	噴嘴閥座						
*11-1-1-7	KAB86310	PIPE (*425mm)	1	洩油膠管(*425mm)						
11-1-1-8	A6100-V30-A002	MAINTENANCE KIT 2	1	化油器小修包2						
*11-1-1-8-1	KAB73320	JET NEEDLE (*SG5A)	1	閥針總成 (*SG5A)						
*11-1-1-8-2	KAB43440	THROTTLE VALVE ASSY.	1	真空活塞組						
*11-1-1-8-3	KAB4CC20	NEEDLE VALVE ASSY.	1	針閥調整						
*11-1-1-8-3-1	KAB42130	NEEDLE VALVE ASSY.	1	針閥總成						
*11-1-1-8-3-2	KAB42210	FLOAT O-RING	1	浮筒扣環						
*11-1-1-8-4	KAB45710	CHAMBER O-RING	1	底蓋方型環						
*11-1-1-8-5	KAB42310	FLOAT ASSY.	1	浮筒總成						
*11-1-1-8-6	KAB61520	DRAIN SCREW ASSY.	1	洩油螺栓總成						
*11-1-1-8-6-1	KAA13510	DRAIN SCREW	1	洩油螺栓						
*11-1-1-8-6-2	KAA13610	DRAIN O-RING	1	洩油O型環						
*11-1-1-8-7	KAB83210	MAIN JET (*104)	1	主噴油嘴(*104)						
11-2	A7910-V30-0000	CABLE ASSY.	1	加油導線總成						

12. OIL COOLER




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
12		OIL COOLER								
12-1	I902A-V30-9001	COOLER COMP OIL ASSY.	1	機油冷卻總成(大)						
12-1-1	I9020-V30-9900	COOLER COMP OIL COATING	1	冷卻器（皮膜處理）						
12-1-2	A9121-V30-0002	OIL HOSE COMP INLET	1	進油管						
12-1-3	A9122-V30-0002	OIL HOSE COMP OUTLET	1	出油管						
12-1-4	I0002-V30-0000	BOLT B OIL PASS	2	油管螺栓						
12-1-5	I4104-12514	WASHER	4	NO:048 平墊圈						
12-2	I0002-V30-0000	BOLT B OIL PASS	2	油管螺栓						
12-3	I4104-12514	WASHER	4	NO:048 平墊圈						

13. ENGINE




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
13		ENGINE ATV								
13-1	AA000-V30-6000	ENGINE ATV	1	引擎總成						
13-2	B0100-FIA0-0000	INLET TUBE , CVT	1	CVT進氣管總成						
13-3	B0200-FIA0-0000	EXH TUBE , CVT	1	CVT排氣管總成						
13-4	A7215-V30-0000	AIR/C CASE DUCT	1	空濾器進氣管						
13-5	H3936-5AA0-0000	WIRE CLAMP	1	線束帶						
13-6	A1105-FIA0-0000	ENGINE RUBBER PLUG	2	引擎橡膠塞						

14. MUFFLER




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
14		MUFFLER ASSY.								
14-1	A830A-FIC0-9000	EXHAUST PIPE ASSY.	1	排氣管總成						
14-2	I7507-FIA0-0000	BOLT,HEXAGON HEAD WITH WASHER	1	六角螺栓附墊圈						
14-3	I0149-08036-01	BOLT ,FLANGE	1	凸緣螺栓						
14-4	I0179-06850	NUT	2	排氣管螺帽						
14-5	I5611-08200	NUT,FLANGE CHECK(M8)	1	凸緣防鬆螺帽						

15.FRAME



ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
15		FRAME								
15-1	E0100-FIC0-9000	FRAME COMP.	1	車架總成						
15-2	H7501-FIC0-0000	EMBLEM	1	銘牌						
15-3	H750A-5BA1-0000	FIX NAIL	2	拉釘(ψ3.5×9)						
15-4	E0351-5EA0-0000	ENGINE SET BOLT(M10×115)	3	引擎裝置螺栓						
15-5	I5611-10200	NUT,FLANGE CHECK	5	凸緣防鬆螺帽						
15-6	I2501-06080-0B	BOLT,HEXAGON HEAD	4	六角螺栓						
15-7	G7223-5EB0-0000	RUBBER PAD	1	防震橡膠塊						
15-8	I6600-06000	GREASE VALVE(1/4")	2	黃油嘴(1/4")						
15-9	E0209-5EA0-0000	CAP, GREASE VALVE	2	黃油嘴蓋						
15-10	I2140-60001	WASHER	4	墊圈						
15-11	E0350-FIA0-0000	ENGINE SUSPENSION ASSY. ,LEFT	1	引擎懸吊裝置總成(左)						
15-12	E0353-FIA0-0000	ENGINE SUSPENSION ASSY. ,RIGHT	1	引擎懸吊裝置總成(右)						
15-13	E0352-FIA0-0000	SCREW,BUTTON HEAD CAP	2	圓頭四角螺絲						
15-14	I5827-08030	BOLT,FLANGE	1	六角螺絲						


16. FENDER



ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
16		FENDER								
16-1	F4300-FIB0-4200	FRONT FENDER (RED)	1	前擋泥板(紅)		N/A		N/A	N/A	
	F4300-FIB0-5400	FRONT FENDER (BLUE)	1	前擋泥板(藍)		N/A		N/A	N/A	
	F4300-FIB0-0700	FRONT FENDER (SILVER)	1	前擋泥板(銀)		N/A		N/A	N/A	
	F4300-FIB0-2500	FRONT FENDER (GREEN)	1	前擋泥板(綠)		N/A		N/A	N/A	
	F4300-FIB0-0C00	FRONT FENDER (CAMO)	1	前擋泥板(迷彩)		N/A		N/A	N/A	
16-2	F4301-FIA0-0800	FRONT CENTRAL COVER(BLACK)	1	前中心蓋(黑)		N/A		N/A	N/A	
16-3	F4302-FIA0-0800	REAR CENTRAL COVER (BLACK)	1	後中心蓋(黑)		N/A		N/A	N/A	
16-4	H3500-FIA0-4200	REAR FENDER(RED)	1	後擋泥蓋(紅)		N/A		N/A	N/A	
	H3500-FIA0-5400	REAR FENDER(BLUE)	1	後擋泥蓋(藍)		N/A		N/A	N/A	
	H3500-FIA0-0700	REAR FENDER(SILVER)	1	後擋泥蓋(銀)		N/A		N/A	N/A	
	H3500-FIA0-2500	REAR FENDER(GREEN)	1	後擋泥蓋(綠)		N/A		N/A	N/A	
	H3500-FIA0-0C00	REAR FENDER(CAMO)	1	後擋泥蓋(迷彩)		N/A		N/A	N/A	
16-5	H3520-FIA0-0800	FOOTREST, RIGHT	1	右置腳踏板(黑)		N/A		N/A	N/A	
16-6	H3620-FIA0-0800	FOOTREST, LEFT	1	左置腳踏板(黑)		N/A		N/A	N/A	
16-7	H3720-FIA0-0800	TRIM,REAR RIGHT	1	右後護片(黑)		N/A		N/A	N/A	
16-8	H3820-FIA0-0800	TRIM,REAR LEFT	1	左後護片(黑)		N/A		N/A	N/A	
16-9	C7203-5PA0-0000	SPEEDOMETER BRACKET ASSY.	1	儀表板固定座						
16-10	F4315-FIC0-0000	RUBBER PAD	1	塑件隔熱海棉						
16-11	E0117-9EA0-0000	BUTTON HEAD SCREW(M6×18)	20	扁圓頭螺絲						
16-12	I5611-06200-0G	NUT ,CHECK	20	防鬆螺帽						
16-13	I0119-06821	BOLT,HEXAGON(M6×20)	8	六角螺栓(M6×20)						
16-14	I0149-06035	BOLT ,FLANGE (M6×35)	2	凸緣螺栓						
16-15	I8310-FIA0-0000	PLASTICS SCREW	2	塑膠螺絲						
16-16	E0117-9EA0-0000	SCREW,BUTTON HEAD (M6×18)	3	扁圓頭螺絲						
16-17	H7129-FIA0-0000	STICKER,INDICATE GEAR	1	排擋指示貼紙						
16-18	H7100-5FA0-0000	LABEL TIRE, WARNING	1	胎壓警告貼紙						


ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
16		FENDER								
16-19	I2804-04013-5C	SCREW(M4x13)	5	自攻螺絲(M4×13)						
16-20	H7103-FIC1-0000	STICKER,YUKON ST.EXL150	2	車身貼紙EXL150						
16-21	F4303-FIB0-0800	HAED LIGHT COVER	1	大燈封蓋						
16-22	I2804-04010-5C	SELF-TAPPING SCREW	1	自攻螺絲(M4×10)						
16-23	I7707-04016	SELF-TAPPING SCREW	4	自攻螺絲M4×16						
16-24	H7107-5EB0-0000	EMBLEM,E-TON LOGO(SILVER)	1	益通銘牌		N/A		N/A	N/A	
16-25	H8806-FIC0-0000	FOAM STICK (A)	2	海棉橡膠條A						
16-26	H8807-FIC0-0000	FOAM STICK (B)	2	海棉橡膠條B						
16-27	E3205-FIC0-0800	COVER,HANDLE BAR UP(BLACK)	1	手把上蓋(黑色)						
16-27-1	C3101-FIA0-0000	BULB(RED)	1	燈炮(紅色)						
16-27-2	C3102-FIA0-0000	BULB(BLUE)	1	燈炮(藍色)						
16-27-3	C3103-FIA0-0000	BULB(GREEN)	1	燈炮(綠色)						
16-28	F3100-5PA0-4200	HEAD LIGHT, GUARD(RED)	1	頭燈罩(紅)						
	F3100-5PA0-5400	HEAD LIGHT, GUARD(BLUE)	1	頭燈罩(藍)						
	F3100-5PA0-0700	HEAD LIGHT, GUARD(SILVER)	1	頭燈罩(銀)						
	F3100-5PA0-2500	HEAD LIGHT, GUARD(GREEN)	1	頭燈罩(綠)						
	F3100-5PA0-0C00	HEAD LIGHT, GUARD (CAM0)	1	頭燈罩(迷彩)						
16-29	E3206-5PA0-0800	HANDLE COVER,LOWER(BLACK)	1	手把下蓋						
16-30	H3502-5PA0-0000	CAP	2	塞頭						

17. SWING ARM




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
17		SWING ARM								
17-1	E0200-FIA0-9000	ARM, SUSPENSION, L.H.	1	左A臂總成						
17-2	E0210-FIA0-9000	ARM, SUSPENSION, R.H.	1	右A臂總成						
17-3	E0201-FIA0-0000	BUSH, ARM SUSPENSION	8	A臂含油襯套						
17-4	E0209-FIA0-0000	SPACER	4	A臂套筒(短)						
17-5	E2205-4HA0-0000	SWING ARM SEAL COVER	8	封蓋						
17-6	E220A-FIB0-9000	SWING ARM SUB ASSY.	1	後叉總成						
17-7	E2208-5EA0-0000	SWING ARM OIL LINER(ψ20)	2	後叉含油襯套						
17-8	E2209-FIA0-0000	SPACER	1	後叉套筒(長)						
17-9	E2205-5EA0-0000	SWING ARM SEAL COVER	2	後叉封套						
17-10	E2202-FIA0-0000	RUBBER SLEEVE	1	後叉軸套						
17-11	E2201-FIA0-0000	BOLT,SWING RAM SET CHECK(M14×265)	1	後叉裝置螺栓						
17-12	I5611-14200	NUT ,FLANGE CHECK(M14)	1	凸緣防鬆螺帽						
17-13	I0149-10080	FLANGE(M10×80)	4	凸緣螺栓(10×80)						
17-14	I5611-10200	NUT,FLANGE CHECK(M10)	4	凸緣防鬆螺帽						
17-15	I6600-06000	GREASE VALVE	5	黃油嘴(1/4")						
17-16	E0209-5EA0-0000	CAP,GREASE VALVE	5	黃油嘴蓋						
17-17	G7112-BCA0-0000	BRACKET,BRAKE HOSE	2	煞車油管固定夾						
17-18	I8556-06016	BOLT,FLANGE(M6x16)	2	凸緣螺絲						

18. SEAT




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
18		SEAT								
18-1	G7200-FIC0-9000	SEAT ASSY.	1	座墊總成						
18-2	G7201-FIA0-0000	SEAT LOCK	1	座墊扣						
18-3	I0149-06012	FLANGE BOLT(M6×12)	2	凸緣螺栓						

19. FUEL TANK, OIL TANK




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
19		FUEL TANK , OIL TANK ASSY								
19-1	A7500-FIC0-0000	FUEL TANK COMP	1	汽油箱						
19-2	A751A-FIA0-1000	FUEL FILTER ASSY.	1	汽油濾清器總成						
19-2-1	A7519-FIA0-1000	FILTER COMP FUEL	1	汽油濾清器						
19-2-2	A7516-5EA0-0000	CLIP(A)	2	汽油管止夾(A)						
19-2-3	A7517-FIA0-0000	CLIP	2	汽油管止夾						
19-2-4	A7514-FIA0-0000	FUEL TUBE(A)	2	汽油濾清器油管(A)						
19-3	A762A-9FA0-0000	FUEL TANK CAP ASSY.	1	汽油箱蓋總成						
19-3-1	A7620-9FA0-0000	FUEL TANK CAP	1	汽油箱蓋						
19-3-2	A7621-9FA0-0000	BREATHE TUBE	1	油箱呼吸管						
19-4	A7622-9FA0-0000	RUBBER PAD, FUEL TANK CAP	1	汽油箱蓋橡膠墊						
19-5	A7510-FIA0-0000	FUEL TANK RUBBER PAD	4	汽油箱橡膠墊						
19-6	A6701-FIA0-0000	FUEL COCK ASSY.	1	旋油塞總成						
19-7	A7511-FIA0-0000	RUBBER INSULATOR	2	汽油箱橡膠隔筒						
19-8	A7512-FIA0-0000	FUEL TANK GASKET SPACER	2	汽油箱墊片隔筒						
19-9	C780A-FIA0-0000	METER FUEL LEVER	1	汽油量表						
19-10	I7507-06225	BOLT ,HEXAGON HEAD	2	六角套頭螺栓						
19-11	I0200-50160	BOLT,WITH WASHER(M5×16)	4	帶墊圈螺栓						
19-12	A751B-FIA0-0000	VACUUM TUBE COMP	1	負壓管						
19-12-1	A7518-FIA0-0000	CLIP	2	負壓管線夾						

20. SUSPENSION




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
20		SUSPENSION								
20-1	E1105-FIA0-9000	SUSPENSION, FRONT	2	前避震器						
20-2	E2400-FIC0-9000	SUSPENSION, REAR	1	後避震器						
20-3	I0102-10040B	PIN HOLE BOLT(M10×40)	6	銷孔螺栓						
20-4	I0469-12006	COTTER PIN	2	B型銷						
20-5	I9900-25019	COTTER PIN (3/32×3/4")	4	開口銷						

21. FRONT WHEEL




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
21		FRONT WHEEL								
21-1	D471A-FIC0-9000	FRONT WHEEL ASSY.,LEFT(21×7-10)	1	左前輪總成			N/A			
	D471A-FIC0-8500	FRONT WHEEL ASSY.,LEFT(21×7-10)	1	左前輪總成		N/A		N/A	N/A	N/A
21-1-1	D4710-FIC0-0000	WHEEL TIRE (21×7-10)	1	輪胎						
21-1-2	D4601-FIC0-0000	WHEEL RIM (10"×5.5)	1	輪圈			N/A			
	D4601-FIC0-0500	WHEEL RIM (10"×5.5)	1	輪圈(綠色)		N/A		N/A	N/A	N/A
21-2	D471B-FIC0-9000	FRONT WHEEL ASSY.,RIGHT(21×7-10)	1	右前輪總成			N/A			
	D471B-FIC0-8500	FRONT WHEEL ASSY.,RIGHT(21×7-10)	1	右前輪總成		N/A		N/A	N/A	N/A
21-2-1	D4710-FIC0-0000	WHEEL TIRE (21×7-10)	1	輪胎						
21-2-2	D4601-FIC0-0000	WHEEL RIM (10"×5.5)	1	輪圈			N/A			
	D4601-FIC0-0500	WHEEL RIM (10"×5.5)	1	輪圈(綠色)		N/A		N/A	N/A	N/A
21-3	D461A-FIC0-0000	WHEEL HUB ASSY	2	前輪轂總成						
21-3-1	D4610-FIC0-0000	WHEEL HUB	2	前輪轂						
21-3-2	D4612-9FA0-0000	BOLT,STUD	8	緊配螺栓						
21-3-3	I6100-6003LLU	BEARING(6003-LLU)	4	軸承						
21-3-4	I1307-24035-10	OUTER OIL SEAL(φ24×35×7)	4	外油封						
21-3-5	D4620-FIA0-0000	INNER SPACER	2	內定距套						
21-4	C7205-5PA0-0000	MAGNET	1	磁石						
21-5	D4613-5PA0-0000	SCREW	1	轉接螺絲						
21-6	D4621-FIA0-0000	OUTER SPACER	2	外定距套						
21-7	D5351-FIC0-0000	BRAKE DISC	2	前碟式煞車盤						
21-8	D4611-FIC0-0000	NUT(M10)	8	螺帽(M10)						
21-9	I9905-14200	WASHER(φ15×24×2.3)	2	墊圈						
21-10	I5500-14100	CASTLE NUT(M14)	2	城堡螺帽(M14)						
21-11	I9900-30032	COTTER PIN(1/8"×1 1/4")	2	開口銷						
21-12	D4609-9FA0-0000	RUBBER CAP	2	橡膠套						
21-13	D5350-FIC0-0000	BOLT,ROUND HEAD	8	煞車盤圓頭螺栓						

22. REAR WHEEL




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
22		REAR WHEEL								
22-1	D471C-FIC0-9000	REAR WHELL ASSY.,LEFT(22×10-10)	1	左後輪總成			N/A			
	D471C-FIC0-8500	REAR WHELL ASSY.,LEFT(22×10-10)	1	左後輪總成		N/A		N/A	N/A	N/A
22-1-1	D4720-FIC0-0000	WHEEL TIRE (22×10-10)	1	輪胎						
22-1-2	D4602-FIC0-8000	WHEEL RIM (10"×8)	1	輪圈(10"×8)			N/A			
	D4602-FIC0-8500	WHEEL RIM (10"×8)	1	輪圈(綠色)		N/A		N/A	N/A	N/A
22-2	D471D-FIC0-9000	REAR WHELL ASSY.,RIGHT(22×10-10)	1	右後輪總成			N/A			
	D471D-FIC0-8500	REAR WHELL ASSY.,RIGHT(22×10-10)	1	右後輪總成		N/A		N/A	N/A	N/A
22-2-1	D4720-FIC0-0000	WHEEL TIRE (22×10-10)	1	輪胎(22×10-8)						
22-2-2	D4602-FIC0-8000	WHEEL RIM (10"×8)	1	輪圈(10"×8)			N/A			
	D4602-FIC0-8500	WHEEL RIM (10"×8)	1	輪圈(綠色)		N/A		N/A	N/A	N/A
22-3	D2705-FIC0-0000	SHAFT CONNECTER WITH BOLTS	2	後軸聯結器總成						
22-4	D4611-FIC0-0000	NUT,FLANGE CHECK(M10)	8	凸緣防鬆螺帽(M10)						
22-5	D2309-5EA0-0000	WHEEL AXLE WASHER, REAR(ψ14×40×4.5)	2	後輪軸墊片						
22-6	I9905-14200	WASHER(ψ15×24×2.3)	2	墊圈						
22-7	I5500-14100	CASTLE NUT(M14)	2	城堡螺帽(M14)						
22-8	I9900-30032	COTTER PIN(1/8"×1/4")	2	開口銷						
22-9	D4609-5EA0-0000	RUBBER COVER	2	橡膠套						

23.FRONT BRAKE




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
23		FRONT BRAKE								
23-1	G7160-FIC0-0000	BRAKE DISC MOUNTING SEAT LEFT	1	卡鉗固定座(左)						
23-2	G7120-FIC0-0000	BRAKE CALL IPER LEFT	1	前煞車卡鉗(左)						
23-2-1	G7131-5EE0-0000	PAD ASSY BRAKE	1	煞車蹄片						
23-3	G7170-FIC0-0000	BRAKE DISC MOUNTING SEAT RIGH	1	卡鉗固定座(右)						
23-4	G7140-FIC0-0000	BRAKE CALL IPER RIGH	1	前煞車卡鉗(右)						
23-4-1	G7131-5EE0-0000	PAD ASSY BRAKE	1	煞車蹄片						
23-5	I7507-FIA0-0000	BOLT,FLANGE	4	六角凸緣螺栓						
23-6	I0401-10034	UNION BOLT,BRAKE HOSE	3	煞車油管通油螺栓						
23-7	I0201-10118	WASHER,PLATE	6	銅墊圈						
23-8	G7110-FIC0-0000	FRONT BRAKE OIL TUBE ASSY	1	前煞車油管總成						
23-8-1	G7111-FIC0-0000	FRONT BRAKE OIL TUBE LEFT	1	前煞車油管(左)						
23-8-2	G7112-FIC0-0000	FRONT BRAKE OIL TUBE RIGHT	1	前煞車油管(右)						
23-8-3	G7113-FIC0-0000	FRONT BRAKE OIL TUBE END	1	前煞車油管(後)						
23-8-4	I0401-10034	UNION BOLT,BRAKE HOSE	2	煞車油管通油螺栓						
23-8-5	I0201-10118	WASHER,PLATE	4	銅墊圈						
23-9	E5451-FIC0-9000	CABLE, FRONT BRAKE ASSY	1	前煞車線總成						
23-10	G7100-FIC0-0000	BRAKE MASTER CYLINDER	1	前煞車主缸						
23-11	D3410-FIC0-9000	BRAKE MASTER CYLINDER ARM	1	煞車主缸搖臂						
23-12	D3419-FIC0-0000	RETURN SPRING	1	搖臂復歸彈簧						
23-13	G7202-9PA0-0000	SWITCH (FLOOR)	1	腳煞車開閥						
23-14	E0711-FIC0-9000	SPG,BRAKE LAMP SWITCH	1	煞車燈開關彈簧						
23-15	I7510-06016-1B	PIN	2	帶頭銷						
23-16	I5300-00500-N	CLIP,E TYPE(ψ5)	2	E型扣環(φ5)						
23-17	E0708-FIC0-9000	PEDAL COMP BRAKE	1	腳踏車踏桿						
23-18	I5300-01500-K	CLIP,E TYPE(ψ15)	1	E型扣環(φ15)						
23-19	I3010-19025-1K	PLAIN WASHER(ψ19xψ25)	1	平墊圈(φ19xψ25)						
23-20	I5827-08030	BOLT,FLANGE(M8x30)	1	六角螺絲						
23-21	I5800-08300	NUT,FLANGE CHECK(M8)	1	螺帽						
23-22	I0050-06025	BOLT,SOCKET(M6x25)	2	內六角螺絲						
23-23	I0149-06016	SCREW,PAD NEAD(M6x16)	1	圓頭螺絲附墊圈						
23-24	I8557-06012	SCREW,PAD NEAD(M6x12)	1	盤頭螺絲附墊圈						
52 23-25	C2962-UE1-0000	CLAMPER	1	線夾						

24. REAR BRAKE




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
24		REAR BRAKE								
24-1	D231A-FIA0-0000	BEARING SEAT ASSY., REAR WHEEL AXLE	1	後輪軸承座總成						
24-1-1	D3142-FIA0-0000	ANCHOR PIN	1	後煞車固定銷						
24-1-2	H7106-FIA0-0000	WARNING STICKER , CHAIN	1	鏈條警告貼紙						
24-2	D2311-FIA0-0000	SPACER	1	軸承座隔筒						
24-3	I6100-6007LLU	BEARING(6007LLU)	2	軸承(6007LLU)						
24-4	D2315-FIA0-0000	OIL SEAL(ψ43×62×12)	1	油封						
24-5	I0141-12036-01	BOLT,FLANGE (M12×36)	4	凸緣螺栓(M12×36)						
24-6	D3141-FIA0-0010	BRAKE ARM CAM,REAR	1	後搖臂凸輪						
24-7	D3410-FIA0-0000	BRAKE ARM ,REAR	1	後煞車搖臂						
24-8	D3120-FIA0-0000	REAR BRAKE SHOE COMP	1	後煞車蹄片組						
24-9	D3145-FIA0-0000	REAR BRAKE INDICATOR	1	後煞車指示器						
24-10	D3419-FIA0-0000	REAR RETURN SPRING	1	後復歸彈簧						
24-11	I0020-06030	BOLT(M6×30)	1	螺栓						
24-12	D3615-FIA0-0000	DRUM COVER,REAR	1	後煞車鼓蓋						
24-13	I8557-06012	SCREW WITH WASHER(M6x12)	6	盤頭螺絲附墊圈						
24-14	D3610-FIA0-1000	REAR BRAKE DRUM	1	後煞車鼓						
24-15	D2316-5EA0-0000	DRAIN PIPE ASSY	1	排水管總成						
24-16	D2319-FIA0-0000	PLUG PURGE HOLE	1	吹氣孔塞						
24-17	E3450-FIC0-9000	CABLE,REAR BRAKE	1	後煞車線總成						
24-18	E0710-FIC0-0000	BRAKE PEDAL CABLE	1	腳煞車線總成						
24-19	D2313-FIA0-0000	OIL SEAL(ψ48×62×7)	1	油封						
24-20	D3611-FIA0-0000	O-RING	1	O型環						
24-21	D3416-FIA0-0000	SPG BRAKE CABEL	2	後煞車線彈簧						
24-22	I2140-60001	WASHER	2	墊片						
24-23	I7510-06016-1B	PIN	1	帶頭銷						
24-24	I5300-00500-N	CLIP,E TYPE(ψ5)	1	E型扣環(φ5)						

25.HANDLE BAR




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
25		HANDLE BAR								
25-1	E3100-FIA0-0000	HANDLE BAR ASSY.	1	手把總成						
25-2	E3180-FIC0-0000	LEVER ASSY. RIGHT	1	右拉桿總成						
25-2-1	E3181-FIC0-0000	LEVER,RIGHT	1	右拉桿						
25-3	E3180-4HA0-0000	LEVER ASSY,RIGHT	1	加油座總成						
25-3-1	E3191-4HA0-0000	ACCELERATOR BODY	1	加油座本體						
25-3-2	E319A-4HA0-0000	LEVER	1	加油座拉桿						
25-3-3	E3189-5EA0-0000	THROTTLE CABLE ARM	1	加油推桿						
25-3-4	E3190-5EA0-0000	SPRING	1	彈簧						
25-3-5	I0010-06020	SCREW (M6×20)	1	螺絲						
25-3-6	I0149-08012H	BOLT,FLANGE(M8x12)	1	帶頭螺絲						
25-3-7	E3192-5EA0-0000	WASHER (ψ20×ψ14.2x1.5)	1	墊圈						
25-3-8	I8506-05024	BOLT(M5x24)	1	螺絲						
25-3-9	I5800-05300	NUT HEX	1	螺帽						
25-4	E3170-FIA0-0000	LEVER ASSY., LEFT	1	左拉桿總成						
25-4-1	E3171-FIA0-0000	LEVER,LEFT	1	左拉桿						
25-4-2	E3174-5EA0-0000	BRAKE SWITCH ASSY.	1	煞車開關						
25-5	E3166-5EA0-0000	GRIP HANDLE	2	握把						
25-6	E3112-5EA0-0000	HANDLE BAR CLAMP, BOTTOM	2	手把固定座(底座)						
25-7	E3110-5EA0-0000	HANDLE BAR CLAMP, CAP, LEFT	1	手把固定座(上蓋,L)						
25-8	E3111-5EA0-0000	HANDLE BAR CLAMP, CAP, RIGHT	1	手把固定座(上蓋,R)						
25-9	I0050-06025	SCREW ,SOCKET (M6×25)	4	內六角螺絲(M6*25)						
25-10	I5611-10200	NUT,FLANGE CHECK (M10)	2	凸緣防鬆螺帽(M10)						
25-11	E3113-5FA0-0000	A MIRROR BRACKET(LEFT)	1	鏡孔座(左)						
25-12	E3114-5FA0-0000	A MIRROR BRACKET(RIGHT)	1	鏡孔座(右)						
25-13	I8506-04016	SCREW PAN HEAD(M4x16)	2	盤頭螺絲						
25-14	E3183-4HA0-0000	COVER,RIGHT LEVER	1	上蓋						
25-15	E3188-5EA0-0000	WASHER	1	墊片						

26.BUMPER,FOOTREST BAR




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
26		BUMPER, FOOTREST BAR								
26-1	E0700-FIA0-0000	FOOTREST BAR	2	置腳踏板固定板						
26-2	I7507-FIA0-0000	SCREW,HEXAGON HEAD WITH WASHER(M8×16)	8	六角螺絲附墊圈						
26-3	I5616-08200	NUT,FLANGE CHECK(M8)	2	凸緣防鬆螺帽(M8)						
26-4	I0149-06823	SCREW,BUTTON HEAD	8	扁圓頭螺絲						
26-5	E0400-FIC0-0000	BUMPER ASSY.	1	前防護桿總成						
26-5-1	E0401-FIC0-0000	PLUG,BUMPER	2	防護桿塞						
26-6	E0410-FIC0-0000	REAR BAR ASSY.	1	後防護桿總成						
26-7	I0105-08040	BOLT ,FLANGE (M8×40)	2	凸緣螺栓(M8×40)						
26-8	E0411-FIC0-9000	REAR PACK	1	後置物架						
26-9	E0117-9EA0-0000	SCREW,BUTTON HEAD (M6×18)	6	扁圓頭螺絲						
26-10	E0402-9FA0-0000	COLLAR, BUMPER	2	防護桿套筒						
26-11	I5611-06200	NUT,SPRING	4	彈簧螺帽						
26-12	I0149-08016	BOLT ,FLANGE (M8×16)	10	凸緣螺栓(M8×16)						
26-13	I9901-08100	SPRING WASHER	4	彈簧墊圈						
26-14	F4001-FIC0-0000	CARRIER COVER REAR	1	後置物架上承板						
26-14-1	C1501-FIB0-0000	FOAM-RUBBER STICK	5	橡膠海棉條						
26-14-2	H7113-9FB0-0000	STICKER ,PACKAGE	1	置物架貼紙						

27.REAR WEHEEL AXLE




ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
27		REAR WHEEL AXLE								
27-1	D0100-FIC0-0000	DRIVE CHAIN ASSY.	1	鏈條(520H×80目)						
27-2	D0101-FIA0-1000	PROTECT COVER	1	軸承座防護蓋						
27-3	D2301-FIA0-0000	REAR AXLE	1	後輪軸						
27-4	D0110-FIA0-0000	SPROCKET HOLDER,REAR ASSY.	1	後鏈齒輪固定座總成						
27-4-1	D0111-FIA0-0000	SPROCKET HOLDER,REAR(34T)	1	後鏈齒輪固定座						
27-4-2	D1111-FIA0-0000	GEAR(520×34T)	1	齒輪						
27-4-3	D2706-9EA0-0000	STUD(M10)	4	緊配螺栓						
27-4-4	I5611-10200	NUT,HEXAGON CHECK(M10)	4	六角防鬆螺帽						
27-5	D2302-FIA0-0000	NUT REAR WHEEL AXLE(M28×1.5)	2	後輪軸螺帽						
27-6	D0120-FIA0-0000	ADJUSTER, CHAIN	1	鏈條調整器						
27-7	I0149-08016	FLANGE BOLT(M8×16)	7	凸緣螺栓(M8×16)						
27-8	D0102-FIA0-0000	DRIVE CHAIN COVER	1	鏈條防護蓋						

28.STEERING



ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
28		STEERING								
28-1	E3200-FIC0-0000	SHAFT ASSY., STEERING	1	轉向桿總成						
28-2	E3201-FIA0-0000	OIL LINER	2	轉向桿含油襯套						
28-3	E3204-FIA0-0000	O-RING (W2.4×d14.8)	2	O型環(w2.4×d14.8)						
28-4	I5611-10200	NUT,FLANGE CHECK (M10)	7	凸緣防鬆螺帽(M10)						
28-5	I9900-25019	COTTER PIN(3/32"×3/4")	7	開口銷						
28-6	E0258-FIA0-1000	STEERING TIE-ROD ASSY,LEFT	1	轉向拉桿(左)						
28-6-1	E0251-FIA0-1000	BOLT,STUD	1	雙頭牙螺栓						
28-6-2	E0252-5EA0-0000	NUT(R)	1	螺帽(右)						
28-6-3	E0253-5EA0-0000	NUT(L)	1	螺帽(左)						
28-6-4	E0255-FIA0-1000	UNIVERSAL JOINT(L)	1	萬向接頭(左)						
28-6-5	E0256-FIA0-1000	UNIVERSAL JOINT(R)	1	萬向接頭(右)						
28-7	E0205-FIA0-1000	KNUCKLE, LEFT	1	前輪轉向軸(左)						
28-7-1	I6600-06000	GREASE VALVE	1	黃油嘴(1/4")						
28-8	E0215-FIA0-1000	KNUCKLE, RIGHT	1	前輪轉向軸(右)						
28-8-1	I6600-06000	GREASE VALVE	1	黃油嘴(1/4")						
28-9	E0211-9FA0-0000	SLEEVE	2	含油套筒						
28-10	E0203-9FA0-0000	CAP	4	封蓋						
28-11	I0102-10105	FLANGE PIN HOLE BOLT(M10×105)	2	凸緣銷孔螺栓						
28-12	E0209-5EA0-0000	CAP, GREASE VALVE	2	黃油嘴蓋						
28-13	E3209-FIA0-0000	OIL SEAL(ψ31.8×37.8×4)	2	油封						
28-14	E3202-FIA0-0000	HOLDER, STEERING SHAFT	2	轉向桿固定環						
28-15	E3203-FIA0-0000	FIX PLATE, STEERING SHAFT	1	轉向桿固定片						
28-16	I0020-08060	BOLT,HEXAGON HEAD(M8×60)	2	六角螺栓(M8×60)						
28-17	E3210-FIA0-0000	HOLDER, STEERING SHAFT PRESSED PLATED	1	轉向桿固定環壓板						
28-18	E3208-FIA0-0000	STEERING , COLLAR	2	固定環隔筒						
28-19	E0259-FIA0-1000	STEERING TIE-ROD ASSY,RIGHT	1	轉向拉桿(右)						
28-19-1	E0251-FIA0-1000	BOLT,STUD	1	雙頭牙螺栓						
28-19-2	E0252-5EA0-0000	NUT(R)	1	螺帽(右)						
28-19-3	E0253-5EA0-0000	NUT(L)	1	螺帽(左)						
28-19-4	E0255-FIA0-1000	UNIVERSAL JOINT(L)	1	萬向接頭(左)						
28-19-5	E0256-FIA0-1000	UNIVERSAL JOINT(R)	1	萬向接頭(右)						


29.ELECTRICAL EQUIPMENT



ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
29		ELECTRICAL PARTS								
29-1	C2100-FIC0-9000	MAIN WIRE ASSY.	1	主配線						
29-1-1	C2010-FIA0-0000	FUSE (10A)	1	保險絲						
29-2	C2101-FIA0-0000	POSITIVE HIGHT PRESSURE CABLE	1	正極高壓導線						
29-3	C2102-FIA0-1000	NEGATIVE LOW PRESSURE CABLE	1	負極高壓導線						
29-4	C1500-FIA0-0000	BATTERY	1	電瓶						
29-5	C1501-9FA0-0000	FOAM RUBBER STRIP	2	電瓶海棉						
29-6	C1502-9FA0-0000	RUBBER CLAMP, BATTERY(89L)	1	電瓶固定帶						
29-7	C501A-5PA0-0000	MAIN SWITCH ASSY.	1	主開關總成						
29-7-1	C5010-9FA0-0000	MAIN SWITCH	1	主開關						
29-7-2	C5011-FIC0-0000	FAUCET LOCK	1	龍頭鎖						
29-8	C5201-FIC0-0000	LEVER HOLDER ASSY	1	左把手開關						
29-9	I8556-06016	SCREW WITH WASHER(M6×16)	1	盤頭螺絲附墊圈						
29-10	I3402-06015	WASHER	4	墊圈						
29-11	C830A-5PA0-0000	FLY RELAY ASSY.	1	閃光器						
29-11-1	C8302-EGA0-0000	FIXER RUBBER, FLY RELAY	2	閃光器固定橡膠						
29-12	H3936-5AA0-0000	WIRE CLAMP	1	線束帶						
29-13	H9020-FIA0-0000	TOOL PACK	1	工具包						
29-14	H9021-9FA0-0000	TOOL PACK CLAMP	1	工具包固定束帶						
29-15	C8110-5BA0-E000	HORN	1	喇叭						
29-16	I0020-05024	BOLT(M5×24)	1	螺栓						
29-17	I8556-06012	SCREW WITH WASHER	1	盤頭螺絲附墊圈						
29-18	I8501-5BA1-0000	BOLT,BROKENABLE	2	斷頭螺絲						
29-19	C0410-V30-9001	C.D.I. UNIT ASSY.	1	CDI . UNIT						
29-20	C0510-V30-0000	IGNITION COIL ASSY.	1	點火線圈						
29-21	C1600-B00-9000	RECTIFIER & REGULATOR	1	整流器						

ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
29		ELECTRICAL PARTS								
29-22	C1850-V30-0000	PTC CONTROLLER	1	PTC控制器						
29-23	C5850-A04-0000	STARTER RELY ASSY.	1	起動開關組						
29-24	C576A-V30-0000	LIGHT CONTROLLER	1	燈號控制器						
29-25	I8557-06012	SCREW ,WITH WASHER(M6×12)	1	盤頭螺絲附墊圈						
29-26	I2140-60001	WASHER	2	高壓線圈墊片						
29-27	I2020-60000	NUT,HEX-FINE	2	起動開關組螺帽						
29-28	I0153-06839	SCREW	2	螺絲						
29-29	C3401-FIC0-0000	FRONT TURN LAMP ASSY.(RIGHT)	1	右前方向燈組						
29-29-1	F1231-FIC0-0000	BULB	1	燈泡						
29-30	I2020-40001	NUT,NYLON(M4)	4	尼龍螺帽						
29-31	C3451-FIC0-0000	FRONT TURN LAMP ASSY.(LEFT)	1	左前方向燈組						
29-31-1	F1231-FIC0-0000	BULB	1	燈泡						
29-32	F1240-5FA0-0000	REAR TURN LAMP ASSY.(LEFT)	1	左後方向燈組						
29-32-1	F1231-5FA0-0000	BULB	1	燈泡						
29-33	F1230-5FA0-0000	REAR TURN LAMP ASSY.(RIGHT)	1	右後方向燈組						
29-33-1	F1231-5FA0-0000	BULB	1	燈泡						
29-34	I2110-50000	SCREW,CROSS RECESS HEAD	2	十字槽盤頭螺絲						
29-35	C720A-FIC0-0000	SPEEDOMETER ASSY	1	碼錶總成						
29-35-1	C7200-FIC0-0000	SPEEDOMETER ASSY	2	碼錶總成						
29-35-2	C7207-FIC0-9000	METER SENSOR	2	碼錶感應組						
29-35-3	I4200-05005-1A	NUT	4	螺帽						
29-36	C7202-5PA0-0000	FUEL METER ASSY.	1	控制儀錶						
29-37	C5850-FIC0-0000	RELAY	1	繼電器						
29-38	C8400-EMA0-0000	BUZZER	1	蜂鳴器						
29-39	I2600-03012	SCREW,FLUSH(M3×12)	2	十字平頭螺絲						

30.PACKING CASE,EXTERNAL



ITEM	PART NO.	NAME	Q'TY	品名	VIN NO	U.S	E.U	A.T	TW	A.S
30		PACKING CASE,EXTERNAL								
30-1	H9500-FIB0-0000	PACKING CASE,EXTERNAL	1	包裝外箱						N/A
30-2	H9900-FIC0-9000	OWNER'S MANUAL	1	使用手冊						N/A N/A
30-3	C3700-5BA0-0000	TAIL LIGHT ASSY.	1	後燈總成						
30-4	I5611-06200-0G	NUT,CHECK	2	防鬆螺帽						
30-5	C510C-FIA0-0000	RUBBER,WASHER	2	橡膠墊片						
30-6	C5030-5PA0-0000	HEAD LIGHT ASSY.	1	頭燈總成						
30-6-1	C5003-5PA0-0000	BULB,HEAD LIGHT	1	頭燈燈泡						
30-7	F1103-BCA0-0000	ADTUST BOLT	1	前燈調整螺栓						
30-8	I0200-06000-0B	LOCK WASHER	1	外齒型墊圈						
30-9	C1501-5FA0-0000	FOAM-RUBBER STICK	2	橡膠海綿條						
30-10	H8100-5BA1-E000	BACK MIRROR ASSY.	1	後視鏡總成(DOT)						
30-10-01	H8110-5BA1-E000	BACK MIRROR,RIGHT	1	右後視鏡						
30-10-02	H8120-5BA1-E000	BACK MIRROR,LEFT	1	左後視鏡						