

**river**

iPet · i10 · 艾娃

English / 中文

Play iPet·i10·艾娃  
English Manual / 中文说明书

1. Locating the controls

2. Key Definition

1.	Power/Pause Key	P	Power On / OFF(Long key)
		P	Play / Pause (Short key)
2.	4Direction Key	Up	Vol. + / Up Side move
		Down	Vol.- / down Side move
		<	REW / Seek
		>	FF / Seek/Select
3.	Mode Key	M	Mode In / Mode Out / Hold
4.	Head Touch	⊙	Touch Point
5.	Belly Touch	⊙	Touch Point
6.	Reset		

3. Main Menu

1. Puppy Mode GUI

- Normal Stage. - Normal Stage.
- Sleepy Stage. - Touch head point more than 3 times.
- Happy Stage. - Touch belly point more than 3 times.
- Surprise Stage. - Earphone In. - USB In.
- Hold. - Hold
- Hungry Stage. - Low Battery.

3. Main Menu

2. Mix Mode GUI

3. Music Mode GUI

EQ Repeat

Play/Pause Mode

Volume

Current File No.

Total File No.

Battery Level

Music Title

Play Time

Total Time

3. Main Menu

4. Setting

Equalizer	Normal / Classic / Jazz / Pop / Rock
Repeat	Normal / Repeat One / Repeat All / Shuffle
Puppy UI	Puppy / Mix
Puppy Sound	On / Off
Vibration	On / Off
Language	English / S-Chinese / T-Chinese / Japanese / Korean
Backlight	3sec / 5sec / 10sec / 30sec / 1min / 3min / Always on
Auto Off	1min / 2min / 3min / 5min / 10min / Off
Information	Firmware-Version / Memory

4. Battery Charging

- Connect the i10 into a PC using USB cable.
- Recharging will be process with Battery Icon waving.
- When recharge complete, the happy stage puppy GUI turn on.(About 3 hours need for full charge.)

5. File Download/ Upload

- Connect the device to your PC using USB Cable. And PC recognizes the device as a mass storage.
- Using mouse right button and make file copy and paste.
- File drag and drop is also possible.

6. Notice for the product

- When the set volume level is more than 30,if power off and than power on,the set volume level will be 30.

7. Product Spec

Memory size	2GB/4GB/8GB
Display Size	OLED(96x64)
Size(HeightXWidthXThickness mm)	38x61x34
Weight(g)	30g
Robot Function	<ul style="list-style-type: none"> <li>GUI/ Dog Face: 6 Mode</li> <li>Touch: 2 Point</li> <li>Vibration: YES</li> <li>Dog's Sound: YES</li> <li>Channel: Right, Left</li> </ul>
Audio	<ul style="list-style-type: none"> <li>Frequency range: 20Hz-20KHz/±3dB</li> <li>SNR / THD: ≥ 90dB</li> <li>Head Phone Impedance: 16Ω</li> <li>Speaker Output: Mono</li> </ul>

7. Product Spec

Digital Audio File Support	File type: MP3, WMA
	Bit Rate: MP3: 8Kbps-320Kbps / WMA: 8Kbps-320Kbps
Power supply	<ul style="list-style-type: none"> <li>Charging: 3 Hours</li> <li>Battery type: Li-on battery</li> <li>Playing time: 15 Hrs with MP3 128Kbps</li> <li>F/W UPGRADE: YES</li> <li>VOLUME: 40 Level</li> <li>FOLDER: YES</li> <li>PLAYLIST: YES</li> <li>MASS STORAGE: YES</li> <li>NAVIGATION: YES</li> <li>EQ: Normal, Classic, Jazz, Pop, Rock</li> <li>PLAY MODE: Normal, Repeat One, Repeat All, Shuffle</li> </ul>

7. Product Spec

	PC INTERFACE	USB 2.0 High Speed
ACCESSORIES	Manual	YES
	Earphone	YES
	Neck Strip	YES
	USB Cable	YES

1. 识别控制按键

2. 按键功能说明

1.	电源/暂停按键	P	电源开启 / 关闭(长按)
		P	播放 / 暂停 (短按)
2.	导航键	上	Vol. + / 向上
		下	Vol. - / 向下
		<	快退
		>	快进 / 选择
3.	模式按键	M	模式进入 / 退出 / 锁定
4.	头部触摸	⊙	触点
5.	腹部触摸	⊙	触点
6.	重置		

3. 主菜单

1. 小狗模式

- 普通状态. - 普通状态.
- 睡眠状态. - 触摸头部触点超过3次.
- 快乐状态. - 触摸腹部触点超过3次.
- 惊讶状态. - 耳机插入. - USB线插入.
- 锁住状态. - 锁住状态.
- 饥饿状态. - 低电量状态.

3. 主菜单

2. 混合模式

3. 音乐模式界面

EQ Repeat

播放/暂停模式

音量

当前文件编号

总文件编号

电池电量

音乐标题

当前播放时间

总播放时间

3. 主菜单

4. 设置

音效模式	普通 / 古典 / 爵士 / 流行 / 摇滚
重置设置	普通模式 / 单曲循环 / 全部循环 / 随机播放
小狗UI	小狗 / 混合
小狗声音	启用 / 关闭
振动	启用 / 关闭
语言	英语 / 简体中文 / 繁体中文 / 日文 / 韩语
背光	3秒 / 5秒 / 10秒 / 30秒 / 1分 / 3分 / 长亮
自动关机	1分钟 / 2分钟 / 3分钟 / 5分钟 / 10分钟 / 关闭
产品信息	固件-版本 / 容量

4. 电池充电

- 使用USB线将i10与电脑相连接。
- 充电电池图标将变成摇摆不定的状态。
- 当充电完成后，将自动快乐状态的小狗模式。（需要约3小时完成充电）

5. 文件下载 / 上传

- 使用USB线将设备与电脑相连接。
- 电脑识别并显示为存储设备。
- 使用鼠标右键按钮，将文件复制和粘贴。
- 将文件拖放到添加的驱动器中。

6. 注意事项

- 音量设置为30以上状态时，将电源关闭再启动后，音量回到当前30设置值。

7. 产品规格

内存大小	2GB/4GB/8GB
屏幕大小	OLED(96x64)
产品大小(高X长X宽 mm)	38x61x34
重量(g)	30g
变化表情	6种模式
触摸	2个部位
振动	是
小狗叫声	是
声道	左, 右
频率范围	20Hz-20KHz/±3dB
信噪比	≥ 90dB
耳机输出	16Ω
喇叭输出	单声道

7. 产品规格

支持文件格式	文件格式: MP3, WMA
	比特率: MP3: 8Kbps-320Kbps / WMA: 8Kbps-320Kbps
电源	<ul style="list-style-type: none"> <li>充电: 3个小时</li> <li>电池类型: 锂电池</li> <li>播放时间: 15个小时 MP3 128Kbps</li> <li>软件升级: 是</li> <li>音量: 40 Level</li> <li>文件夹: 是</li> <li>文件搜索: 是</li> <li>可移动磁盘: 是</li> <li>文件浏览: 是</li> <li>音效模式: 普通 / 古典 / 爵士 / 流行 / 摇滚</li> <li>重置设置: 普通模式 / 单曲循环 / 全部循环 / 随机播放</li> </ul>

7. 产品规格

	高速USB数据传输	USB 2.0 High Speed
配件	说明书	有
	耳机	有
	挂绳	有
	USB 数据线	有

产品内有有害物质信息 (i10)

零件项目	有害物质或元素					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr6+)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
LCD显示	○	○	○	○	○	○
电子产品	×	○	○	○	○	○
包装类	○	○	○	○	○	○
结构部品	○	○	○	○	○	○
辅料	○	○	○	○	○	○

○: 部品中有有害物质含量在(含RoHS标准、RoHS指令)  
 X: 部品中有有害物质含量超过(含RoHS标准、RoHS指令)  
 \*注: EU RoHS指令(2002/95/EC)禁止以下所列物质在电气、电子设备中使用  
 1. 多溴联苯类(PBB) 2. 多溴二苯醚类(PBDE)  
 2. 在商品化的产品中,含有有害物质(含RoHS指令)的含量不得超过以下所列的限制:  
 \*上述有害物质限制,不超过中国有害物质限制法所允许的范围。