



Register your product and get support at
www.philips.com/welcome

DS7550

Quick start guide English
快速入门指南 中文



PHILIPS



ENGLISH

GB

Important safety instructions

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with dry cloth.
- 7 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 8 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 9 Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 10 Only use attachments/accessories specified by the manufacturer.
- 11 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 12 Unplug this apparatus during lightning storms or when unused for long periods of time.

- 13 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- 14 Apparatus shall not be exposed to dripping or splashing.
- 15 Do not place any sources of danger on the apparatus (e.g. liquid filled objects, lighted candles).
- 16 This product may contain lead and mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal and recycling information, please contact your local authorities or the Electronic Industries Alliance; www.eiae.org.
- 17 Your product contains batteries covered by the European Directive 2006/66/EC, which cannot be disposed of with normal household waste. Please inform yourself about the local rules on separate collection of batteries. The correct disposal of batteries helps prevent potentially negative consequences on the environment and human health. Always bring your product to a professional to remove the built-in battery.
- 18 Where the Mains plug is used as the disconnect device, the disconnect device shall remain readily operable.



中文

ZH-CN

重要安全说明

- 1 阅读这些说明。
- 2 保留这些说明。
- 3 注意所有警告。
- 4 遵循所有说明。
- 5 不要在靠近水的地方使用本设备。
- 6 只能使用干布进行清洁。
- 7 不要堵塞任何通风口。按照制造商的说明进行安装。
- 8 不要在任何热源附近安装，如散热器、蓄热器、炉具或其它发热设备（包括扩音器）。
- 9 防止电源线被踩踏或挤夹，特别是在插头、电源插座和设备电源线出口位置。
- 10 仅使用制造商指定的附件/配件。
- 11 仅使用制造商指定或随设备销售的手推车、支座、三脚架、支架或桌台。使用手推车时，请小心移动载有产品的手推车，以避免翻倒造成伤害。
- 12 在雷电天气期间或长期不用的情况下，请拔下本设备的电源插头。
- 13 所有维修均应由合格的维修人员来执行。设备有任何损坏时，如电源线或插入损坏，液体溅到或物体落到设备上，设备淋雨或受潮，无法正常运行，或者跌落，均需要进行维修。
- 14 切勿将本设备暴露在漏水或溅水环境下。
- 15 不要将任何危险源放在设备上（例如装有液体的物体、点燃的蜡烛）。

- 16 本产品可能含铅或汞。出于环境考虑，可能需要按规定处理这些材料。有关弃置或回收的信息，请联系当地管理部门或电子工业联盟：www.eiae.org。
- 17 该产品含有符合欧洲指令 2006/66/EC 的电池，不能与一般的生活垃圾一同弃置。请熟悉当地有关单独收集电池的规章制度，因为正确弃置将有助于避免对环境及人类健康造成负面影响。如需拆除内置电池，请务必送交专业人员处理。
- 18 将电源插头用作断开设备时，该断开设备应可以随时使用。

The type plate is located under the foot stand of the apparatus.

型号铭牌位于本设备支架背面。

Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

不可将电池置于高温环境，如阳光直射处、明火或类似环境。

1 X certified AC/DC adapter Brand name: PHILIPS,

Model No.: OH - 1028A0903000U-CCC,

Input: 100-240V~50/60Hz 800mA MAX

Output: 9V = 3A

1 X 认证 AC/DC 变压器商标: PHILIPS,

型号: OH - 1028A0903000U-CCC,

输入: 100-240V~50/60Hz 800mA MAX

输出: 9V = 3A

产地: 中国广东

部件名称 Name of the Parts	有毒有害物质或元素 Hazardous/Toxic Substance					
	铅 (Pb) (Lead)	汞 (Hg) (Mercury)	镉 (Cd) (cadmium)	六价铬 (Chromium 6+)	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
Housing 外壳	0	0	0	0	0	0
Loudspeakers 喇叭单元	0	0	0	0	0	0
PWBs 电源板组件	X	0	0	0	0	0
Accessories (Remote control & cables) 附件 (遥控器、电源 线、连接线)	X	0	0	0	0	0

0: 表示该有毒有害物质在该部件所有均质材料中的含量均在SJ/T11363 - 2006 标准规定的限量要求以下。
0: Indicates that this toxic or hazardous substance contained in all of the homogeneous materials for this part is below the limit requirement in SJ/T11363 - 2006.

X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出SJ/T11363 - 2006 标准规定的限量要求。
X: Indicates that this toxic or hazardous substance contained in at least one of the homogeneous materials used for this part is above the limit requirement in SJ/T11363 - 2006.

10 环保使用期限 Environmental Protection Use Period
This logo refers to the period (10 years)
电子信息产品中含有的有毒有害物质或元素在正常使用的条件下不会发生外泄或突变，电子信息产品使用期间该电子信息产品不会对环境污染或对人体、财产造成严重损害的期限。

This logo refers to the period (10 years) during which the toxic or hazardous substances or elements contained in electronic information products will not leak or mutate so that the use of these [substances or elements] will not result in any severe environmental pollution, any bodily injury or damage to any assets.

Meet Philips at the Internet
http://www.philips.com/welcome

