







Register your product and get support at
www.philips.com/welcome

HTS2201



Quick Start



PHILIPS





Video cable




FM Antenna





1






3




4







2




1




2

3




HOME THEATER




4

5





HOME THEATER





3



DISC



FM






MIC





USB 



www.philips.com/support



Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V.
or their respective owners.
2010 © Koninklijke Philips Electronics N.V. All rights reserved.
sgsna_1108/93_v1



Be responsible
Respect copyrights

