
PHILIPS

## Quick Start Guide






AC power cord



5 Press **PROG/CLOCK** to confirm the time.






## Тір

Detailed playback features and additional functions are described in the accompanied owner's manual. Notes for the remote control: - First, select the source you wish to control by pressing one of the source select keys on the remote control (CD or TUNER, for example).

- Then select the desired function (  $\triangleright$ II,  $\mid \triangleleft$ ,  $\triangleright$ I for example).

## Playing iPod using the dock

- Select the correct dock adaptor supplied, then snap the adaptor into the dock connector (iPod) to provide a snug fit for the player.
  - The indication on the adaptor's back fits specific iPod player.
- 2 Correctly place your player in the dock connector.
- 3 Connect the cables of the dock to **DOCKING IN** jacks on the main set correspondingly.
- 4 Press **SOURCE** repeatedly or on the set (or **DOCK** on the remote) to select DOCK source.
  - The connected player will play automatically.
  - The iPod battery will be charged in either normal standby mode or power-on mode.



## Тір

Refer to the user manual supplied for detailed descriptions of "Compatible portable players", "Selecting the correct dock adaptor", "Installing the dock adaptor", and the important notes for dock operation.



© Royal Philips Electronics N.V. 2008 All rights reserved.

