

Continue

Rinnai tankless water heater r94ls manual

How do you reset a rinnai tankless water heater.

Enjoy an endless supply of hot water with this high efficiency non-condensing Low Nox model natural gas tankless water heater from Rinnai. Only the size of a small suitcase, the RLX94iN is compact, easy-to-install, reliable and perfect for indoor locations. Rinnai products provide peace of mind with warranties that surpass the competition. Energy Factor: 0.82Uniform Energy Factor: 0.82 Warranty 12 yrs on Heat Exchanger/ 5 years on Parts/ 1 Year on Labor 10,300 BTU (minimum)192,000 BTU (maximum) Indoor Search below for product documents. If you can’t find what you need, contact Rinnai. Select Product Category Commercial Heating Commercial Water Heating Residential Boiler Residential Heating Residential Water Heating Venting & Accessories Please select a product category above to display all brochures, case studies, certifications, energy guides, manuals, spec sheets, tech sheets, and warranties for that category or model. New Parts on R75LS and R94LS TECHNICAL BULLETIN 40 Rev A While most components of the new LS series R75 and R94 models are interchangeable with the previous R75 and R85 models, there are some parts that are unique and thus not interchangeable. Please refer to the list of new LS series parts, along with the exploded view drawing which identifies the location of these new parts on the product. A Rinnai America part number (RAP number) has been assigned to the new parts. This new part numbering system consists of a nine digit, all numerical, part number. All new parts and all kitted parts will begin using this new numbering system. Another significant change is the release of a number of kitted components (gas valve, heat exchanger, etc.). These kits will include the major component, along with any gasket, O-ring, installation instructions, etc, that may be needed in the completion of a repair. View Description Item Number Suggested To Inventory R94LSiN R94LSiP R75LSiN R75LSiP R94LSeN R94LSeP R75LSeN R75LSeP 001 Main Body (FFU) 109000010 1 1 1 1 001 Main Body (W) 109000011 1 1 1 1 002 Wall Mounting Bracket (FFU) 109000024 1 1 1 1 004 Connection Reinforcement Panel 109000023 1 1 1 1 1 1 1 1 006 Front Panel 109000012 1 1 1 1 006 Front Panel 109000013 1 1 1 1 009 Remote Controller Ass'y MC-91-1US-S- 1 1 1 1 FLVA 010 Remote Controller Bracket 103000011 1 1 1 1 015 Rain Hood 109000026 1 1 1 1 017 Screw Cover Assy 109000022 2 2 2 2 2 2 2 2 100 Gas Control Kit 104000021 * 1 1 1 1 1 1 1 1 103 Burner Unit Assy (LPG) 106000011 1 1 1 1 103 Burner Unit Assy (NG) 106000012 1 1 1 1 110 Manifold Assembly (LPG) 106000013 1 1 1 1 110 Manifold Assembly (FF-NG) 106000014 1 1 110 Manifold Assembly (W-NG) 106000015 1 1 114 Combustion Chamber Sightglass Plate 106000016 1 1 1 1 1 1 1 1 116 Electrode Kit 104000023 * 1 1 1 1 1 1 1 1 117 Flame Rod Kit 104000022 * 1 1 1 1 1 1 1 1 119A Sparker Bracket 106000018 1 1 1 1 1 1 1 1 125 Fan Assembly Kit 104000024 * 1 1 1 1 125 Fan Assembly Kit 104000026 * 1 1 1 1 Rinnai Corporation • 103 International Drive • Peachtree City, GA 30269 • Toll-Free: 1-800-621-9419 • Fax: 678-829-1666 • www.rinnai.us 1 TB-40 Rev A New Parts on R75LS and R94LS View Description Item Number Suggested To Inventory R94LSiN R94LSiP R75LSiN R75LSiP R94LSeN R94LSeP R75LSeN R75LSeP 135 Air Inlet Box Assembly 108000013 1 1 1 1 135 Flue Outlet 108000012 1 1 1 1 138 Seal Packing 109000017 1 1 1 1 139 Air Inlet Duct 108000014 1 1 1 1 143 Heat Exchanger Assembly Kit 104000030 * 1 1 143 Heat Exchanger Assembly Kit 104000032 * 1 1 143 Heat Exchanger Assembly Kit 104000031 * 1 1 143 Heat Exchanger Assembly Kit 104000033 * 1 1 144 Flue Connection Assembly 108000015 1 1 1 1 144 Flue Connection Assy - Male (optional) 108000016 1 1 1 1 145 O-ring 108000017 1 1 1 1 146 O-ring 108000018 1 1 1 1 147 Pipe Seal 108000019 1 1 1 1 148 Cap 108000020 1 1 1 1 401 Water Flow Servo & Sensor Kit 104000028 * 1 1 1 1 401 Water Flow Servo & Sensor Kit 104000029 * 1 1 1 1 405 Plug Band 109000018 1 1 1 1 1 1 1 1 410 Plug Band (small) 109000019 1 1 1 1 1 1 1 1 413 Cover 109000020 1 1 1 1 1 1 1 1 700 PCB Kit 104000026 * 1 1 1 1 700 PCB Kit 104000027 * 1 1 1 1 702 PCB cover - side 105000015 1 1 1 1 702 PCB cover - side 105000016 1 1 1 1 703 PCB cover - front 105000017 1 1 1 1 1 1 1 1 707 High Tension Cord 105000019 1 1 1 1 1 1 1 1 709 Thermistor - Heat Exchanger 105000020 1 1 1 1 1 1 1 1 713 Anti Frost Heater (120V) 105000022 1 1 1 1 713 Anti Frost Heater (120V) 105000023 1 1 1 1 715 Valve Heater (120V) Assembly 105000024 1 1 1 1 1 1 1 1 Rinnai Corporation • 103 International Drive • Peachtree City, GA 30269 • Toll-Free: 1-800-621-9419 • Fax: 678-829-1666 • www.rinnai.us