

I am not robot!

Saitek x52 pro calibration.



3 When the Welcome screen appears, click Next to continue. 4 After reading the Disclaimer, select the I accept the terms of the Disclaimer option and click Next to continue. 5 At the Driver Setup screen, if you havenÕt already done so, plug in your controller and click on Next. 6 At the Driver Setup screen, click Next to test your controller. 7 When the Saitek Controller screen appears, try out all your controllerÕs buttons and controls to show that it isworking properly. When you have finished, click OK. For more information on the use of the control panel, pleasesee the Maintaining your Controller Settings section of this manual.Page 3 7 ENGLISH 6 7 When the Controller Properties screen appears, click Next to view the Test screen. 8 Now try out all your controllerÕs buttons and controls to show that it is working properly. When you have finished, clickOK. 9 At the Programming Software screen, select Typical User and click Next.

10 At the Registration screen, select Register and follow the on-screen instructions or select Register Later and click Next. 11 Click on Finish to complete the installation. B) Drivers and Programming Software For Advanced Users 1 Follow points 1 Ð 8 of the install procedure in A), then at the Programming Software screen, select Advanced Userand click Next. 2 At the Programmable Controller Drivers screen, click Update and follow the on-screen instructions. 3 Then at the Installation of programming software successful screen, click Next. 4 At the Registration screen, select Register and follow the on-screen instructions or select Register Later and clickNext. 5 Upon completion of the installation, you have the option to Run Profile Editor, which will give you a view of the 3Dprogramming environment. If you do not wish to see the Profile Editor at this point, just uncheck the box and click onFinish to complete the installation. INSTALLATION FOR USERS OF WINDOWS¨ 98 AND MEA) Drivers Only For Typical Users 1 With your computer switched on, close down any programs that are currently running and insert the Saitek SmartTechnology CD into your CD-ROM drive. 2 When the Introduction Screen appears, click Install Software to continue. If the CD does not run automatically, selectStart from the Windows¨ Taskbar, then Run and type D:\Setup.exe (where D: is your CD drive) and click OK. 3 When the Welcome screen appears, click Next to continue. 4 After reading and accepting the Disclaimer, click Next to continue. Note: For your controller to work, you must have a minimum of Microsoft¨ DirectX¨ 8.1 installed on your computer. The B) Drivers and Programming Software For Advanced Users 1 Follow points 1 Ð 7 of the install procedure in A), then at the Software Setup screen, select Install the SSTProgramming Software and click Next. 2 In the following Software Setup screen, click Next and follow the on-screen instructions. At this point you will beasked to install such features as the Saitek Magic Mouse, HID-compliant mouse, Saitek Magic Keyboard andHID Keyboard Device (these are what XP calls the various elements of your Saitek controller). Continue to click onNext and Finish to accept the installation until the Registration screen appears. 3 At the Registration screen, select Check this box to register now and follow the on-screen instructions, or do notselect this option and register later. 4 Upon completion of the installation, you have the option to Run Profile Editor, which will give you a view of the 3Dprogramming environment. If you do not wish to see the Profile Editor at this point, just uncheck the box and click onFinish to complete the installation. INSTALLATION FOR USERS OF WINDOWS¨ 2000 A) Drivers Only For Typical Users 1 With your computer switched on, close down any programs that are currently running and insert the Saitek SmartTechnology CD into your CD-ROM drive.

2 When the Introduction Screen appears, click Install Software to continue. If the CD does not run automatically,select Start from the Windows¨ Taskbar, then Run and type D:\Setup.exe and click OK - where D:\ is letter of yourCD-ROM drive. 3 When the Welcome screen appears, click Next to continue. 4 After reading the Disclaimer, select the I accept the terms of the Disclaimer option and click Next to continue. 5 At the Device Driver Installation screen, click on Next and follow the on-screen instructions. 6 When prompted, plug your controllerÕs USB connector into your computer, then click on Configure. X52 manual(ok) (24/11/04) 2004.12.22 9:05 PM Page 6 This manual is related to the following products: Saitek's X52 defines precise flight simulator operation, employing a multifunction LCD for easy access to an astounding 282 programmable commands. Coordinate your flight plan with clock and stopwatch function, plus an adjustable handle to accommodate a wide range of hand sizes. Precision Centering Mechanism A highly accurate centering mechanism ensures the joystick will easily return to the neutral position whenever you need it to. Non-contact technology on the X and Y axes, along with constant spring force, enhance control while increasing durability.