
Manual
Laser Wireless Earphones
AO-AB300



WHAT'S IN THE BOX:

- 1 x Laser TWS Earphone Set
- 1 x Charging Case (USB-C)
- 1 x USB-A to USB-C Charging Cable
- 1 x Silicone Earbud Set

SPECIFICATIONS:

Bluetooth Version:	5.1
Bluetooth Range:	10 meters
Earphone Battery Capacity (each):	40mAh
Earphone Speaker Impedance:	32Ω ± 15%
Earphone Runtime:	6 hours
Earphone Charge Time:	1 hour
Case Battery Capacity:	320mAh
Case Charge Time:	1.5 hours

PAIRING:


- Take the earphones out of the charging case.
- The earphones will automatically turn on, sync together, and enter pairing mode.
- Open the Bluetooth settings on your device e.g. Smart phone then search for and select AO-AB300.

RE-SYNCING YOUR EARPHONES:

If the 2 earphones are not synced together or enter a disconnected state during use, please follow these instructions to re-sync:

- Press and hold the touch area on each earphone for approx. 3 seconds to turn them off.
- Place both earphones back into the case, close the charging case lid, wait 5 seconds then open the lid, and take the earphones out.
- The earphones should now be re-synced to each other.

OPERATION:



POWER ON / OFF

- Take the earphones out of the case to turn them on.
- Put the earphones back in the case to turn them off.
- Alternatively press and hold the touch area on either earphone for approx. 3 seconds to turn them on/off.

PLAY / PAUSE TRACK

- When listening to audio double tap the touch area on either earphone to play/pause.

PREVIOUS / NEXT TRACK

- When listening to audio press and hold the left earphone for previous track or press and hold the right earphone for next track.

VOLUME

- Tap the left earphone once to decrease the volume or tap the right earphone once to increase the volume.


ANSWER / REJECT / HANG UP CALL

- When there is an incoming call tap either earphone once to answer the call or press and hold for 2 seconds to reject the call.
- Tap either earphone once during a call to hang up.

VOICE ASSISTANT

- Triple tap either earphone to activate connected Smartphones' voice assistant (Siri or Google Assistant).

CHARGING:



Please fully charge the case and earphones before first use.

- To charge the case connect a USB-C cable to the charging port on the bottom of the case. Plug the other end of the cable into a USB wall adapter or a similar powered USB port to begin charging.
- A full case charge will take approx. 1.5 hours.
- To charge the earphones, unplug the USB-C cable from the case and leave the earphones inside. The case will then begin charging the earphones.
- A full earphone charge will take approx. 1 hour.

TROUBLESHOOTING:

Why is sound only coming out of one earphone?

- Make sure both earphones have been charged.
- Follow the instructions outlined in this manual to re-sync your earphones.

Why are the earphones not connecting to my device?

- Pairing is done via Bluetooth.
- Take both earphones out of the charging case and place them next to the device they are being connected to.
- Wait a minute for your Bluetooth device list to update then search for and select AO-AB300.

Why is the sound skipping, pausing, or stuttering when playing audio?

- The maximum wireless range from the earphones to the connected device is 10 meters. If close to or exceeding this distance the sound signal may be affected.
- When handling the earphones i.e. taking them in/out of ears be mindful of the 'Touch Area' on each earphone.

For more helpful guides visit us at YouTube | **LASER**
www.youtube.com/LasercoAu

WARRANTY

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.