Thanks for choosing Sevenoak and congratulations on your purchase of Sevenoak SK-EBH01 Pro Electronic ball head. Before use, please read the instruction manual and follow the instructions.

SK-EBH01 Pro is a specially designed light weight and por table electronic panorama ball head for use with smart phone, action cameras, and light weight DSLRs around 2.0 KG. SK-EBH01 Pro is an easy-to-use time lapse device, users can set different rotating angle and time directly on the device.

SK-EBH01 Pro comes with 1/4" screw thread on the top for mounting camera and comes with 1/4" to 3/8" screw hole at the bottom, so it can be used together with tripod, slider or any other device with 1/4" or 3/8" screw thread.

With SK-EBH01 Pro, users can make their own time lapse videos easily with low budget.

Specifications

Battery capacity: 1200mAh
Charging voltage: DC 5V/1A
Working temperature: -10~45 degree
Standby time: over 50 hours
Max load capacity: 2.0KG (Horizontal)
Max load capacity: 2.0KG (30 degree slope)
Max load capacity: 1.5KG (Vertical)
Max load capacity: 1.5KG (Hang upside down)
Battery charge time: 8 hours
Motor: step motor
Battery life: 6 hours when the load capacity is about 1KG

Warnings

- Please read and follow these instructions, and keep this manual in a safe place.
- Handle the unit with care.
- Clean the unit with a soft, dry cloth.
- Use only parts provided by the manufacturer.
- Make sure everything is secure before proceeding.
- Make sure the item is intact and that there are no missing parts.
- Do not exceed the maximum load capacity.
- All photos are for illustrative purposes only.

Limited One-year Warranty

Sevenoak provides a limited warranty that this product is free from defects in materials and workmanship to the original purchaser under normal use for a period of one (1) year from the original purchase date or thirty (30) days after replaceme nt (the "Warranty Period"), whichever occurs later. Our respon sibility with respect to this limited warranty shall be limited solely to repair or replacement, at its option, of any product which fails during normal consumer use.
To obtain warranty coverage during the Warranty period, contact your place of purchase ("Seller") to obtain a return merchandise authorization ("RMA") number, and return to Seller the defective product along with proof of purchase and the RMA number.

This warranty does not extend to damage or failure which results from misuse, neglect, accident, alternation,abuse, improper installation or maintenance. Except as provided her ein, sevenoak makes neither any express warranties nor any implied warranties, including but not limited to any implied warranty of merchantability or fitness for a particular purpose. This warranty provides you with specific legal rights, and you may also have additional rights which vary from state to state.

© 2016 Sevenoak Inc.Visit us on the web at www.sevenoak.biz

SEVENOAK®




SK-EBH01 Pro

Electronic Ball Head Pro

© 2016 Sevenoak Inc.Visit us on the web at www.sevenoak.biz


Components

1. Angle/duration indicator
2. Rotating time indicator
3. Direction indicator
4. Angle/duration selecting button
5. Rotating time selecting button
6. Start/stop button
7. Clockwise/counter-clockwise buttons




8. USB Port


9. Battery charger indicator




10. Power switch on/off



11. 1/4"-20 screw thread on the top



12. 1/4"-20 to 3/8" screw hole at the bottom




13. Micro USB cable




Start to set


1. Turn the power switch on, when the R.T LED "5' "and Duration LED "15°" are on, means this device is working normally.




2. Duration button means that you can select different angle at your desire. Press Duration button, select an angle (such as 90°) you need, the LED under the angle (such as 90°) will be on. This means that the angle has been set correctly.




3. R.T button means that you can select a time to accomplish the angle you selected. Press R.T button, select a time (such as 5') you need, the LED under the time (such as 5') will be on. This means that the time has been set correctly.




4. Start/stop button means to start or stop the setting you selected. Press Start/stop button, SK-EBH01 Pro starts to work as the setting you selected, press start/stop button again, SK-EBH01 Pro stops working, and in the meantime, the setting you selected will not be saved automatically.




5. When SK-EBH01 Pro stops working (but with poweron), you can set it to run clockwise or anti-clockwise by short pressing Duration and R.T button at the same time.



6. After use, switch the power off, the Duration and R.T LEDs will be off which means the device is off.



Note: When four R.T LED lights blink at the same time, it means battery is low or will be power off soon, you need a 5V/1A Micro USB cable to re-charge the battery.Do not force to rotate the rotating table by hand to avoid damage the motor inside.You can set the device to run 360 degree in 5 minutes, when it comes to 0 degree, press the stop buttom.



jiayz™ 深圳市长丰影像器材有限公司					
产品/零件名称	SK-EBH01 Pro说明书	比例	1：1	版本	V02
工程图号	SK-EBH01 Pro说明书V02	物料描述	128G双铜 双面印刷 虚线压痕 4折页		
物料编号	1F14015SK0098	尺寸/用量	尺寸：386*216mm 1PCS		
制图人/日期	吴蒙蒙/2017/2/20	审核/日期			