EUROVAC

Vacuum Arch
INSTALLATION MANUAL



PRIOR TO INSTALLING MAT RACKS

1. Review packing slip against received material to be sure that all needed parts are on hand for installation.

   If any parts are missing, contact the office

INSTALLING VACUUM PALM ARCH MAT RACK

1. Locate the mat rack along with upper and lower attachment brackets for the mat rack (Figure 1)



Figure 1

2. Secure upper and lower attachments brackets to mat rack as shown using the hardware provided (Figure 2)



Figure 2

3. Align slots in upper and lower attachment brackets with holes in vacuum arch post (Figure 3)
    a. Secure upper and lower attachment bracket to post using hardware provided (Figure 4)

		Figure 3
		Figure 4