SONY®

4-172-376-**31**(2)

立体声耳机

使用说明书

Stereo Headphones

Operating Instructions

©2010

MDR-PQ2

©2010 Sony Corporation Printed in Thailand

A



B



简体中文

立体声耳机

特点

-
-
-

如何使用

本耳机搭配立体声迷你插孔使用。

“right” “left”

“left” **A**

如何调节头带长度（见图 **B**）

提示

规格

/ 30 mm
/ 1000 mW (IEC*) / 1 kHz 24 Ω
/ 100 dB/mW / 10 - 24000 Hz /
1.2 m Y / L
/ 135 g / (1)

* IEC =

注意事项

-
-
-
-
-
-
-
-

Sony

For China Market Only:
制造商： 索尼公司
地址： 日本国东京都港区港南1-7-1
总经销商：索尼（中国）有限公司
地址： 中国北京市朝阳区东三环北路霞光里18号佳程大厦A座25层
原产地： 泰国
出版日期：2010年4月

产品中有毒有害物质或元素的名称及含量

5 35 ○ ×

	Pb	Hg	Cd	Cr VI	PBB	PBDE
	×	○	○	○	○	○
	○	○	○	○	○	○

○ SJ/T11363-2006

× SJ/T11363-2006

A



B



English

Stereo headphones

Features

- Smooth and seamless hanger structure
- Neodymium magnets deliver clear and powerful sound
- Durable flat cord

How to use

These headphones are for use with a stereo mini jack.

Wear the headphone marked “right” on your right ear, and the one marked “left” on your left ear.
There is a tactile dot on the unit marked “left” to distinguish the left side (see fig. A).

How to adjust the headband length (see fig. B)

Hold the top of the headband and the unit to adjust the headband length.

tip
You cannot adjust the headband length by holding the side of the headband.

Specifications

Type: Closed, dynamic (supra-aural) / Driver unit: 30 mm, dome type / Power handling capacity: 1,000 mW (IEC*) / Impedance: 24 Ω at 1 kHz / Sensitivity: 100 dB/mW / Frequency response: 10 – 24,000 Hz / Cord: 1.2 m (47 1/4 in), Y type, flat / Plug: Gold-plated L-shaped stereo mini plug / Mass: Approx. 135 g (4.8 oz), without cord / Supplied accessory: Operating Instructions (1)

* IEC = International Electrotechnical Commission
Design and specifications are subject to change without notice.

Precautions

- Listening with headphones at high volume may affect your hearing. For traffic safety, do not use while driving or cycling.
- Do not subject the headphones to excessive shock.
- Handle the driver units carefully.
- Do not put weight or pressure on the headphones as it may cause the headphones to deform during long storage.
- The earpads and the headband cover may deteriorate due to long-term storage or use.
- Do not leave the jack plug dirty otherwise the sound may be distorted.
- Clean the headphones with a soft dry cloth. Do not blow on the units when cleaning. Do not allow the plug to become dirty, otherwise the sound may deteriorate.
- Do not leave the stereo headphones in a location subject to direct sunlight, heat or moisture.

Optional replacement earpads can be ordered from your nearest Sony dealer.