# SKM Standalone Knock Module Part Number #53116

## **Basic specifications**

## **Inputs**

- Knock sensor input
- Knock window input
- Power supply 8 V

## **Outputs**

- Knock Signal
- Audio

## **Physical**

- Case size 38 x 90 x 25 mm excluding connector
- · Weight 100 grams
- 1 x 13 pin Autosport connector

#### Other information

## Compatibility

- 'hundred series' ECUs M400, M600, M800 and M880 – using ECU Manager software v3.5 and up
- i2 data analysis
- All knock sensors

#### **Related Software**

 Gold Wave Audio Analysis Software for frequency analysis.

#### Download from www.goldwave.com

#### **Accessories**

- · Stereo headphones
- Knock sensor
- SKM tuning loom #61114 (optional)

#### **User Manual**

Download from www.motec.com/downloads




MoTeC's **Standalone Knock Module (SKM)** enables individual cylinder closed loop knock control on our 'hundred series' ECUs. The knock module allows tuners to safely optimise high performance ignition maps.

It is housed in a robust aluminium casing and can be mounted in the vehicle as required. It is wired between the ECU and the knock sensor.

To set up a reliable electronic knock control system it is necessary to determine knock levels accurately and differentiate knock from normal engine noise. MoTeC's Knock Modules use the vehicle's original, factory-fitted knock sensors to detect detonation, improving this detection by reducing the influence of background engine noise using a combination of data gating and frequency filtering.

A competent tuner needs to carry out a frequency analysis to determine the target frequency and knock module settings. This is highly specialised work and therefore the Knock Modules will only be available through authorised dealers that have undertaken specific training.

#### **Dimensions**



## Connector, Pinout and Wiring

#### Connector

Autosport 13 pin mating connector #65041

SKM		Connect to	
Pin	Function	Device/connector	Input
1	Select 0		
2	Select 1		
3	Knock ECU Out	M400/M600/M800/M800	any available AV input, preferable a Lambda sense input
4	Knock Audio Out	3.5 mm stereo connector	tip (left channel)
5	Audio Ground	3.5 mm stereo connector	ring (ground)
6	Sensor 1 Input	knock sensor	signal
7	Sensor 2 Input		
8	Sensor 3 Input		
9	Sensor 4 Input		
10	Shield	knock sensor	shield
	Knock Window	M400/M600	injector8 only
11		M800/M880	any spare ignition or injector output
11		3.5 mm stereo connector	via 100 K $\Omega$ resistor to ring (right channel)
12	8 V	M400/M600/M800/M880	8 V
13	Ground	M400/M600/M800/M880	ground



## SKM Tuning Loom #61114

Optionally MoTeC's SKM Tuning Loom can be used. It is wired with three connectors to connect to the ECU, the knock sensor and the headphones.

Connector 1 Stereo plug				
Pin	Function			
Base	Audio Ground	Connect to		
Middle right channel	Knock Window	stereo headphones		
Tip left channel	Knock Audio Out			

Connector 2					
2 pin DTM Mating connector #68051					
Pin	Function	Connect to knock sensor			
1	Shield	Shield			
2	Knock Signal	Signal			

- Length of the ECU and knock sensor leads is 600 mm
- Length of the audio lead is 1850 mm

Connector 3				
4 pin DTM Mating connector #68054				
Pin	Function	Connect to M400/ M600/M800/M880		
1	Ground	Ground		
2	Knock ECU Out	Any available AV input, preferable a Lambda sense input		
		Any spare ignition or		

injector output

injector8 only

8 V

Note: on M400/M600

Knock

8 V

Window

3

4

## SKM connector

