Tera Synth

Modular Analog Synthesizer



VirSyn Software Synthesizer

Introd	uction5
	Welcome to Tera Synth5
	Features6
Basics	8
	Top bar8
	Interfaces9
	Keyboard Bar9
	Scale
	Keyboard
	Sound Presets
	Arpeggio Presets
	Audio Recordings14
	Audiocopy / SoundCloud14
Synthe	esis15
	Modular Analog Synthesis
	Routing of Modules
	Keyboard
	Oscillator 1
	Oscillator 2
	Oscillator 323
	WaveGuide25
	Ringmodulator27
	Noise Generator
	Subharmonic Oscillator
	Mixer29
	Filter 1 / 2
	Formant Filter
	Amplifier34

Modulation	36
Low Frequency Oscillators (LFO)	36
Standard Envelopes	38
Multi Envelopes	41
Arpeggiator	44
Overview	44
Global Settings	45
Step Matrix Editor	47
Effects	48
Distortion	48
Phaser	49
Delay	49
Chorus	49
Reverb	50
Appendix	51
Troubleshooting	51

Introduction

WELCOME TO TERA SYNTH

Explore new sound spaces with Tera Synth that go beyond the emulation of synthesizer legends. Use the power of analog and digital synthesis combined with new modules for physical modelling. Wireless patching of modules combined with an intelligible modulation routing simplifies the development of new synthesizer designs from scratch. Distortion effect, Delay/Chorus/Phaser and Reverb effects give your sounds the final polishing. Tera Synth gives your music an individual character with its unique fat sound. The well-designed algorithms and the economical modular structure provides you with a comparatively high voice yield. Precise timing with the unique built-in Arpeggiator let you feel the rhythm.

Tera Synth supports Audiobus and Inter-App-Audio for integration with other Music Apps.

With the Apple iPad Camera Connection Kit you can use a CoreMIDI compatible MIDI Keyboard to control Tera Synth from external hardware equipment.

For updated informations about Tera Synth please visit our website at mobile.virsyn.com.

FEATURES

Modular Analog Synthesizer

- Modular synthesizer with free connections between modules.
- 25 Sound Modules.
- 4 Low frequency oscillators.
- 4 Standard ADSR Envelope generators.
- 4 Multi Segment Envelopes with tempo sync.
- 64 time/level segments per envelope.
- Monophonic or polyphonic with 8 voices.
- More than 920 factory presets, unlimited user presets can be shared.
- Chorus with four delay lines.
- 8 pole Analog Phaser.
- Distortion Effect with Tape/Tube simulation.
- Stereo Echo/Delay Effect
- Hi end reverberation unit.

Live

- Play melodies live with the onscreen keyboard. Drag fingers for slides and vibrato.
- With the Apple iPad Camera Connection Kit you can use a CoreMIDI compatible MIDI Keyboard to control Tera Synth.
- Select from dozens of scales and play them with scale optimised keyboard layout.

Full featured programmable Arpeggiator

- Uses programmable sequences with up to 32 steps.
- · Can trigger single notes and chords.
- Unique randomizer generates Arpeggios with 100% usability.
- 32 Arpeggios included, unlimited user arpeggios possible.
- For each step you can program tie, accent, transposition and note order

Global

- · Audiobus compatible (Output).
- Inter App Audio compatible.
- Audio pasteboard for exchange with other Apps
- Exchange user presets with File Sharing in iTunes.
- Support for virtual MIDI input connections.
- MIDI Learn function for parameters.
- Publish recordings online with the SoundCloud audio platform.
- Exchange user presets with File Sharing in iTunes.

Basics

The user interface of Tera Synth is quite simple and is divided into four different main screens:

- Synthesis page for sound generating and processing modules
- Modulation page for modulator source modules
- Arpeggiator page
- Effects page

TOP BAR



Functions from left to right:

- VirSyn Logo opens About box (and can be used as MIDI Panic button)
- SYN Switch to Synthesis page.
- MOD Switch to Modulator page.
- ARP Switch to ARP page for Arpeggiator settings
- FX Switch to Effects page
- Preset name tap to open preset selection for sounds/arpeggios
- Disc icon tap to save preset/arpeggio
- **Dice** tap to generate a new random preset.
- Tempo/Metronome setting opens Tempo/Metronome page*
- REC opens audio recorder page
- **HELP** open help overlay for current page.

^{*}Note that you can enter the tempo also with the "Tempo" knob in the Arpeggiator module on the arpeggio page.

INTERFACES

KEYBOARD BAR



- **Q** If Key Quantize is set: swiping over the keys is constrained to exact tuning (Glissando), otherwise pitch bends continuously (Glide).
- MIDI Sets the MIDI channel Tera Synth is listening for MIDI Notes coming from an external Keyboard or from another App connected via virtual MIDI.
- Scale select the key and the scale used by the keyboard (see below for details)
- Keyboard range Tap to select keyboard range, double tap to size the keyboard.
- HOLD If set all keys tapped remain on until tapped again. Good to hold notes while designing sounds.
- **BKGD AUDIO** If set Tera Synth doesn't stop working if running in the background. This let you for example have a sequencer App in the foreground and Tera Synth working in the background.

Please note that the full keyboard bar with all parameters is only visible in the FX page.

SCALE

If Scale is set to another value than 'Chromatic', notes played on the live keyboard or entered in the sequencer 'snap' to notes allowed by the scale set. The following scales are available:

Chromatic	Chord Major	Algerian
Diatonic Major	Chord (m)	Arabic
Diatonic minor	Chord (6)	Bali Island Pelog
Pentatonic Major	Chord (7)	Byzanthine
Pentatonic minor	Chord (maj7)	Chinese
Blues Major	Chord (maj7+5)	Egyptian
Blues minor	Chord (m7)	Hawaiian
Whole-tone	Chord (sus4)	Hindu
Ionian	Chord (7sus4)	Japanese
Dorian	Chord (dim)	Mongolian
Phrygian	Chord (dim7)	Oriental
Lydian	3rd Interval	Persian
Mixolydian	4th Interval	Ryukyu
Aeolian	5th Interval	Spanish
Locrian		

The base note transposes all live played/sequenced notes if set to another value than 'C'.

KEYBOARD

Tera Synth can be played by either the on-screen keyboard or a CoreMIDI compatible Hardware controller keyboard.

The on-screen keyboard seems to miss a pitch bender / modulation wheel but this functions are there in a more touch screen compatible way:

- Pitch bending is done with moving the fingers left/right. (if "Q" is not set)
- Modulation wheel is simulated by moving fingers up/down.

SOUND PRESETS

The presets in Tera Synth are organised in eight predefined sound categories.

Tap on the preset name in the top bar to open a popup window with a list of all available presets.

Popup window for presets:




Import/Export of sound presets:

The presets are saved as files with the extension ".fxp" and they can be directly accessed within the iTunes File Sharing section of the App. Download the folder "presets" in the App section of the iTunes File sharing. Then you'll find all presets in the subfolders named "Leads", "Bass", and so on. To import a preset just upload the preset files you want to import in the iTunes File sharing section. They will then automatically imported by Tera Synth with the next start of the App.

Save preset:

Tap on the Disc Icon and you'll get the following dialog:




Tap on the category you want this sound to be in and name the preset to your liking.

ARPEGGIO PRESETS

Touch on the "Arpeggio" field to open a popup window listing all preset arpeggios. The first entry is always the arpeggio in the current sound preset since every preset can contain it's own arpeggio. "Arp from preset" is the arpeggio pattern saved inside the current sound preset.

Arpeggio preset popup:



Functions in Arpeggio preset popup:

- Right arrow: window opens where you can rename the pattern
- Edit: use this to delete arpeggios.

To save an Arpeggio pattern tap on the Disc Icon.

AUDIO RECORDINGS

Tap on the record button (red circle) in the top bar to bring up the Audio Recorder popover which let you enter the recorder settings and you can start recording of audio from here:



Recording starts after a count-in of one bar indicated by the metronome and stops with the next tap on "REC". Start the recording with a tap on the "Record" button.

The recorded audio is saved in a wave file with the preset name set as default file name. You can access the the files in the iTunes File sharing folder for Tera Synth.

In addition the midi note on/off information coming from playing the onscreen or external keyboard is recorded into a file with the same name and the file extension ".mid". If the arpeggiator is active the notes from the arpeggiator are recorded in the MIDI file.

To change the file name just tap on the name field and enter the new file name.

Tap on the right arrow of an existing recording in the list to replay it.

AUDIOCOPY / SOUNDCLOUD

The recorded audio can also be copied into the Audio Pasteboard and uploaded to SoundCloud in this Popup. Just select the recording in the list and tap on "SoundCloud" or "Clipboard".

Synthesis

MODULAR ANALOG SYNTHESIS

The modular synthesizer uses independent sound generating and processing modules. The modules are not hardwired together but can be freely connected together using virtual wires (patch cords).

These modules can be accessed on the Synthesis (SYN) Page and on the Modulation (MOD) page of Tera Synth divided by their main usage as sound generating/processing and modulation source.

Tap on a free in the modules pane and drag left/right to reveal more modules.

The modules on the Synthesis Page:

Keyboard

Master tuning / Portamento.

Oscillator 1

Main oscillator with wave modulation.

Oscillator 2

Oscillator with wave modulation and FM input.

Oscillator 3

Oscillator with FM input.

Ringmodulator

Multiplication of two input signals.

Noisegenerator

White and Red noise.

Wavemixer

Mixer 3 + 2 in 1.

2 Multimode filter

Filter with adjustable slope (24/18/12 dB) and characteristic (Lowpass / Highpass / Bandpass / Bandreject).

Formant filter

3 Bandpass or bandreject filter for formant sounds and phasing effects.

WaveGuide

Physical modelling for simulating string and wind instruments.

Amplifier

Final amplifier with overdrive and LoFi effects.

The modules on the Modulation Page:

4 Multi segment envelope generator

syncable Envelopes with up to 64 breakpoints.

4 Envelope generator

Envelopes with D-ADSR characteristic.

4 LFO

Low frequency oscillator with synchronisation and Sample&Hold function.

ROUTING OF MODULES


To show you the routing of modules we will build a very simple synthesizer: An oscillator with an envelope generator for the volume envelope as the most basic sound modulation.

The routing between the modules can be made on two different levels:

1. Routing of sound output of some module to the sound input of another.

For our example we need one oscillator (we take Oscillator 1, but it can be any) and want the output of this oscillator be routed to the input of the Amplifier module (This module must be used by any patch).

Tap on the connection box labelled "INPUT 1" and select "Oscillator 1" from the upcoming list of Sound outputs:



2. Routing of control signals to modulate sound parameters.

Next step is to route the control signal of an envelope generator – let's take ADSR1 in this example – to modulate the volume of the sound. The Volume parameter can be set with the circular knob right above the label "VOLUME". Below the knob you see three sliders with associated connection boxes. This allows for up to three modulations for the parameter Volume. Now we use the first one for the routing of the output of ADSR1 to the Volume parameter:

Tap on the connection box below the slider and select ADSR1 from the upcoming list of modulation sources:



By selecting the ADSR the dialog automatically expands to show you all parameters of the envelope generator ADSR1. Set the MODULATION AMOUNT slider to maximum – this sets the amount of modulation the envelopes applies to the volume parameter.


You will find this schema:

- Circular knob adjusts parameter value
- One or more slider(s)/connection box(es) for routing of modulation sources on most parameters of Tera's modules.

Now you're ready to play some notes with the first synthesizer you've just crafted!

KFYBOARD

The keyboard module provides you with access to parameters influencing the processing of note events coming from the Keyboard or the internal arpeggiator.



Master Pitch coarse/fine

Sets the absolute pitch for all oscillators and the waveguide module in the range of +/- 24 semitones if tracking is set. Otherwise the absolute pitch of the oscillator is set.

Pitch Mod

Modulate the master pitch with up to two selectable modulation sources. Select a modulation source by tapping into the square field below the slider and set the amount of modulation with the slider.

Portamento

Smooth transition of the pitch between two notes played in succession. The time to reach the final pitch can be adjusted in the range of 0 milliseconds to 70 seconds. This effect is typical for many lead sounds on monophonic synthesizers, but can also be used here in polyphonic mode.

Fingerd

In normal mode all notes played will have the portamento effect. In fingered mode only legato-played notes will have this effect.

MIDI Bend

Adjusts the pitch bend range (up to \pm 48 semitones) applied to the sound if an external MIDI Keyboard with a Pitch bender control is connected to Tera.

Poly

Here you can limit the maximum number of voices which can be played simultaneously.

You can select between:


- monophonic
- mono/legato
- polyphonic

Phase

With "Free Phase" all oscillators are running freely. This has the effect that the same note value played repeatedly can sound slightly different from each other. This is the preferred mode for most sounds. With "Sync Phase" the oscillators starts synchronously on each note start. Then repeated notes all sound equal. This is the preferred mode for drum sounds. Note that this mode can lead to clicks in the onset of sounds.

OSCILLATOR 1

Oscillators provides you with the base material for sound synthesis. They generate periodic oscillations of analog and digital waveforms with controllable frequency. The oscillators in Tera use anti-aliasing algorithms to produce waveforms without digital distortion even in the highest register. Nevertheless, Tera's oscillators provide you with an outstandingly fat sound in the lower registers.



Pitch coarse/fine

Sets the relative pitch for this oscillators in the range of +/-4 octaves if tracking is set. Otherwise the absolute frequency of the oscillator is set.

If FM RATIO button is set, then the pitch can be set in integer multiples of the master pitch. The range is from 1:1 to 1:17. This mode is especially suited for setting the typical carrier/modulator frequency ratios used in FM synthesis.

Waveform

Select the waveform used by the oscillator from a list of 64 waveforms including the classical waveforms sawtooth, square, triangle and sine. If you select "Custom" from the waveform menu a dialog pops up where you can specify the level of up to 256 partials which determine the waveform. To open the waveform list just tap on the module box.

PM - Phase modulation

With phase modulation activated (Button PM) the oscillator's output is added to a phase shifted copy of itself. The phase shift is controlled by the phase modulation knob.

If you select the waveform sawtooth then the result is a pulse waveform with variable pulse width. In contrast to traditional pulse implementations you can use this for all the available waveforms.

Below the Phase knob you find a slider/selector combination to modulate the phase with one of the many possible modulation sources.

Pitch Mod

Modulate the oscillator's pitch with up to two selectable modulation sources. Select a modulation source by tapping into the square field below the slider and set the amount of modulation with the slider.

Track


This button activates keyboard tracking. When switched on the oscillator will track the keyboard at the rate of one semitone for each key. When switched off the oscillator will have a fixed pitch independent of the notes played on the keyboard.

6x - Spread

To make wonderful fat and powerful supersaw like sounds you need several oscillators tuned nearly in unison. Just tap the 6x button and Oscillator 1 will then output six detuned waves concurrently. The amount of detuning between this six oscillators can be adjusted with the "Spread" knob.

OSCILLATOR 2

In addition to the functions of Oscillator 1 this one has a linear FM input for FM synthesis.



Pitch coarse/fine

Sets the relative pitch for this oscillators in the range of +/- 4 octaves if tracking is set. Otherwise the absolute frequency of the oscillator is set.

If FM RATIO button is set, then the pitch can be set in integer multiples of the master pitch. The range is from 1:1 to 1:17. This mode is especially suited for setting the typical carrier/modulator frequency ratios used in FM synthesis.

Waveform

Select the waveform used by the oscillator from a list of 64 waveforms including the classical waveforms sawtooth, square, triangle and sine. If you select "Custom" from the waveform menu a dialog pops up where you can specify the level of up to 256 partials which determine the waveform. To open the waveform list just tap on the module box.

PM - Phase modulation

With phase modulation activated (Button PM) the oscillator's output is added to a phase shifted copy of itself. The phase shift is controlled by the phase modulation knob.

If you select the waveform sawtooth then the result is a pulse waveform with variable pulse width. In contrast to traditional pulse implementations you can use this for all the available waveforms.

Below the Phase knob you find a slider/selector combination to modulate the phase with one of the many possible modulation sources.

Pitch Mod

Modulate the oscillator's pitch with up to two selectable modulation sources. Select a modulation source by tapping into the square field below the slider and set the amount of modulation with the slider.

Track

This button activates keyboard tracking. When switched on the oscillator will track the keyboard at the rate of one semitone for each key. When switched off the oscillator will have a fixed pitch independent of the notes played on the keyboard.

FM-Input


With this input you can modulate the oscillator frequency with the output signal of another module, for example a filter or an oscillator. The amount of the modulation, called Modulation index in FM synthesis terminology, can be adjusted in the the range of 1 to 16.

FM-Index

The modulation index can be modulated with up to two selectable modulation sources. Select a modulation source by tapping into the square field below the slider and set the amount of modulation with the slider.

OSCILLATOR 3

Oscillator 3 has the same functions as Oscillator 2, except the phase modulation feature.



Pitch coarse/fine

Sets the relative pitch for this oscillators in the range of +/- 4 octaves if tracking is set. Otherwise the absolute frequency of the oscillator is set.

If FM RATIO button is set, then the pitch can be set in integer multiples of the master pitch. The range is from 1:1 to 1:17. This mode is especially suited for setting the typical carrier/modulator frequency ratios used in FM synthesis.

Waveform

Select the waveform used by the oscillator from a list of 64 waveforms including the classical waveforms sawtooth, square, triangle and sine. If you select "Custom" from the waveform menu a dialog pops up where you can specify the level of up to 256 partials which determine the waveform. To open the waveform list just tap on the module box.

Pitch Mod

Modulate the oscillator's pitch with up to two selectable modulation sources. Select a modulation source by tapping into the square field below the slider and set the amount of modulation with the slider.

Track

This button activates keyboard tracking. When switched on the oscillator will track the keyboard at the rate of one semitone for each key. When switched off the oscillator will have a fixed pitch independent of the notes played on the keyboard.

FM-Input


With this input you can modulate the oscillator frequency with the output signal of another module, for example a filter or an oscillator. The amount of the modulation, called Modulation index in FM synthesis terminology, can be adjusted in the the range of 1 to 16.

FM-Index

The modulation index can be modulated with up to two selectable modulation sources. Select a modulation source by tapping into the square field below the slider and set the amount of modulation with the slider.

WAVEGUIDE

This module is the basic building block for physical modelling synthesis. First of all it sums the signals from its two audio inputs (INPUT and FEEDBACK), and is attenuated by the input knob and the feedback knob settings. The sum is then delayed with a pitch synchronous delay time and low-pass filtered with an adjustable cutoff frequency. In the simplest form one can use this module as a delay line with real-time control of the delay time.



But how can we make a physical model of an instrument with this delay line?

To simulate the travelling wave of a string or an air tube the output of the delay line has to be patched to the FEEDBACK Input to get a closed feedback loop. This loop needs some initial energy put into INPUT to resonate and thereby produce a sound. To accomplish this, patch some oscillators or the noise generator to INPUT and modulate the input level by a very short attack/decay envelope. The spectrum of this input signal strongly determines the resulting sound in a very interesting manner: the resulting sound is filtered by the spectrum of the input signal!

If, for example, a mix of three sine tones with fixed frequencies are used as excitation sources the resulting output sounds like a formant filter with three bandpass filters having fixed centre frequencies and infinite slopes.

The built-in loop filter (6dB lowpass) corresponds to the damping of high frequencies in the physical model. Due to this loop filter higher harmonics decay much faster than lower harmonics. With the cutoff frequency set to 0 you get the typical sound of plucked strings, like a guitar. For steady state sounds you should set the cutoff frequency to maximum.

In the physical model the source for the FEEDBACK input is usually the WaveGuide output simulating the reflection of the travelling wave on both ends of a string or tube. But you can choose any audio source if you want to use this module for other purposes. The input level is controlled in an unusual manner by the feedback slider. This slider gives you control over the decay time of the sound in the range of 50 ms to 200 seconds. Negative values simulate the travelling wave of a tube with one open end and one closed end resulting in a hollow, square-like sound. In this case the pitch is one octave lower than for positive feedback values.

INPUT

Choose an audio source for the initial energy impulse by clicking into this field and selecting a source from the popup menu.

LEVEL

Adjusts the level for Input 1. Modulate this input with a short attack/decay envelope to simulate the injection of an energy impulse.

FEEDBACK INPUT

Second input for the delay line. The input level can be adjusted with the feedback slider. For physical modelling synthesis the WaveGuide output has to be patched to this input.

TRACK

This button activates keyboard tracking. When switched on the WaveGuide will track the keyboard at the rate of one halftone for each key. When switched off the WaveGuide will have a fixed pitch independent of the notes played on the keyboard.

COARSE

Coarse tuning of the oscillator relative to the master tuning adjusted in the keyboard module within a range of +/-48 semitones.

FINE

Fine tuning of the pitch in the range of -50 to +50 cent with variable resolution from 0.02 cent to 2.0 cent for one slider increment. (100 cent = 1 halftone step)


CUTOFF

Controls the cutoff frequency of the loop filter (6dB lowpass). Low cutoff values lead to faster decay of the higher harmonics compared to the lower harmonics. In addition the decay time of all harmonics is always proportional to the pitch and influenced by the feedback slider.

FEEDBACK

Adjusts the level for the feedback input. If the WaveGuide output is patched to the feedback input you get a closed loop with the feedback slider controlling the decay time of the sound in the range of 50 ms to 200 seconds

RINGMODULATOR



This module combines two input signals by multiplying them. The resulting spectrum contains the sum-of and the differences-between the frequency components of the two input signals. When the frequency of one input signal is below 20 Hz the result is a tremolo effect. But when the frequency is in the audible range the result is a change in timbre. If the pitch of the input signals are in an integer ratio to one another, the resulting spectrum is harmonic, otherwise the spectrum is inharmonic.

Example:

Sine tone with 1000Hz at input 1

Sine tone with 300Hz at input 2

Result on Output: two sine tones with 1300Hz and 700Hz.


INPUT 1

Choose an audio source for input 1 by tapping into this field and selecting a source from the popup menu.

INPUT 2

Choose an audio source for input 2 by tapping into this field and selecting a source from the popup menu.

NOISE GENERATOR



The noise generator provides you with two different types of noise. Use the noise generator to produce sounds simulating wind, ocean breakers or unpitched drums:

White noise

The spectrum of white noise contains all frequencies with equal power. It sounds very bright and sharp.


Pink noise

Lowpass filtered white noise. The lowpass filter has a fixed cut-off frequency of 0 Hz and a slope of 3dB/octave. Pink noise sounds darker and smoother than white noise.

Every voice in Tera has its own noise generator to avoid undesirable correlations when many voices are sounding simultaneously.

There are no user interface elements for the noise generator. The module appears only in the menu of the module inputs as one of the selectable sound sources.

SUBHARMONIC OSCILLATOR



Oscillator 1 has an additional output for subharmonic sounds. The pulse width of this sound is always controlled by the wave modulation slider, even if wave modulation is deactivated. The subharmonic sound is a mix of six pulse oscillators with a frequency ratio of 1:2:3:4:5:6.

This module is inspired by Oskar Sala's Mixtur-Trautonium and the Ondes Martenot, both legendary instruments created in the beginning of the 20th century.

MIXER

With this module you can mix down up to 5 input signals to the mix outputs.



The three outputs of the wave mixer provides you with the following sub mixes:

Mix 1-3

Mix of the signals on input 1 to 3.

Mix 4-5

Mix of the signals on input 4 and 5.

Mix

Mix of all input signals.

Mix (hidamp)

Mix of all input signals with a filter to damp high frequencies.


Therefore you can also use this mixer as two independent mixers with, respectively, 2 and 3 inputs.

INPUT 1-5

Choose the audio source for the inputs 1 to 5 by tapping into the appropriate field and selecting an audio source from the popup menu.

FILTER 1 / 2

The two multimode filters are the most important sound design tools in Tera. They simulate the characteristics of the filter types used in traditional analogue synthesizers. With the built-in overdrive you get a soft distortion. Several filter characteristics with 12, 18 and 24 dB/octave slopes are available. The filter resonance can be adjusted up to the level of self-resonance, where the filter behaves like a sine oscillator.



Here are the available filter characteristics in detail:

Lowpass 24dB Typ I

The lowpass filter attenuates frequencies above the cutoff frequency with 24dB/octave giving a warm and fat sound. The design of this filter is also known as "State variable filter".

Highpass 24dB Typ I

The highpass filter attenuates frequencies below the cutoff frequency with 24dB/octave giving a bright and sharp sound. The design of this filter is also known as "State variable filter".

Bandpass 12dB

The bandpass filter attenuates frequencies below and above the cutoff frequency with 12dB/octave giving a nasal and thin sound.

Bandreject 12dB

The bandreject filter attenuates frequencies near the cutoff frequency with 12dB/octave giving a phaser like sound.

Lowpass 12dB

The lowpass filter attenuates frequencies above the cutoff frequency cutoff with 12dB/octave giving a warm and natural sound.

Highpass 12dB

The highpass filter attenuates frequencies below the cutoff frequency with 12dB/octave giving a bright and thin sound.

Lowpass 24dB Typ II

This lowpass filter has a classical cascade design and attenuates frequencies below the cutoff frequency with 24dB/octave giving a warm and dark sound.

Lowpass 18dB Typ II

This lowpass filter has a classical cascade design and attenuates frequencies below the cutoff frequency with 18dB/octave giving a 303 like sound.

The filter parameter in detail:

INPUT

Choose an audio source for input 1 by clicking into this field and selecting a source from the popup menu.

Filter type

Selection of the filter characteristic. tap in the filter box for selection menu.

DRIVE

Adjusts the filter input level in the range of -10dB to +30dB. Actual input levels above 0dB results in a soft distortion of the input signal. Note that with increasing input level the filter resonance fades.

TRACK

Adjusts the keyboard tracking of the filter cutoff frequency. With a value of 1 the keyboard will control the cutoff frequency at a rate of one halftone per key. With a value of 0 keyboard tracking is off.

CUTOFF

Adjusts the filter cutoff frequency. For a lowpass filter higher values result in brighter tones and lower values result in darker tones. The range is from 20Hz to 20kHz. The cutoff frequency which is shown in the info window below the cutoff slider is the value for the key A4 (440Hz) if keyboard tracking is active.

RESONANCE

Adjusts the filter resonance which emphasizes frequencies close to the cutoff frequency. With very high values the filter will start to oscillate itself, producing a sine wave.

SHIFT

Each filter is internally built by two or more sub-filters connected in series. This parameter shifts the cutoff frequency of these subfilters. The effect depends on the filter characteristic:

Lowpass adjusts the slope of the filter Highpass adjusts the slope of the filter

Bandpass adjusts the bandwidth of the passband adjusts the bandwidth of the stopband

This parameter has no effect for the filter types Lowpass 12dB and Highpass 12dB.

FORMANT FILTER

The Formant filter contains three independent filters which can be used in two different configurations:


3 band pass filter in parallel

Formant filter for fixed and dynamically controllable formants. This configuration is useful for simulating vocal sounds and for filter morphing.

3 band reject filter in series

This filter configuration results in sounds comparable to comb filters and phaser effects useful for "spacey" sounds.

As opposed to common fixed filter banks, with this one you can dynamically control all filter parameters using different modulation sources!



INPUT

Choose an audio source for input by tapping into this and selecting a source from the popup menu.

Peak filter/Notch filter

Switches the filter configuration between "parallel bandpass" and "serial band reject" filters.

DEPTH

The depth parameter controls the mix of the filtered and the original input signal. The range is from 0.0 to 1.0. With depth set to 1.0 only the filtered signal is sent to the output. With depth set to 0.0 only the original signal is sent to the output.

FREQU 1 .. 3

Adjusts the centre frequency of the peak/notch filters. All frequencies below and above the centre frequency will be attenuated for the bandpass filter. All frequencies around the centre frequency will be attenuated for the bandreject filter. The range is from 20 Hz to 20000 Hz.

Q1..3

Adjusts the bandwidth of the bandpass filter relative to the centre frequency:

bandwidth [Hz] = center frequency [Hz] / resonance


The range is from 0.5 to 512. For a centre frequency of 1000 Hz this results in a bandwidth ranging from 2000 Hz to 2 Hz.

L1..3

The output level for the bandpass filter relative to the other two bandpass filters. The range is from -50 dB to +20 dB.

AMPLIFIER

The amplifier is the last module in every patch. This module mixes the selected input sources of all voices down to a stereo output. All parameters act independently on every voice before the final stereo mix is done. The pan position for example, can therefore be different for every voice in a polyphonic part. The stereo output is routed to the effects section for further processing.



INPUT 1/2

Choose an audio source by tapping into this field and selecting a source from the context menu.

CROSSFADE

Mix between input 1 and 2

OVERDRIVE

Adjust the amount of ranging from "Off" to +64dB (maximal distortion).

A soft distortion unit is inserted between the input of the amplifier and the volume slider. For this reason the degree of distortion is independent of the volume setting. If the volume is modulated by an envelope generator – as in most sound programs – the degree of distortion is also independent of the dynamic envelope. If you modulate the amplitude with an envelope generator before the signal goes into the amplifier unit then the degree of distortion varies with the dynamic envelope just as usual. Every voice has its own distortion unit, so there's no inter–modulation between the notes in polyphonic play. Therefore the sound is quite different in comparison to a standard distortion unit.

VOLUME

Output level ranging from -40dB to +40dB

PAN

Adjusts the position of the sound in the stereo panorama. Opposed to the pan slider in the part mixer this one works independently for each voice! If for example the pan is modulated by an LFO this means every voice can have an independent position.


DIRECT LEFT/RIGHT inputs

These two inputs are routed directly to the stereo output of the amplifier. This makes it possible to produce stereophonic patches directly in the synth patch.

Modulation

LOW FREQUENCY OSCILLATORS (LFO)

Tera Synth provides you with four low frequency oscillators which can be freely assigned to modulate one or more sound parameters.



This module provides you with oscillations useful for periodic and random sound parameter modulations. The LFO can produce seven different modulation waveforms. Every LFO can also be used to Sample & Hold the waveform of another LFO. The rate of the LFO can be synced to the tempo of the Arpeggiator.

Wave

Selects one of the following waveforms:

- 2.1. Sine
- 2.2. Triangle
- 2.3. Square
- 2.4. Ramp up
- 2.5. Ramp down
- 2.6. S & H (Sample & Hold)
- 2.7. Random Aperiodic waveform.

Using the waveform S & H produces a Sample & Hold effect. In this mode the module takes samples of the output of the next LFO at the rate of the LFO frequency. For Example LFO 2 takes samples from LFO 1. To create the traditional Sample & Hold effect select a random modulation waveform for the sampled LFO.

Wave

Sets the rate of the modulation oscillator. The rate of the oscillator can be specified in two ways:

If the Sync parameter is set to "Tempo sync'd" then the rate depends on the tempo of the Arpeggiator. Then you specify the cycle length in terms of note length with a range from 1/32 triplet to 4/1 dotted.

Otherwise the rate can be specified in a range from 1 cycle every 100 seconds to 689 cycles / second.

Sync

Sets the LFO phase and rate synchronisation. The following modes are available:

Common - All voices of a part are modulated in sync.

Tempo Sync'd - The rate is synced to the tempo of the internal Arpeggiator

Random - Every voice has its own LFO starting with random phase on key down. The

modulation is therefore phase-shifted for every voice of a polyphonic chord.

Key - Every voice has its own LFO starting with zero phase on key down.


STANDARD ENVELOPES

The envelope generator lets you shape the parameters of a sound over time, beginning from when a key is hit, continuing as the key is held, and adjusting how the sound decays after the key is released. You can also trigger the envelope by one of the four LFOs instead of hitting a key. TERA uses envelopes with ADSR characteristic (like most analogue synthesizers do), extended by a delay phase and the option to thicken short attack/decay envelopes with the punch option.



For every single voice TERA provides you with four independent envelope generators.

This is how the envelope evaluates after triggering:



DELAY

Sets the delay time between note triggering and the start of the attack phase. Range is from 0.7 ms to 132 seconds.

ATTACK

Sets the time the envelope needs to reach the maximum level. The curvature is logarithmic, which means that from the start the signal builds up quickly and slowly rises when approaching the maximum level. Range is from 0.7 ms to 132 seconds.

DECAY

Sets the time the envelope needs to reach the sustain level after the attack phase has ended. The curvature is exponential, which means that from the start the signal decays quickly and slowly falls when approaching the sustain level. Range is from 0.7 ms to 132 seconds. The decay time has no effect if the sustain level is set at maximum.

SUSTAIN

Sets the sustain level the envelope will stay until release. Range is from 0 to 1.

RELEASE

Sets the time the envelope needs to reach the level 0 after the key is released. The curvature is exponential, which means that from the start the signal decays quickly and slowly falls when approaching the level 0. If the release time is set to 0 then the release time automatically follows the decay time. This results in an Attack/Delay only envelope.

PUNCH

The punch switch delays the start of the decay phase by a few milliseconds. The result is a "thicker" attack similar to a compressor effect. This effect is audible only on short attack/decay time envelopes.

Trigger mode

With the trigger mode you decide when and how the envelope is triggered. The following modes are available:

KEY

The envelope starts on key down with the last actual level.

KEY RESET

The envelope starts on key down with the level 0.

KEY ONCE

Like Key trigger, but the envelope won't start with legato played notes.

LFO 1

The envelope starts with every new cycle of LFO 1.

LFO 2

The envelope starts with every new cycle of LFO 2.

LFO₃

The envelope starts with every new cycle of LFO 3.

LFO 4

The envelope starts with every new cycle of LFO 4.


MULTI ENVELOPES

Tera Synth provides you with four multi segment envelopes which can be freely assigned to modulate one or more sound parameters.

These envelopes have up to 64 time/level segments giving you all from simple Attack/Decay style envelopes up to complex rhythmical patterns which can even be synchronised to MIDI tempo.

The four envelopes are completely independent from each other: They can have different number of segments with free time/level values.

The main envelope editor figured below provides you with a context menu for copying and pasting envelopes through the clipboard and for selecting them from about 64 predefined envelopes.



Editing the envelopes is an easy and straightforward process:

You can change the time or level of any segment by dragging the small yellow circle at the end of each segment into the desired position. Clicking the small black dot within the segment changes the slope. All editing take effect immediately!

With this dragging you also have selected this segment and then you can use alternatively the value fields for delta, level and slope for editing these values. Tap into the appropriate value field and drag your finger up or down for changing the values.

To insert a new segment/delete an existing one first tap on the "Insert/Delete" Button to switch mode and then tap the segment you want to insert/delete.

The two grey vertical lines are the loop marker positions for the envelope. They are managed automatically by Tera Synth. The looping of the envelope between these two lines come automatically in effect as soon as more than one envelope segment is inside the marker positions.

You can scroll and zoom in the envelope window concurrently by tapping on the time bar below the envelope window and drag up/down for zooming and drag left or right for scrolling in the window.

If you want to edit a segment without changing the positions of other segments switch off the slide mode with a tap into the mode field above the envelope.

To create tempo synchronised envelopes tap into the sync field which will show then the value "On" and the time bar will show you then note values instead of absolute time.

Arpeggiator



OVERVIEW

Tera Synth features an arpeggiator with a very flexible step matrix editor for programming and a unique "rolling dice" random arpeggio generator. Every sound preset can store it's own arpeggio pattern. You can build arpeggios from scratch or use one of the 32 preset arpeggios as foundation. You can also create an unlimited number of user arpeggio presets.

Just play a chord or a single note and it gets transformed into a grooving monophonic synth line or a rhythmical chord pattern.

GLOBAL SETTINGS



Tap on the arpeggio button to start/stop the arpeggio.

The mode parameter determines the way the pressed keys are sequenced. Available modes are: Up/Down/Alternate/Random/Incl/Excl.

The trigger parameter controls the way pressed notes and chords are handled:

standard - all currently pressed notes are used for the arpeggio.

hold - the last pressed notes are taken and the arpeggio continues even after you lift of all notes.

key sync - like "standard, but the arpeggio restarts at step 1 with every new press of some notes.

The clock parameter sets the basic step length.

The Tempo can be set in bpm (40-300) with the tempo knob. To enter a tempo value by tapping a rhythm tap on the tempo display in the top bar of the main window.

With Shuffle every other step in the arpeggio is moved forward or backward in timing.

The fix parameter is a performance function and if on the global settings of the arpeggio don't change on sound or arpeggio preset selection. This is useful if you want to use different arpeggios for one sound or different sounds for one arpeggio with the same settings.

Note that if fix is on the selection of another preset doesn't load the presets own arpeggio, the currently active arpeggio stays as it is.

Some more parameter are available on the right side of the Arpeggio page:



With the "rolling dice" you can get another randomly generated arpeggio with each tap on the dice and be surprised how useful they can be!


The gate parameter controls the length of each note relative to the step time.

With the accent row in the step matrix you can boost the velocity for selective steps. The velocity used for accented steps can be set with the accent knob shown above.

If "key velo" is set the arpeggiator uses a constant velocity set with the "velocity" knob above for all steps which are not accented. Otherwise the arpeggiator uses the velocity with which the notes were pressed.

STEP MATRIX EDITOR

The step matrix editor is the programmable "heart" of the Arpeggiator. The matrix rows represents the five parameters which can be set individually for each step in the pattern, the steps being represented by the columns of the matrix.



The current position of the arpeggio in the timeline is shown by a running highlight in the position row on top of the matrix. Tap and drag in the position row to change the length of the pattern from 1 to 32 steps.

In the next row you can set or reset the tie control for each step. With tie activated on a step the note before this step will get played legato to the note in the step. If both steps play the same note no note off message is generated which means that the note just gets played longer. With legato and slew set on the keyboard page the tied notes also gets the typical 303 type note glide effect.

In the next row you can set an accent on each step you like to boost the velocity for this step.

In the note and octave row you can set the transposition relative to the played notes. Tapping directly on the yellow transpose marker mutes this step.

Parameter row functions

In each parameter row you can set the following functions from left to right:

Rolling dice: tap to get another random set of step parameter for this row.


Left arrow: rotate the contents for this parameter in the row on step to the left.

Right arrow: rotate the contents for this parameter in the row one step to the right.

Reset sign: reset the parameter for this row to their default value.

Effects

Tera Synth is equipped with five studio quality effects.



DISTORTION

The distortion effect provides you with different types of distortion from hard clipping to soft distortion simulating old tube amplifiers. The sound balance can be adjusted using a combined High/Lowpass filter.

- **DRIVE** Sets the amount of distortion by amplifying the input signal.
- **CUTOFF** This parameter sets the crossover frequency of the distortion filter. The distortion filter consists of a lowpass filter and a highpass filter with a cutoff frequency equal to the crossover frequency. The relative amount of lowpass and highpass filtered signal power is controlled by the Tone parameter.
- TYPE Select from following distortion types:
 - 1. Hard clipping distortion characteristic.
 - 2. Soft clipping distortion characteristic.
 - 3. Distortion simulating the characteristic of magnetic tape recordings.
 - 4. Soft distortion simulating old tube amplifiers.
- TONE This parameter controls the relative amount of low- and highpass filtered signal power.
- LEVEL Output level of distorted signal.

PHASER

The Phaser is built of an 8-pole allpass filter, which gives you a very short and frequency dependent delay time. This delay time is modulated by an LFO.

- **DEPTH** This parameter controls the depth of the delay modulation.
- FEEDBACK Sets the feedback amount for the delay lines of the chorus to further increase the chorus effect.
- DELAY The mean delay time of the chorus. Set this to 10-20ms for typical chorus effect.
- RATE The modulation rate of the effect.
- DRY/WET Balances between original and delayed signal.

DELAY

The delay effect provides you with two different types of delay effects using two delay lines. The delay times are set by note lengths and are relative to the currently set tempo. The delayed signal can be feed back to the input for echo effects. You can select between a stereo delay and a ping-pong delay where the echoes bounces across the stereo field.

- FEEDBACK Controls the decay time of the echoes.
- DELAY L/R- Sets the the delay time in note lengths for the left/right channel.
- CUTOFF A lowpass filter is build into the feedback loop of the delay. This parameter controls the cutoff of this filter resulting in successive echoes sounding darker.
- DRY/WET Balances between original and delayed signal.

CHORUS

Use the chorus effect to fatten the voice and give it more width in the stereo panorama.

- **DEPTH** This parameter controls the depth of the delay modulation.
- FEEDBACK Sets the feedback amount for the delay lines of the chorus to further increase the chorus effect.
- DELAY The mean delay time of the chorus. Set this to 10-20ms for typical chorus effect.
- SPREAD Use this to decrease the periodicity of the modulation.
- RATE The modulation rate of the effect.
- DRY/WET Balances between original and delayed signal.

RFVFRB

The reverb unit in Tera Synth is a stripped down version of our hi-end reverb REFLECT which is famous for his natural and smooth sound.

You can use the reverb effect in two ways: for each preset you can have your own reverb settings within each preset. Switch on "global" if you prefer to set the reverb the same for all presets.

- **DELAY** Sets the amount of time that elapses between the direct sound and the reverberation tail. This time correlates with the perceived size of the simulated room. The adjustable range is from 0 ms to 300 ms.
- REVERB TIME The time the reverb takes to die away by 60dB after the end of the initial sound. This
 parameter correlates with the perceived size of the simulated room. The adjustable range is from 50
 ms to 100 seconds.
- ROOM SIZE The room size parameter sets the average distance between the reflecting walls.
- **DIFFUSION** The Diffusion parameter controls the echo density of the resulting reverberant sound. The adjustable range is from 0% to 100%. A higher value corresponds to a higher echo density which is in most cases more natural sounding.
- ABSORPTION The Absorption parameter simulates the surface and air absorption of high
 frequencies. The adjustable range is from 0% to 100%. Due to absorption the reverberation time is
 shorter for high frequencies than for low frequencies. With higher absorption high frequencies will
 decay much faster.
- STEREO Adjusts the stereo image width of the reverberation tail.
- DRY/WET Balance between the dry and reverberant part of the output signal.

Appendix

TROUBLESHOOTING

Fresh installation

Sometimes Apps having problems after first installation or update. Please try the following:

- trash the app
- boot your device. (most important!)
- repurchase again from the AppStore (you don't have to pay again, they know that you already have)
- sometimes another reboot can be helpful.
- This removes usually problems of this kind and has only be done once.

Support e-mail

If you have any problem please send us a support form from our website <u>mobile.virsyn.com</u> This is the best way to contact us.

Please keep in mind that we can't reply to App Store reviews!