


Your HTC Desire

Quick start guide



htc
quietly brilliant

Before you do anything else, please read this

Charge the battery

The battery in your phone hasn't been charged yet. While your phone is charging, it's important that you do not remove the battery pack. Doing so can damage your phone. Also, please don't try to take your phone apart. (If you do, it may invalidate your warranty.)

Know about privacy laws

Some countries have strict laws about how and when you can record phone conversations. For example, you may need to tell the person you're speaking to before you start recording. It's a good idea to find out what the laws are where you live before you use your phone's recording feature.

And finally, a few important words from our legal team (LIMITATION OF DAMAGES)

To the maximum extent permitted by applicable law, in no event shall HTC or its affiliates be liable to you, any user, or third party for any indirect, special, consequential, incidental or punitive damages of any kind, arising in contract, tort, or otherwise, including, but not limited to, injury, loss of revenue, loss of goodwill, loss of business opportunity, loss of data, and/or loss of profits, regardless of the foreseeability thereof or whether HTC or its affiliates have been advised of the possibility of such damages. And in no event shall the total liability of HTC or its affiliates exceed the amount received from you, regardless of the legal theory under which the cause of action is brought. The foregoing does not affect any statutory rights which may not be disclaimed.

This quick start guide will help you get started with your phone. In this guide, we use the following symbols to indicate important or useful information:



Notes



Important information



Tips



Safety precaution

For the complete user guide and other helpful resources, check out the HTC support website at www.htc.com/support.

Contents


1. What's in the box	4
2. Get to know your phone	4
3. Before you turn on your phone	5
4. Get started	7
5. Add your contacts	9
6. Make your first call	10
7. Status Bar and Notifications	10
8. HTC Sense	11
9. Connect to the Internet	13
10. Get your messages across	16
11. Managing Your Applications	18
12. Stay in touch with friends	19
13. Get files into your phone	20
14. Sync your phone with your computer	21
15. Factory resetting	23
16. Troubleshooting tips	24

1. What's in the box


Here's what you should find inside the box:

- Phone
- Battery
- USB cable
- 3.5mm stereo headset
- Power adapter
- microSD™ card (pre-installed in the device)
- This quick start guide
- Safety and regulatory guide

2. Get to know your phone




3. Before you turn on your phone




1 Remove the back cover

Lift the top of the back cover. There's a narrow opening (near the POWER button) where you can use your finger to remove the back cover.




2 Insert the battery

1. Align the battery's exposed copper contacts with the battery connectors inside the battery compartment.
2. Insert the contacts side of the battery first and then gently push the battery into place.



3 Replace the back cover

1. Secure and press the bottom part of the back cover first by aligning into the two openings located at the bottom part of the back of the phone.
2. Press the sides and the top part of the back cover down to lock the cover into place. You will hear a click when the back cover is locked in place.



4 Charge the battery

1. Plug the power adapter into the USB connector at the bottom of your phone.
2. Plug in the power adapter to an electrical outlet to start charging the battery. It will take about three hours for the battery to be fully charged.

After installing and charging the battery, you are now ready to turn your phone on for the first time. Press the POWER button to turn on your phone.

Read on and start exploring what you can do with your phone.

4. Get started

On the Home screen, tap  > **Setup** .

1. Choose the phone language you want to use, and then tap **Next**.
2. Your phone walks you through a tutorial on how to use the onscreen keyboard. Follow through the tutorial to learn how to use the onscreen keyboard. Tap **Skip** to not go through the tutorial.
3. On the Internet connection screen, select how you want to connect to the Internet, and then tap **Next**.
4. If there are Wi-Fi networks in range, you will be asked if you want to connect to a Wi-Fi network. Tap **Next** and then tap the wireless network that you want, or clear the **Connect to Wi-Fi network** checkbox, and then tap **Next** to set up your Wi-Fi connection at a later time.
5. Some phone features such as Weather and Footprints require Google's location service to automatically determine your current location. On the Location consent screen, you can choose whether to allow Google's location service to collect information about your location. Clear or select the checkbox, and then tap **Next**.
6. On the Set up accounts screen, choose the type of account you want to set up and follow the onscreen instructions to complete the setup. Tap **Skip** to set up accounts at a later time.

- To set up your Google Account, tap **Google account** > **Next** > **Sign in**, enter your Google Account details, and then tap **Sign in**.
- To learn how to set up POP3 and Microsoft Exchange ActiveSync accounts, see the Sync and Email chapters to learn how to set up these accounts.

After setting up an account, you will be taken back to the Set up accounts screen so you can set up more accounts. When you are done setting up your accounts, tap **Next**.



7. On the Set up social networks screen, choose the type of social network account such as Facebook (for HTC Sense) and Twitter that you want to access from your phone. Follow the onscreen instructions to log in to your social network account. Tap Skip to set up social network accounts at a later time. See the Social chapter for more information about Facebook for HTC Sense.

When you are done setting up your accounts, tap Next on the Set up social networks screen.

5. Add your contacts

There are several ways you can add contacts to your phone.

Adding a new contact

1. On the Home screen, tap  > **People**.
2. On the **All** tab, tap **Add contact**.
3. Tap the **Name** field, enter the first and last name of the contact, and then tap **OK**.
4. Tap  to hide the onscreen keyboard, tap the **Display name** box, and then choose how you want the contact name to be displayed in your contacts list.
5. Tap **OK**.
6. Choose the **Contact account** under which to create your contact.
7. Enter the rest of the contact information into the relevant fields.
8. Scroll to the bottom of the screen, and then tap **Save**.

Synchronizing contacts from other sources

My Contacts Backup application from U.S. Cellular is preloaded on the device. With My Contacts backup you can download contacts you have saved from a previous device using the application and secure your existing phone contacts.

You can quickly and seamlessly sync your phone with your contacts in your Google Account, Microsoft Office Outlook, Outlook Express, Exchange ActiveSync account, and even Facebook. Take a look at the complete user guide on our website, www.htc.com/support, to see how it's done.

6. Make your first call

1. On the Home screen, tap **Phone** at the bottom of the screen.
2. Dial the number or contact you want to call, and then tap **Call**.

As you tap the keys on the phone dialer, the screen will display matches found on your phone and call log based on the keys you have tapped.

3. To hang up, tap **End call**.

7. Status Bar and Notifications



At the top of your screen you will notice a Status Bar. On the right side, it shows the time, battery level, signal strength, data connection status, etc. On the left side will appear notification icons.

When a new notification icon displays in the status bar, press and hold the status bar, then slide your finger downward to open the Notifications panel. Tapping the individual notification provides more information, such as opening the message or appointment, or giving you other options.

To close the Notifications panel, you can either press and hold the bottom bar of the Notifications panel, then slide your finger up the screen, or just press the BACK button.

8. HTC Sense

Discover HTC Sense™ on your phone, an intuitive, seamless experience built upon three fundamental principles — make it mine, stay close, and discover the unexpected.

Personalized Home screen

The Home screen is highly customizable and extends beyond the screen width, giving you lots of room to add the information that matters most to you and tools or applications that make your life easier. There are up to seven screens that extend to the left and right sides of your phone display.



Slide your finger left or right to go to the other parts of the extended Home screen.

OR


Pinch the screen to show a snapshot of the Home screen and extended Home screen, and then tap a screen thumbnail to directly go that screen.



You can press the HOME button anytime, whatever you're doing on your phone, and go straight to the Home screen.

Widgets

Widgets put at-a-glance important information and media content up front on your Home screen. A wide selection of widgets is available on your phone, or if that's not enough, you can download more widgets from Android Market to add to the Home screen.

To add widgets to the Home screen, tap , and then select **Widget**.

Scenes

Can't decide how to set up your Home screen? Check out **Scenes** that we've included in the phone. Scenes are preset Home screen layouts that you can quickly apply. On the Home screen, press MENU, and then tap **Scenes** to check out the presets.

After selecting a preset, you can customize it and save it as a new scene.

1. Customize the Home screen by changing the wallpaper. You can also add widgets, shortcuts, and more by tapping the "+" button and selecting the item you want to add. You can remove an unwanted item by tapping and holding its icon, then dragging it to the trash can. Or you can move it to an unused position by tapping and holding its icon, then dragging it to the new location on the screen.
2. After you're done customizing, press MENU, and then tap **Scenes**.
3. Select **Current (unsaved)**, and then tap **Save**.
4. Enter the **Scene name**, and then tap **Done**.



You can rename or delete a custom scene. From the Home screen, press MENU and tap **Settings > Personalize > Scenes**. Under **My scenes**, press and hold a scene and make the change you want.

People

Bring the people who matter the most closer. Your phone organizes all text exchanges, email conversations, Facebook status, online photo albums and phone logs of a contact all in one place.


Tap the name of a contact and you can see all your recent communications with that person at a glance.

Friend Stream

Streamline your social network accounts through Friend Stream. With Friend Stream, you can post what's on your mind simultaneously across your social network, view status updates and tweets, and look through photos from your social network accounts.

News

Subscribe to news feeds to keep up with the latest buzz on the Internet. News monitors RSS feeds from your favorite news sites, blogs and more, and downloads the most current updates.



9. Connect to the Internet

Your phone puts the whole Internet in your pocket. You can get online using a data connection or Wi-Fi.

Using a data connection

It's simple. When you turn your phone on for the first time, it should connect automatically to your mobile operator's data service.

If you don't get a connection automatically, there are two things to try.

- **Check that the data connection is turned on.**
It may just be that your data connection isn't turned on. To check whether it is on:
 1. On the Home screen, press MENU, and then tap **Settings**.
 2. Tap **Wireless & networks**, and select the **Mobile network** check box to turn your connection on.
- **Check that the right mobile network is selected.**
 1. On the Home screen, press MENU, and then tap **Settings**.
 2. Tap **Wireless & networks > Mobile networks > Enable always-on mobile data**.



Using Wi-Fi

1. On the Home screen, press MENU, and then tap **Settings > Wireless & networks**.
2. Select the **Wi-Fi** check box to turn Wi-Fi on. The phone will scan for available wireless networks.
3. Tap **Wi-Fi settings**. You'll see the network names and security settings of any detected Wi-Fi networks.
4. Tap a Wi-Fi network to connect to. If you select an open network, you'll be automatically connected. If


you select a secured network, enter the key, and then tap **Connect**.

Browsing the Web

Your phone's Browser makes web browsing easy and fun.

1. On the Home screen, tap  > **Internet**.
2. On the Browser screen, press MENU, and then tap the URL field on top of the screen.
3. Enter the web address. As you enter the address, matching web addresses will appear on the screen. Tap an address to go directly to that webpage, or continue entering the web address of your choice, and then tap the Enter key .
4. On the webpage, use finger gestures to browse the webpage or to zoom in or out.

Spread your thumb and index finger across a webpage to zoom in.




Pinch your thumb and index finger on a webpage to zoom out.

10. Get your messages across

Access your email accounts right from your phone.

Adding a POP3/IMAP email account

1. On the Home screen, tap  > Mail.
2. On the Choose a mail provider screen, tap **Other (POP3/IMAP)**.





If the account type you want to set up isn't already in your phone's database, you'll be asked to enter a few more details. Have your incoming/outgoing server information ready, to save time. Your email provider can tell you this information if you don't already know it.

3. Enter the **Email address** and **Password** for the email account, and then tap **Next**.
4. Enter the **Account name** and **Your name**, and then tap **Finish setup**.



You can also set up an Exchange ActiveSync account. See the Email chapter of the user guide on our website to see how.

Sending an email message



1. On the Home screen, tap  > Mail.
2. On the email account Inbox, press MENU and then tap **Compose**.
3. Fill in one or more recipients. You can:
 - Enter email addresses directly in the **To** field. If you're sending the email to several recipients, separate the email addresses with a comma.
 - Tap the  icon, and then select the contacts to whom you want to send the message. When you have selected all the message recipients, tap **OK**.
4. Enter the subject, and then enter your message.
5. If you want to add an attachment to your e-mail, press

MENU, tap Add attachment, and then tap the type of attachment to be added. Then follow the prompted actions based on the type of attachment you selected.

6. Tap **Send**.

Other types of messages - SMS and MMS

Other types of messages let you send either text-only messages (SMS) or multimedia messages (MMS) to other mobile phones.



To send a message, press HOME , tap  > Messages. On the All Messages screen, tap **New Message**. Enter one or more recipients, then enter your message and tap **SEND**.

To send a multimedia message, while composing your message, press MENU and tap **Attach**. Select the type of multimedia content you want to send (such as a picture, video, vCard, etc.)



Multimedia messages are limited to 1MB. If your content is larger than that, you may need to crop large photos, reduce the resolution, or shorten the length of the video that you are trying to send.

11. Managing Your Applications

Explore the thousands of additional applications for your device using the Android Market. To access the market, press HOME , tap  >Market. The first time you access the market, you will have to agree to the terms and conditions presented. If you have not already set up your google account, you will also have to do that before you can access the Android Market.


You can search for an application by tapping the spyglass icon  and entering one or more keywords.

To remove or update applications downloaded from the Market, tap My apps at the top of the screen. If there are updates for an application you have downloaded, you will see a notification on this screen. Tap the application to begin downloading and installing the update. To remove an application, tap its name on the My apps screen, then tap Uninstall. You can reinstall the application later if you want.

Sharing games and applications

Having fun with a game or application that you downloaded from Android Market? Share it instantly with your circle of friends.



For your friends to link to the game or application and download it from Android Market, they must be using an Android phone.

1. From the Home screen, tap .
2. Tap App Sharing. Or, press MENU and then tap Share. You'll then see the list of games and applications that you downloaded and installed from Android Market.
3. Tap an application, and then choose how to share it.

When your friends see the link in your sent text, email, or status update, they can simply tap the link to go directly to the game or application in Android Market to download it.

12. Stay in touch with friends

Your phone has everything you need to stay in contact with your friends online. **People** and **Friend Stream** give you direct access to all the leading social networks. You can update your status on Facebook, look at photos in your online albums, and follow your tweets on Twitter. It's all built in and really easy to use.



See the Social chapter of the user guide on our website to learn more about Friend Stream, Facebook, and Peep (the Twitter client on your phone).

13. Get files into your phone

Bring your files with you wherever you go. With your phone, you can view Word, Excel, PowerPoint, and PDF files. You can also listen to music and look at your prized gallery of photos and videos.



You'll need to plug in your microSD card before you can copy files into your phone.

1. Connect the phone to your computer using the supplied USB cable.
2. When the **Connect to PC** dialog box appears, select **Disk drive**, and then tap **Done**.
3. On your computer, the connected phone is recognized as a removable disk. Go to this removable disk and open it.
4. Copy the files to the storage card.
5. After copying the files, unmount your phone as required by your computer's operating system to safely remove your phone.
6. Open the Notifications panel on your phone, and then tap **Turn off USB storage**. When prompted, tap **Turn Off**.
7. Disconnect the phone from the computer.

14.Sync your phone with your computer

You can use HTC Sync to sync Outlook contacts and calendar or Outlook Express contacts between your computer and your phone.

Installing HTC Sync that came with the microSD card

Use the HTC Sync installer that's in the supplied microSD card to install.

1. Make sure the microSD card is inserted on your phone.
2. Connect your phone to your computer using the USB cable that came with your phone.
3. You'll see the Connect to PC screen on your phone. Tap **Disk drive** and then tap **Done**.
4. Your computer will treat your phone as a removable disk (just like any USB drive). Open this removable disk so you can see what's inside the microSD card.
5. Copy HTCSync.exe to your computer.
6. Press HOME > MENU and tap **Notifications**. Then tap **Turn off USB storage** and tap **Turn off**. You can now unplug your phone from the computer.
7. On your computer, double-click HTCSync.exe and follow the onscreen instructions to install HTC Sync.

Setting up HTC Sync

After installing, set up HTC Sync to recognize and sync with your phone.

1. Connect your phone to your computer.
2. On the Connect to PC screen in your phone, tap **HTC Sync** and then tap **Done**. Your phone then attempts to find HTC Sync on your computer which may take a few seconds.



If your phone displays a message indicating that it's unable to find HTC Sync, try disconnecting and reconnecting the USB cable, and then repeat step 2.

3. When your phone finds HTC Sync, your computer will display the Phone Connection Wizard. Click **Next**.
4. Enter a name for your phone, and then click **Finish**.
5. Check the HTC Sync icon on the computer. If it's green in color, that means your phone is connected with your computer and HTC Sync recognizes the phone.



6. Double-click the green HTC Sync icon. Then click **Synchronize Now** (or **Sync Manager > Settings**).
7. In the Synchronization Settings Wizard, click **Next**.
8. In the next few dialog boxes, choose whether to sync Outlook or Outlook Express, select the type of information to sync (contacts and/or calendar), and choose to sync them automatically with your phone.
9. Click **Finish**.

Synchronizing your phone and computer automatically

Do the following first to make sure your phone will sync automatically with your computer:

1. Press **HOME > MENU**, and then tap **Settings > Applications > Development**.
2. Make sure the **USB debugging** check box is selected.


Whenever you connect your phone to your computer, synchronization starts automatically.

Downloading the latest HTC Sync upgrade

Visit the HTC support website (www.htc.com/support) from time to time to check for the most recent HTC Sync upgrade so you can download and install it on your computer. After installing the latest upgrade, follow the steps again in "Setting up HTC Sync" to set up HTC Sync to recognize and sync with your phone.

15.Factory resetting

Need to start over? If you're passing your phone on to someone else or just want a fresh start, you can factory reset your phone. It's not a step to be taken lightly. Factory resetting your phone will delete all your data, including any applications you've downloaded and installed. It returns the phone to the state it was in before the first time you turned it on.

 Be sure to back up any data that you want to keep before you factory reset your phone.

Resetting the phone through settings

1. On the Home screen, press MENU, and then tap **Settings > SD & phone storage > Factory data reset**.
2. On the Factory data reset screen, tap **Reset phone**, and then tap **Erase everything**.

Resetting the phone using phone buttons

1. With the phone turned off, press and hold the **VOLUME DOWN** button, and then briefly press the **POWER** button.
2. Wait for the screen with the 3 Android images to appear, and then release the **VOLUME DOWN** button.
3. Press **VOLUME DOWN** to select **CLEAR STORAGE**, and then press **POWER**.
4. When asked to confirm, press **VOLUME UP**.

Factory resetting your phone does not delete the contents in your microSD card.

16. Troubleshooting tips

If you ever have any problems using your phone, here are some things you can do to set things right again.

- Check whether there is enough free space on the phone to run the application.

To check free space, go to the Home screen, press MENU, and then tap **Settings > SD card & phone storage**.

- Clear your data and cache of applications.

To clear the data and cache, go to the Home screen, press MENU, and then tap **Settings > Applications > Manage applications**. Select application then clear cache.

- Uninstall any third-party applications.

To uninstall third-party applications, go to the Home screen, press MENU, and then tap **Settings > Applications > Manage applications**. Select application then uninstall.

- If your phone becomes unresponsive, remove the battery, wait for three seconds, then reinsert the battery and turn the phone on. Or back up your important data and factory reset the phone.

To factory reset, press HOME > MENU, and then tap **Settings > SD & phone storage > Factory data reset**.

- Check for additional updates and useful tips on our website: www.htc.com/support.



91H0xxxx-xxM Rev.A