


USER MANUAL

O2CX

IN-SITU COMBUSTION OPTIMIZATION MONITOR

PART 1 OPERATION



O2CX Compact Model



O2CX Remote Control Model



O2CX High Temperature Model

Inspect Shipment for Damage

Carefully inspect the entire shipment for damage in the presence of the shipper's agent, removing packaging material if necessary. Note any damage to packaging and/or goods on Packing List and have it signed by the shipper's agent prior to accepting the shipment. Submit damage claim to Process Insights | COSA Xentaur immediately.

NOTE: Damage claims not received by Process Insights | COSA Xentaur within 3 days of receipt of shipment will not be accepted.

Save the original box and the packing material for use if the analyzer must be shipped in the future.

The products described in this manual are subject to continuous development and improvement and it is therefore acknowledged that this manual may contain errors or omissions. Process Insights | COSA Xentaur encourages customer feedback and welcomes any comments or suggestions relating to the product or documentation.

Please forward all comments or suggestions to the Customer Feedback Department at the following address:

COSA Xentaur
4140 World Houston Parkway
Suite 180
Houston, TX 77032
USA

+1 713 947 9591
www.cosaxentaur.com
service@cosaxentaur.com

This manual is intended solely as a guide to the use of the product.

Process Insights | COSA Xentaur, its affiliates and agents cannot be held responsible in any way for damage or injuries resulting from improper use, misuse or neglect in operating this equipment.

Process Insights | COSA Xentaur, its affiliates and agents cannot be held, shall not be liable for any loss or damage whatsoever arising from content errors or misinterpretation of information's from this manual or any misuse resulting from the use of this manual.

<u>1</u>	Content	4
<u>2</u>	INTRODUCTION	6
2.1	O2CX.....	6
<u>3</u>	RETURNED GOODS	6
3.1	Return of analyzer.....	6
<u>4</u>	Safety	7
<u>5</u>	O₂ sensor – operating theory	8
<u>6</u>	CO_e sensor – operating theory	9
<u>7</u>	System components, general information	10
7.1	Optimizing combustion	10
7.2	O2CX features	11
7.3	Probe models	12
7.3.1	Compact model O2CX (O2CX.61417).....	12
7.3.2	Remote transmitter model O2CX RT (O2CX.63467RT)	13
7.3.3	High temperature model O2CX HT (O2CX.63467HT)	14
7.4	Principle of flow guidance tube	15
7.5	Manual calibration	16
7.6	Recommended calibration gas	17
<u>8</u>	Software flow chart	18
<u>9</u>	Operation	19
9.1	Start-up	19
9.2	Warm-up	19
9.3	Main measuring menu	20
9.4	Info menu.....	20
9.5	Service menu.....	21
9.6	Settings menu	22
9.6.1	PIN code level 1	22
9.6.2	Set analog output	23
9.6.3	Damping	23
9.6.4	Back-purge setup	23
9.6.5	Interval auto-calibration	24
9.6.6	Set calibration cylinder values	24

9.6.7	Set temperature measuring unit	24
9.6.8	Set gas humidity	25
9.6.9	Solenoid test.....	25
9.6.10	O2CX settings.....	25
9.6.11	Reset to (factory) defaults	26
9.7	Calibration	27
9.7.1	O2CX model compact probe (O2CX.61417)	28
9.7.2	O2CX RT model remotetransmitter (O2CX.63467RT).....	29
9.7.3	O2CX HT model high temperature (O2CX.63467HT).....	30
9.7.4	Pin Code level 2	31
9.7.5	O ₂ cell setup (by factory only).....	32
9.7.6	CO _e cell setup (by factory only)	32
9.7.7	Adjustment O ₂ cell amplifier (by factory only)	33
9.7.8	Adjustment 4 mA – 20 mA (factory only)	34
9.7.9	Calibration AIR	35
9.7.10	Calibration AIR & GAS	35
9.7.11	CO correction factor	37
9.7.12	O ₂ heat resistor regulation (factory only)	38
9.7.13	CO _e heat resistor regulation (factory only).....	38
9.7.14	History auto-calibration.....	39
10	Troubleshooting	40
11	Technical specifications	40
12	Appendix	41
12.1	Error codes.....	41
12.2	Modbus Slave specification	42
12.3	Declaration of conformity.....	43

2.1 O2CX

Thank you for purchasing the O2CX In-Situ oxygen and combustibles (O₂ and CO_e) monitoring probe.

- Please read this instruction manual carefully before attempting to operate the analyzer. After you have become familiar with this manual, move on to installation, operation and maintenance of the analyzer. Incorrect use of the analyzer could cause an accident or injury.
- Product development and improvement are dynamic goals of Process Insights | COSA Xentaur, and specifications of this analyzer are subject to change without prior notice.
- Modification of this analyzer is strictly prohibited unless written approval is obtained from the manufacturer. Process Insights | COSA Xentaur will not be responsible for any issues of any kind resulting from any modification made to the analyzer without written permission.
- It is important that this manual remains in the custody of the actual operator of the analyzer.
- After reading the manual carefully, it should be stored in a safe, but accessible place.
- This instruction manual should be delivered to the end user immediately upon delivery.

NOTICE:

- It is prohibited to transfer part or all of this manual in written format without Process Insights | COSA Xentaur written permission.
- Product development and improvement are dynamic goals of Process Insights | COSA Xentaur, and descriptions and illustrations of the analyzer used herein are subject to change without prior notice.

Please note:

Our warranty and guarantee obligations for O2CX do not cover the usage of the analog signal 4 - 20 mA for regulation - and control-purposes. We exclude any liability for consequential damages.

3 RETURNED GOODS

Packing regulation of 12.07.1991

If your local waste facility does not except Process Insights | COSA Xentaur packing materials for disposal, you may return it to Process Insights | COSA Xentaur or our local sales representative. Packing materials returned to Process Insights | COSA Xentaur must be returned prepaid.

3.1 Return of analyzer

Process Insights | COSA Xentaur is required to accept the return, for proper disposal, of all analyzers delivered after 13th of August 2005. Analyzers must be returned to Process Insights | COSA Xentaur prepaid.

4 Safety

- The O₂ probe may only be used in original, undamaged condition and in accordance with the operation manual.
- All individuals dealing with the installation, commissioning, operation and maintenance of the analyzer or probe must be qualified to do so and must strictly observe this operation manual.
- Unauthorized modifications to any part of the analyzer or probe can create safety risks and are not permitted.
- Power other than that specified in this manual must never be provided to the probe.
- Service of transmitter electronics by non skilled personnel is not allowed.
- Do not allow condensate to come into contact with the sensors.
- Do not attempt to clean the probe with water.
- The probe shall not be used in under-stoichiometric combustion conditions, due to the possible presence of flammable gases, eventually over the LEL (low explosion level).
- Power must always be provided to the probe, even during boiler shut-down, to prevent the formation of condensate which can damage the sensors.
- Do not use the probe for any purpose other than that specified in this manual.
- Exposure to corrosive gases such as silicone vapor, alkaline and heavy metals, P, Pb, high SO₂, etc. will shorten the life time of the sensors.

It is mandatory to the user to insure that all persons operating this equipment are properly trained in its operation and fully understand the operating principals of the equipment.


Process Insights | COSA Xentaur, its affiliates and agents cannot be held responsible in any way for damage or injuries re-sulting from improper use, misuse or neglect in operating this equipment.

Caution

Probes installed inside flue ducts and stacks operate at elevated temperatures (often 1.000° F and higher) create danger of serious skin burns to operators if proper handling precautions and extreme care are not taken.

5 O₂ sensor – operating theory

Heated zirconium oxide (ZrO₂) is used as a ceramic solid electrolyte that is a good oxygen ion conductor at temperatures of approximately 1.550 °F (850 °C), generated by an internal low power (20 W) heater element. The heater element is a PTC type, self-regulating device that does not require a thermocouple for temperature regulation. Constant sensor temperature is maintained by controlling the heater voltage and current to fixed resistance of the heater element.



The electro-motive force (emf) that is generated across the solid electrolyte by the presence of oxygen ions can be measured as a sensor voltage (according to Nernst law).

$$U_s = U_0 + \frac{RT}{4F} \ln \frac{P_{O_2 \text{ ref}}}{P_{O_2 \text{ sample}}}$$

where:

U_0	=	offset voltage (for $P_{O_2 \text{ ref}} = P_{O_2 \text{ sample}}$)
R	=	universal gas constant
T	=	zirconium temperature
F	=	Faraday constant
$P_{O_2 \text{ ref}}$	=	oxygen partial pressure reference side
$P_{O_2 \text{ sample}}$	=	oxygen partial pressure sample side

This voltage is measured by micro-controller based transmitter electronics and converted into a standard 4 – 20 mA signal, linearized for oxygen in the range of 0 – 25 %.

The expected lifetime of this sensor is about 5 years + under normal operating conditions, and is not dependent on fuel type, but:

CAUTION:


- If combustible gas (CO, H₂, HC) in high concentrations are present in the sample gas, erroneous O₂ readings will result due to local combustion at the sensors' hot surface.
- Exposure to corrosive gases (silicone vapor, alkaline and heavy metals, P, Pb, high SO₂, etc.) will shorten the life of the sensor.
- Condensation of flue gas moisture close to the sensor's flange must be prevented.

6 CO_e sensor – operating theory

A solid ceramic electrolyte with thin-layer technology is used to measure the combustible gases (C_xH_y equivalent CO₂). The ceramic electrolyte is a good oxygen ion conductor at temperatures of approximately 1.300 °F (700 °C) generated by an internal, low power (10 W) self regulating heater element.



The heated electrolyte has an initial voltage (U_0 approximately zero mV) in the absence of combustible gases (H₂, CO or CH₄ or C₃H₈, etc). In presence of these gases, the output voltage increases (see chart below) as these gases are oxidized at the hot surface of sensor.



The cell voltage is measured by micro-controller based transmitter electronics and converted into a standard, linearized 4 – 20 mA signal for combustibles equivalent carbon monoxide (CO_e) in the range of approximate 0 – 1000 ppm.

Since the sensor is reacting to the presence of any combustible gas, but calibrated with CO+H₂, equivalent CO measurements will be reported.

The expected lifetime of this sensor is about 5 years + under normal operating conditions, and is not dependent on fuel type, but:


CAUTION:

- **Exposure to corrosive gases (silicone vapor, alkaline and heavy metals, P, Pb, high SO₂, etc.) will shorten the life of the sensor.**


7 System components, general information

The O2CX used to continuously measure oxygen and combustible gas concentrations in flue and stacks of industrial boilers or furnaces, and those measurements are used to finely tune the combustion process.

7.1 Optimizing combustion



Optimum combustion conditions are achieved by decreasing the amount of excess air in the stack gas to the point where combustibles start to increase. See combustion diagram below:




The absolute value of combustibles in the stack gas of a burner depends very much on the design and construction of the burner/boiler. Combustibles (C_xH_y) are lower in a well-designed system than they are one that is poorly designed.

It is important to monitor the rising level of combustibles, labeled opt in the above diagram, and to trim the air/fuel ratio of the burner to compensate for changing ambient conditions (pressure and humidity) and maintain the point of maximum heat efficiency.

The diagram below illustrates the burner operating under two conditions:

- Conventional operation with increased safety margin (higher O₂ concentration in the stack gas).
- Improved operation with optimized combustion (lowest O₂ concentration in the stack gas without a corresponding increase in combustibles).



The difference between the yellow area and the brown area represents the degree of combustion optimization, which in turn represents savings in fuel.

7.2 O2CX features

The main features of O2CX stem are:

- Compact, reliable and rugged industrial design.
- Special reference air not required (uses ambient by natural diffusion).
- True wet gas analysis and calculation of dry oxygen level if humidity of gas is known.
- Fast response time.
- Low energy consumption for both O₂ and CO_e sensors.
- Micro-controller based electronics with backlit, graphic LCD display.
- Linearized, galvanic isolated 4 - 20 mA signal outputs for both O₂ and CO_e.
- RS485 galvanic isolated digital data transfer (Modbus protocol RTU).
- Field replaceable transmitter.
- Fast, safe and easy servicing by a single technician without removing the probe from the stack.
- Dust tight and water proof enclosure IP65 (NEMA 4).
- Easy operation and maintenance.

7.3 Probe models


There are three distinctive models of the O2CX probe available:

1. The **compact** model **O2CX** uses the flow guidance tube principle. The probe tube can be made of stainless steel for stack gas temperatures up to 1.200 ° F (650 ° C) or made of AISI300 steel for stack gas temperatures up to 1.000 ° C (1.800 ° F)
2. The **remote transmitter** model **O2CX-RT**, which is similar to above model but has the transmitter electronics separated from the probe by means of a 10 m (30 ft) special cable
3. The **high temperature** model **O2CX-HT** has no flow guidance tube but uses a ceramic tube and an air jet pump (ejector) to extract the sample from the tip of ceramic tube. It can be used for clean flue gas temperatures up to 1.700 ° C (3.100 ° F).

7.3.1 Compact model O2CX (O2CX.61417)

This model shall be used at site with low heat radiated from the process (ambient temperature to transmitter electronics is less then 60 ° C (140 ° F)).

COMPACT PROBE O2CX




Compact model components are:

- probe with flow guidance tube and flange DN65/PN6 (4" ANSI150 only using flange adapter O2CX.63607M)
- mounting flange assembly (supplied by user)
- transmitter with electronics and sensors for O₂ and CO_e
- back purge system (blow-down) is not available
- pneumatic device (option) for automatic calibration

For higher temperature, less then 1.200 oC (2.000 oF), but higher then 650 ° C (1200 ° F), the model O2CX-RT with alloy AISI300 steel is recommended.

7.3.2 Remote transmitter model O2CX-RT (O2CX.63467RT)

This model shall be used when radiated heat from the process (duct, stack etc) will cause rising of ambient temperature higher than 60 °C (140 °F).



Remote transmitter model components are:


- probe with flow guidance tube and flange DN65/PN6 (4" ANSI150 using flange adapter O2CX.63607M)
 - SS316Ti material for temperature below 650 °C (1200 °F)
 - AISI300 material for temperature below 1.000 °C (1.800 °F)
- mounting flange assembly (supplied by user)
- detector head with junction box for sensors O2 and COe
- transmitter with electronics and switched power supply
- special cable between junction box and transmitter
- back purge system (option) for high dust conditions → only for site with flying ash type of dust
- pneumatic device PU420 (option) for automatic calibration

This model can be equipped :

- with blow-down (back-purge) for dusty stack gases (O2CX.63467RT)
- without blow-down (back-purge) for clean stack gases (O2CX.61417RT)

7.3.3 High temperature model O2CX-HT (O2CX.63467HT)

This model shall be used at sites with high temperature flue gas, less then 1.700 °C (3.100 °F)



High temperature model components are:

- probe with ceramic tube, ejector and flange 4" ANSI-150
- mounting flange assembly (supplied by user)
- detector head with junction box for sensors O₂ and CO_e
- transmitter with electronics and switched power supply
- special cable between junction box and transmitter
- pneumatic device PU420 (option) for automatic calibration
- back purge is available through calibration inlet port


The main differences between the remote transmitter model and the high temperature models are:

- the use of ceramic tube of sampling probe on the high temperature model
- the use of an ejector (air jet pump) to draw sample to the sensors..

When the ejector is purging instrument air with some 300 l/h, a negative pressure on the back-side of a nozzle will be created. The negative pressure draws the sample gas from the tip of ceramic tube to the sensors.

7.4 Principle of flow guidance tube

The construction of the sampling probe is using the flow guidance principle



The tube is divided in half by a metal plate welded into the middle of the tube.

The probe is mounted on the stack by means of an 8-hole flange (ANSI 4", 150 lbs or DN100). The tip of the divider plate is oriented facing towards the flow, which directs the stack gas into and through the tube at the same velocity as the flow in the stack.

The detector body is mounted on the flanged side of the tube through a hole in the flange cut for that purpose. In the body, behind a filter screen (the measuring side of detector), the two sensors for oxygen and combustibles are exposed to the stack gas flowing through the filter screen. In the detector behind the sensors, ambient air for reference gas diffuses through another filter screen (for dust protection) and flushes the backside of sensors (the reference side of the detector).





Illustration for compact probe only

The flange feeds compressed air to several holes placed strategically around the detector and through a small tube, with air-releasing orifices spaced along its entire length, which is mounted along the metal plate in the center of the probe. The timing, duration and number of pulses of compressed air is controlled by user-settable electronic parameters and released by a solenoid valve. During purging, compressed air blows across the filter screen protecting the sensors, and from the holes in the tiny blow-back tube in the center of the probe, dislodging any accumulation of particulates so they will flow freely out of the probe and back into the stack.

7.5 O2CX transmitter electronics

The transmitter is housed in an aluminum enclosure (IP65, NEMA4X) that contains:

- Printed circuit board with u-processor (PCB "MAIN")
- Backlit, graphic display and dust proof keypad
- Printed circuit board for the sensor connection (PCB "OMS")
- Electrical connector for power supply and data transfer




7.5 Manual calibration

To perform calibration of the instrument, the user can use following schematic diagram (or similar).

It is advisable to use moistured calibration gas (see § 4.7) and two hand-ball valves to select between instrument air (zero gas) and calibration gas (span gas) supply to calibration inlet port of unit.

COMPACT PROBE 02CX with MANUAL CALIBRATION



The procedure of calibration is described in chapter § 6.7.


7.6 Recommended calibration gas

For automatic calibration or manual calibration (see procedure in chapter 6.7.3) customer shall use following calibration gases:

- 1) zero gas = instrument air (21 %O₂ , 0 ppm HC)
- 2) span gas = 2...3 %O₂ ; 400...600 ppm CO ; 400...600 ppm H₂ ; rest N₂

Note: It is highly recommended to use water bubbler to moisture the calibration gas!!!

8 Software flow chart



9 Operation

9.1 Start-up

Prior to start-up, use the following check list to verify that all conditions are set for proper start-up:

Checklist transmitter

- Transmitter removed from the probe? (Note: always power up with transmitter removed from the probe/stack!!)
- Cast cover closed and screwed on?
- Transmitter easily accessible and visible?
- Ambient temperature around transmitter electronics in operating range of -20 °C to 60 °C (0°F to 140 °F)?
- Correct location of transmission cable (not in close proximity to high power supply cables or engines)?
- Connection for power supply connected properly?
- Signal connection connected properly?
- Power supply (factory provided line power fuse) switched on?
- Start up considerations:


Wiring: Most problems are due to incorrect wiring. Please double check the wiring. Shield should be grounded only at one side of the cable.

Leaks: Check the calibration inlet port plug for correct fit.

Insulation: Check that the mounting flange has been properly insulated to prevent gas condensation.

Temperature: Check mounting flange temperature: min. 70 °C (160 °F) and max. 150 °C (300 °F).
Check ambient temperature of transmitter for max. 60 °C (+140 °F).


Note: **If flange temperature at site with mounted probe and transmitter is below 70 °C (160 °F) it is necessary to use a flange heater (ask Process Insights | COSA Xentaur) to prevent condensation!!!**



After power is switched on, the COSA Xentaur logo and model of the unit will be displayed!

9.2 Warm-up

Warm-up time: minimum 30 minutes



LCD will display a time count down for 30 minutes.

During warm-up, some inside measured values (heaters current and voltages) will be compared with credible thresholds and in case of "out-of-range", an error message will be displayed. After countdown, if everything is OK, the message will change from "please wait" to the main measuring menu.

The "SKIP" function is used only for service purposes, to allow the operator to access other unit functions without waiting until the end of warm-up interval time. During this time, measurement values are not credible.

During warm-up, all other menus (info, service and setting) are accessible.

9.3 Main measuring menu

After warm-up, the unit will start automatically by displaying the main measurement menu.

O₂ real time value with 0.01% resolution

CO₂ real time value with ppm resolution

Oxygen %w		COe ppm	
3.00		51	
INFO	SERV	SET	CALIB

Press "INFO" key for "info" menu

Press "SERV" key for "service" menu

Press "SET" key for "settings" menu

Press "CALIB" key for "calibration" menu

(see chapter 9.4)

(see chapter 9.5)

(see chapter 9.6)

(see chapter 9.7)

NOTE:

If between 30 min no button is pressed during the measurement, the level will be set on "0". I.e. the menus SET and CALIB are only by renewed PIN input usable.

9.4 Info menu

Oxygen %w		COe ppm	
3.00		51	
INFO	SERV	SET	CALIB

press

Back-purge in		01:57
Auto-cal int.		----
Gas humidity disabled		
O2 value		wet
4-20 mA O2		0-20.96
4-20 mA CO		0-1000
BACK	UP	DOWN

press

```

Firmware          V1.00
Hardware          V1.00
Serial number     123456
O2 cell          installed
CO cell          installed

```

BACK	UP	DOWN
------	----	------

In the "INFO" menu the following parameters can be called up from a scroll up/down list:

- Next back-purge in hours/minutes
- Next automatic set to zero in days/hours
- If the display shows „----“ the automatic set to zero is not activated
- Gas humidity display in % 1 - 25 or disabled
- O₂ value
 - wet: The O₂ display is calculated to "wet" (*)
 - dry: The O₂ display is calculated to "dry" (*).
 - The gas humidity can be set by "SET" to "Set gas humidity"
- 4 - 20 mA O₂ setting range of analog O₂ output
- 4 - 20 mA CO_e setting range of analog CO_e output
- Firmware installed firmware version
- Hardware installed hardware version
- Serial number display of the serial number
- O₂ sensor installed
- CO sensor installed/not installed

(*) Formula for O₂ calculation dry/wet

$$O_2 \text{ max} = 20.97\% \quad \text{oxygen content in air}$$

O_{2wet} = measured O_2 -value in wet stack gas

$$O_2dry = \text{calculated (\%)} O_2\text{-value dry}$$

$$H = \text{water content (\%)} \text{ in stack gas, (value entered manually)}, \quad H = 100 \cdot \left(1 - \frac{O_{2wet}}{O_{2dry}} \right)$$

therefore calculation of $O_{2dry} = O_{2wet} \cdot \left(\frac{100}{100 - H} \right)$

9.5 Service menu

Oxygen %w		COe ppm		O2 cell -10.01 mV				Unit temp. 96.8 °F			
3.00		51		O2 heater 12.012 V				Error code 0			
				O2 heater 1.309 A							
				CO cell 5.0 mV							
				CO heater 8.021 V							
				CO heater 403 mA							
INFO	SERV	SET	CALIB	press				press			
				SERV				UP			
				BACK UP DOWN				BACK UP DOWN ERROR			

Displays actual 6 lines from a scroll up/down list with measured (A/D converter) components information.

Press the "UP" or "DOWN" key and return back to main measuring menu by pressing "BACK".

	standard value	allowed deviation
O ₂ cell	- 10 mV (with operation temperature and 21 % O ₂)	± 5 mV
O ₂ heater	12 V (depending on flange temperature)	± 2 V
O ₂ heater	1,3 A (heater current)	± 0,3 A
CO cell	5 mV (after warm-up and with fresh air)	± 5 mV
CO heater	7,5 V (depending on flange temperature)	-3,0 V.... + 1 V
CO heater	0,4 A (heater current)	± 0,1 A
Unit temperature		less then 60 °C (140 °F)

Typical mV-values for COe sensor:

O₂ = 3 %, CO = 200 ppm → 98,0 mV

O₂ = 3 %, CO = 500 ppm → 190,0 mV

O₂ = 10 %, CO = 200 ppm → 32,0 mV


O₂ = 10 %, CO = 500 ppm → 93,0 mV

If the system detects an error, the plain text meaning will be displayed after pressing "ERROR" key

9.6 Settings menu

This menu is protected by a user level 1 PIN code. Changing the pin code is described in following chapter.

9.6.1 PIN code level 1



Entering the factory default PIN code 1111 (user level 1), gains access to the SET main menu and the above settings.

9.6.2 Set analog output

Analog output Damping Back-purge-setup Interval auto-cal Calibration cylinder BACK UP DOWN ENTER press OK	press ENTER	Analog output O2 0 - 20.96% CO 0 - 1000 ppm Hold after purge 20 BACK PREV NEXT EDIT press EDIT	press EDIT	Analog output O2 0 - 20.96% CO 0 - 1000 ppm Hold after purge 20 OK UP DOWN POS
---------------------------------------------------------------------------------------------------------------------------------------	----------------	-------------------------------------------------------------------------------------------------------------------------	---------------	---------------------------------------------------------------------------------------------------

PREV or NEXT move cursor to values which can be changed
 EDIT change value by means of UP/DOWN and POS
 OK save values
 BACK return to main menu

Factory defaults are: 20mA: O₂ 0 – 21.00 %
 20mA: CO_e 0 – 1.000 ppm
 Hold after purge typical 20 sec. (from 5 to max 200 seconds)

Notice: The last measured value on analog output 4-20mA after back-purge is hold even after back-purge cycle is finished.

9.6.3 Damping

This function allows user to set a damping (averaging the measurement over a period of time) of measurement, in the display as well in the analog output.

Analog output Damping Back-purge-setup Interval auto-cal Calibration cylinder BACK UP DOWN ENTER press ENTER	press ENTER	Damping O2 -> 0 sec. CO --> 0 sec. BACK EDIT press EDIT	press EDIT	Damping O2 -> 0 sec. CO --> 0 sec. BACK EDIT
------------------------------------------------------------------------------------------------------------------------------------------	----------------	-------------------------------------------------------------------------------	---------------	--------------------------------------------------------------

PREV or NEXT move cursor to values which can be changed
 EDIT change value by means of UP/DOWN and POS
 OK save values
 BACK return to main menu

Integration times from 0 to 30 seconds are settable, where 0 seconds means no damping.

9.6.4 Back-purge setup

This function allows setup of the optional back-purge solenoid valve to control:

- interval time between back purges (hours and minutes)
- pulse duration or interval time for energizing the solenoid valve (opening the valve)
- number of pulses during one back purge cycle

Analog output Damping Back-purge-setup Interval auto-cal Calibration cylinder BACK UP DOWN ENTER press OK	press ENTER	Back-purge-setup interval 2 hrs 0 min Pulse duration 2 Pulse number 6 BACK PREV NEXT EDIT press EDIT	press EDIT	Back-purge-setup interval 2 hrs 0 min Pulse duration 2 Pulse number 6 OK UP DOWN POS
---------------------------------------------------------------------------------------------------------------------------------------	----------------	-------------------------------------------------------------------------------------------------------------------------------	---------------	---------------------------------------------------------------------------------------------------------

PREV or NEXT move cursor to values which can be changed
 EDIT change value by means of UP/DOWN and POS
 OK save values
 BACK return to main menu

If hours and minutes are 0, the back purge function is deactivated. The delivery state of this function is off.

9.6.5 Interval auto-calibration

This function allows setting the interval of auto calibration

Analog output Damping Back-purge-setup Interval auto-cal Calibration cylinder BACK UP DOWN ENTER	press	Interval auto-cal interval (days) 1 purg time (min) 0 Auto-Cal AIR/GAS BACK START EDIT	press	Interval auto-cal interval (days) 1 purg time (min) 0 Auto-Cal AIR/GAS OK UP DOWN NEXT
------------------------------------------------------------------------------------------------------------------------	-------	----------------------------------------------------------------------------------------------------	-------	-----------------------------------------------------------------------------------------------------------

PREV or NEXT move cursor to values which can be changed
 EDIT change value by means of UP/DOWN and NEXT
 BACK return to main menu
 START Starts the auto cal immediately

Interval: 0 – 99 days **.Note: If "interval" is 0, the auto cal. function is deactivated!**
 Purge time: 1 – 10 minutes
 Auto-cal: AIR or AIR and Gas
 AIR: 1 point calibration with AIR (zero gas)
 AIR/GAS: 2 points calibration with combined AIR an GAS (zero gas and span gas)
 First calibration must always be the zero calibration with AIR".

The delivery state of this function is "off".

9.6.6 Set calibration cylinder values

This function allows setting the values of span gas cylinders used for calibration.

Analog output Damping Back-purge-setup Interval auto-cal Calibration cylinder BACK UP DOWN ENTER	press	Calibration cylinder zero span O2 (%) 20.96 2.00 CO (ppm) 0 500 BACK PREV NEXT EDIT	press	Calibration cylinder zero span O2 (%) 20.96 2.00 CO (ppm) 0 500 OK UP DOWN POS
------------------------------------------------------------------------------------------------------------------------	-------	-------------------------------------------------------------------------------------------------	-------	--------------------------------------------------------------------------------------------

press

OK

PREV or NEXT move cursor to values which can be changed
 EDIT change value by means of UP/DOWN and POS
 OK save values
 BACK return to main menu

The set values for "zero" are fixed values, programmed into the unit's firmware.

The values for the calibration gas cylinder setting have to be set to the correct cylinder values for both O₂ and CO_e.

9.6.7 Set temperature measuring unit

Damping Back-purge-setup Interval auto-cal Calibration cylinder Measuring units BACK UP DOWN ENTER	press	Measuring units Temp °F BACK EDIT	press	Measuring units Temp °F OK UP DOWN POS
--------------------------------------------------------------------------------------------------------------------------	-------	-----------------------------------------	-------	-----------------------------------------------------

press

OK

EDIT change value by means of UP/DOWN
 OK save values
 BACK return to main menu

Set the temperature units to °C or °F

9.6.8 Set gas humidity

This function allows setting the value of gas humidity (if known) and selection of either wet oxygen measurement or dry oxygen calculation.

Back-purge-setup Interval auto-cal Calibration cylinder Measuring units Set gas humidity	press	Gas humidity Display O2 Humidity	wet --.0 %	press	Gas humidity Display O2 Humidity	wet --.0 %
BACK UP DOWN ENTER	ENTER	BACK	EDIT	EDIT	OK UP DOWN POS	
press						
OK						

NEXT move cursor to values which can be changed
 EDIT change value by means of UP/DOWN
 OK save values
 BACK return to main menu

Change value of gas humidity (XX.X %) if this is known.

Using the formula: Humidity $H \% = (1 - O_{2wet}/O_{2dry}) \times 100$ the dry oxygen is calculated and displayed.

Default value for humidity = disabled

In the main menu the readings are w → wet oxygen measurement and d → dry oxygen calculation

9.6.9 Solenoid test

With the menu option "Solenoid test" allows to test each individual solenoid valve (if installed)

Interval auto-cal Calibration cylinder Measuring units Set gas humidity Solenoid test	press	O2 (%) CO (ppm) SV1 Backpurge SV2 Zerogas SV3 Spangas
BACK UP DOWN ENTER	ENTER	BACK SV1 SV2 SV3

A manual switch ON or OFF of all 3 individual solenoid valves is possible.

By means of the key F1 the solenoid valve SV1 is switched ON or OFF, key F2 the solenoid valve SV2 is switched ON or OFF and with the key F3 the single solenoid valve SV3 is switched ON or OFF.

The display shows the current O₂ and/or CO_e value(s).

Warning: All valves can be switched at the same time. It does not take place monitoring on a meaningful position of the single solenoid valves. This operation is only for authorized technical personal!

9.6.10 02CX settings

This function allows change of display contrast and set of transmitter address for multiple transmitter connection on the same RS485 data bus.

Calibration cylinder Measuring units Set gas humidity Solenoid test OMS 420 settings	press	Contrast (0-20) Device-ID (Modbus)	10 1	press	Contrast (0-20) Device-ID (Modbus)	10 1
BACK UP DOWN ENTER	ENTER	BACK PREV NEXT EDIT	EDIT	EDIT	OK UP DOWN POS	
press						
OK						

to get back to main settings menu

PREV or NEXT move cursor to values which can be changed
 EDIT change value by means of UP/DOWN and POS
 OK save values
 BACK return to main menu

LCD – Contrast 0-20 (10 for default)

Device-ID (Modbus) Slave address (RS 485-Modbus RTU)

9.6.11 Reset to (factory) defaults

Measuring units	press ENTER	Reset to defaults Are you shure?	
Set gas humidity			
Solenoid test			
OMS 420 settings			
Reset to defaults			
BACK UP DOWN ENTER		YES NO	

YES System parameters will be reset to factory defaults
 NO Function will be aborted

Factory defaults

Auto-calibration	OFF
Back-purge	OFF
4 – 20 mA Range O ₂	20,96 %
4 – 20 mA range CO _e	1.000 ppm
O ₂ cylinder1	21,00 %
O ₂ cylinder2	2,00 %
CO cylinder1	0 ppm
CO cylinder2	500 ppm (mixture gas with additional 500 ppm H ₂ gas is expected!)
Pulse duration	2 sec.
Numb. of pulses	6
Hold after purge	20 sec.
Unit temp.	°C
Display O ₂	wet
Humidity	--.- % (without)
Interval (days)	0 (auto-calibration = OFF)
Purge time (min.)	0
Auto-Cal.	AIR (only 1 point calibration)

9.7 Calibration

The transmitter should be powered up for at least 2 ... 3 hours before calibration.


A test (calibration) gas cylinder is connected to the calibration gas inlet port for calibration.

Adjustment can be done manually or automatically using the solenoid valves of the optional pneumatic unit PU420.

The test gas (clean fresh air/instrument air or calibration gas) flows through the hole inside the small flange (sensor manifold), purges the sensors and exits through the filter screen to the inside probe tube mounted on the stack.

On site calibration is done without removing the probe from the stack.

After calibration, tighten the calibration inlet port plug with a 14 mm wrench for 1/6 of a turn.




Perform adjustment:

- 1 Purge sensor with ambient air (40 l/h using the calibration gas inlet port).
- 2 When being purged with fresh air, the analog output signal should be 17.37 mA (for 0 – 25 % O₂ measuring range).
- 3 With calibration gas (2% O₂ in N₂), the analog output should be 5.28mA (for 0 - 25% O₂ measuring range).
- 4 The transmitter is now ready for operation.

Use calibration gas cylinder at least every 3 - 6 months.


Calibration with ambient clean air can be done automatically on a daily basis using the pneumatic option PU420.

9.7.1 O2CX model compact probe (O2CX.61417)





Pos.	Description
1	Electrical connector
2	Hose connection cal gas
3	Probe tube (stainless steel)
4	Flange DN65PN6 (stainless steel)
5	Probe head (transmitter with electronics)
6	Calibration gas cylinder
7	Pressure regulator with flow volume control

9.7.2 02CX-RT model remote transmitter (02CX.63467RT)



Pos.	Description
1	Hose PTFE connection of back purge air
2	Hose PTFE connection cal gas and back purge air
3	Probe tube (stainless or Inconel steel)
4	Flange DN65 PN6 (stainless steel)
5	Probe detector head
6	Calibration gas cylinder
7	Pressure regulator with flow volume control
8	Transmitter with electronics
9	Special connection cable (10 m or 30 m)
10	Compressed air or Nitrogen N ₂ (6 – 8 bar) supply

9.7.3 O2CX-HT model high temperature (O2CX.63467HT)



Pos.	Description
1	Hose connection injector
2	Hose connection cal gas and back purge air
3	Probe tube (Inconel or ceramic)
4	Flange 4" AINSI 150
5	Probe head
6	Calibration gas cylinder
7	Pressure regulator with flow volume control
8	Transmitter
9	Special connection cable (10 m or 30 m)
10	Compressed air or Nitrogen N ₂ (6 – 8 bar) supply

IMPORTANT: Only authorized persons or manufacturer's trained technicians are authorized to perform calibration adjustments on the O2CX.

9.7.4 Pin Code level 2

Calibration with AIR (zero gas) or GAS (span gas) requires the use of level 2 pin code

Oxygen %w	COe ppm
3.00	51
INFO	SERV SET CALIB

press

PIN code			
BACK	UP	DOWN	ENTER

see chapter 9.6.1

Pin code	----
User level:	0
BACK	EDIT

press

Pin code	2222
User level:	2
BACK	EDIT

POS **position**
UP / DOWN **to change the numbers**

NOTE:

Below displayed values e.g. O₂ factor and offset values are examples!

9.7.5 O₂ cell setup (by factory only)

If there is no calibration gas available and the cell must be replaced, this function permits changing a cell without calibration. This can only be done if the cell factors have been measured at COSA Xentaur and delivered together with the spare sensor.

O₂ cell setup CO cell setup Adj. O ₂ cell amplif. Adj. 4 mA and 20 mA Calibration AIR BACK UP DOWN ENTER	press	O ₂ (%) 1,88 O ₂ factor 1648 O ₂ offset -100 Temp. offs 0 BACK PREV NEXT EDIT	press	O ₂ (%) 1,88 O ₂ factor 1648 O ₂ offset -100 Temp. offs 0 OK UP DOWN POS
press	OK	press	press	press
		press	press	press
		press	press	press

PREV or NEXT move cursor
 EDIT change value by means of UP/DOWN and POS
 OK save values
 BACK return to calibration menu

- 1) O₂ cell setup requires input (edit function) of O₂ factor and O₂ offset values delivered with the spare sensor
- 2) Temperature compensation of 20.9 % O₂ is required when oxygen value at air is changed too much because of gas or flange temperature change. The difference of air oxygen measurement at lower temperature to measurement at higher temperature will be edit as "Temp.offs" value.

NOTE:

This procedure should be followed by new calibration using calibration gas cylinder.

Only authorized persons or manufacturer's trained technicians are authorized to perform adjustments on the O2CX.

9.7.6 CO_e cell setup (by factory only)

If there is no calibration gas available and the cell must be replaced, this function permits changing a cell without calibration. This can only be done if the cell factors have been measured at COSA Xentaur and delivered together with the spare sensor.

O₂ cell setup CO cell setup Adj. O ₂ cell amplif. Adj. 4 mA and 20 mA Calibration AIR BACK UP DOWN ENTER	press	CO (ppm) 450 CO factor 997 CO offset 0 BACK PREV NEXT EDIT	press	press
	press		press	

PREV or NEXT move cursor
 EDIT change value by means of UP/DOWN and POS
 OK save values
 BACK return to calibration menu

CO_e cell setup factor and CO offset setup factor will be edit using the values delivered together with the spare sensor.

Set point of heat resistor [Ohm] must be also carried out according to § 9.7.13.

NOTE:

This procedure should be followed by new calibration using calibration gas cylinder.

Only authorized persons or manufacturers trained staff are allowed to perform adjustments on the O2CX.

9.7.7 Adjustment O₂ cell amplifier (by factory only)

The diagram illustrates the sequence of screen displays for setting the O2 cell amplifier. Each screen shows the current value (29.22 mV) and the parameter being adjusted. The sequence is as follows:

- Screen 1: O2 cell setup, CO cell setup, Adj. O2 cell amplif., Adj. 4 mA and 20 mA, Calibration AIR. Buttons: BACK, UP, DOWN, ENTER.
- Action: press ENTER.
- Screen 2: Adj. O2 cell amplif., Set offset, Set span (1002). Buttons: BACK, PREV, NEXT, EDIT.
- Action: press EDIT.
- Screen 3: Adj. O2 cell amplif., Set offset, Set span (1002). Buttons: OK, UP, DOWN, POS.
- Action: press OK, UP, DOWN, POS.
- Screen 4: Adj. O2 cell amplif., Set offset, Set span (1002). Buttons: BACK, PREV, NEXT, EDIT.
- Action: press BACK.
- Screen 5: Adj. O2 cell amplif., Set offset, Set span (1002). Buttons: BACK, PREV, NEXT, EDIT.

PREV or NEXT	move cursor
EDIT	change value by means of UP/DOWN and POS
OK	save values
BACK	return to calibration menu

This procedure is required only when a new O₂ cell is installed.

Source a precision voltage device to the input connectors of the O₂ cell signal (see picture below) and select


-10mV for offset trim and +100mV for span trim.

If actual values displayed are other than -10mV to +100mV setting can be adjusted by selecting "Set offset" or "Set span" and editing and replacing the displayed numbers with the actual numbers.

Factory default = factory adjusted values

ATTENTION:

Changes of these factors require new gas calibration. Only authorized persons or manufacturer's trained technicians are authorized to perform adjustments on the O2CX.



9.7.8 Adjustment 4 mA – 20 mA (factory only)

Connect precision 100 Ohm resistor (0.1% tolerance) to both analog outputs of O₂ and CO measurements.

Measure the voltage across the resistors using a precision digital multi-meter.



O2 cell setup CO cell setup Adj. O2 cell amplif. Adj. 4 mA and 20 mA Calibration AIR press BACK UP DOWN ENTER	Adj. analog current Adj. 4 mA 20 mA O2 out 7 1012 CO out 5 1009 press BACK PREV NEXT EDIT	Adj. analog current Adj. 4 mA 20 mA O2 out 7 1012 CO out 5 1009 press OK UP DOWN POS
----------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------

Adj. analog current Adj. 4 mA 20 mA O2 out 7 1012 CO out 5 1009 press OK	Adj. analog current Adj. 4 mA 20 mA O2 out 7 1012 CO out 5 1009 press BACK
-----------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------

PREV or NEXT move cursor
 EDIT change value by means of UP/DOWN, until you read 400mV, up to 2000mV on the multi-meter
 OK save values
 BACK return to calibration menu

Note:

The 4 – 20mA analog output factory adjustment can deteriorate over time, so measured values must be verified occasionally. Only authorized persons or manufacturers trained staff are allowed to perform adjustments on the O2CX.



9.7.9 Calibration AIR

This menu performs the 1 point calibration with AIR (zero gas).

O2 cell setup	
CO cell setup	
Adj. O2 cell amplif	
Adj. 4mA and 20 mA	
Calibration AIR	
BACK	press ENTER

Calibration: -- AIR--	
O2 (%) cylinder measure	
20.96 20.90	
CO (ppm) 0 5	
press CALIB	

Calibration: -- AIR--	
O2 (%) cylinder measure	
20.96 20.90	
CO (ppm) 0 5	
Please wait...	

Calibration: -- AIR--	
O2 (%) cylinder measure	
20.96 20.96	
CO (ppm) 0 0	
O2 o.k. CO o.k.	

Calibration: -- AIR--	
O2 (%) cylinder measure	
20.96 20.96	
CO (ppm) 0 5	
press OK	

O2 cell setup	
CO cell setup	
Adj. O2 cell amplif	
Adj. 4mA and 20 mA	
Calibration AIR	
BACK	press ENTER

Wait approximately 5 minutes while instrument air is being supplied to sensors to allow signals to stabilize.

Press "CALIB" key

Wait for approximately 3 seconds.

Zero gas (AIR) calibration was successful.

If calibration fails, an error message will be displayed.

Return to setting menu.

O₂ OK. CO OK or O₂ failed! CO failed!

If calibration fails, an error message will be displayed.

9.7.10 Calibration AIR & GAS

This menu performs the 2 points calibration with combined AIR and GAS (zero gas and span gas).

For the calibration, the use of moistured mixture gas (O₂, CO and H₂) is mandatory.

Moisturing the span gas requires the use of water bubbler!

With single component CO gas, the calibration is not correct (must be avoided)

If no mixture gas is available, then see chapter 9.7.11.

Calibration of O₂ only: set CO cylinder (value) = 0 → no calibration

Calibration of CO only: set O₂ cylinder (value) = 0 → no calibration

First calibration must always be the zero calibration with "AIR"

CO cell setup			
Adj. O2 cell amplif			
Adj. 4mA and 20 mA			
Calibration AIR			
Calibration AIR / GAS			
BACK	UP	DOWN	ENTER

press

ENTER

Calibration: -- AIR--			
cylinder measure			
O2 (%)	20.96	20.90	
CO (ppm)	0	5	
BACK		CALIB	

press

CALIB

Wait approximately 5 minutes while instrument air is being supplied to sensors to allow signals to stabilize.

Press "CALIB" key

Calibration: -- AIR--			
cylinder measure			
O2 (%)	20.96	20.90	
CO (ppm)	0	5	
Please wait...			

Wait for approximately 3 seconds!

Calibration: -- AIR--			
cylinder measure			
O2 (%)	20.96	20.96	
CO (ppm)	0	0	
O2 o.k. CO o.k.			

Zero gas (AIR) calibration was successful.

If calibration fails, an error message will be displayed.

Calibration: -- AIR--			
cylinder measure			
O2 (%)	20.96	20.96	
CO (ppm)	0	5	
OK		CALIB	

press

OK

Second calibration shall be the span calibration with "GAS"

Calibration: -- GAS--			
cylinder measure			
O2 (%)	2.00	2.05	
CO (ppm)	500	457	
BACK	O2	CALIB	CO

press

CALIB

Read calibration gas cylinder values and if any change is required (other cylinder values) then edit O₂ and CO in the display by pressing "O₂" then the "CO" key.

Wait approximately 5 minutes while calibration gas is being supplied to sensors to allow signals to stabilize, then press "CALIB" key.

Calibration: -- GAS--			
cylinder measure			
O2 (%)	2.00	2.05	
CO (ppm)	500	457	
Please wait...			

Wait for approximately 3 seconds.

Calibration: -- GAS--			
cylinder measure			
O2 (%)	2.00	2.00	
CO (ppm)	500	500	
O2 o.k. CO o.k.			

Span gas (GAS) calibration was successful.

If calibration fails, an error message will be displayed.

Calibration: -- GAS--			
cylinder measure			
O2 (%)	2.00	2.00	
CO (ppm)	500	500	
OK	O2	CALIB	CO

press

OK

Return to previous setting menu.

9.7.11 CO correction factor

This function allows user to perform site calibration of combustibles measurement with a comparative selective CO measurement, using **portable CO analyzer** (e.g. DELTA65). This will make the equivalency to CO and is recommended to be carried out at stable, constant combustion process.

[illegible]


Because sensor is measuring all combustibles in the flue gas, a difference to selective CO measurement will occur.

By using the correction factor, this difference will be minimized, the instrument will display same value as the comparing CO selective measuring instrument.

- 1) The measured value by means of DELTA65 can be set ("desired value") by pressing "EDIT" key.
- 2) Using the "UP" and "DOWN" keys will change this value until it corresponds to Delta65 measurement of CO.
- 3) Then press "OK" key to correct the combustibles measurement to selective CO measured value.

NOTE: by pressing the key "FACT." the CO correction factor will be set to 1000 (amplification is 1)!!!!

In that case, adjustment of COe reading according to measurement by means of Delta65 is out of order!



Use a portable analyzer to measure CO in the flue gas and to adjust accordingly the "desired value".

9.7.12 O2 heat resistor regulation (factory only)

Adj. 4mA and 20 mA Calibration AIR Calibration AIR / GAS CO correction factor O2 heat resistor	press	O2 heater 5.034 V Reg. point 0.397 Set. point 9.000	press	O2 heater 5.034 V Reg. point 0.397 Set. point 9.00 0
BACK UP DOWN ENTER	ENTER	BACK PREV NEXT EDIT	EDIT	OK UP DOWN POS

press	O2 heater 5.034 V Reg. point 0.397 Set. point 9.000
OK	BACK PREV NEXT EDIT

PREV or NEXT move cursor
 EDIT change value by means of UP/DOWN and POS
 OK save values
 BACK return to calibration menu

First line: regulation point actual (O₂)

Second line: new set point (Heat resistor [Ohm])

ATTENTION:

Changes of these parameters require new calibration.

Only authorized persons or manufacturer's trained technicians are authorized to perform adjustments on the O2CX

9.7.13 COe heat resistor regulation (factory only)

Calibration AIR Calibration AIR / GAS CO correction factor O2 heat resistor CO heat resistor	press	CO heater 8.012 V Reg. point 0.3883 Set. point 21.000	press	CO heater 8.009 V Reg. point 21.500 Set. point 21.00 0
BACK UP DOWN ENTER	ENTER	BACK PREV NEXT EDIT	EDIT	OK UP DOWN POS

press	CO heater 5.744 V Reg. point 0.3883 Set. point 21.000
OK	BACK PREV NEXT EDIT

PREV or NEXT move cursor
 EDIT change value by means of UP/DOWN and POS
 OK save values
 BACK return to calibration menu

First line: regulation point actual (CO)

Second line: new set point (Heat Resistor [Ohm])

Heat resistor [Ohm]

COe: $R_{25^{\circ}\text{C}} * (\text{approx } 9 \Omega)$

$$R_{\text{setpnt}} = R_{25^{\circ}\text{C}} * 2,5 + K [\Omega]$$

where $K = 0$ for compact probe

$K = 0,7$ for RT(HT) probe with 10m cable

$K = 2,1$ for RT(HT) probe with 30m cable

R higher → higher temperature → lower offset signal, faster response time, low CO response signal

R lower → lower temperature → larger CO response signal, and lower response time

ATTENTION:

Changes of these parameters require new calibration.

Only authorized persons or manufacturer's trained technicians are authorized to perform adjustments on the O2CX.

9.7.14 History auto-calibration

This function allows the user to see the last auto calibration values.

Calibration AIR / GAS		Factor	last	current
CO correction factor		O2 Off.	0	0
O2 heat resistor		CO Off.	0	0
CO heat resistor		O2 Span	10	845
History (auto-cal)	press	CO Span	3	968
BACK UP DOWN ENTER	ENTER	BACK		

10 Troubleshooting

If the system detects an error, the plain text will be displayed after pressing the "Error" key in the service menu.

<u>Malfunction:</u>	<u>Corrective action:</u>
No display	Check power supply, check cables and connectors
Display: Heating current<0.5A Sensor element defect	O ₂ sensor element defect Check heater resistance of sensor Replace sensor
Display: Configuration not ok Checksum wrong	New adjustment required
Display: Flash error!	New adjustment required Please contact your dealer (manufacturer).
Display: Unit to warm Hot environment	Ambient temperature too high! Use heat shield or attach a compressed air based Vortec cooler
Transmitter does not react with sample gas from stack	Clean the filter screen.
Calibration error	Calibration factor cannot be set. Test gas cylinder is empty, filter screen dirty or clogged Calibration offset value cannot be set. Instrument air supply is not available,
Transmitter does not react with test gas	Please contact your dealer (manufacturer).

11 Technical specifications

Measurements	Oxygen and combustibles (equivalent CO _e) contained in flue gas
Measurement principle	Heated zirconium oxide cell for O ₂ Heated solid electrolyte cell for CO _e
Lifetime of cells	more than 5 years under normal conditions (*)
Warm-up time	minimum 30 minutes
Measurement range	0 – 25.0 % for O ₂ 0 – 1,000 ppm for CO _e
Resolution	0.01 % for O ₂ and 1 ppm for CO _e
Repeatability	within ± 1 % of full scale for O ₂
Linearity	better than ± 1 % of full scale for O ₂
Accuracy	O ₂ : ± 0.2 % O ₂ or ± 5 % of reading (whichever is larger) CO _e : not selective measurement, accuracy is not an issue
Response time	< 10 seconds
Electronics	micro-controlled based, on board graphic backlit LCD
Output signals	2 x 4 – 20 mA, galvanic isolated, max. 500 R (for direct transfer to process PLC) RS 485, galvanic isolated digital data transfer (Modbus protocol RTU)
Power supply	18 Vdc to max. 24 Vdc, 100 W for compact probe model O2CX 100...240Vac / 50-60Hz, 100W for all other models
Ambient temperature	- 4° F ... 140° F (-20°C ...+ 65°C)
Ambient humidity	5 – 95 %, non condensing
Protection	IP 65 (NEMA 4)

(*) in the absence of heavy metals, silicones, silicates, aggressive and/or corrosive gases

12 Appendix

12.1 Error codes

- 02 Configuration Error, new adjustment required.
- 04 Flash Error, new adjustment required Please contact your dealer (manufacturer).
- 08 Unit too warm, ambient temperature too high!
- 01 Heating current < 0.5A, O₂ sensor not ok.
- 32 Heating current < 0.1A, CO_e sensor not ok.
- 64 Heating current < 0.1A, CO_e sensor not ok.
- 128 Calibration error, calibration factor cannot be set.
Test gas cylinder is empty, filter dirty or clogged.
Calibration offset value cannot be set.
Instrument air supply is not available.

At the same time if several errors line up, then the error codes are to be added.

Here is one example:

- 33 Heating current < 0.5A, O₂ sensor not ok and
Heating current < 0.1A, CO_e sensor not ok.

12.2 Modbus Slave specification

General information

- supports only the binary Modbus protocol (RTU)
- the slave modbus address is user definable from 1 to 49
- communication parameter are user definable as follows:
 - 9600 baud
 - 8-Bit
 - even parity and 1 stop bit
- data types (used in table below):

U	16 bit unsigned integer value (0...65535)
I	16 bit signed integer value (-32768...32767)
UL	32 bit unsigned integer value (0...4.294.967.295)
L	32 bit signed integer value (-2.147.483.648...2.147.483.647)
F 3	32 bit floating point value (reads -1E38, when not available)

Defined registers

Available data with modbus command 4 READ INPUT REGISTERS:

PLC address	Protocol address	Data type	Number of registers	Register content
				Device info / status
40001	0	U	1	Error-Flags
40002	1	U	1	Reserved for further flags
40003	2	U	1	Status
40004	3	I	1	O ₂ [%] 1152 -> 11,52 %
40005	4	I	1	CO [ppm] 123 -> 123 ppm

Error Flags

Bit 0 Heating current<0.5A, O₂ sensor not ok.

Bit 1 Config error

Bit 2 Flash error

Bit 3 Unit to warm

Bit 4

Bit 5 Heating current<0.1A, CO_e sensor not ok.

Bit 6

Bit 7 Calibration error

Status



Status 0 Busy

Status 2 Measurement active

Status 5 Backpurge active

Status 6 Calibration active

12.3 Declaration of conformity

	EG-Konformitätserklärung <i>Declaration of conformity</i>	
-----------------------------------------------------------------------------------	---------------------------------------------------------------------	-------------------------------------------------------------------------------------

MRU Messgeräte für Rauchgase und Umweltschutz GmbH

Fuchshalde 8 + 12

74172 Neckarsulm-Obereisesheim

Deutschland / Germany

Tel.: +49 (0) 7132 - 99 62 0

Fax: +49 (0) 7132 - 99 62 20

E-Mail / mail: info@mru.de

Internet / site: www.mru.eu



Bevollmächtigte Person, für die Zusammenstellung der technischen Unterlagen

Person authorized to compile the technical documents

Name / name: Dierk Ahrends
 Funktion / function: QM-Beauftragter / QM- Representative
 Firmenname / company: Messgeräte für Rauchgase und Umweltschutz GmbH
 Straße / street: Fuchshalde 8 + 12
 Ort / city: 74172 Neckarsulm
 Land / country: Deutschland / Germany

Produkt/Product


Bezeichnung / designation: ZrO₂ Sauerstoffmesssystem
 ZrO₂ based oxygen monitoring system
 Produktname / name: OMS 420
 Funktion / function: siehe Bezeichnung / see designation

Hiermit erklären wir, dass das oben beschriebene Produkt allen einschlägigen Bestimmungen entspricht, es erfüllt die Anforderungen der nachfolgend genannten Richtlinien und Normen:

We declare the conformity of the product with the applicable regulations listed below:

- EMV-Richtlinie / EMV-directive 2014/30/EU
- Niederspannungsrichtlinie / low voltage directive 2014/35/EU
- RoHS-Richtlinie / RoHS directive 2011/65/EU (RoHS II)

Neckarsulm, 01.07.2016



Erwin Hintz, Geschäftsführer / Managing Director

PREMIUM INSIGHTS – GAIN REAL-TIME INSIGHT INTO YOUR PROCESS

Process Insights' products and solutions deliver innovative and differentiated analysis and measurement solutions and technologies that add high value to our customers and protect the environment.

Our commitment is to deliver smart and affordable innovation that optimizes process, improves safety, and transforms our world.

CENTERS OF EXCELLENCE

PROVIDING PROVEN SOLUTIONS FROM A GLOBAL TECHNOLOGY LEADER

COSA Xentaur

4140 World Houston Parkway
Suite 180
Houston, TX 77032
USA
+1 713 947 9591
www.cosaxentaur.com
service@cosaxentaur.com

Process Insights – The Americas

4140 World Houston Parkway
Suite 180
Houston, TX 77032
USA
+1 713 947 9591
info@process-insights.com

Process Insights – EMEA

ATRICOM
Lyoner Strasse 15
60528 Frankfurt
Germany
+49 69 20436910
info@emea.process-insights.com

Process Insights – APAC

Wujiang Economic and Technology
Development Zone
No. 258 Yi He Road, 215200 Suzhou
Jiangsu Province China
+86 400 086 0106
info@apac.process-insights.com

OUR PREMIUM GLOBAL BRANDS

