

MasterScope SystemManager G

Version 8.0

Manager (Linux Version)

Duplication Setup Guide

(ExpressCluster X Edition)

July 2018

CONTENTS

Chapter 1 Preface	1
1.1 Supplemental information	1
1.2 Application range	1
Chapter 2 Configuration Procedure	2
2.1 Creating failover groups.....	2
2.2 Setting up shared resources(FloatingIP, Shared(mirror)disk)	3
2.3 Setting up MasterScope SystemManager G	7
2.4 Setting up MasterScope SystemManager G WebConsole Option	12
2.4.1 Installing MasterScope SystemManager G WebConsole Option	12
2.4.2 Setting up MasterScope SystemManager G WebConsole Option	13
2.5 Configuring shared resources (start and stop scripts).....	14
2.6 Set up the resources and monitor resources of MasterScope SystemManager G	23
2.7 Set up the resources and monitor resources of MasterScope SystemManager G WebConsole Option.....	23
Chapter 3 Switching between connected nodes.....	25
Chapter 4 Uninstalling SystemManager G.....	26
4.1 Uninstalling SystemManager G	26
4.2 Deleting Files	26
Chapter 5 Other Notes	27
5.1 Registering Licenses.....	27

Chapter 1 Preface

This document provides an example procedure for using ExpressCluster X to set up a cluster configuration that has two nodes (for duplication). ExpressCluster X is an NEC product that can be used to switch running processes between nodes in a duplicated system.

In this document, a host system included in a cluster is referred to as a node.

1.1 Supplemental information

If the incorrect procedure is used to upgrade the OS on a cluster server, failovers might occur at unexpected times. In the worst case, this might damage the system. Only upgrade the OS in accordance with the procedure on the setup card.

1.2 Application range

This document describes ExpressCluster X 3.1 for Linux.

ExpressCluster X[®] is a registered trademark of NEC Corporation.

Linux is a registered trademark of Mr. Linus Torvalds in the United States and other countries.

Other system names, company names, and product names are trademarks or registered trademarks of their respective companies.

Chapter 2 Configuration Procedure

This chapter provides a procedure for configuring a MasterScope SystemManager G cluster environment.

This document assumes that ExpressCluster X is installed and that a cluster environment has been set up. For details about how to configure a cluster environment, also see the ExpressCluster X documents.


- * These documents can be downloaded from the following website:

<http://www.nec.com/en/global/prod/expresscluster/en/support/manuals.html?>

2.1 Creating failover groups

For ExpressCluster X, nodes connected to the cluster are managed using units called failover groups (referred to as *groups* below).

For details about how to create groups, see the relevant ExpressCluster X document (chapter 5 in the Installation and Creation Guide).



The screenshot displays the WebManager interface for a cluster. The left pane shows a tree view with 'rhelcluster' expanded to show 'Servers' (RHELcluster1, RHELcluster2), 'Groups' (ManagementGroup, MasterScope), and 'Monitors'. The right pane shows the 'Group Name: MasterScope' configuration table.

Properties	Value
Comment	
Status	Online
Started Server	RHELcluster2
Resource Status	
disk1	Online
exec	Online
fip	Online

Below the configuration table is an event log table:

Type	Received Time	Time	Server Name	Module Name	Event ID	Message
Info	2013/03/21 12:26:06.399	2013/03/21 12:30:06.188	RHELcluster2	rc	11	Activating group MasterScope
Info	2013/03/21 12:26:04.396	2013/03/21 12:30:05.875	RHELcluster2	rm	1	Monitoring fipw1 has started.

Figure 2-1 WebManager

2.2 Setting up shared resources(FloatingIP, Shared(mirror)disk)

The following describes how to set up shared resources for a failover group.

Here, the following shared resources are assumed:

- Floating IP address: 192.168.1.10
- Shared (mirror) disk: /dev/sdb

Start WebManager, and then select a failover group. (Here, select [MasterScope].)




Figure 2-2 Group Properties

Right click the group, and then select [Add Resource] from the displayed pop-up menu. The [Definition of a resource] dialog box is displayed.

First, set up the shared disk. For [Type], select [disk resource] or [mirror disk resource], and then enter the group name of the shared disk in the [Name] text box. Set up the disk in accordance with the instructions in the dialog box.




Figure 2-3 Definition of a resource (Shared Disk)

Next, set up the floating IP address. Right click the group, select [Add Resource] from the displayed pop-up menu, select [floating ip resource] for [Type], and then enter the group name in the [Name] text box.




Figure 2-4 Definition of a resource (Floating IP Address)

Specify the floating IP address in the [IP Address] text box.




Figure 2-5 Floating IP Address Addition

2.3 Setting up MasterScope SystemManager G

Install the MasterScope SystemManager G manager on the Linux computers to be used as active and standby servers.

For details about how to do so, see the *Release Notes* supplied with the product.


The following shared resources are assumed:

- Virtual host name: vhost1
- Shared disk(mount point): /shared_disk

Notes

- * Install MasterScope SystemManager G on the active server first, and then on the standby server.
- * It must be possible to reference the shared disk when installing the active server manager.
- * Use the same drive and folder as the installation destination for MasterScope SystemManager G on the active and standby servers.
- * vhost1 is a host name that can be resolved to a floating IP address (192.168.1.10).
- * For notes on setting up the CDO message reporting API, see 8 Setting for Duplicating Manager in MasterScope SystemManager G Release Memo - CDO Message API Edition -.

A redundant manager configuration is illustrated below.




Configure the agent and console to connect to the virtual host.

The following describes the procedure for installing the MasterScope SystemManager G manager.

First, start up the cluster from the active node, and then install MasterScope SystemManager G on the active node.

Installing SystemManager G in the active server node is illustrated below.



Specify each item in the installation setting dialog box for the SystemManager G manager for the active server node as shown below.

- Specify any value for [Install directory path], [Agent port] and [Viewer port].For the values that can be set, see “MasterScope Media Release Notes”.
- Specify the virtual host name for [Self hostname] and any directory on the shared disk for [Data Directory].
- Specify [Yes] for [Change Data Directory] and [Store initial setting data].
- Enter the same value for "Service number" on the active node and the standby node.

Example settings are shown below.


Setting	Value	Remark
Install directory path	/opt/UMF/Operations	Local disk path
Self hostname	vhost1	Virtual host name
Agent port	12520	
Viewer port	12521	
Change Data Directory	Yes	(Fixed)
Data Directory	/shared_disk/MCO	Shared disk path
Store initial setting data	Yes	(Fixed)

\Manager\sg is automatically added to the data area folder, and settings that must be shared are stored here.

After installation finishes, confirm that \Manager\sg has been created in the data area folder.

Next, set up the MasterScope SystemManager G manager on the standby node.

Installing SystemManager G in the active server node is illustrated below.



Specify each item in the installation setting dialog box for the SystemManager G manager for the standby server node as shown below.

- Specify the same values as for the active server node except for [Store initial setting data].
- Specify [No(Only for Cluster standby system)] for [Store initial setting data].
- Enter the same value for "Service number" on the active node and the standby node.

Example settings are shown below.

Setting	Value	Remark
Install directory path	/opt/UMF/Operations	Local disk path
Self hostname	vhost1	Virtual host name
Agent port	12520	
Viewer port	12521	
Change Data Directory	Yes	(Fixed)
Data Directory	/shared_disk/MCO	Shared disk path
Store initial setting data	No(Only for Cluster standby system)	(Fixed)

After installation, run the following command on both the active and standby nodes to set the service not to start automatically.

- SystemManager G Service *

In the OS of which system is controlled by init, enter the following command.

When init is used, the process name (the second field) in /proc/1/stat is init.

```
# chkconfig --del UMFOperationsManager_1
```

In the OS of which system is controlled by systemd (for example, Red Hat Enterprise Linux 7.1), enter the following command.

When systemd is used, the process name (the second field) in /proc/1/stat is systemd.

```
# systemctl disable UMFOperationsManager_1
```

- MCOperations CDO Service

Execute this service when using the CDO message API function.

```
# chkconfig --del UMFMCOperationsCDO
```

*If you install them in an environment where other MasterScope products are using rc script files with the same names as them, their last numeric characters will be changed to 2 or higher (e.g.: UMF Operations Manager_2 and UMFOperationsAgent_3). You need to reread the explanation above according to your actual environment.

2.4 Setting up MasterScope SystemManager G WebConsole Option

2.4.1 Installing WebConsole Option

To use WebConsole Option, install the WebConsole Option components in the active and standby nodes, similarly to the SystemManager G manager. On the WebConsole

installation screen, specify the following for the active and standby nodes.

Item	Value	Remark
Installation folder	/opt/nec/pf/opm/manager	Local disk path
Data Directory	/shared_disk/SYSMGRG/WebConsole	Shared disk path
Hostname/IPAddress	vhost1	Virtual host name
API Gateway		
Hostname/IPAddress	localhost	
Port	22522	
Database		
Hostname/IPAddress	localhost	
Port	5432	
Admin password	postgres	

2.4.2 Setting up WebConsole Option

Change the service startup attributes from [Auto] to [Manual] on both the active and standby nodes.

```
# systemctl disable ServiceGovernor
# systemctl disable msc_apigateway
# systemctl disable msc_auth
# systemctl disable msc_businessview
# systemctl disable msc_extlink
# systemctl disable msc_messagestore
# systemctl disable msc_perfdatastore
# systemctl disable msc_report
# systemctl disable msc_status
# systemctl disable postgresql-9.6
```

2.5 Configuring shared resources (start and stop scripts)

How to configure the following shared resources for a failover group is described below.

Here, the following shared resources are assumed:

- Start script: Manager start.sh
- Stop script: Manager stop.sh

Start WebManager, and then select the failover group. (Here, select [MasterScope].)(See Figure 2-2.)

Right-click the group, select [Add Resource] from the displayed pop-up menu, select [execute resource] for [Type], and then enter the group name in the [Name] text box.




Figure 2-6 Resource Definition (Execute resource)

Select [Script create with this product] for the advanced setting.




Figure 2-7 Configuring start and stop scripts

Edit start.sh and stop.sh as shown below.

start.sh

Describe the following SystemManager G start script for when a start event and a failover event occur.

```
/etc/init.d/UMFOperationsManager_1 start *
```

* If SystemManager G is installed in an environment in which other MasterScope products use a service and rc script file with the same name, the suffix number is changed to 2 or higher. (e.g. UMFOperationsManager_2) Replace UMFOperationsManager_1 described above with this.

* When init is used in Linux, the process name (the second field) in /proc/1/stat is init. When systemd is used, the process name (the second field) in /proc/1/stat is systemd.

How to edit start.sh is illustrated below. The text in red is the edited part.

```
#!/bin/sh
#*****
#*          start.sh          *
#*****

if [ "$CLP_EVENT" = "START" ]
then
    if [ "$CLP_DISK" = "SUCCESS" ]
    then
        echo "NORMAL1"
```

```

        if [ "$CLP_SERVER" = "HOME" ]
        then
            echo "NORMAL2"
        else
            echo "ON_OTHER1"
        fi
        /etc/init.d/UMFOperationsManager_1 start
    else
        echo "ERROR_DISK from START"
    fi
elif [ "$CLP_EVENT" = "FAILOVER" ]
then
    if [ "$CLP_DISK" = "SUCCESS" ]
    then
        echo "FAILOVER1"
        if [ "$CLP_SERVER" = "HOME" ]
        then
            echo "FAILOVER2"
        else
            echo "ON_OTHER2"
        fi
        /etc/init.d/UMFOperationsManager_1 start
    else
        echo "ERROR_DISK from FAILOVER"
    fi
else
    echo "NO_CLP"
fi
echo "EXIT"
exit 0

```

stop.sh

Describe the following SystemManager G start script for when a start event and a failover event occur.

```
/etc/init.d/UMFOperationsManager_1 stop *
```

* If SystemManager G is installed in an environment in which other MasterScope products use a service and rc script file with the same name, the suffix number is changed to 2 or higher. (e.g. UMFOperationsManager_2) Replace UMFOperationsManager_1 described above with this.

* When init is used in Linux, the process name (the second field) in /proc/1/stat is init. When systemd is used, the process name (the second field) in /proc/1/stat is systemd.

How to edit stop.sh is illustrated below. The text in red is the edited part.

```

#!/bin/sh
#*****
#*           stop.sh           *
#*****

if [ "$CLP_EVENT" = "START" ]
then
    if [ "$CLP_DISK" = "SUCCESS" ]
    then
        echo "NORMAL1"
        if [ "$CLP_SERVER" = "HOME" ]
        then
            echo "NORMAL2"
        else
            echo "ON_OTHER1"
        fi
        /etc/init.d/UMFOperationsManager_1 stop
    else
        echo "ERROR_DISK from START"
    fi
elif [ "$CLP_EVENT" = "FAILOVER" ]
then
    if [ "$CLP_DISK" = "SUCCESS" ]
    then
        echo "FAILOVER1"
        if [ "$CLP_SERVER" = "HOME" ]
        then
            echo "FAILOVER2"

```

```
        else
            echo "ON_OTHER2"
        fi
        /etc/init.d/UMFOperationsManager_1 stop
    else
        echo "ERROR_DISK from FAILOVER"
    fi
else
    echo "NO_CLP"
fi
echo "EXIT"
exit 0
```

To set up the dependencies, clear the [Follow the default dependence] check box, and then add resources that depend on the floating IP address and shared disk.




Figure 2-8 Specifying the dependencies

After specifying the settings, return to the failover group properties, and then confirm that the settings have been applied (by confirming that the dialog box is like the one shown in Figure 2-2).

* To use the CDO message issuance API, add the resources for the MISSION CRITICAL OPERATIONS CDO service in the same way. Set up the resource dependencies so that the CDO message API is dependent on SystemManager G.

2.6 Setting Up the SystemManager G Manager Monitor Resources

Add monitor resources to the failover group. In the process name monitoring resources, perform this operation on the following processes of SystemManager G Manager.

Component	Process Name	Remark
Manager	/opt/UMF/Operations/Manager/bin/SysMonMgr	
	/opt/UMF/Operations/Manager/bin/ProcessExec	
Bundled DB	/opt/UMF/Operations/Manager/bin/dbms1/bin/postgres	Using the bundled DB
CDO message API	/usr/diux/bin/dcomsgdmn.mco	Using CDO message API

* If SystemManager G manager is installed on /opt/UMF/Operations.

2.7 Setting Up the WebConsole Option Resources and Monitor Resources

Add monitor resources to the failover group. In the process name monitoring resources, perform this operation on the following processes of WebConsole Option.

Component	Process Name	Remark
Web GUI	/opt/UMF/Operations/Tomcat/JRE/JavaHome/bin/java	
Authorization	/opt/nec/pf/opm/manager/bin/msc_auth	
MessageStore	/opt/nec/pf/opm/manager/bin/msc_messagestore	
ExternalLink	/opt/nec/pf/opm/manager/bin/msc_extlink	
Status	/opt/nec/pf/opm/manager/bin/msc_status	
BusinessView	/opt/nec/pf/opm/manager/bin/msc_businessview	
Report	/opt/nec/pf/opm/manager/bin/msc_report	
Performance DataStore	/opt/nec/pf/opm/manager/bin/msc_perfdatastore	
API Gateway	/opt/nec/pf/opm/manager/bin/msc_apigateway	
Database	/usr/pgsql-9.6/bin/postmaster	Using bundled version(9.6).

* If SystemManager G manager is installed on /opt/UMF/Operations.

* If WebConsole Option is installed on /opt/nec/pf/opm/manager.

This concludes the ExpressCluster X setup.

Chapter 3 Switching between connected nodes

To switch between the active and standby nodes, use the following method.

Enter the following command.

```
> clpgrp -m <group name>
```

The nodes can also be switched by right-clicking the icon next to a group name displayed in the left WebManager pane and then selecting [Move] from the displayed pop-up menu.




Figure 3-8 Switching between connected nodes

Chapter 4 Uninstalling SystemManager G

4.1 Uninstalling SystemManager G

To uninstall SystemManager G, perform the procedure described in the SystemManager G Release Memo (relememo.pdf).

Note If using the CDO message API, uninstall the API by performing the procedure described in the CDO Release Memo (CDO_relememo.pdf).

4.2 Deleting Files

After uninstalling SystemManager G, files and directories remain on the shared disk. Manually delete directories on the shared disk specified during installation.

Chapter 5 Other Notes

5.1 Registering Licenses

Register licenses for a cluster environment on both the active and standby nodes.