

INSTALLATION GUIDE

EYE X02

IMPORTANT: Read Before Using.



Notice

Grounding Instructions

In the event of a malfunction or breakdown, grounding provides a path of least resistance for electrical current to reduce the risk of electric shock. This tool is equipped with an electrical cord having an equipment grounding conductor and a grounding plug. The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.

Do not modify the plug provided. If it will not fit the outlet, have proper outlet installed by a qualified electrician.

Step 1: Hardware Installation Guide



Step 2: Software Installation Guide



Contents

Section	Page
WARNING: To Ensure Safe Use	4 - 5
1. Installation Environment	6
2. Included Items	7
3. Hardware Install	8
3.1 Mounting Bracket	9
3.2 Slide Sensor	10
3.3 Connection	11
3.4 Connection Status	12
5. Software Install	13 - 20
6. Club Sticker Guide	21 - 27
7. Specifications	28



To Ensure Safe Use

Improper handling or operation of this machine may result in injury or damage to property. Points which must be observed to prevent injury or damage are described as follows.

 <p>WARNING</p>	<p>Used for instructions intended to alert the user to the risk of severe injury should the unit be used improperly.</p>
 <p>Caution</p>	<p>Used for instructions intended to alert the user to the risk of injury or material damage should the unit be used improperly. Material damage refers to damage to home, furnishing, or anything within the unit's vicinity.</p>
 <p>NEVER</p>	<p>This symbol alerts the user to items that should never be carried out.</p>

To Ensure Safe Use - Continued


 This is a heavy machine.

WARNING

	Install in a level and stable location. Failure to do so may result in falling of the machine, leading to injury.
	Never attempt to disassemble, repair, or modify the machine. Doing so may result in fire, electrical shock, or injury. Entrust repairs to a trained technician.
	Never use outside or in any location where exposure to water or high humidity may occur. Do not touch the power cord or electrical outlet with wet or dirty hands. Doing so may result in electrical shock.
	Conduct play in a clean and brightly lit location. Operating in a dark or cluttered space may lead to accidents.
	Be aware of your surroundings and use cautiously with children around. Swinging the club during play without being aware will result in serious injury or death.

Installation Environment

Installation Environment




PC Specifications:

Category	Requirement
CPU	Intel i5 8400 or higher*
RAM	8 GB
Graphics Card	GeForceGTX 1060 or higher
Operating System	Windows 10 (64bit) Version 1803 or higher
Resolution	1920 x 1080
Connectivity	Ethernet Port Required

* AMD: 3rd gen Ryzen or higher and AMD Ryzen 3600 or higher (AMD 2700 is not compatible).


Included Items

The following items are included with the sensor. Make sure they are all present and accounted for.

			
EYEXO2 Sensor Bar	Bracket	Email – Software Installer	Calibration Chart

			
Power Cable	Power Adapter	Power Connector	USB Ethernet Adapter

			
Ethernet LAN Cable	Level	Club Stickers	M4 32mm screws

		
M6 15mm screws	M6 15mm high screws	M6 15mm low screws

Included Items

Hardware Install

 <p>WARNING</p>	<p>Confirm installation requirements are met from Section 1 "Installation Requirements," and outline bracket location on ceiling.</p>
 <p>WARNING</p>	<p>Consult with building manager or landlord about the specifications and weight capacity of the ceiling before installation. The sensor and bracket are approximately 30 lbs and 9 M4 32mm screws are required to screw in the bracket and hold the sensor. Failure to do so may result in serious injury or damage to property.</p>
 <p>CAUTION</p>	<p>Two or more persons are recommended for mounting the bracket on the ceiling and extreme caution is required while on the ladder. Failure may result in serious injury or damage to property.</p>


Ladder	Phillips Screwdriver	M4 32mm Screw x9	Bracket	Sensor Bar
				

■ Necessary Tool ● Necessary Part(s)


3.1 Hardware Install - Continued

Step 1: Mount Bracket


- 1 The EYE XO2 Sensor and bracket come attached together in the box. Slightly loosen the black M6 15 mm screws that are holding the sensor to the bracket so you can remove it. Please make sure you have measured 3.5 feet from the front and middle of the sensor to your tee position. Do NOT align to the bracket.



- 2 Place the ladder under the location on the ceiling where the bracket will be mounted. Place the bracket flat against the ceiling with the hinges facing down toward the ground. The longer side of the hinges must be closet towards the impact screen.



- 3 With the bracket in position, grab the 10 silver M4 32mm screws and screw them in the locations below in the diagram.



3.2 Hardware Install - Continued

Step 2: Slide Sensor

- 1 After the bracket has been firmly mounted to the ceiling, you will install the sensor bar.


The sensor bar comes with 6 black M6 15mm screws already inserted; 3 screws in the front and 3 screws in the back. Make sure all 6 screws are about halfway into the bar and even in length.



- 2 Slide the sensor bar with the 6 screws up and over through the bracket hinges. Make sure the screws are secured in the hook part of the hinges. Once the sensor is secured in the bracket hinges, tighten the 6 screws to the bracket.



- 3 The tilt of the sensor can be adjusted with the high and low M6 15mm screws. The regular M6 15mm screws are already screwed into the sensor. You can change this out with the M6 155 High or Low screws to adjust the angle/ tilt.



3.3 Hardware Install - Continued

Step 3: Connection

Ethernet LAN Cable	Power Cord	Power Adapter	Power Connector
			

■ Necessary Parts

1 Take out the Ethernet LAN cable from the box. Connect the end with the tag that reads “Connect this side of LAN cable to Sensor ONLY” to the sensor. Connect the other end DIRECTLY to your PC ethernet port and NOT the USB adapter.



2 Take out all 3 components of the power source: power cable, power adapter, and power connector. Connect all 3 accordingly and connect the “Power Connector” end directly to the sensor as shown below. Turn on red switch.



Note: The plug must be plugged into a matching outlet that is properly installed and grounded in accordance with all local codes and ordinances.


An extra green grounding wire is provided on the end of the power connector in case your outlet is not grounded.

3.4 Hardware Install – Continued

Step 4: Connection Status

Make sure to check the connection status before you start the software installation process.

- 1 Check and see if the power is on. You will see a bright red light on the switch of the sensor.
- 2 Check and see if your EYE XO2 Sensor and PC are paired through the network.



Please refer to our “Network Setup Guide” below to set the IP address.

NETWORK GUIDE

Software Install

 <p>WARNING</p>	<p>Please make sure PC requirements are met from section 1 "Installation Environment," before the installation process. Failure to do will result in installation issues and slow gameplay.</p>
 <p>WARNING</p>	<p>Please make sure the connection statuses are clear and everything is paired. Failure to do will result in installation issues.</p>

Software



Software Install – Continued


EYE XO2 Installation

- 1 You will receive an email with a license code from your retailer which looks like this:
 EYEXO2_30000XXXXX.license.
 Please download it and save it to the Uneekor Folder


Click here: [EYE XO2 Installer Link](#)

- 2 Ctrl + Click the EYE XO2 Installer link above to begin EYE XO2 Installation or manually enter the URL: https://download.uneekor.com/dist/EYEXO2/Uneekor_EYEXO2_Setup.exe

- 3 Under downloads you will see, "Uneekor_EYEXO2_Setup.exe" Click open file.




- 4 "Uneekor EYE XO2 (2.10.0.0) Setup" will open. Click "Next."




3.5 Software Install – Continued

EYE XO2 Software Installation

- 5 Keep the destination folder as “C:\Uneekor” and click Install.




- 6 Please wait while installer completes installation.




3.6 Software Install – Continued

EYE XO2 Software Installation

**If these two pop-ups occur, please hit ok for both.



- 7 The “Run Uneekor EYE XO2” is checked. **Uncheck it** and click finish.




3.7 Software Install - Continued

EYE XO2 Sensor Activation

1 Go to the C: Drive-> Uneekor Folder -> Device -> Launch Monitor -> EYEXO

Find and double click “EYEXO2_Check”



Make sure the Sensor LAN connection is good before the software installation process.




If you don't get the Sensor LAN connection, please refer to our "Network Settings Guide."

2 In the “EYEXO” folder click on “EYEXO2_Activation”


Click “Browse” to find the license key saved from step 1 above.

Then click “Activation”



After adding the license please click “Activate.”

The EYE XO2 Sensor installation is now complete.




3.8 Software Install - Continued

EYE XO2 Network Config


1

Once the sensor has been activated, you will have a screen like the one on the right. Click Set Network Param & Firewall to continue



2

After the selection, you will be asked to restart the PC. Click Yes to restart to finish the Sensor installation



3.8 Software installation - Continued

EYE XO2 Calibration

To complete the installation of the EYE XO2.
Follow the calibration guide linked below:

[EYE XO2 Calibration Guide](#)

3.9 Software Install – Continued


VIEW Software Installation

Click here: [VIEW Installer](https://download.uneekor.com/dist/View/VIEW_Setup.exe)

- 1 Ctrl + click on the VIEW Installer above or enter the URL manually:
https://download.uneekor.com/dist/View/VIEW_Setup.exe

Open downloads on the right.

If you receive this warning, follow the steps below.



- 3.8.1 Hover over the download, click the 3 dots on the right side, and click keep.
- 3.8.2 Click the “Show more” drop down and click “Keep anyway.”
- 3.8.3 Then click “Open file” under downloads.

Make sure you trust VIEW_Setup.exe before you open it


Microsoft Defender SmartScreen couldn't verify if this file is safe because it isn't commonly downloaded. Make sure you trust the file you're downloading or its source before you open it.

Name: VIEW_Setup.exe
Publisher: Unknown

Show more ▾



- 2 “VIEW_SETUP 20220721 Setup” will open. Click “Next.”




5.6 Software Install – Continued

VIEW Software Installation

3

Keep the Destination Folder as “C:\VIEW” and click “Install.”





Software

4

Check the “I agree” box and click “Install.”


If a error pops up, click close and continue to VIEW Setup.

Click “Start setup”




Optional:

If the C++ files are already installed on your PC, you may receive the error on the right



Click Close and then next to continue




5.7 Software Install – Continued

VIEW Software Installation

5

Make sure all boxes are checked and the Directory matches the picture on the right, then Click “Next.”



6


Click “Finish”

7

Click “browse” and select the license file you saved in the Uneekor folder from the earlier steps, and click “Activation.”

Then click “Activate”


VIEW Software installation is now complete.



EYE X02

Club Data

Club Speed




The speed of the club before impact.

Smash Factor



The amount of energy transferred from the club head to the golf ball.

Face to Path



The angle difference between Face Angle and Club Path.

EYE X02


Club Data

Attack Angle




The up and down movement of the club head at the time of impact. Attack angle is measured relative to the horizon.

Club Path



The in to out or out to in movement of the club head's geometric center at the time of impact. Club Path is the direction (right or left) the club head is moving at impact and is measured relative to the target line.

Face Angle




The direction (right or left) the club face is pointed at impact. It is measured relative to the target line.



EYE X02

Club Data

Dynamic Loft



The amount of loft of the club face at the center point of impact.


Club Lie Angle



Lie angle is the angle created between the center of the shaft and ground when you put your iron down in the address position.

Impact Point



Vertical. Horizontal



Where you strike the ball on the club face.

EYE X02


Club Sticker Placement



2 types of stickers provided by Uneekor

EYE X02

Sticker Placement



- 1.) The position closest to the horizontal center line should be used as a reference.
- 2.) The Dot sticker should line up to the middle of the Bar sticker.
- 3.) Avoid placing both stickers near the sweet spot
- 4.) Attach to the flat surface of the face to avoid creasing or bending of the stickers.
- 5.) Attach in line with the grooves.



1. Bar Sticker

Align the middle of the Bar Sticker to the horizontal center line or the 7th groove.


2. Dot Sticker

Align to the middle of the bar sticker and parallel between the grooves.

EYE XO2

Sticker Application 1

The stick must not cross or bend over the leading edge.



Bring the stickers in the sweet spot if it cannot fit inside the whole face.



The sticker must be attached inside the club face for proper reading.



All 4 corners of the stickers must be attached to the club face. If the club face is short and all 4 corners of the bar sticker cannot fit on the club face down the horizontal line, you can move up the horizontal line so all of the Bar Sticker can be placed inside the club face.


*In the case where you do have to raise the horizontal line beyond the center to fit all 4 corners of the Bar Sticker, the data will be calculated higher.



EYE X02

Sticker Application 2

Driver



Clubs without grooves

All 4 corners of the stickers should be attached inside the club face. If there is an aim marker on the crown of the driver, use it as reference for the vertical center line. The top of the bar and dot sticker must be aligned with the horizontal center line.

CLUB DATA CANNOT BE READ IF THE BALL IS COVERING ONE OF THE TWO STICKERS. CLUB DATA WILL BE ONLY SHOWN IF BOTH STICKERS ARE VISIBLE.

7.1 Specifications

Items	Contents
Components	3 High Speed Cameras 4 Infrared LED Boards 1 Control Board 1 Power Board
Data Interface	Ethernet (CAT6 and above)
Communication Speed	1 Gbps
Spin Data	Total Spin $\pm 12,000$ rpm
Measurement Range	Ball Speed Putter: 0.1 m/s ~ 30 m/s Ball Speed Driver/Iron: 5 m/s ~ 100 m/s
Sensing Angle	Driver: -5 ~ 50 Degree Iron: 0.1 ~ 80 Degree (shots over 60° can damage the unit)

MASTER YOUR PASSION

Uneekor, Inc.

15770 Laguna Canyon Rd Suite
100 Irvine, CA 92618

sales@uneekor.com

support@uneekor.com

