

MiTAC PB5500C-256K, Rev 1E (AT&T OEM) Board

Connectors and jumper-settings. These are based on what's written on the PCB itself, as I don't have the manual. Stars indicate selection on my board, which I assume may be default settings for a 60MHz Pentium.

Connectors:

J1	Keyboard
J2	External Battery
J13	Speaker
J14	Keylock
J15	Reset
BANK1	2x 72-pin SIMM
BANK2	2x 72-pin SIMM
PC1	PCI
PC2	PCI
PC3	PCI
PC4	PCI

CPU:

		JP17	JP18	JP19
	33MHz	Closed	Closed	Closed
	40MHz	Closed	Closed	Open
	50MHz	Open	Open	Closed
*	60MHz	Open	Closed	Open
	66MHz	Closed	Open	Closed

Cache:

		JP1	JP2	JP15	
*	Bank 0	1-2	1-2	1-2	
	Bank 0 + Bank 1	2-3	2-3	2-3	
		JP9	JP10	JP11	JP12
	8Kx8	Open	Open	Open	Open
	8Kx8 + 8Kx8	Closed	Open	Open	Open
*	32Kx8	Closed	Closed	Open	Open
	32Kx8 + 32Kx8	Closed	Closed	Closed	Open
	128Kx8	Closed	Closed	Closed	Closed

Bus:

			JP5
	Back to Back IO Delay Disabled		Open
*	Back to Back IO Delay Enabled		Closed
		JP6	JP7
	ATCLK = LCLK/2	Open	Open
	ATCLK = LCLK/3	Open	Closed
*	ATCLK = LCLK/4	Closed	Open
	ATCLK = LCLK/5	Closed	Closed
		JP20	JP23
*	External LCLK source	1-2	Closed
	Internal LCLK source	2-3	Open

		JP21
	LCLK W/ F08	1-2
*	Direct Drive LCLK	2-3
		JP3
*	VESA Local Bus Enabled	Open
	VESA Local Bus Disabled	Closed
		JP4
*	82C822 LDEV# Sample at end of 1st T2	Open
	82C822 LDEV# Sample at end of 2nd T2	Closed
		JP22
*	MDHODE# Inactive at end of last T2	Open
	MDHODE# Inactive at beginning of last T2	Closed
		JP26
*	VESA Local Bus ID0 = 0	Closed
	VESA Local Bus ID0 = 1	Open
		JP27
	VESA Local Bus ID1 = 0	Closed
*	VESA Local Bus ID1 = 1	Open
		JP28
*	VESA Local Bus ID2 = 0	Closed
	VESA Local Bus ID2 = 1	Open
		JP29
	VESA Local Bus ID3 = 0	Closed
*	VESA Local Bus ID3 = 1	Open
		JP30
	VESA Local Bus ID4 = 0	Closed
*	VESA Local Bus ID4 = 1	Open
Misc:		
		JP13
	Erase CMOS Settings	1-2
*	Normal, keep CMOS Settings	2-3
		JP24
	+12V on EPROM VPP	1-2
*	+5V on EPROM VPP	2-3
		JP25
*	Reserved (1 on KBD-Ctrl P16)	Open
	Reserved (0 on KBD-Ctrl P16)	Closed