



S7025

Version 1.40

Copyright

Copyright © MiTAC Computer Corporation, 2009. All rights reserved. No part of this manual may be reproduced or translated without prior written consent from MiTAC Computer Corp.

Trademark

All registered and unregistered trademarks and company names contained in this manual are property of their respective owners including, but not limited to the following.

TYAN[®] is a trademark of MiTAC Computer Corporation

Intel[®] is a trademark of Intel[®] Corporation.

AMI[®], AMIBIOS[®] and combinations thereof are trademarks of AMI Technologies.

Microsoft[®], Windows[®] are trademarks of Microsoft Corporation.

IBM[®], PC[®], AT[®] and PS/2[®] are trademarks of IBM Corporation.

Winbond[®] is a trademark of Winbond Electronics Corporation.

Notice

Information contained in this document is furnished by MiTAC Computer Corporation and has been reviewed for accuracy and reliability prior to printing. MiTAC assumes no liability whatsoever, and disclaims any express or implied warranty, relating to sale and/or use of TYAN[®] products including liability or warranties relating to fitness for a particular purpose or merchantability. MiTAC retains the right to make changes to product descriptions and/or specifications at any time, without notice. In no event will MiTAC be held liable for any direct or indirect, incidental or consequential damage, loss of use, loss of data or other malady resulting from errors or inaccuracies of information contained in this document.

Contents










Before you begin...	5
Chapter 1: Instruction	6
1.1 - Congratulations	6
1.2 - Hardware Specifications	6
1.3 - Software Specifications	10
1.4 - AST2050 User Guide	10
Chapter 2: Board Installation	12
2.1 - Board Image	13
2.2 - Block Diagram	14
2.3 - Board Parts, Jumpers and Connectors	15
2.4 - Installing the Processor	22
2.5 - Heat sink Installation	24
2.6 - Thermal Interface Material	25
2.7 - Finishing Installing the Heat sink	26
2.8 - Tips on Installing Motherboard in Chassis	27
2.9 - Installing the Memory	29
2.10 - Attaching Drive Cables	32
2.11 - Installing Add-In Cards	33
2.12 - Connecting External Devices	34
2.13 - Installing the Power Supply	35
2.14 - Finishing Up	36
Chapter 3: BIOS Setup	38
3.1 - About the BIOS	38
3.2 - BIOS Menu Bar	38
3.3 - Setup Basics	39
3.4 - Getting Help	39
3.5 - In Case of Problems	39
3.6 - BIOS Main Menu	40
3.7 - BIOS Advanced Menu	41
3.8 - PCI PnP Menu	61
3.9 - Boot Menu	63
3.10 - Security Menu	65
3.11 - Chipset Menu	66
3.12 - Exit Menu	71
Chapter 4: Diagnostics	72
4.1 - Beep Codes	72
4.2 - Flash Utility	72
4.3 - AMIBIOS Post Code	73

Appendix: How to Make a Driver Diskette.....	76
Glossary.....	78
Technical Support.....	84

Before you begin...

Check the box contents!

The retail motherboard package should contain the following:

	1x S7025 Motherboard
	6 x SATA Cable
	2x mini-SAS Cables (option for SAS SKU only)
	1x USB Cable
	1x Audio Cable
	1 x S7025 User's manual
	1 x S7025 Quick reference guide
	1 x TYAN® Driver CD
	1 x I/O shield



Note:

- 1). TYAN created audio cable to suite your needs. Please contact our supporting team.

Chapter 1: Instruction

1.1 - Congratulations

You have purchased one of the most powerful server solutions based on the Intel® Tylersburg 5520 chipset. The TYAN® S7025 motherboard is designed to support up to two Intel® Nehalem-EP 2S processors and up to 64GB DDR3-800/1066/1333 memory. Leveraging the advanced technology from Intel, TYAN® S7025 is capable of offering a scalable 32 and 64-bit computing environment with high-bandwidth memory design and lightning-fast PCI-E bus providing a rich feature set with incredible performance.

TYAN® S7025 is designed around several different configurations which are all detailed in the following Hardware Specification section:

1.2 - Hardware Specifications

TYAN S7025 (S7025WAGM2NR)

Processor	Supported CPU Series		Intel® Xeon® processors 5500 series
	Socket Type / QTY		LGA1366 / (2)
	Thermal Design Power (TDP) wattage		130W
	System Bus		Up to 4.8/ 5.86/ 6.4GT/s with Intel QuickPath Interconnect (QPI) support
Chipset	IOH / ICH		Intel® (2) 5520 / ICH10R
	Super I/O		Winbond W83627DHG
Memory	Supported DIMM Qty		(8) DIMM sockets
	DIMM Type / Speed		DDR3 800/1066/1333 RDIMM/UDIMM
	Capacity		Up to 64GB
	Memory channel		6 Channels (3 Channels per CPU)
	Memory voltage		1.5V
Expansion Slots	PCI-E		(4) PCI-E Gen.2 x16 slots (1) PCI-E Gen.2 x8 slot (w/ x4 link) (1) PCI-E Gen.2 x4 slot
	PCI		(1) PCI 32-bit slot
LAN	Port QTY		(2)
	Controller		Intel® 82574L
Storage	SAS	Connector	(2) Mini-SAS connectors (support 8 ports)
		Controller	LSI SAS1068E
		Speed	3.0 Gb/s
		RAID	RAID 0/1/1E (LSI Integrated RAID)

	SATA	Connector	(6) SATA
		Controller	ICH10R
		Speed	3.0 Gb/s
		RAID	RAID 0/1/10/5 (Intel® Matrix RAID)
Graphic	Connector type		D-Sub 15-pin
	Resolution		1600x1200@60Hz
	Chipset		Aspeed AST2050
Audio	Chipset		Realtek ALC262
	Feature		HDA 2.0 spec. complaint
TPM	Chipset		Infineon SLB9635
	Version		TPM v1.2
Input /Output	USB		(9) USB2.0 ports (4 at rear, 4 via cable, 1 type A onboard)
	COM		(2) ports (1 at rear, 1 via cable)
	SAS		(2) Mini-SAS (4-in-1) connectors
	VGA		(1) D-Sub 15-pin VGA port
	Audio		(1) CD_IN Header (1) 2x5-pin front panel audio header
	RJ-45		(2) GbE ports
	Power		SSI 24-pin + 8-pin + 8-pin power connectors / EPS12V
	Front Panel		(1) 2x12-pin SSI front panel header
	SATA		(6) SATA-II connectors
System Monitoring	Chipset		Winbond W83793G
	Voltage		Monitors voltage for CPU, memory, chipset & power supply
	Fan		Total (7) 4-pin headers
	Temperature		Monitors temperature for CPU & system environment
	Others		Chassis intrusion detection Watchdog timer support
Server Management	Onboard Chipset		Onboard Aspeed AST2050
	AST2050 IPMI Feature		IPMI 2.0 compliant baseboard management controller (BMC) Supports storage over IP and remote platform flash BIOS update USB 2.0 virtual hub
	AST2050 iKVM Feature		24-bit high quality video compression Dual 10/100 Mb/s MAC interfaces
BIOS	Brand / ROM size		AMI / 4MB
	Feature		Plug and Play (PnP) / PCI2.3 WfM2.0 / SMBIOS2.3 / PXE Boot ACPI 2.0 power management Power on mode after power recovery User-configurable H/W monitoring Auto-configurable of hard disk types Multiple boot options
Form Factor	Form Factor		SSI EEB
	Board Dimension		12"x13" (305x330mm)

Operating System	OS supported list	Please refer to our OS supported list.
Regulation	FCC (DoC)	Class B
	CE (DoC)	Yes
Operating Environment	Operating Temp.	10° C ~ 35° C (50° F ~ 95° F)
	Non-operating Temp.	- 40° C ~ 70° C (-40° F ~ 158° F)
	In/Non-operating Humidity	90%, non-condensing at 35° C
RoHS	RoHS 6/6 Complaint	Yes

TYAN S7025 (S7025AGM2NR)

Processor	Supported CPU Series	Intel® Xeon® processors 5500 series
	Socket Type / QTY	LGA1366 / (2)
	Thermal Design Power (TDP) wattage	130W
	System Bus	Up to 4.8/ 5.86/ 6.4GT/s with Intel Quick Path Interconnect (QPI) support
Chipset	IOH / ICH	Intel® (2) 5520 / ICH10R
	Super I/O	Winbond W83627DHG
Memory	Supported DIMM QTY	(8) DIMM sockets
	DIMM Type / Speed	DDR3 800/1066/1333 RDIMM/UDIMM
	Capacity	Up to 64GB
	Memory channel	6 Channels (3 Channels per CPU)
	Memory voltage	1.5V
Expansion Slots	PCI-E	(4) PCI-E Gen.2 x16 slots (1) PCI-E Gen.2 x8 slot (w/ x4 link) (1) PCI-E Gen.2 x4 slot
	PCI	(1) PCI 32-bit slot
LAN	Port QTY	(2)
	Controller	Intel® 82574L
Storage	SATA	Connector (6) SATA
		Controller ICH10R
		Speed 3.0 Gb/s
		RAID RAID 0/1/10/5 (Intel® Matrix RAID)
Graphic	Connector type	D-Sub 15-pin
	Resolution	1600x1200@60Hz
	Chipset	Aspeed AST2050
Audio	Chipset	Realtek ALC262
	Feature	HDA 2.0 spec. complaint

TPM	Chipset	Infineon SLB9635
	Version	TPM v1.2
Input /Output	USB	(9) USB2.0 ports (4 at rear, 4 via cable, 1 type A onboard)
	COM	(2) ports (1 at rear, 1 via cable)
	VGA	(1) D-Sub 15-pin VGA port
	Audio	(1) CD_IN Header (1) 2x5-pin front panel audio header
	RJ-45	(2) GbE ports
	Power	SSI 24-pin + 8-pin + 8-pin power connectors / EPS12V
	Front Panel	(1) 2x12-pin SSI front panel header
	SATA	(6) SATA-II connectors
	SATA	(6) SATA-II connectors
System Monitoring	Chipset	Winbond W83793G
	Voltage	Monitors voltage for CPU, memory, chipset & power supply
	Fan	Total (7) 4-pin headers
	Temperature	Monitors temperature for CPU & system environment
	Others	Chassis intrusion detection Watchdog timer support
Server Management	Onboard Chipset	Onboard Aspeed AST2050
	AST2050 IPMI Feature	IPMI 2.0 compliant baseboard management controller (BMC) Supports storage over IP and remote platform flash BIOS update USB 2.0 virtual hub
	AST2050 iKVM Feature	24-bit high quality video compression Dual 10/100 Mb/s MAC interfaces
BIOS	Brand / ROM size	AMI / 4MB
	Feature	Plug and Play (PnP) / PCI2.3 WfM2.0 / SMBIOS2.3 / PXE Boot ACPI 2.0 power management Power on mode after power recovery User-configurable H/W monitoring Auto-configurable of hard disk types Multiple boot options
Form Factor	Form Factor	SSI EEB
	Board Dimension	12"x13" (305x330mm)
Operating System	OS supported list	Please refer to our OS supported list.
Regulation	FCC (DoC)	Class B
	CE (DoC)	Yes

Operating Environment	Operating Temp.	10° C ~ 35° C (50° F ~ 95° F)
	Non-operating Temp.	- 40° C ~ 70° C (-40° F ~ 158° F)
	In/Non-operating Humidity	90%, non-condensing at 35° C
RoHS	RoHS 6/6 Complaint	Yes

Remember to visit TYAN[®]'s website at <http://www.tyan.com>. There you can find information on all of TYAN[®]'s products with FAQs, online manuals and BIOS upgrades and more.

1.3 - Software Specifications

For OS (operation system) support, please check the TYAN[®] website for the latest information.

1.4 - AST2050 User Guide

Remember to visit the TYAN[®]'s website at <http://www.tyan.com> for the AST2050 user guide.

Chapter 2: Board Installation

You are now ready to install your motherboard.

How to install our products right... the first time

The first thing you should do is reading this user's manual. It contains important information that will make configuration and setup much easier. Here are some precautions you should take when installing your motherboard:

- (1) Ground yourself properly before removing your motherboard from the antistatic bag. Unplug the power from your computer power supply and then touch a safely grounded object to release static charge (i.e. power supply case). For the safest conditions, TYAN® recommends wearing a static safety wrist strap.
- (2) Hold the motherboard by its edges and do not touch the bottom of the board, or flex the board in any way.
- (3) Avoid touching the motherboard components, IC chips, connectors, memory modules, and leads.
- (4) Place the motherboard on a grounded antistatic surface or on the antistatic bag that the board was shipped in.
- (5) Inspect the board for damage.


The following pages include details on how to install your motherboard into your chassis, as well as installing the processor, memory, disk drives and cables.



Note:


DO NOT APPLY POWER TO THE BOARD IF IT HAS BEEN DAMAGED.

2.1 - Board Image




This diagram is representative of the latest motherboard revision available at the time of publishing. The board you receive may not look exactly like the above diagram.

2.2 - Block Diagram



S7025 Block Diagram

2.3 - Board Parts, Jumpers and Connectors






This diagram is representative of the latest board revision (S7025WAGM2NR) available at the time of publishing. The board you receive may not look exactly like the above diagram.


Jumpers & Connectors

Jumper/Connector	Function
J17	COM2 Header
J18/J19	Mini SAS Ports
J27/J29	USB Header
J36/J40/J43	Front Fan
J37/J51	CPU FAN
J42	Front Panel
J45	PSMI Header
J46	IPMB
J47/J48	Rear Fan
J49	Audio Header
J50	SATA SGPIO
J73	Chassis Intrusion Header
J167	SSI Fan Header
J168	SPDIF Header
J169	CD IN
JP1	Clear CMOS


Jumper Legend

	OPEN - Jumper OFF	Without jumper cover
	CLOSED - Jumper ON	With jumper cover


	Pin	1	2	3	4
	Signal	GND	+12V	FANIN	FANCTL

 Pin_1	Pin	1	2	3	4
	Signal	GND	+12V	FANIN	FANCTL


J42: Front Panel Header

	Signal	Pin	Pin	Signal
	PW_LED+	1	2	FP_PWR
	CUT	3	4	ID_LED+
	PW_LED-	5	6	ID_LED-
	HDD_LED+	7	8	FAULT_LED1-
	HDD_LED-	9	10	FAULT_LED2-
	PWR_SW#	11	12	LAN1_ACTLED+
	GND1	13	14	LAN1_ACTLED-
	RST_SW#	15	16	SMBUS_SDA
	GND2	17	18	SMBUS_SCL
	SYS_ID_SW	19	20	INTRUSION#
	TEMP_SENSOR	21	22	LAN2_ACTLED+
	NMI_SW#	23	24	LAN2_ACTLED-


J45: PSMI Header


	Pin	Signal
	1	SMB_CLK
	2	SMB_DAT
	3	SMB_ALER
	4	GND
	5	3.3V

J46: IPMB Connector


	Pin	1	2	3	4
	Signal	IPMB DATA	GND	IPMB CLK	NC

J49: Audio Header


	Signal	Pin	Pin	Signal
	MIC2_L_FP	1	2	GND_AUDIO
	MIC2_R_FP	3	4	Front_Present_N
	LINE2_R_FP	5	6	MIC2-JD
	GND_AUDIO	7	8	CUT
	LINE2_L_FP	9	10	LINE2-JD




J50 SATA SGPIO Header

	Signal	Pin	Pin	Signal
	SMBUS_3V3_CLK	1	2	ICH_SDATAOUT0
	SMBUS_3V3_DATA	3	4	ICH_SDATAOUT1
	GND	5	6	ICH_SLOAD
	CUT	7	8	ICH_SCLOCK
	NC	9	10	ICH_HDD_ERR


J73: Chassis Intrusion Header

	Pin	1	2
	Signal	INTRUDER_N	GND


J167: SSI Fan Connector

	Signal	Pin	Pin	Signal
	FANIN4	1	2	FANIN8
	FANIN5	3	4	FANIN1
	FANIN6	5	6	FANIN3
	FANIN2	7	8	FANIN9
	FANIN7	9	10	FANIN10
	GND	11	12	CUT
	FANCTL5	13	14	FANCTL4
	FANIN11	15	16	FANIN13
	FANIN12	17	18	FANIN14
	NC	19	20	FAN_BP_PWM3


J168: SPDIF Header

	Pin	1	2
	Signal	SPDIF	GND

J169: CD_IN


	Pin	1	2	3	4
	Signal	CD_L	GND	GND	CD_R

JP1: Clear CMOS

	Normal (Default)	<p>You can reset the CMOS settings by using this jumper if you have forgotten your system/setup password or need to clear system BIOS setting.</p> <ul style="list-style-type: none">- Power off system and disconnect both power connectors from the motherboard- Put jumper cap back to Pin_1 and Pin_2 (default setting)- Use jumper cap to close Pin_2 and Pin_3 for several seconds to Clear CMOS <p>Reconnect power & power on system</p>
	Clear CMOS	

Onboard ID LED

You can identify the specific system using this LED. It is convenient for you to active ID LED through IPMI from remote site.


	Pin	Signal	
	+	P3V3_AUX	
	-	ID_SW_L	
	State	Color	Description
	On	Blue	System identified
	Off	Off	System not identified

2.4 - Installing the Processor

Your brand new S7025 supports the latest Tylersburg platform from Intel®. Only Intel® “Nehalem-EP 2S” processors are certified and supported with this motherboard.


Check our website for latest processor support. <http://www.tyan.com>


TYAN® is not liable for damage as a result of operating an unsupported configuration.




Step1:
Press the lever
and unlock the
CPU socket.

Step2:
Lift the CPU
protection cap
up and lay the
CPU into the
socket(A),
ensuring pin1
is correctly
located(B).





Step3:
Close the socket cover and press the CPU lever down to secure the CPU.




2.5 - Heat sink Installation

After installing the processor, you should proceed to install the heat sink. The CPU heat sink will ensure that the processor do not overheat and continue to operate at maximum performance for as long as you own them. The overheated processor is dangerous to the motherboard.

For the safest method of installation and information on choosing the appropriate heat sink, using heat sinks validated by Intel®.


Please refer to Intel®'s website at www.intel.com

The following diagram illustrates how to install heat sink onto the CPU of S7025.




Place the heat sink on top of the CPU and secure it to the motherboard using four screws clockwise.

2.6 - Thermal Interface Material



There are two types of thermal interface materials designed for use with the processors.

The most common material comes as a small pad attached to the heat sink at the time of purchase. There should be a protective cover over the material. Take care not to touch this material. Simply remove the protective cover and place the heat sink on the processor.



The second type of interface material is usually packaged separately. It is commonly referred to as 'thermal compound'. Simply apply a thin layer on to the CPU lid (applying too much will actually reduce the cooling).



Note:

Always check with the manufacturer of the heat sink & processor to ensure the thermal interface material is compatible with the processor and meets the manufacturer's warranty requirements.

2.7 - Finishing Installing the Heat sink


After you have finished installing the heat sink onto the processor and socket, attach the end wire of the fan (which should already be attached to the heat sink) to the motherboard. The following diagram illustrates how to connect fans onto the motherboard.



Once you have finished installing all the fans you can connect your drives (hard drives, CD-ROM drives, etc.) to your motherboard.










2.8 - Tips on Installing Motherboard in Chassis

Before installing your motherboard, make sure your chassis has the necessary motherboard support studs installed. These studs are usually metal and are gold in color. Usually, the chassis manufacturer will pre-install the support studs. If you are unsure of stud placement, simply lay the motherboard inside the chassis and align the screw holes of the motherboard to the studs inside the case. If there are any studs missing, you will know right away since the motherboard will not be able to be securely installed.




Some chassis' include plastic studs instead of metal. Although the plastic studs are usable, TYAN® recommends using metal studs with screws that will fasten the motherboard more securely in place.

Below is a chart detailing what the most common motherboard studs look like and how they should be installed.

Mounting the Motherboard		
Type	Solutions for installing	
		
		
		

2.9 - Installing the Memory

Before installing memory, ensure that the memory you have is compatible with the motherboard and processor.
Check the TYAN® web site at: www.tyan.com for details of the type of memory recommended for your motherboard.
The following diagram shows common types of DDR3 memory modules.



- TYAN® S7025 series support up to 64GB DDR3 memory.
- DDR3 800/1066/1333 memories are supported.
- All installed memory will automatically be detected and no jumpers or settings need changing.

Note:



- 1). For the DIMM number please refer to the motherboard placement in “2.3 - Board Parts, Jumpers and Connectors” for memory installation.
- 2). Refer to the memory population option table for recommended memory installation instruction.

Memory Population Option Table

To achieve the best performance, TYAN® strongly recommended memory installation configuration as listed below:

1. Single CPU installed (CPU0 Only)

Quantity of memory		1	2	3	4
DIMM Slot					
CPU0 DIMM CHA1					✓
CPU0 DIMM CHA0		✓	✓	✓	✓
CPU0 DIMM CHB0			✓	✓	✓
CPU0 DIMM CHC0				✓	✓
CPU1 DIMM CHD1					
CPU1 DIMM CHD0					
CPU1 DIMM CHE0					
CPU1 DIMM CHF0					

2. Single CPU installed (CPU1 Only)

Quantity of memory DIMM Slot	1	2	3	4
CPU0 DIMM CHA1				
CPU0 DIMM CHA0				
CPU0 DIMM CHB0				
CPU0 DIMM CHC0				
CPU1 DIMM CHD1				✓
CPU1 DIMM CHD0	✓	✓	✓	✓
CPU1 DIMM CHE0		✓	✓	✓
CPU1 DIMM CHF0			✓	✓

3. Dual CPU installed (CPU0 & CPU1)

Quantity of memory DIMM Slot	1	2	3	4	5	6	7	8
CPU0 DIMM CHA1							✓	✓
CPU0 DIMM CHA0	✓	✓	✓	✓	✓	✓	✓	✓
CPU0 DIMM CHB0			✓	✓	✓	✓	✓	✓
CPU0 DIMM CHC0					✓	✓	✓	✓
CPU1 DIMM CHD1								✓
CPU1 DIMM CHD0		✓	✓	✓	✓	✓	✓	✓
CPU1 DIMM CHE0				✓	✓	✓	✓	✓
CPU1 DIMM CHF0						✓	✓	✓

Note:




- 1). “✓” indicates a populated DIMM slot.
- 2). If installing only **one** processor, you can choose either CPU0 or CPU1.
- 3). For **two slots per channel** configuration, it requires population to start with the DIMM slots furthest away from the processor.


Memory Installation Procedure

Follow these instructions to install memory modules into the S7025.


1. Press the locking levers in the direction shown in the following illustration.



2. Align the memory module with the socket. The memory module is keyed to fit only one way in the socket.



3. Seat the module firmly into the socket by gently pressing down until it sits flush with the socket. The locking levers pop up into place.



2.10 - Attaching Drive Cables


Attaching Serial ATA Cables

S7025 is equipped with 6 Serial ATA (SATA) channels. Connections for the drives are very simple.

There is no need to set Master/Slave jumpers on SATA drives.

If you are in need of SATA/SAS cables or power adapters please contact your place of purchase.

The following pictures illustrate how to connect an SATA drive



2.11 - Installing Add-On Cards

Before installing add-on cards, it's helpful to know if they are fully compatible with your motherboard. For this reason, we've provided the diagrams below, showing the slots that may appear on your motherboard.

PCI-E x 16 slot



PCI-E x 8 slot



PCI-E x 4 slot



PCI 32bit slot



Simply find the appropriate slot for your add-on card and insert the card firmly. Do not force any add-on cards into any slots if they do not seat in place. It is better to try another slot or return the faulty card rather than damaging both the motherboard and the add-on card.

TIP: It's good practice to install add-on cards in a staggered manner rather than making them directly adjacent to each other. Doing so allows air to circulate within the chassis more easily, thus improving cooling for all installed devices.




Note:

YOU MUST ALWAYS unplug the power connector to the motherboard before performing system hardware changes to avoid damaging the board or expansion device.

2.12 - Connecting External Devices

Your motherboard supports a number of different interfaces through connecting peripherals. See the following diagrams for the details.




Note:

Peripheral devices can be plugged straight into any of these ports but software may be required to complete the installation.


Onboard LAN LED Color Definition

The three onboard Ethernet ports have green and yellow LEDs to indicate LAN status. The chart below illustrates the different LED states.

10/100/1000 Mbps LAN Link/Activity LED Scheme			
		Left LED	Right LED
10 Mbps	Link	Green	Off
	Active	Blinking Green	Off
100 Mbps	Link	Green	Green
	Active	Blinking Green	Green
1000 Mbps	Link	Green	Yellow
	Active	Blinking Green	Yellow
No Link		Off	Off

2.13 - Installing the Power Supply


The S7025 supports EPS12V/SSI power supplies that have 1x 24-pin, 2x 8-pin power connectors. **PWR1**, **PWR3**, **PWR5** should be used in combination.



PWR 3/5: 8-Pin EPS 12V PWR Connector

	Signal	Pin	Pin	Signal
	GND	1	5	+12V
	GND	2	6	+12V
	GND	3	7	+12V
	GND	4	8	+12V

PW 1: 24-Pin EPS 12V PWR main Connector

	Signal	Pin	Pin	Signal
	+3.3V	1	13	+3.3V
	+3.3V	2	14	-12V
	GND	3	15	GND
	+5V	4	16	PS_ON
	GND	5	17	GND
	+5V	6	18	GND
	GND	7	19	GND
	PWRGD	8	20	NC
	5VSB	9	21	+5V
	+12V	10	22	+5V
	+12V	11	23	+5V
	+3.3V	12	24	GND

We suggest using a 1000W or higher power supply, this is of course depends on how many devices you attach. 1000W is sufficient for common system (i.e. 1 hard drive, 1 expansion card) configuration. However, a higher wattage solution may be needed if the system is fully loaded. Refer to www.tyan.com website for further information.



Note:

YOU MUST unplug the power supply before plugging the power cables to motherboard connectors.

2.14 - Finishing Up

Congratulations on making it this far! You're finished setting up the hardware aspects of your computer. Before closing up your chassis, make sure that all cables and wires are connected properly, especially IDE cables and most importantly, jumpers. You may have difficulty powering on your system if the motherboard jumpers are not set correctly. In the rare circumstance that you have experienced difficulty, you can find help by asking your vendor for assistance. If they are not available for assistance, please find setup information and documentation online at our website or by **calling your vendor's support line**.

Chapter 3: BIOS Setup

3.1 - About the BIOS

The BIOS is the basic input/output system, the firmware on the motherboard that enables your hardware to interface with your software. The BIOS determines what a computer can do without accessing programs from a disk. The BIOS contains all the code required to control the keyboard, display screen, disk drives, serial communications, and a number of miscellaneous functions. This chapter describes the various BIOS settings that can be used to configure your system.

The BIOS section of this manual is subject to change without notice and is provided for reference purposes only. The settings and configurations of the BIOS are current at the time of print and are subject to change, and therefore may not match exactly what is displayed on screen.

This section describes the BIOS setup program. The setup program lets you modify basic configuration settings. The settings are then stored in a dedicated, battery-backed memory (called NVRAM) that retains the information even when the power is turned off.

To start the BIOS setup utility:

1. Turn on or reboot your system.
2. Press during POST (<Tab> on remote console) to start the BIOS setup utility.

3.2 - BIOS Menu Bar

The menu bar at the top of the windows lists these selections:

Main	To configure basic system setups
Advanced	To configure the advanced chipset features
PCI/PnP	To configure legacy Plug & Play or PCI settings
Boot	To configure system boot order
Security	To configure user and supervisor passwords
Chipset	To configure chipset management features
Exit	To exit setup utility

3.3 - Setup Basics

The table below shows how to navigate in the setup program using the keyboard.

Key	Function
<F1>	General help window
<ESC>	Exit current menu
← → arrow keys	Select a different menu
↑ or ↓ arrow keys	Move cursor up/down
<Tab> / <Shift-Tab>	Cycle cursor up/down
<Home> / <End>	Move cursor to top/bottom of the window
<PgUp> / <PgDn>	Move cursor to next/previous page
<->	Select the previous value/setting of the field
<+>	Select the next value/setting of the field
<F8>	Load Fail Safe default configuration values of the menu
<F9>	Load the Optimal default configuration values of the menu
<F10>	Save and exit
<Enter>	Execute command or select submenu

3.4 - Getting Help

Pressing [F1] will display a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press [ESC].

3.5 - In Case of Problems

If you have trouble booting your computer after making and saving the changes with the BIOS setup program, you can restart the computer by holding the power button down until the computer shuts off (usually within 4 seconds); resetting by pressing CTRL-ALT-DEL; or clearing the CMOS. The best advice is to only alter settings that you thoroughly understand. In particular, do not change settings in the Chipset section unless you are absolutely sure of what you are doing. The Chipset defaults have been carefully chosen either by TYAN® or your system manufacturer for best performance and reliability. Even a seemingly small change to the Chipset setup options may cause the system to become unstable or unusable.

Note:



The following pages provide the details of BIOS menu. Please be noticed that the BIOS menu are continually changing due to the BIOS updating. The BIOS menu provided are the most updated when this manual is written. Please visit TYAN®'s website at <http://www.tyan.com> for the information of BIOS update.

3.6 - BIOS Main Menu

The Main BIOS Menu is the first screen that you can navigate. The Main BIOS setup menu screen has two main frames. The left frame displays all the options that can be configured. "Grayed-out" options cannot be configured, options in blue can be changed.

The right frame displays the key legend. Above the key legend is an area reserved for a text message. When an option is selected in the left frame, it is highlighted in white. Often, a text message will accompany it.

BIOS Setup Utility						
Main	Advanced	PCI/PnP	Boot	Security	Chipset	Exit
System Overview				Use [ENTER], [TAB] or [SHIFT-TAB] to select a field Use [+] or [-] to configure system time. ← → Select Screen ↑ ↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit		
AMIBIOS						
Version : vx.xx						
Build Date : DD/MM/YY						
ID : xxxx_xxx						
Processor		X55700@2.93GHz				
Intel (R) Xeon(R) CPU						
Speed : xxxx MHz						
Count : x						
System Memory						
Size : xxxx MB						
System Time		[HH:MM:SS]				
System Date		[MM:DD:YYYY]				

Feature	Option	Description
Main		
System Time	HH : MM : SS	Set the system time
System Date	MM : DD : YYYY	Set the system date

3.7 - BIOS Advanced Menu

You can select any of the items in the left frame of the screen, such as Super I/O Configuration, to go to the sub menu for that item. You can display an Advanced BIOS Setup option by highlighting it using the <Arrow> keys. All Advanced BIOS Setup options are described in this section. The Advanced BIOS Setup screen is shown below. The sub menus are described on the following pages.

BIOS Setup Utility						
Main	Advanced	PCI/PnP	Boot	Security	Chipset	Exit
Advanced Settings				Configure CPU ← → Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit		
WARNING: Setting wrong values in below sections may cause system to malfunction. ▶ CPU Configuration ▶ IDE Configuration ▶ Super IO Configuration ▶ USB Configuration ▶ ACPI Configuration ▶ AHCI Configuration ▶ IPMI 2.0 Configuration ▶ Intel VT-d Configuration ▶ PCI Express Configuration ▶ Remote Access Configuration ▶ Trusted Computing						

Feature	Option	Description
Advanced Settings		
CPU Configuration	Menu Item	Configure CPU
IDE Configuration	Menu Item	Configure the IDE device(s)
Super IO Configuration	Menu Item	Configures Super IO Chipset Win627DHG
USB Configuration	Menu Item	Configure the USB support
ACPI Configuration	Menu Item	Section for Advanced ACPI Configuration
AHCI Configuration	Menu Item	Section for AHCI Configuration
IPMI 2.0 Configuration	Menu Item	IPMI configuration including server monitoring and event log
Intel VT-d Configuration	Menu Item	Configure Intel® Virtualization Technology for Directed I/O (VT-d) support
PCI Express Configuration	Menu Item	Configure PCI Express Support
Remote Access Configuration	Menu Item	Configure Remote Access
Trusted Computing	Menu Item	Configure settings related to Trusted Computing Information

3.7.1 - CPU Configuration

You can use this screen to view CPU Configuration Menu. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility	
Advanced	
Configure advanced CPU settings Module Version : XX.XX	Sets the ratio between CPU Core Clock and the FSB Frequency.
Manufacturer : Intel Intel(R) Xeon(R) CPU @ xxxx @xxxGHz Frequency :x.xxGHz BCLK Speed :xxxMHz Cache L1 : xxxKB Cache L2 :XXXXKB Cache L3 :XXXXKB Ratio Status : Unlocked (Min:12,Max:22) Ratio Actual Value :22	
Ratio CMOS Setting [22] Hardware Prefetcher [Enabled] Adjacent Cache Line Prefetch [Enabled] Max CPUID Value Limit [Disabled] Intel(R) Virtualization Tech [Enabled] Execute-Disable Bit Capability [Enabled] Intel(R) HT Technology [Enabled] Active Processor Cores [All] A20M [Disabled] Intel® SpeedStep™ Tech [Enabled] Intel® C-STATE tech [Enabled] C3 State [ACPI C2] C6 State [Enabled] C State package limit setting [Auto] C1 Auto Demotion [Enabled] C3 Auto Demotion [Enabled] ACPI T State [Enabled]	← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
CPU Configuration		
Manufacturer	Read only	Displays information about CPU
Frequency		
BCLK Speed		
Cache L1		
Cache L2		
Cache L3		
Ratio Status		
Ratio Actual Value		
Ratio CMOS Setting	[22]	Sets the ratio between CPU Core Clock and the FSB Frequency.
Hardware Prefetcher	Enabled	For UP platforms, leave it enabled. For DP/MP servers, it may use to time performance to the specific application.
	Disabled	
Adjacent Cache Line Prefetch	Enabled	For UP platforms, leave it enabled. For DP/MP servers, it may use to time performance to the specific application.
	Disabled	
Max CPUID Value Limit	Enabled	Disabled for Windows XP
	Disabled	
Intel (R) Virtualization Tech	Enabled	When enabled, a VMM can utilize the additional HW Caps. Provided by Intel(R) Virtualization Tech. Note: A full reset is required to change the setting.
	Disabled	
Execute-Disable Bit Capability	Enabled	When disabled, force the XD feature flag to always return 0.
	Disabled	
Intel (R) HT Technology	Enabled	When 'Disabled' only one thread per enabled core is enabled.
	Disabled	
Active Processor Cores	[All]	Number of cores to enable in each processor package.
A20M	Disabled	Legacy OSes and APs may need A20M enabled.
	Enabled	
Intel® SpeedStep™ Tech	Enabled	Enable (GV3)
	Disabled	Disable (GV3)
Intel® C-STATE tech	Enabled	C-State: CPU idle is set to C2/C3/C4
	Disabled	
C3 State	[ACPI C2]	/
C6 State	[Enabled]	/
C State package limit setting	Auto	Selected option will program into C state package limit register.
	C1	
	C3	
	C6	
	C7	
C1 Auto Demotion	Enabled	When enabled, CPU will conditionally demote C3/C6/C7 requests to C1 based on uncore auto-demote information.
	Disabled	
C3 Auto Demotion	Enabled	When enabled, CPU will conditionally demote C6/C7 requests to C3 based on uncore auto-demote information.
	Disabled	
ACPI T State	/	Report processor throttling in ACPI

3.7.2 - IDE Configuration Sub-Menu

You can use this screen to select options for the IDE Configuration Settings. Use the up and down <Arrow> Keys to select an item. Use the <Plus> and <Minus> Keys to change the value of the selection options.

BIOS Setup Utility		
Advanced		
IDE Configuration		Options
SATA Configuration	[Enhanced]	Disabled Compatible Enhanced ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Configure SATA as	[IDE]	
▶ Primary IDE Master	[Not Detected]	
▶ Secondary IDE Master	[Not Detected]	
▶ Third IDE Master	[Not Detected]	
▶ Third IDE Slave	[Not Detected]	
▶ Fourth IDE Master	[Not Detected]	
▶ Fourth IDE Slave	[Not Detected]	
Hard Disk Write Protect	[Disabled]	
IDE Detect Time Out (Sec)	[35]	

Feature	Option	Description
IDE Configuration		
SATA Configuration	Enhanced	Configure SATA devices
	Disabled	
	Compatible	
Configure SATA as	IDE	Select legacy IDE, RAID or AHCI as the SATA interface.
	RAID	
	AHCI	
Hard Disk Write Protect	Disabled	Enable/Disable device write protection. This will be effective only if device is accessed through BIOS.
	Enabled	
IDE Detect Time Out (Sec)	0~35 (at 5 interval)	Select the time out value for detecting ATA/ATAPI device(s).

3.7.2.1 - Primary IDE Master Configuration Sub-Menu

BIOS Setup Utility		
Advanced		
Primary IDE Master		Select the type of device connected to the system. ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Device: Not Detected		
TYPE	[Auto]	
LBA/Large Mode	[Auto]	
Block (Multi-Sector Transfer)	[Auto]	
PIO Mode	[Disabled]	
DMA Mode	[Auto]	
S.M.A.R.T.	[Auto]	
32Bit Data Transfer	[Enabled]	

Feature	Option	Description
Primary IDE Master/Slave		
Type	Auto	Selects the type of device connected to the system.
	Not Installed	
	CD/DVD	
	ARMD	
LBA/Large Mode	Auto	Auto: Enabled LBA Mode if the device supports it and the device is not already formatted with LBA Mode disabled.
	Disabled	Disabled: Disabled LBA Mode.
Block (Multi-Sector Transfer)	Auto	Disabled: The Data transfer from and to the device occurs one sector at a time.
	Disabled	Auto: The Data transfer from and to the device occurs multiple sectors at a time if the device supports it.
PIO Mode	Auto	Select the PIO Mode. Select Auto to enhance hard disk performance by optimizing the hard disk timing.
	0~4(at 1 interval)	
DMA Mode	Auto	Select DMA Mode. Auto: Auto detected.
S.M.A.R.T.	Auto	S.M.A.R.T. (Self-Monitoring Analysis and Reporting Technology) is a utility that monitors your disk status to predict hard disk failure.
	Disabled	
	Enabled	
32Bit Data Transfer	Enabled	Enable 32-bit to maximize the IDE hard disk data transfer rate.
	Disabled	

3.7.2.2 - Secondary IDE Master Configuration Sub-Menu

Advanced		BIOS Setup Utility	
Secondary IDE Master		Select the type of device connected to the system.	
Device: Not Detected			
TYPE	[Auto]		
LBA/Large Mode	[Auto]	← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit	
Block (Multi-Sector Transfer)	[Auto]		
PIO Mode	[Disabled]		
DMA Mode	[Auto]		
S.M.A.R.T.	[Auto]		
32Bit Data Transfer	[Enabled]		

3.7.2.3 - Third IDE Master Configuration Sub-Menu

BIOS Setup Utility		
Advanced		
Third IDE Master		<div>Disabled: Disables LBA Mode.</div> <div>Auto: Enables LBA Mode if the device supports it and the device is not already formatted with LBA Mode disabled.</div> <div>← → Select Screen</div> <div>↑↓ Select Item</div> <div>+/- Change Option</div> <div>F1 General Help</div> <div>F10 Save and Exit</div> <div>ESC Exit</div>
Device: Not Detected		
LBA/Large Mode	[Auto]	
Block (Multi-Sector Transfer)	[Auto]	
PIO Mode	[Disabled]	
DMA Mode	[Auto]	
S.M.A.R.T.	[Auto]	
32Bit Data Transfer	[Enabled]	

3.7.2.4 - Third IDE Slave Configuration Sub-Menu

BIOS Setup Utility		
Advanced		
Third IDE Slave		Disabled: Disables LBA Mode. Auto: Enables LBA Mode if the device supports it and the device is not already formatted with LBA Mode disabled. ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Device: Not Detected		
LBA/Large Mode	[Auto]	
Block (Multi-Sector Transfer)	[Auto]	
PIO Mode	[Disabled]	
DMA Mode	[Auto]	
S.M.A.R.T.	[Auto]	
32Bit Data Transfer	[Enabled]	

3.7.2.5 - Fourth IDE Master Configuration Sub-Menu

BIOS Setup Utility		
Advanced		
Fourth IDE Master		Disabled: Disables LBA Mode. Auto: Enables LBA Mode if the device supports it and the device is not already formatted with LBA Mode disabled. ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Device: Not Detected		
LBA/Large Mode	[Auto]	
Block (Multi-Sector Transfer)	[Auto]	
PIO Mode	[Disabled]	
DMA Mode	[Auto]	
S.M.A.R.T.	[Auto]	
32Bit Data Transfer	[Enabled]	

3.7.2.6 - Fourth IDE Slave Configuration Sub-Menu

BIOS Setup Utility		
Advanced		
Fourth IDE Slave		Disabled: Disables LBA Mode. Auto: Enables LBA Mode if the device supports it and the device is not already formatted with LBA Mode disabled. ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Device: Not Detected		
LBA/Large Mode	[Auto]	
Block (Multi-Sector Transfer)	[Auto]	
PIO Mode	[Disabled]	
DMA Mode	[Auto]	
S.M.A.R.T.	[Auto]	
32Bit Data Transfer	[Enabled]	

3.7.3 - Super I/O Configuration Sub- Menu

You can use this screen to select options for the Super I/O settings. Use the up and down arrow (/) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option.

BIOS Setup Utility		
Advanced		
Configure Win627DHG Super IO Chipset		Allows BIOS to Select Serial Port1 Base Addresses.
Serial Port1 Address	[3F8/IRQ4]	
Serial Port2 Address	[2F8/IRQ3]	← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Watchdog Mode	[Disabled]	
Chassis intrusion detection	[Disabled]	

Feature	Option	Description
Configure Win627 Super I/O Chipset		
Serial Port1 Address	3F8 IRQ4	Allow BIOS to select Serial Port1 Base Addresses.
	3E8 IRQ4	
	2E8 IRQ3	
	Disabled	
Serial Port1 Address	3F8 IRQ4	Allow BIOS to select Serial Port2 Base Addresses.
	3E8 IRQ4	
	2E8 IRQ3	
	2F8 IRQ3	
Watchdog Mode	Disabled	POST: BIOS POST Watchdog timer counting, start at PowerOn stop at OS boot. OS: OS boot watchdog, start at OS boot. PowerOn: Start at PowerOn
	POST	
	OS	
	Power ON	
Chassis intrusion detection	Disabled	When a chassis open event is detected, the BIOS will record the event and issue a warning beep.
	Enabled	

3.7.4 - USB Configuration Sub- Menu

You can use this screen to view the USB Configuration Menu. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility	
Advanced	
USB Configuration	Enables support for legacy USB. AUTO option disables legacy support if no USB devices are connected.
Module Version – X.XX.X-XX.X	
USB Devices Enabled: 1 Keyboard, 1 Mouse	← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Legacy USB Support [Enabled]	
USB 2.0 Controller Mode [HiSpeed]	
BIOS EHCI Hand-Off [Enabled]	
Hotplug USB FDD Support [Auto]	

Feature	Option	Description
USB Configuration		
Legacy USB Support	Disabled	Enables support for legacy USB. AUTO option disables legacy support if no USB devices are connected.
	Auto	
	Enabled	
USB 2.0 Controller Mode	Hi Speed	Configure the USB 2.0 controller in Hi Speed (480Mbps) or Full Speed (12Mbps).
	Full Speed	
BIOS EHCI Hand-Off	Enabled	This is a work around for OSES without EHCI hand-off support. The EHCI ownership change should claim by EHCI driver.
	Disabled	
Hotplug USB FDD Support	Enabled	Enable or disable hotplug USB floppy support. A dummy FDD device is created that will be associated with the hotplugged FDD later. AUTO option creates this dummy device only if there is no USB FDD present.
	Disabled	
	Auto	

3.7.5 – ACPI Configuration Sub- Menu

You can use this screen to view the ACPI Configuration Menu. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility	
Advanced	
ACPI Settings	General ACPI Configuration settings
<ul style="list-style-type: none"> ▶ General ACPI Configuration ▶ Advanced ACPI Configuration ▶ Chipset ACPI Configuration 	<p>← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit</p>

3.7.5.1 - General ACPI Configuration Sub- Menu

BIOS Setup Utility		
Advanced		
General ACPI Configuration		Select the ACPI state used for System Suspend. ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Suspend mode	[AUTO]	
Repost Video on S3 Resume	[No]	

Feature	Option	Description
General ACPI Configuration		
Suspend mode	S1(DOS)	Select the ACPI state used for System Suspend.
	S3(STR)	
	AUTO	
Repost Video on S3 Resume	NO	Determines whether to invoke VGA BIOS post on S3/STR resume.
	YES	

3.7.5.2 - Advanced ACPI Configuration Sub- Menu

BIOS Setup Utility		
Advanced		
Advanced ACPI Configuration		Enabled RSDP pointers to 64-bit Fixed System Description Tables. DiACPI version has some ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
ACPI Version Features	[ACPI v3.0]	
ACPI APIC support	[Enabled]	
AMI OEMB table	[Enabled]	
Headless mode	[Disabled]	

Feature	Option	Description
Advanced ACPI Configuration		
ACPI Version Features	ACPI v3.0	Enable RSDP pointers to 64-bit Fixed System Description Tables. Di ACPI version has some.
	ACPI v2.0	
	ACPI v1.0	
ACPI APIC support	Enabled	Include ACPI APIC table pointer to RSDT pointer list.
	Disabled	
AMI OEMB table	Enabled	Include OEMB table pointer to R(X)SDT pointer lists.
	Disabled	
Headless mode	Enabled	Enable or disable Headless operation mode through ACPI.
	Disabled	

3.7.5.3 - South Bridge ACPI Configuration Sub- Menu

BIOS Setup Utility		
Advanced		
South Bridge ACPI Configuration		Option
Energy Lake Feature	[Disabled]	Enabled
APIC ACPI SCI IRQ	[Disabled]	Disabled
High Performance Event Timer	[Enabled]	
HPET Memory Address	[FED00000h]	
		← → Select Screen
		↑↓ Select Item
		+/- Change Option
		F1 General Help
		F10 Save and Exit
		ESC Exit

Feature	Option	Description
Chipset ACPI Configuration		
Energy Lake Feature	Disabled	Allow you to configure Intel's Energy Lake power management technology. If you are running a Media Center you can install the Intel VIIV software to get the correct driver; otherwise disable the Energy Lake feature in BIOS (it relates purely to Intel's Quick Resume feature, which is generally useless).
	Enabled	
ACPI APIC SCI IRQ	Disabled	Enable / Disable ACPI APIC SCI IRQ
	Enabled	
High Performance Event Timer	Enabled	Enable/disable High Performance Event Timer.
	Disabled	
HPET Memory Address	FED00000h	Choose HPET Memory Address
	FED01000h	
	FED02000h	
	FED03000h	

3.7.6 - AHCI Configuration Sub- Menu

You can use this screen to view the AHCI Configuration Menu. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility		
Advanced		
AHCI Settings		Enables for supporting ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
AHCI BIOS Support	[Enabled]	
AHCI CD/DVD Boot Time out	[35]	
▶ AHCI Port0	[Not Detected]	
▶ AHCI Port1	[Not Detected]	
▶ AHCI Port2	[Not Detected]	
▶ AHCI Port3	[Not Detected]	
▶ AHCI Port4	[Not Detected]	
▶ AHCI Port5	[Not Detected]	

Feature	Option	Description
AHCI Configuration		
AHCI BIOS Support	Disabled	Enable for supporting AHCI.
	Enabled	
AHCI CD/DVD Boot Time out	0	Some SATA CD/DVD in AHCI mode need to wait ready longer.
	5	
	10	
	15	
	20	
	25	
	30	
	35	

3.7.6.1 - AHCI Port 0/1/2/3/4/5 Sub- Menu

BIOS Setup Utility		
Advanced		
AHCI PORT X		Select the type of device connected to the system. ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Device : Not Detected		
SATA Port X	[AUTO]	
S.M.A.R.T.	[Enabled]	

Feature	Option	Description
AHCI Port X		
SATA Port X	AUTO	Select the type of device connected to the system.
	Not Installed	
S.M.A.R.T.	Disabled	S.M.A.R.T. stands for Self-Monitoring, Analysis and Reporting Technology.
	Enabled	

3.7.7 - IPMI 2.0 Configuration Sub-Menu

You can use this screen to view the IPMI 2.0 Configuration Settings. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility		
Advanced		
IPMI 2.0 Configuration		View all events in the BMC Event Log. It will take a max. of 15 seconds to read all BMC SEL records. ← → Select Screen ↑ ↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit
Status of BMC	Not Working	
▶ View BMC System Event Log		
Clear BMC System Event Log		
▶ Set LAN Configuration		
▶ Set PEF Configuration		
BMC Watch Dog Timer Action	[Disabled]	
BMC Alert LED and Beep	[Off]	
FW Key:	[0000000]	

Feature	Option	Description
IPMI 2.0 Configuration		
Status of BMC	Read only	Display BMC status
Clear BMC System Event Log	[Enter]	Clear all events in BMC System Event Log.
BMC Watch Dog Timer Action	Disabled	Allows the BMC to reset or power down the system if the operating system crashes or hangs.
	Reset System	
	Power Down	
	Power Cycle	
BMC Alert LED and Beep	Off	BMC Alert LED and Beep On/Off
	On	
FW Key	/	Enter IPMI FW Key upgrade to IPMI or iKVM function.

3.7.7.1 - View BMC System Event Log Sub-Menu

BIOS Setup Utility	
Advanced	
Total Number of Entries: N/A	Use +/- to traverse the event log. ← → Select Screen ↑↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit
SEL Entry Number [N/A]	

Please refer to BMC event log.

3.7.7.2 - Set LAN Configuration Sub-Menu

BIOS Setup Utility		
Advanced		
LAN Configuration		IPMI IP Address Source STATIC/DHCP
Channel Number Status:	BMC Not Alive/Present	After Setup Parameter, need to Save IP Setup Parameter. ← → Select Screen ↑↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit
IP Address Configuration		
IP Address Source	[DHCP]	
Current IP address in BMC:	Could Not Read BMC	
Current Subnet Mask in BMC:	Could Not Read BMC	
Current MAC address in BMC:	Could Not Read BMC	

Feature	Option	Description
LAN Configuration		
Channel Number Status	Read only	Channel Number is OK.
IP Address Source	DHCP	IPMI IP Source STATIC/DHCP
	STATIC	
Current IP Address in BMC	Read only	/
Current MAC Address in BMC	Read only	/
Current Subnet Mask in BMC	Read only	/

3.7.7.3 - Set PEF Configuration Sub-Menu

BIOS Setup Utility	
Advanced	
Set PEF Configuration Parameters Command	Enable or Disable PEF Support
PEF Support [Disabled]	← → Select Screen ↑↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Set PEF Configuration Parameters Command		
PEF Support	Disabled	Enable or Disable PEF Support
	Enabled	

3.7.8 Intel VT-d Configuration Sub-Menu

You can use this screen to view the Intel VT-d Configuration Settings. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility	
Advanced	
Intel VT-d Configuration	Options Enabled Disabled
Intel VT-d [Disabled]	← → Select Screen ↑↓ Select Item +/- Change Option Tab Select Field F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Intel VT-d Configuration		
Intel VT-d	Enabled	Enable or disable Intel® Virtualization Technology for Directed I/O (VT-d) support. VT-d support on Intel platforms provides the capability to ensure improved isolation of I/O resources for greater reliability, security, and availability.
	Disabled	

3.7.9 - PCI Express Configuration Sub-Menu

BIOS Setup Utility		
Advanced		
PCI Express Configuration		Enable/Disable PCI Express L0s and L1 link power status.
Active State Power-Management	[Disabled]	← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
PCI Express Configuration		
Active State Power-Management	Disabled	Enables/Disable PCI Express L0s and L1 link power states.
	Enabled	

3.7.10 - Remote Access Configuration Sub-Menu

You can use this screen to view the Remote Access Configuration Menu. This feature allows access to the Server remotely via serial port. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility		
Advanced		
Configure Remote Access type and parameters		Select Remote Access type.
Remote Access	[Disabled]	← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Configure Remote Access type and parameters		
Remote Access	Enabled	Enables remote access to system through serial port.
	Disabled	
NOTE: The items listed below will appear when Remote Access is set to [Enabled].		
Serial Port Number	COM1	Select Serial Port for console redirection. Make sure the selected port is enabled.
	COM2	
Base Address, IRQ	Read only	
Serial Port Mode	115200 8, n, 1	Select Serial Port settings.
	57600 8, n, 1	
	38400 8, n, 1	
	19200 8, n, 1	
	9600 8, n, 1	
Flow Control	None	Select Flow Control for console redirection.
	Hardware	
	Software	
Redirection After BIOS POST	Disabled	Disable: Turns off the redirection after POST Boot Loader: Redirection is active during POST and during Boot Loader. Always: Redirection is always active. <Some OSs may not work if set to Always>
	Boot Loader	
	Always	
Terminal Type	ANSI	Select the target terminal type.
	VT100	
	VT-UTF8	
VT-UTF8 Combo Key Support	Enabled	Enable VT-UTF8 Combination key Support for ANSI/VT100 terminals.
	Disabled	
Sredir Memory Display Delay	No Delay	Gives the delay in seconds to display memory information
	Delay 1 Sec	
	Delay 2 Sec	
	Delay 4 Sec	

3.7.11 – Trusted Computing Configuration Sub-Menu

BIOS Setup Utility		
Advanced		
Trusted Computing		Enable/Disable TPM TCG (TPM 1.1/1.2) support in BIOS
TCG/TPM SUPPORT	[No]	← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Trusted Computing		
TCG/TPM Support	No	Enable/Disable TPM
	Yes	TCG (TPM 1.1/1.2) support in BIOS
NOTE: The items listed below will appear when TCG/TPM Support is set to [Yes].		
Execute TPM Command	Don't Change	Enable (Activate) / Disable (Deactivate) command to TPM
	Disabled	
	Enabled	
Clearing the TPM	[Press Enter] See dialog box below	Select [OK] to clear the TPM or [Cancel] to exit.
TPM Enable/Disable Status	read only	Report TPM Enable/Disable status
TPM Owner Status	read only	Report TPM Owner status

Clearing the TPM is the process of returning the TPM to factory defaults. It is possible the platform owner will change when in this state.

Are you sure you want to clear it?

OK

Cancel

3.8 - PCI PnP Menu

You can use this screen to view PnP (Plug & Play) BIOS Configuration Menu. This menu allows the user to configure how the BIOS assigns resources & resolves conflicts. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option. The settings are described on the following pages.

BIOS Setup Utility PCI/PnP	
Advanced PCI/PnP Settings	Clear NVRAM during System Boot.
WARNING: Setting wrong values in below sections may cause system to malfunction.	
Clear NVRAM [No]	
Plug & Play O/S [No]	
PCI Latency Timer [64]	
Allocate IRQ to PCI VGA [Yes]	
Palette Snooping [Disabled]	
PCI IDE BusMaster [Enabled]	
	← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Advanced PCI/PnP Settings		
Clear NVRAM	No	Clears NVRAM during system Boot.
	Yes	
Plug & Play O/S	Yes	No: lets the BIOS configure all the devices in the system. Yes: lets the operating system configure Plug and Play (PnP) devices not required for boot if your system has a Plug and Play operating system.
	No	
PCI Latency Timer	32	This setting controls how many PCI clocks each PCI device can hold the bus before another PCI device takes over. When set to higher values, every PCI device can conduct transactions for a longer time and thus improve the effective PCI bandwidth. Values in units of PCI clocks for PCI device latency timer register.
	64	
	96	
	128	
	160	
	192	
	224	
	248	
Allocate IRQ to PCI VGA	Yes	Yes: assigns IRQ to PCI VGA card if card requests IRQ.
	No	

Feature	Option	Description
Palette Snooping	Disabled	This is the default setting and should not be changed unless the VGA card manufacturer requires Palette Snooping to be Enabled. Enabled: informs the PCI devices that an ISA graphics device is installed in the system so the card will function correctly.
	Enabled	
PCI IDE BusMaster	Disabled	Enabled: BIOS uses PCI bus mastering for reading / writing to IDE drives.
	Enabled	

3.9 - Boot Menu

You can display Boot Setup option by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility Boot	
Boot Settings	Configures settings during System Boot. ← → Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit
▶ Boot Settings Configuration	

3.9.1 - Boot Settings Configuration Sub-Menu

Use this screen to select options for the Boot Settings Configuration. Use the up and down arrow (↑/↓) keys to select an item. Use the Plus and Minus (+/-) keys to change the value of the selected option.

BIOS Setup Utility Boot	
Boot Settings Configuration	Allows BIOS to skip certain tests while booting. This will decrease the time needed to boot the system. ← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
Quick Boot [Disabled] Quiet Boot [Disabled] AddOn ROM Display Mode [Force BIOS] Boot up Num-Lock [On] Wait for 'F1' if Error [Enabled] Hit 'DEL' Message Display [Enabled] Interrupt 19 Capture [Enabled] Boots Graphic Adapter Priority [Auto] Onboard VGA device [Enabled]	

Feature	Option	Description
Boot Settings Configuration		
Quick Boot	Enabled	This option allows user bypass BIOS self test during POST.
	Disabled	
Quiet Boot	Disabled	Disabled: displays normal POST messages.
	Enabled	Enabled: displays OEM log instead of POST messages.
AddOn ROM Display Mode	Force BIOS	Allows user to force BIOS/Option ROM of add-on cards to be displayed during quiet boot.
	Keep Current	
Boot up Num-Lock	On	Selects Power-on state for Numlock.
	Off	
Wait for 'F1' If Error	Enabled	Waits for F1 key to be present if error occurs.
	Disabled	
Hit 'DEL' Message Display	Enabled	Displays "Press DEL to run Setup" in POST.
	Disabled	
Interrupt 19 Capture	Disabled	Enabled: allows option ROMs to trap interrupt 19.
	Enabled	
Boots Graphic Adapter Priority	—	Select which graphics controller to use as the primary boot device.
Onboard VGA device	Enabled	Enable/Disable onboard VGA chip. Note: Do not disable if you have not other VGA card attachment.
	Disabled	

3.10 - Security Menu

The system can be configured so that all users must enter a password every time the system boots or when BIOS Setup is entered, using either the Supervisor password or User password. The Supervisor and User passwords activate two different levels of password security. If you select password support, you are prompted for a one to six character password. Type the password on the keyboard. The password does not appear on the screen when typed. Make sure you write it down. If you forget it, you must clear CMOS and reconfigure.

BIOS Setup Utility	
Security	
Security Settings	Install or change the password.
Supervisor Password : Not Installed User Password : Not Installed	
Change Supervisor Password Change User Password	
Boot Sector Virus Protection [Disabled]	← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
Security Settings		
Supervisor Password	Not Installed	If the password has been set, Installed displays. If no password is set, Not Installed displays.
	Installed	
User Password	Not Installed	If the password has been set, Installed displays. If no password is set, Not Installed displays.
	Installed	
Change Supervisor Password	—	Selects this option to change or install Supervisor Password.
Change User Password	—	Selects this option to change or install User Password.
Boot Sector Virus Protection	Disabled	When it is set to [Enabled], BIOS will issue a virus warning message and beep if a write to the boot sector or the partition table of the HDD is attempted.
	Enabled	

3.11 - Chipset Menu

This menu allows the user to customize functions of the Intel Chipsets. Select a menu by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility	
Chipset	
Advanced Chipset Settings	Configure CPU Bridge features.
<p>WARNING: Setting wrong values in below sections may cause system to malfunction.</p> <ul style="list-style-type: none"> ▶ CPU Bridge Configuration ▶ Northbridge Configuration ▶ Southbridge Configuration ▶ ME Subsystem Configuration 	<p>← → Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit</p>

3.11.1 - CPU Bridge Configuration Sub- Menu

BIOS Setup Utility	
Chipset	
CPU Bridge Chipset Configuration	Transition the links to the specified speed when transitioning the links to full-speed.(if supported by all components)
CPU Revision :B0	<p>← → Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit</p>
Current QPI Frequency :x.xxxGT	
Current Memory Frequency : xxxxMHz	
QPI Frequency [Auto]	
QPI L0s and L1 [Disabled]	
Memory Frequency [Auto]	
Memory Mode [Independent]	
Demand Scrubbing [Enabled]	
Patrol Scrubbing [Enabled]	
Throttling-Closed Loop [Enabled]	
Hyster temp [1.5 C]	
Guardband temp [006]	
Inlet temp [070]	
Temp Rise [020]	
Air Flow [1500]	
Altitude [Sea Level or Below]	

Feature	Option	Description
CPU Bridge Chipset Configuration		
QPI Frequency	Auto	Transition the links to the specified speed when transitioning the links to full-speed.(if supported by all components)
	4.800GT	
	5.866GT	
	6.400GT	
QPI L0s and L1	Disabled	Enable/Disable L0s and L1.
	Enabled	
Memory Frequency	Auto	Forces a DDR3 frequency slower than the common tCk detected via SPD.
	Force DDR-800	
	Force DDR-1066	
	Force DDR-1333	
Memory Mode	Independent	Independent: Independent channel. Mirroring: Mirrors channel space between channels. Lockstep: lockstep between channel 0 and 1. Spare: Sparing mode.
	Channel Mirroring	
	Lockstep	
	Sparing	
Demand Scrubbing	Disabled	ECC Demand scrub enable/disable
	Enabled	
Patrol Scrubbing	Disabled	ECC patrol scrub enable/disable
	Enabled	
Throttling-Closed Loop	Disabled	BIOS to program Closed Loop throttling for memory compents.
	Enabled	
Hyster temp	Disabled	Temperature Hysteresis.
	1.5°C	
	3°C	
	6°C	
Guardband temp	/	Temperature guardband to apply to DIMM temp sensor Threshold. (in 0.5°C units)
Inlet temp	/	Temperature at the chassis inlet. (in 0.5°C units)
Temp Rise	/	Temperature rise to the DIMM thermal zone. (in 0.5°C units)
Air Flow	/	Air speed to the DIMMs. (in units of mm/sec)
Altitude	Sea Level or Below	The system altitude above sea level(in meters)
	1~300	
	301~600	
	601~900	
	901~1200	
	1201~1500	
	1501~1800	
	1801~2100	
	2101~2400	
	2401~2700	
	2701~3000	

3.11.2 - Northbridge Configuration Sub-Menu

This menu gives options for northbridge devices settings. Select a menu by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility		Chipset
North Bridge Chipset Configuration		
NB Revision	[B3]	
Current QPI Frequency	X.XXXGT	
		← → Select Screen ↑↓ Select Item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
North Bridge Chipset Configuration		
NB Revision	/	North Bridge Chipset Revision
Current QPI Frequency	/	Current QPI Frequency

Read only.

3.11.3 - Southbridge Configuration Sub-Menu

This menu gives options for southbridge devices settings. Select a menu by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility		Chipset
South Bridge Chipset Configuration		Options Enabled Disabled
HAD Controller	[Enabled]	← → Select Screen ↑↓ Select item +/- Change Option F1 General Help F10 Save and Exit ESC Exit
SMBUS Controller	[Enabled]	
SLP_S4# Min. Assertion Width	[4 to 5 seconds]	
Restore on AC Power Loss	[Power Off]	
Lan2	[Auto]	
Lan2 OP-ROM	[Disabled]	
Lan1	[Auto]	
Lan1 OP-ROM	[Disabled]	

Feature	Option	Description
South Bridge Chipset Configuration		
HAD Controller	Enabled	Enabled/Disabled SMBUS HAD Controller
	Disabled	
	3 to 4 seconds	
	2 to 3 seconds	
	1 to 2 seconds	
SMBUS Controller	Enabled	Enable or disable SMBUS controller
	Disabled	
SLP_S4# Min. Assertion Width	4-5 seconds	Select Timing for SLP_S4#
	3-4 seconds	
	2-3 seconds	
	1-2 seconds	
Restore on AC Power Loss	Power Off	Configure how the system board responds to a power failure.
	Power On	
	Last State	

3.11.4 – ME Subsystem Configuration Sub-Menu

This menu gives options for ME subsystem configuration devices settings. Select a menu by highlighting it using the Arrow (↑/↓) keys and pressing Enter. The settings are described on the following pages.

BIOS Setup Utility		Chipset
ME Subsystem Configuration		Options
ME-HECI	[Enabled]	Enabled Disabled
		← → Select Screen ↑↓ Select item +/- Change Option F1 General Help F10 Save and Exit ESC Exit

Feature	Option	Description
ME Subsystem Configuration		
ME-HECI	Enabled	Enabled/Disabled ME-HECI
	Disabled	

3.12 - Exit Menu

You can display an Exit BIOS Setup option by highlighting it Arrow (↑/↓) keys and pressing Enter.

BIOS Setup Utility	
Exit	
Exit Options	
Save Changes and Exit Discard Changes and Exit Discard Charges Load Optimal Defaults Load Failsafe Defaults	Exit system setup after saving the changes. F10 key can be used for this operation. ← → Select Screen ↑↓ Select Item Enter Go to Sub Screen F1 General Help F10 Save and Exit ESC Exit

Save Changes and Exit

Use this option to exit setup utility and re-boot.

All new selections you have made are stored into CMOS.

System will use the new settings to boot up.

Discard Changes and Exit

Use this option to exit setup utility and re-boot.

All new selections you have made are not stored into CMOS.

System will use the old settings to boot up.

Discard Changes

Use this option to restore all new setup values that you have made but not saved into CMOS.

Load Optimal Defaults

Use this option to load default performance setup values.

Use this option when system CMOS values have been corrupted or modified incorrectly.

Load Failsafe Defaults

Use this option to load all default failsafe setup values.

Use this option when troubleshooting.

Chapter 4: Diagnostics

If you experience problems with setting up your system, always check the following things in the following order:

Memory, Video, CPU

By checking these items, you will most likely find out what the problem might have been when setting up your system. For more information on troubleshooting, check the TYAN® website at: <http://www.tyan.com>.

4.1 - Beep Codes

Fatal errors, which halt the boot process, are communicated through two kinds of audible beeps.

- A single long beep followed by two short beeps: It indicates that a Video error has occurred.
- A single long beep repeatedly: It indicates that a DRAM error has occurred. The most common type of error is a memory error.

Before contacting your vendor or TYAN® Technical Support, be sure that you note as much as you can about the beep code length and order that you experience. Also, be ready with information regarding add-in cards, drives and O/S to speed the support process and come to a quicker solution.

4.2 - Flash Utility

Every BIOS file is unique for the motherboard it was designed for. For Flash Utilities, BIOS downloads, and information on how to properly use the Flash Utility with your motherboard, please check the TYAN® web site:

<http://www.tyan.com/>

Note:



Please be aware that by flashing your BIOS, you agree that in the event of a BIOS flash failure, you must contact your dealer for a replacement BIOS. There are no exceptions. TYAN® does not have a policy for replacing BIOS chips directly with end users. In no event will TYAN® be held responsible for damages done by the end user.

4.3 - AMIBIOS Post Code

The POST code checkpoints are the largest set of checkpoints during the BIOS pre-boot process. The following table describes the type of checkpoints that may occur during the POST portion of the BIOS:

Checkpoint	Description
03	Disable NMI, Parity, video for EGA, and DMA controllers. Initialize BIOS, POST, Runtime data area. Also initialize BIOS modules on POST entry and GPNV area. Initialized CMOS as mentioned in the Kernel Variable "wCMOSFlags."
04	Check CMOS diagnostic byte to determine if battery power is OK and CMOS checksum is OK. Verify CMOS checksum manually by reading storage area. If the CMOS checksum is bad, update CMOS with power-on default values and clear passwords. Initialize status register A. Initializes data variables that are based on CMOS setup questions. Initializes both the 8259 compatible PICs in the system
05	Initializes the interrupt controlling hardware (generally PIC) and interrupt vector table.
06	Do R/W test to CH-2 count reg. Initialize CH-0 as system timer. Install the POSTINT1Ch handler. Enable IRQ-0 in PIC for system timer interrupt. Traps INT1Ch vector to "POSTINT1ChHandlerBlock."
08	Initializes the CPU. The BAT test is being done on KBC. Program the keyboard controller command byte is being done after Auto detection of KB/MS using AMI KB-5.
0A	Initializes the 8042 compatible Key Board Controller.
0B	Detects the presence of PS/2 mouse.
0C	Detects the presence of Keyboard in KBC port.
0E	Testing and initialization of different Input Devices. Also, update the Kernel Variables. Traps the INT09h vector, so that the POST INT09h handler gets control for IRQ1. Uncompress all available language, BIOS logo, and Silent logo modules.
13	Early POST initialization of chipset registers.
24	Uncompress and initialize any platform specific BIOS modules.
30	Initialize System Management Interrupt.
2A	Initializes different devices through DIM. See <i>DIM Code Checkpoints</i> section of document for more information.
2C	Initializes different devices. Detects and initializes the video adapter installed in the system that have optional ROMs.
2E	Initializes all the output devices.
31	Allocate memory for ADM module and uncompress it. Give control to ADM module for initialization. Initialize language and font modules for ADM. Activate ADM module.
33	Initializes the silent boot module. Set the window for displaying text information.
37	Displaying sign-on message, CPU information, setup key message, and any OEM specific information.
38	Initializes different devices through DIM. See <i>DIM Code Checkpoints</i> section of document for more information.

Checkpoint	Description
39	Initializes DMAC-1 & DMAC-2.
3A	Initialize RTC date/time.
3B	Test for total memory installed in the system. Also, Check for DEL or ESC keys to limit memory test. Display total memory in the system.
3C	Mid POST initialization of chipset registers.
40	Detect different devices (Parallel ports, serial ports, and coprocessor in CPU, ... etc.) successfully installed in the system and update the BDA, EBDA...etc.
50	Programming the memory hole or any kind of implementation that needs an adjustment in system RAM size if needed.
52	Updates CMOS memory size from memory found in memory test. Allocates memory for Extended BIOS Data Area from base memory.
60	Initializes NUM-LOCK status and programs the KBD typematic rate.
75	Initialize Int-13 and prepare for IPL detection.
78	Initializes IPL devices controlled by BIOS and option ROMs.
7A	Initializes remaining option ROMs.
7C	Generate and write contents of ESCD in NVRam.
84	Log errors encountered during POST.
85	Display errors to the user and gets the user response for error.
87	Execute BIOS setup if needed / requested.
8C	Late POST initialization of chipset registers.
8E	Program the peripheral parameters. Enable/Disable NMI as selected
90	Late POST initialization of system management interrupt.
A0	Check boot password if installed.
A1	Clean-up work needed before booting to OS.
A2	Takes care of runtime image preparation for different BIOS modules. Fill the free area in F000h segment with 0FFh. Initializes the Microsoft IRQ Routing Table. Prepares the runtime language module. Disables the system configuration display if needed.
A4	Initialize runtime language module.
A7	Displays the system configuration screen if enabled. Initialize the CPU's before boot, which includes the programming of the MTRR's.
A8	Prepare CPU for OS boot including final MTRR values.
A9	Wait for user input at config display if needed.
AA	Uninstall POST INT1Ch vector and INT09h vector. Deinitializes the ADM module.
AB	Prepare BBS for Int 19 boot.
AC	End of POST initialization of chipset registers.
B1	Save system context for ACPI.
00	Passes control to OS Loader (typically INT19h).

Appendix: How to Make a Driver Diskette

Follow the steps below to make a driver diskette from the TYAN[®] driver CD provided.

1. Start the system and insert the TYAN[®] CD into the CD-ROM drive to boot from CD. You will see the following menu. Then press [1] and [Enter] to boot the system to TYAN[®] diskette maker. (If you would like to boot from hard disk, press 0 and Enter or just wait for 10 seconds to boot automatically from hard disk.).

Boot from CD:

ISOLINUX 2.00 2002-10-25 Copyright (C) 1994-2002 H. Peter Anvin

0) Boot from first hard drive

1) Boot to TYAN diskette maker

boot: 1_

2. Choose the chipset vender which you need from the main menu.

TYAN Driver Diskette Maker V1.0


** Main Menu**

====Choose Chipset Vendor=====


- | | |
|----|---------------|
| 01 | Adaptec |
| 02 | Intel |
| 03 | LSI |
| 04 | nVidia |
| 05 | Promise |
| 06 | Silicon Image |
| 07 | VIA |

EXIT


3. The following picture pops up after selecting the chipset model.



4. After selecting the chipset model, select the OS to start the diskette making.



5. Follow the instruction on menu to insert a diskette and press [ENTER].



6. Using "ESC" key to quit the TYAN® diskette maker. The system will automatically restart.

Glossary

ACPI (Advanced Configuration and Power Interface): a power management specification that allows the operating system to control the amount of power distributed to the computer's devices. Devices not in use can be turned off, reducing unnecessary power expenditure.

AGP (Accelerated Graphics Port): a PCI-based interface which was designed specifically for demands of 3D graphics applications. The 32-bit AGP channel directly links the graphics controller to the main memory. While the channel runs only at 66 MHz, it supports data transmission during both the rising and falling ends of the clock cycle, yielding an effective speed of 133 MHz.

ATAPI (AT Attachment Packet Interface): also known as IDE or ATA; a drive implementation that includes the disk controller on the device itself. It allows CD-ROMs and tape drives to be configured as master or slave devices, just like HDDs.

ATX: the form factor designed to replace the AT form factor. It improves on the AT design by rotating the board 90 degrees, so that the IDE connectors are closer to the drive bays, and the CPU is closer to the power supply and cooling fan. The keyboard, mouse, USB, serial, and parallel ports are built-in.

Bandwidth: refers to carrying capacity. The greater the bandwidth, the more data the bus, phone line, or other electrical path can carry. Greater bandwidth results in greater speed.

BBS (BIOS Boot Specification): a feature within the BIOS that creates, prioritizes, and maintains a list of all Initial Program Load (IPL) devices, and then stores that list in NVRAM. IPL devices have the ability to load and execute an OS, as well as provide the ability to return to the BIOS if the OS load process fails. At that point, the next IPL device is called upon to attempt loading of the OS.

BIOS (Basic Input/Output System): the program that resides in the ROM chip, which provides the basic instructions for controlling your computer's hardware. Both the operating system and application software use BIOS routines to ensure compatibility.

Buffer: a portion of RAM which is used to temporarily store data; usually from an application though it is also used when printing and in most keyboard drivers. The CPU can manipulate data in a buffer before copying it to a disk drive. While this improves system performance (reading to or writing from a disk drive a single time is much faster than doing so repeatedly) there is the possibility of

losing your data should the system crash. Information in a buffer is temporarily stored, not permanently saved.

Bus: a data pathway. The term is used especially to refer to the connection between the processor and system memory, and between the processor and PCI or ISA local buses.

Bus mastering: allows peripheral devices and IDEs to access the system memory without going through the CPU (similar to DMA channels).

Cache: a temporary storage area for data that will be needed often by an application. Using a cache lowers data access times since the information is stored in SRAM instead of slower DRAM. Note that the cache is also much smaller than your regular memory: a typical cache size is 512KB, while you may have as much as 4GB of regular memory.

Closed and open jumpers: jumpers and jumper pins are active when they are “on” or “closed”, and inactive when they are “off” or “open”.

CMOS (Complementary Metal-Oxide Semiconductors): chips that hold the basic startup information for the BIOS.

COM port: another name for the serial port, which is called as such because it transmits the eight bits of a byte of data along one wire, and receives data on another single wire (that is, the data is transmitted in serial form, one bit after another). Parallel ports transmit the bits of a byte on eight different wires at the same time (that is, in parallel form, eight bits at the same time).

DDR (Double Data Rate): a technology designed to double the clock speed of the memory. It activates output on both the rising and falling edge of the system clock rather than on just the rising edge, potentially doubling output.

DIMM (Dual In-line Memory Module): faster and more capacious form of RAM than SIMMs, and do not need to be installed in pairs.

DIMM bank: sometimes called DIMM socket because the physical slot and the logical unit are the same. That is, one DIMM module fits into one DIMM socket, which is capable of acting as a memory bank.

DMA (Direct Memory Access): channels that are similar to IRQs. DMA channels allow hardware devices (like soundcards or keyboards) to access the main memory without involving the CPU. This frees up CPU resources for other tasks. As with IRQs, it is vital that you do not double up devices on a single line. Plug-n-Play devices will take care of this for you.

DRAM (Dynamic RAM): widely available, very affordable form of RAM which loses data if it is not recharged regularly (every few milliseconds). This refresh requirement makes DRAM three to ten times slower than non-recharged RAM such as SRAM.

ECC (Error Correction Code or Error Checking and Correcting): allows data to be checked for errors during run-time. Errors can subsequently be corrected at the same time that they're found.

EEPROM (Electrically Erasable Programmable ROM): also called Flash BIOS, it is a ROM chip which can, unlike normal ROM, be updated. This allows you to keep up with changes in the BIOS programs without having to buy a new chip. TYAN®'s BIOS updates can be found at <http://www.tyan.com>

ESCD (Extended System Configuration Data): a format for storing information about Plug-n-Play devices in the system BIOS. This information helps properly configure the system each time it boots.

Firmware: low-level software that controls the system hardware.

Form factor: an industry term for the size, shape, power supply type, and external connector type of the Personal Computer Board (PCB) or motherboard. The standard form factors are the AT and ATX.

Global timer: onboard hardware timer, such as the Real-Time Clock (RTC).

HDD: stands for Hard Disk Drive, a type of fixed drive.

H-SYNC: controls the horizontal synchronization/properties of the monitor.

HyperTransport™: a high speed, low latency, scalable point-to-point link for interconnecting ICs on boards. It can be significantly faster than a PCI bus for an equivalent number of pins. It provides the bandwidth and flexibility critical for today's networking and computing platforms while retaining the fundamental programming model of PCI.

IC (Integrated Circuit): the formal name for the computer chip.

IDE (Integrated Device/Drive Electronics): a simple, self-contained HDD interface. It can handle drives up to 8.4 GB in size. Almost all IDEs sold now are in fact Enhanced IDEs (EIDEs), with maximum capacity determined by the hardware controller.

IDE INT (IDE Interrupt): a hardware interrupt signal that goes to the IDE.

I/O (Input/Output): the connection between your computer and another piece of hardware (mouse, keyboard, etc.)

IRQ (Interrupt Request): an electronic request that runs from a hardware device to the CPU. The interrupt controller assigns priorities to incoming requests and delivers them to the CPU. It is important that there is only one device hooked up to each IRQ line; doubling up devices on IRQ lines can lock up your system. Plug-n-Play operating systems can take care of these details for you.

Latency: the amount of time that one part of a system spends waiting for another part to catch up. This occurs most commonly when the system sends data out to a peripheral device and has to wait for the peripheral to spread (peripherals tend to be slower than onboard system components).

NVRAM: ROM and EEPROM are both examples of Non-Volatile RAM, memory that holds its data without power. DRAM, in contrast, is volatile.

Parallel port: transmits the bits of a byte on eight different wires at the same time.

PCI (Peripheral Component Interconnect): a 32 or 64-bit local bus (data pathway) which is faster than the ISA bus. Local buses are those which operate within a single system (as opposed to a network bus, which connects multiple systems).

PCI PIO (PCI Programmable Input/Output) modes: the data transfer modes used by IDE drives. These modes use the CPU for data transfer (in contrast, DMA channels do not). PCI refers to the type of bus used by these modes to communicate with the CPU.

PCI-to-PCI Bridge: allows you to connect multiple PCI devices onto one PCI slot.

Pipeline burst SRAM: a fast secondary cache. It is used as a secondary cache because SRAM is slower than SDRAM, but usually larger. Data is cached first to the faster primary cache, and then, when the primary cache is full, to the slower secondary cache.

PnP (Plug-n-Play): a design standard that has become ascendant in the industry. Plug-n-Play devices require little set-up to use. Devices and operating systems that are not Plug-n-Play require you to reconfigure your system each time you add or change any part of your hardware.

PXE (Preboot Execution Environment): one of four components that together make up the Wired for Management 2.0 baseline specification. PXE was

designed to define a standard set of preboot protocol services within a client with the goal of allowing networked-based booting to boot using industry standard protocols.

RAID (Redundant Array of Independent Disks): a way for the same data to be stored in different places on many hard drives. By using this method, the data is stored redundantly and multiple hard drives will appear as a single drive to the operating system. RAID level 0 is known as striping, where data is striped (or overlapped) across multiple hard drives, but offers no fault-tolerance. RAID level 1 is known as mirroring, which stores the data within at least two hard drives, but does not stripe. RAID level 1 also allows for faster access time and fault-tolerance, since either hard drive can be read at the same time. RAID level 0+1 is both striping and mirroring, providing fault-tolerance, striping, and faster access all at the same time.

RAIDIOS: RAID I/O Steering (Intel)

RAM (Random Access Memory): technically refers to a type of memory where any byte can be accessed without touching the adjacent data and is often referred to the system's main memory. This memory is available to any program running on the computer.

ROM (Read-Only Memory): a storage chip which contains the BIOS; the basic instructions required to boot the computer and start up the operating system.

SDRAM (Synchronous Dynamic RAM): called as such because it can keep two sets of memory addresses open simultaneously. By transferring data alternately from one set of addresses and then the other, SDRAM cuts down on the delays associated with non-synchronous RAM, which must close one address bank before opening the next.

Serial port: called as such because it transmits the eight bits of a byte of data along one wire, and receives data on another single wire (that is, the data is transmitted in serial form, one bit after another).

SCSI Interrupt Steering Logic (SISL): Architecture that allows a RAID controller, such as AcceleRAID 150, 200 or 250, to implement RAID on a system board-embedded SCSI bus or a set of SCSI busses. SISL: SCSI Interrupt Steering Logic (LSI) (only on LSI SCSI boards)

Sleep/Suspend mode: in this mode, all devices except the CPU shut down.

SDRAM (Static RAM): unlike DRAM, this type of RAM does not need to be refreshed in order to prevent data loss. Thus, it is faster and more expensive.

SLI (Scalable Link Interface): NVIDIA SLI technology links two graphics cards together to provide scalability and increased performance. NVIDIA SLI takes advantage of the increased bandwidth of the PCI Express bus architecture, and

features hardware and software innovations within NVIDIA GPUs (graphics processing units) and NVIDIA MCPs (media and communications processors). Depending on the application, NVIDIA SLI can deliver as much as two times the performance of a single GPU configuration.

Standby mode: in this mode, the video and hard drives shut down; all other devices continue to operate normally.

UltraDMA-33/66/100: a fast version of the old DMA channel. UltraDMA is also called UltraATA. Without a proper UltraDMA controller, your system cannot take advantage of higher data transfer rates of the new UltraDMA/UltraATA hard drives.

USB (Universal Serial Bus): a versatile port. This one port type can function as a serial, parallel, mouse, keyboard or joystick port. It is fast enough to support video transfer, and is capable of supporting up to 127 daisy-chained peripheral devices.

VGA (Video Graphics Array): the PC video display standard

V-SYNC: controls the vertical scanning properties of the monitor.

ZCR (Zero Channel RAID): PCI card that allows a RAID card to use the onboard SCSI chip, thus lowering cost of RAID solution

ZIF Socket (Zero Insertion Force socket): these sockets make it possible to insert CPUs without damaging the sensitive CPU pins. The CPU is lightly placed in an open ZIF socket, and a lever is pulled down. This shifts the processor over and down, guiding it into the board and locking it into place.

Technical Support

If a problem arises with your system, you should first turn to your dealer for direct support. Your system has most likely been configured or designed by them and they should have the best idea of what hardware and software your system contains. Hence, they should be of the most assistance for you. Furthermore, if you purchased your system from a dealer near you, take the system to them directly to have it serviced instead of attempting to do so yourself (which can have expensive consequences).

If these options are not available for you then TYAN® Computer Corporation can help. Besides designing innovative and quality products for over a decade, TYAN® has continuously offered customers service beyond their expectations. TYAN®'s website (www.tyan.com) provides easy-to-access resources such as in-depth Linux Online Support sections with downloadable Linux drivers and comprehensive compatibility reports for chassis, memory and much more. With all these convenient resources just a few keystrokes away, users can easily find the latest software and operating system components to keep their systems running as powerful and productive as possible. TYAN® also ranks high for its commitment to fast and friendly customer support through email. By offering plenty of options for users, TYAN® serves multiple market segments with the industry's most competitive services to support them.

"TYAN's tech support is some of the most impressive we've seen, with great response time and exceptional organization in general"

----Anandtech.com

Help Resources:

1. See the beep codes section of this manual.
2. See the TYAN® website for FAQ's, bulletins, driver updates, and other information: <http://www.tyan.com>
3. Contact your dealer for help BEFORE calling TYAN®.
4. Check the TYAN® user group:
alt.comp.periphs.mainboard.tyan

Returning Merchandise for Service

During the warranty period, contact your distributor or system vendor FIRST for any product problems. This warranty only covers normal customer use and does not cover damages incurred during shipping or failure due to the alteration, misuse, abuse, or improper maintenance of products.

Note:



A receipt or copy of your invoice marked with the date of purchase is required before any warranty service can be rendered. You may obtain service by calling the manufacturer for a Return Merchandise Authorization (RMA) number. The RMA number should be prominently displayed on the outside of the shipping carton and the package should be mailed prepaid. TYAN® will pay to have the board shipped back to you.

**Notice for the USA**

Compliance Information Statement (Declaration of Conformity Procedure) DoC
FCC Part 15: This device complies with part 15 of the FCC Rules

Operation is subject to the following conditions:

This device may not cause harmful interference, and this device must accept any interference received including interference that may cause undesired operation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and the receiver.

Plug the equipment into an outlet on a circuit different from that of the receiver.

Consult the dealer on an experienced radio/television technician for help.

Notice for Canada

This apparatus complies with the Class B limits for radio interference as specified in the Canadian Department of Communications Radio Interference Regulations. (Cet appareil est conforme aux normes de Classe B d'interférence radio tel que spécifié par le Ministère Canadien des Communications dans les règlements d'interférence radio.)



Notice for Europe (CE Mark)

This product is in conformity with the Council Directive 2004/108/EC, 92/31/EEC (EMC).

CAUTION: Lithium battery included with this board. Do not puncture, mutilate, or dispose of battery in fire. Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type recommended by manufacturer. Dispose of used battery according to manufacturer instructions and in accordance with your local regulations.

Document #: D 2001-120