


# LoRaWAN Gateway and Wireless Sensor

## User Guide

How to Work with 3<sup>rd</sup>-party Standard LoRaWAN Gateway or TTN Server

Version: V1.3



# Table of Contents

Table of Contents .....	2
1 Product Introduction.....	4
2.1 The gateway connects to the Internet.....	6
2.1.1 Installing Antenna.....	6
2.1.2 Connecting to the Internet.....	6
2.1.3 Connecting to Power Cable .....	8
2.1.4 The Function of the Red LED .....	8
2.2 Setting the APN.....	9
3 Add Gateway to User's TTN Server .....	11
3.1 Gateway Network Configuration .....	12
3.1.1 Installing Antenna.....	12
3.1.2 Connecting to the Internet.....	12
3.1.3 Connecting to Power Cable .....	13
3.1.4 The Function of the Red LED .....	14
3.2 Setting the Gateway Service Address .....	15
3.3 Gateway Registration on TTN.....	18
4 Add Sensor Node to User's TTN Server .....	21
4.1 Get Node's EUI and Key.....	21
4.2 Add Application and AppEUI.....	22
4.3 Sensor Node Registration on TTN.....	23
4.4 Connect the Node to TTN .....	25
4.4.1 Power on .....	25
4.4.2 Sensor Node Working Status.....	26
4.4.3 Checking Sensor Node Connection to the TTN .....	26
5 Add Gateway to ChirpStack LoRaWAN Network Server Stack .....	28
5.1 Turn on ChirpStack LoRa Server Mode.....	28
5.2 ChirpStack LoRa Server Configuration .....	31
5.3 MQTT Bridge Configuration .....	34
5.3.1 Gateway Configuration.....	34
5.3.2 MQTT Client Configuration .....	38
5.3.3 Scheduling a Downlink.....	39
5.4 ChirpStack Application Server .....	40
5.4.1 Log on to the background .....	40
5.4.2 Add the Network-servers .....	40
5.4.3 Create the Gateway-profiles .....	42
5.4.4 Create the Service-profiles .....	43
5.4.5 Create the Device-profiles .....	45
5.5 Add Sensor Node to ChirpStack LoRa Server .....	48
5.5.1 Get Node's EUI and Key.....	48
5.5.2 Create an Application.....	48

5.5.3	Create a Gateway .....	49
5.5.4	Create a Device .....	51
5.5.5	Power on .....	52
5.5.6	Sensor Node Working Status.....	52
5.5.7	Checking Data Upload .....	53
5.6	Add a 3rd Part Node Device .....	54
6	The Node Connects to a Standard Gateway.....	55
6.1	Node Frequency Plans .....	55
6.2	A Standard LoRaWAN Gateway Configuration Example .....	57
6.2.1	Radio Settings.....	57
6.2.2	Channel Settings.....	58
6.2.3	Power on .....	59
6.2.4	Sensor Node Working Status.....	59
6.2.5	Checking Data Upload .....	60
6.3	Modify Node's EUI, KEY, and Duty .....	61
6.4	Modify the Data Interval Remotely.....	65
6.4.1	Modify the Data Interval via the Chirpstack .....	66
7	Decoding.....	68
7.1	Packet Parsing.....	69
7.1.1	Example 1 - Air Temperature & Humidity Sensor: .....	69
7.1.2	Example 2 - CO2 Sensor: .....	70
7.1.3	Example 3 - Soil Moisture and Temperature Sensor: .....	71
7.1.4	Example 4 – Light Intensity Sensor: .....	72
7.1.5	Example 5 – Barometric Pressure Sensor:.....	72
7.2	Exception.....	74
8	Device Installation.....	76
8.1	Part List .....	77
8.1.1	Gateway Part List.....	77
8.1.2	Sensor Node Part List.....	78
8.1.3	Other Accessories & Tool List .....	78
8.2	Gateway Installation.....	79
8.2.1	Gateway Installation Methods.....	79
8.2.2	Installation Precautions.....	81
8.2.3	Installing Fiberglass LoRa Antenna .....	82
8.2.4	Installing Ground Cable .....	83
8.3	Installing Sensor Node.....	84
8.3.1	Installing the Sensor Node Bracket .....	84
8.3.2	Installing Sensor Nodes .....	85
8.3.3	Dos and Don'ts in Installing Sensor Probes .....	86

# 1 Product Introduction



SenseCAP is an industrial wireless sensor network that integrates easy-to-deploy hardware and data API services, enabling low-power, long-distance environmental data collection. SenseCAP includes several versions, such as LoRaWAN, LoRaPP, etc.

SenseCAP LoRaWAN version products include LoRaWAN Gateways and Sensor Nodes. Based on the LoRaWAN protocol, it can realize one-to-many, long-distance networking and bilateral communication. The LoRaWAN Gateway supports Ethernet and 4G. The Sensor Node is powered by a high-capacity battery that lasts up to 3 years (if uploading data once every hour). It also supports hot-swap, making it easy for maintenance and upgrading.

## Main Features:

- Gateway: High-performance Cortex A8 1GHz processor
- Gateway uses multiple methods to connect to the Internet: 4G and Ethernet
- Gateway supports third-party TTN account and server
- Sensors support LoRaWAN v1.0.2 protocol and are suitable for standard LoRaWAN Gateway
- Super long-distance communication: 10km in the line-of-sight scenario, 2km in the urban scenario
- Industrial protection rating IP66-rated enclosure, suitable for the outdoor environment at  $-40^{\circ}\text{C}\sim 70^{\circ}\text{C}$
- Easy-to-deploy, enabling people without engineering background to install the devices quickly

## LoRaWAN Gateway:



## LoRaWAN Sensor Node:



### Sensor Node Controller

- LoRa Communication module
- Ultra-low power microcontroller
- Battery

### Sensor Probe

- Hot swap connector
- Different sensor probe
- Replaceable




## 2 Gateway Network Configuration

### 2.1 The gateway connects to the Internet

#### 2.1.1 Installing Antenna

Screw clockwise to install the 4G and LoRa antennas onto the gateway.




#### 2.1.2 Connecting to the Internet

There are two ways to connect to the Internet. Choose the one that works for you.


##### (1) Connecting to Ethernet Cable

Unscrew to open the protection cap, plug the Ethernet cable through the cap and then into the Ethernet port. Screw to fasten this part.




## (2) Connecting to 4G

Use the hex key (included in the package) to unscrew the 6 screws and open the lid.




Swipe downward to open the SIM card socket, insert the Micro SIM card and swipe upward to lock the SIM card socket. Make sure it is installed correctly and close the lid with the screws.



### 2.1.3 Connecting to Power Cable

Unscrew to take off the power cap, plug in the extension cord and screw to fasten it onto the gateway. The other end of the extension cord is connected to the power adapter.




**Notice:** Make sure all antennas are correctly installed before powering on the gateway. Please note the device should be POWERED OFF when installing the antenna, or the antenna circuits might be damaged.

### 2.1.4 The Function of the Red LED




## 2.2 Setting the APN


Prepare a router, and the network connection is shown in the figure:



- (1) Check the IP of "sensecap" in the background of the router.
- (2) Enter IP in the browser: IP:8000  
If the IP is 192.168.1.1, enter 192.168.1.1:8000




- (3) User: sensecap  
Password: sensecap!!!
- (4) Click the "Cellular" button.



- ① Cellular Mode: AUTO(default), Gateway automatically selects mode.
- ② 3G/2G APN Settings: when the mode is 3G/2G, the APN information of SIM card operator needs to be filled in.
- ③ 4G APN Settings: optional.


(5) Click "APPLY". Then "CHECK CONNECTION", if return "cellular technology powered and connected", it means ok.



### 3 Add Gateway to User's TTN Server

The SenseCAP LoRaWAN Gateway supports connecting to the user's own The Things Network account and server.


Learn more about TTN: <https://www.thethingsindustries.com/docs/>



## 3.1 Gateway Network Configuration

### 3.1.1 Installing Antenna

Screw clockwise to install the 4G and LoRa antennas onto the gateway.




### 3.1.2 Connecting to the Internet

There are two ways to connect to the Internet. Choose the one that works for you.


#### (3) Connecting to Ethernet Cable

Unscrew to open the protection cap, plug the Ethernet cable through the cap and then into the Ethernet port. Screw to fasten this part.




#### (4) Connecting to 4G

Use the hex key (included in the package) to unscrew the 6 screws and open the lid.




Swipe downward to open the SIM card socket, insert the Micro SIM card and swipe upward to lock the SIM card socket. Make sure it is installed correctly and close the lid with the screws.



### 3.1.3 Connecting to Power Cable

Unscrew to take off the power cap, plug in the extension cord and screw to fasten it onto the gateway. The other end of the extension cord is connected to the power adapter.




**Notice:** Make sure all antennas are correctly installed before powering on the gateway. Please note the device should be POWERED OFF when installing the antenna, or the antenna circuits might be damaged.

### 3.1.4 The Function of the Red LED



## 3.2 Setting the Gateway Service Address


Prepare a router, and the network connection is shown in the figure:



(6) Check the IP of "sensecap" in the background of the router.

(7) Enter IP in the browser: IP:8000


If the IP is 192.168.1.1, enter 192.168.1.1:8000




(8) User: sensecap

Password: sensecap!!!

(9) LoRa→Use Seeed's Server→Off Button



(10)



- ① Server Address: Please input your Server Address.  
Refer to the website:

#### Version info

# v3.13.2

#### Component status

 <ul style="list-style-type: none"> <li>Application Server eu1.cloud.thethings.network</li> </ul>	 <ul style="list-style-type: none"> <li>Gateway Server eu1.cloud.thethings.network</li> </ul>
 <ul style="list-style-type: none"> <li>Identity Server eu1.cloud.thethings.network</li> </ul>	 <ul style="list-style-type: none"> <li>Join Server eu1.cloud.thethings.network</li> </ul>
 <ul style="list-style-type: none"> <li>Network Server eu1.cloud.thethings.network</li> </ul>	

Uplink / Downlink Port (default): **1700**

(11) APPLY.

Seeed Technology Co., Ltd. Authorised


### 3.3 Gateway Registration on TTN

TTN website: <https://www.thethingsnetwork.org>

TTN console: <https://console.cloud.thethings.network/>

Tip: v2 will be discontinued and v3 is recommended.

(1) Follow the instruction to create your account, and access “Console”.



(2) Register Gateway

Gateway ID ⓘ \*

Gateway EUI ⓘ

①

Gateway name ⓘ

Gateway description ⓘ

Optional gateway description; can also be used to save notes about the gateway

Gateway Server address

The address of the Gateway Server to connect to

Require authenticated connection ⓘ

 Enabled

Controls whether this gateway may only connect if it uses an authenticated Basic Station or MQTT connection

Gateway status ⓘ

 Public

The status of this gateway may be visible to other users

Gateway location ⓘ

 Public

- ① Gateway EUI: View the labels on the gateway.  
Select 'I'm using the legacy packet forwarder'.
- ② Frequency Plan: View the labels on the gateway.

EU868	Europe 863-870 MHz (SF9 for RX2 -recommended)
US915	United States 902-928 MHz, FSB 2 (used by TTN)
AU915	Australia 915-928 MHz, FSB 2 (used by TTN)
AS923-1	Asia 920-923 MHz
AS923-2	Asia 923-925 MHz

**LoRaWAN options**
**Frequency plan** ⓘ

Europe 863-870 MHz (SF9 for RX2 - recommended) | v

②

**Schedule downlink late** ⓘ

 Enabled

Enable server-side buffer of downlink messages

**Enforce duty cycle** ⓘ

 Enabled

Recommended for all gateways in order to respect spectrum regulations

**Schedule any time delay** ⓘ \*

530

milliseconds | v

Configure gateway delay (minimum: 130ms, default: 530ms)

③ Other use default.

④ Create Gateway.

Gateway Status displays connected, indicating successful registration.


**SenseCAP Gateway**

ID: demo-gw

• Last seen 18 seconds ago ↑ 0 ↓ 0 👤 1 Collaborator 🔑 0 API keys

Created 2 minutes ago

**General information**

Gateway ID: demo-gw

Gateway EUI: 2C F7 F1 10 22 50 00 19

Gateway description: SenseCAP Gateway Demo

Created at: Jul 2, 2021 18:42:56

Last updated at: Jul 2, 2021 18:42:56

Gateway Server address: eu1.cloud.thethings.network

**LoRaWAN information**

Frequency plan: EU\_863\_870\_TTN

 Global configuration: [Download global\\_conf.json](#)
**Live data**
[See all activity](#) →

```

18:44:50 Receive gateway status Metrics: { ackr: 0, rxfw: 0, rxin: 0,
18:44:41 Connect gateway
18:42:56 Create gateway
    
```

**Location**
[Change location settings](#) →


## 4 Add Sensor Node to User's TTN Server

### 4.1 Get Node's EUI and Key

(1) DeviceEUI and DeviceCode is on the SenseCAP product label.



(2) SenseCAP sensor device's AppEUI and AppKey have been flash into the device by Seeed. Use HTTP API to retrieve App EUI and App Key. You can use browser to issue an HTTP GET request.

**Curl:**

```
https://sensecap.seeed.cc/makerapi/device/view_device_info?nodeEui=2CF7F12014700297&deviceCode=34BF25920A4EFBF4
```

In the API, replace the DeviceEUI and deviceCode with your own DeviceEUI and DeviceCode respectively. And you will get the following response.

```
{
  "code": "0",
  "data": {
    "nodeEui": "2CF7F12014700297",
    "deviceCode": "34BF25920A4EFBF4",
    "lorawanInformation": {
      "dev_eui": "2CF7F12014700297",
      "app_eui": "8000000000000006",
      "app_key": "6FD0EF47CBC6E00F1921A08C2E94E8E5"
    }
  },
  "time": 0.019
}
```

## 4.2 Add Application and AppEUI

(1) TTN console → Application → Add application

(2)

### Add application

Owner\*

Application ID\*

Application name

Description


Optional application description; can also be used to save notes about the application

Create application

- ① Application ID: Enter a unique name.
- ② Description: Enter a description.
- ③ Add application.

## 4.3 Add Sensor Node to TTN

(1) Application → End Devices → Add end device



(2)

Applications > SenseCAP node > End devices > Register from The LoRaWAN Device Repository

### Register end device

From The LoRaWAN Device Repository    Manually

#### 1. Select the end device

Brand <sup>?</sup> * SenseCAP   v	Model <sup>?</sup> * SenseCAP Wireless Air T...   v	Hardware Ver. <sup>?</sup> * 2.0   v	Firmware Ver. <sup>?</sup> * 3.4   v	Profile (Region) * EU_863_870   v
--------------------------------------	--	---	---	--------------------------------------

①
②
③
④

**SenseCAP Wireless Air Temperature and Humidity Sensor - LoRaWAN**  
 MAC V1.0.2, PHY V1.0.2 REV B, Over the air activation (OTAA), Class A



It measures temperature and humidity in the atmosphere. It's designed with a 2-in-1 sensor, a custom battery, and an industry-grade enclosure, optimized for outdoor use cases that need reliable data collection for years.

[Product website](#) <sup>?</sup>

- ① Brand: SenseCAP
- ② Model: Select your sensor. (If not, use manual add)
- ③ Hardware / Firmware Version: Usually choose the latest
- ④ Device ID: Enter a unique name.

## 2. Enter registration data

Frequency plan <sup>?</sup> \*

Europe 863-870 MHz (SF9 for RX2 - recommended) ⑤

AppEUI <sup>?</sup> \*

80 00 00 00 00 00 00 09 00

DevEUI <sup>?</sup> \*

2C F7 F1 20 25 20 00 BB ⑥

AppKey <sup>?</sup> \*

54 7E F3 ED 34 3B DB F3 2A 51 5A BF 4B A4 F8 3D ↻

End device ID <sup>?</sup> \*

2cf7f120252000bb

### After registration

- View registered end device
- Register another end device of this type

Register end device

⑤ Frequency plan: View the labels on the Node.

EU868	Europe 863-870 MHz (SF9 for RX2 -recommended)
US915	United States 902-928 MHz, FSB 2 (used by TTN)
AU915	Australia 915-928 MHz, FSB 2 (used by TTN)
AS923-1	Asia 920-923 MHz
AS923-2	Asia 923-925 MHz


- ⑥ Device EUI: Enter the node's Device EUI that you got in the 3.1 step.  
 App Key: Enter the node's App Key that you got in the previous step.  
 App EUI: Enter the node's App EUI.
- ⑦ Register end device.

## 4.4 Connect the Node to TTN

### 4.4.1 Power on

The power switch is hidden inside the device. Open the device and turn on the power before installing the sensors. Here is the step-by-step instruction:

- 1) Loosen the Sensor Probe by turning the cap counterclockwise. Use the white cap opener to make this process easier. The image below uses TH Sensor as an example and applies to all other SenseCAP sensors.




- 2) After opening the device, turn the switch to "ON", and the LED on the lower right corner will flash, indicating that the power is on. Wait for about 10 seconds, then the LED will flash quickly for 2 seconds, indicating that the device is connected to the network.



- 3) After the device is connected to the network, connect the Sensor Probe back with the Sensor Node Controller by turning it clockwise. Please note that the labels on both parts should be aligned as shown in the image below, otherwise the two parts will not be attached to function properly and data will not be uploaded.

## 4.4.2 Sensor Node Working Status

You can refer to the LED indicator for the Sensor Node for its working status. Please see the status explanations in the image below:




### LED Status

After powering on the device

1. LED flashes once after powering on, then turn OFF
2. After 10 seconds, LED flashes quickly for 2 seconds, indicating it has joined the network
3. After joining the network, the LED stays off to save energy
4. Push the reset button to re-join the network if the LED does not start flashing 15 seconds after powering on

## 4.4.3 Checking Sensor Node Connection to the TTN

On the Data page, data package is uploaded. For the format of the payload, refer to the Decoding section.



Time	Type	Data preview
18:57:43	Forward uplink data message	Payload: [ err: 0, messages: [-], payload: "010600000000002F87", valid: true ] 01 06 00 00 00 00 2F 87 FPort: 2 SNR: 12 RSSI: -42 Bandwidth: 125000
18:57:12	Forward uplink data message	Payload: [ err: 0, messages: [-], payload: "00000004030002007006400050001010001010001010200F02001501030030F1F72C9104000A0C3314010500000000001010", valid: true ] 00 00 00 04 03 00 02 00 07 00 64 00 05 00 01 01 00 01
18:56:46	Accept join-request	
18:56:34	Update end device	[ "root_keys_app_key.key" ]
18:56:14	Join-request to cluster-local Join Se...	MIC mismatch

Applications >  sensecap-node > Devices >  th-sensor > Data

 Overview **Data** Settings

**APPLICATION DATA**
 pause  clear

 Filters uplink downlink activation ack error

	time	counter	port		
▲	19:25:48	4	2	retry confirmed	payload: 01 01 10 90 65 00 00 01 02 10 78 E6 00 00 92 AF
▼	19:25:47		0		
▲	19:25:47	4	2	confirmed	payload: 01 01 10 90 65 00 00 01 02 10 78 E6 00 00 92 AF
▲	19:25:25	3	2		payload: 01 06 00 00 00 00 00 2F 87
▼	19:25:05		0		
▲	19:25:04	2	2	confirmed	payload: 01 06 00 00 00 00 00 2F 87
▼	19:24:48		0		
▲	19:24:47	1	2	confirmed	payload: 01 06 00 00 00 00 00 2F 87
▼	19:24:30		0		
▲	19:24:29	0	2	confirmed	payload: 00 00 00 03 03 00 02 00 07 00 4A 00 3C 00 01 01 00 00 01 00 01 01 02 00 99 00 30 12 01 03 00
⚡	19:24:19				dev addr: 26 01 27 DB app eui: 80 00 00 00 00 00 06 dev eui: 2C F7 F1 20 14 70 02 97


# 5 Add Gateway to ChirpStack LoRaWAN Network Server Stack

ChirpStack provides open-source components for LoRaWAN networks. Together they form a ready-to-use solution including an user-friendly web-interface for device management and APIs for integration.


SenseCAP LoRaWAN Gateway has already integrated with ChirpStack LoRaWAN Network Server stack (hereinafter called the "ChirpStack LoRa Server"). The following LoRa Server components are accessible and configurable in Gateway: ChirpStack Gateway Bridge, ChirpStack Network Server and ChirpStack Application Server.

## 5.1 Turn on ChirpStack LoRa Server Mode

Prepare a router, and the network connection is shown in the figure:




- (1) Check the IP of "sensecap" in the background of the router.
- (2) Enter IP in the browser: IP:8000  
If the IP is 192.168.1.1, enter 192.168.1.1:8000




(3) User: sensecap

Password: sensecap!!!


(4) Turn off the “Use Seeed’s Server”, and turn on “Use Local LoRa Server”.



(5) Turn on the “Use LoRa Server” button, and apply. (“LoRa Server” is the name of ChirpStack LoRa Server)



The screenshot shows the 'Seeed LoRaWAN Gateway' configuration interface. On the left is a dark sidebar with navigation options: Dashboard, Wi-Fi, LoRa, Cellular, and Lora Server (highlighted with a red box). The main content area is titled 'Seeed LoRaWAN Gateway' and contains a 'LoRa Server Configuration' section. In this section, the 'Use LoRa Server' toggle switch is currently turned off. A red arrow points from the 'Lora Server' menu item in the sidebar to the toggle switch. An 'APPLY' button is visible in the bottom right corner of the configuration section.




The screenshot shows the 'Seeed LoRaWAN Gateway' configuration interface after the 'Use LoRa Server' toggle has been turned on. The sidebar navigation remains the same, with 'Lora Server' highlighted. The 'LoRa Server Configuration' section now shows the toggle switch turned on, with a red box around it and a red arrow pointing to the 'APPLY' button, which is also enclosed in a red box. Below this is the 'LoRa Server Status' section, which displays the following information:

- Gateway Bridge Status  
Active: inactive (dead)
- Network Server Status  
Active: inactive (dead)
- Application Server Status  
Active: inactive (dead)
- Start LoRa Server on system startup  
false

At the bottom of the status section are two buttons: 'START' (red) and 'CHECK STATUS' (grey). Below the status section are three configuration tabs: 'Gateway Bridge Configuration', 'Network Server Configuration', and 'Application Server Configuration'.

## 5.2 ChirpStack LoRa Server Configuration

First, click the “Start” button to start the service.




(1) ChirpStack Gateway Bridge:

Refer to: <https://www.chirpstack.io/gateway-bridge/>

It converts LoRa® Packet Forwarder protocols into a ChirpStack Network Server common data-format (JSON and Protobuf).

For security reasons, this file is read-only.




### (2) ChirpStack Network Server:

Refer to: <https://www.chirpstack.io/network-server/>

The responsibility of the Network Server component is the de-duplication of received LoRaWAN frames by the LoRa® gateways and for the collected frames handle the: Authentication; LoRaWAN mac-layer (and mac-commands); Communication with the ChirpStack Application Server; Scheduling of downlink frames.

In general, the default configuration is used. Please refer to the official tutorial before making any modifications. Click "APPLY" to save the configuration after making changes.

Then, click "STOP" in "Application Server Status" and finally click "START" to make the configuration take effect.



The screenshot displays the ChirpStack web interface for configuring the Network Server. The interface is divided into several sections:

- Application Server Status:** Shows the server is active and running. A red box highlights the **STOP** button.
- Gateway Bridge Configuration:** Contains general settings like log levels and syslog options.
- Network Server Configuration:** This panel is highlighted with a red box. It includes:
  - Log level settings (debug=5, info=4, warning=3, error=2, fatal=1, panic=0).
  - Log to syslog options.
  - PostgreSQL settings, including a note that PostgreSQL 9.5+ is required and a sample dsn: `postgres://user:password@hostname/databas`.
- Application Server Configuration:** Contains general settings and PostgreSQL settings, including a note about password hashing iterations.

At the bottom of each configuration panel, there are **RESET** and **APPLY** buttons. A red arrow points from the **STOP** button in the status section to the **APPLY** button in the Network Server Configuration panel.


### (3) ChirpStack Application Server:

Refer to: <https://www.chirpstack.io/application-server/>

It is responsible for the device "inventory" part of a LoRaWAN infrastructure, handling of join-request and the handling and encryption of application payloads.

In general, the default configuration is used. Please refer to the official tutorial before making any modifications. Click "APPLY" to save the configuration after making changes.

Then, click "STOP" in "Application Server Status" and finally click "START" to make the configuration take effect.



Dashboard

- Wi-Fi
- LoRa
- Cellular
- Lora Server

### Seeed LoRaWAN Gateway

Application Server Status  
Active: active (running) since Tue 2020-10-20 07:27:39 UTC; 1s ago

Start LoRa Server on system startup  
false

**STOP** **CHECK STATUS**

#### Gateway Bridge Configuration

```
[general]
# debug=5, info=4, warning=3, error=2, fatal=1,
panic=0
log_level=4

# Log to syslog.
#
# When set to true, log messages are being written
to syslog.
log_to_syslog=false

# Filters.
#
# These can be used to filter LoRaWAN frames to
reduce bandwidth usage between
# the gateway and ChirpStack Gateway Bridge.
Depending the used backend, filtering
# will be performed by the Packet Forwarder or
ChirpStack Gateway Bridge.
[filters]
```

For security reasons, this file is read-only.

**RESET** **APPLY**

#### Network Server Configuration

```
[general]
# Log level
#
# debug=5, info=4, warning=3, error=2, fatal=1,
panic=0
log_level=4

# Log to syslog.
#
# When set to true, log messages are being
written to syslog.
log_to_syslog=false

# PostgreSQL settings.
#
# Please note that PostgreSQL 9.5+ is required.
[postgres]
# PostgreSQL dsn (e.g.:
postgres://user:password@hostname/databas
e?sslmode=require)
```

**RESET** **APPLY**

#### Application Server Configuration

```
[general]
# Log level
#
# debug=5, info=4, warning=3, error=2, fatal=1,
panic=0
log_level=4

# Log to syslog.
#
# When set to true, log messages are being
written to syslog.
log_to_syslog=false

# The number of times passwords must be
hashed. A higher number is safer as
# an attack takes more time to perform.
password_hash_iterations=100000

# PostgreSQL settings.
```

**RESET** **APPLY**


(4) If you have the wrong configuration, click "RESET" to restore the default configuration.

## 5.3 MQTT Bridge Configuration

The MQTT Bridge is able to publish all the uplink data from devices to your remote MQTT broker, and also subscribe downlink topic. Please visit ChirpStack( <https://www.chirpstack.io/application-server/integrations/mqtt/> ) for more information about scheduling downlink data.

### 5.3.1 Gateway Configuration

(1) Click "Use MQTT Bridge".



(2) After filling in each parameter, click "APPLY".

①

MQTT Server address: **mqtt://xxx.xx** or **mqttps://xxx.xx**

If xxx.xx (IP) is 111.230.200.102, the address is **mqtt://111.230.200.102** or **mqttps://111.230.200.102**

If xxx.xx (url) is mybroker.com, the address is **mqtt:// mybroker.com** or **mqttps:// mybroker.com**

②

MQTT Server 's Port.

In general, mqtt corresponds to port 1883 and mqttps to port 8883.

③

Keepalive:

60 is default value. When the MQTT connection between the Gateway and the Server is disconnected over 60 seconds, it determines that the client is offline.

0 means turn off the keepalive function.

④

CleanSession:

true: the gateway reconnects to the network after a power outage or disconnection, and cannot receive data from MQTTpub to the gateway for that period.

false: the gateway reconnects to the network after a power outage or disconnection, and can receive data from MQTTpub to the gateway for that period.

⑤

Username: Null if none, depending on the server configuration.

⑥

Password: Null if none, depending on the server configuration.

⑦


Client ID: Custom the name, and each Client ID is unique to the same MQTT server.

⑧

Publish QoS: 0, 1 or 2. (refer to the MQTT rules)

⑨

Subscribe QoS: 0, 1 or 2. (refer to the MQTT rules)



**Seeed LoRaWAN Gateway**

Use MQTT Bridge

Remote MQTT Broker URL, support 'mqtt' and 'mqtts', (e.g. mqtt://mybroker.com) ①

Port 0 ②

Keepalive, default to 60, set 0 to disable ③

CleanSession, default to true, set false to receive QoS 1 and 2 messages while offline ④

Username ⑤

Password ⑥

Client ID ⑦

Publish QoS 0 ⑧

Subscribe QoS 0 ⑨

Verify server certificate

---

**Seeed LoRaWAN Gateway**

Remote MQTT Broker URL, support 'mqtt' and 'mqtts', (e.g. mqtt://mybroker.com)  
mqtt://111.230.200.102

Port 1883

Keepalive, default to 60, set 0 to disable 60

CleanSession, default to true, set false to receive QoS 1 and 2 messages while offline true

Username

Password

Client ID Test


Publish QoS 0

Subscribe QoS 0

Verify server certificate

CHECK STATUS APPLY

- (3) It is off by default and can generally be ignored: Verify server certificate.  
 If true, the server certificate is verified against the list of supplied CAs.  
 If false, the server certificate is verified against your self-signed certificate.



Seeed LoRaWAN Gateway

Password

Client ID  
Test

Publish QoS  
0


Subscribe QoS  
0

Verify server certificate

Use self signed CA certificate

CHECK STATUS APPLY

(4) Check Status: Disconnected / Reconnecting / Connected.



Seeed LoRaWAN Gateway

For security reasons, this file is read-only. RESET APPLY

### MQTT Bridge Configuration

The MQTT Bridge is able to publish all the uplink data from devices to your remote MQTT broker, and also subscribe downlink topic. Please visit [chirystack](#) for more information about scheduling downlink data.

Connect Status  
connected

Use MQTT Bridge

Remote MQTT Broker URL, support 'mqtt' and 'mqtts', (e.g. mqtt://mybroker.com)  
mqtt://111.230.200.102

Port  
1883

Keepalive, default to 60, set 0 to disable  
60

CleanSession, default to true, set false to receive QoS 1 and 2 messages while offline  
true

Username


Password

RESET APPLY

## 5.3.2 MQTT Client Configuration

For details, please refer to: <https://www.chirpstack.io/application-server/integrations/events/#ack>

ApplicationID: the Application ID.




The screenshot shows the ChirpStack web interface. A sidebar on the left contains navigation links: Dashboard, Network-servers, Gateway-profiles, Organizations, All users, and API keys. The main content area is titled 'Applications' and features a table with the following data:

ID	Name	Service-profile	Description
1	test-app	test-service-profile	testing

At the bottom right of the table, it indicates 'Rows per page: 10' and '1-1 of 1'. A '+ CREATE' button is visible in the top right corner of the table area.

DevEUI: Device EUI.



The screenshot shows the 'Applications / test-app' configuration page. It has tabs for 'DEVICES', 'APPLICATION CONFIGURATION', 'INTEGRATIONS', and 'FUOTA'. The 'DEVICES' tab is active, displaying a table of devices:

Last seen	Device name	Device EUI	Device profile	Link margin	Battery
an hour ago	868-node	2cf7f1202100029b	test-device-profile	n/a	n/a

At the bottom right of the table, it indicates 'Rows per page: 10' and '1-1 of 1'. A '+ CREATE' button is visible in the top right corner. A 'DELETE' button is also present in the top right corner of the page.

### (1) Device data subscription

```
application/[ApplicationID]/device/[DevEUI]/event/up
```

e.g. application/1/device/ 2cf7f1202100029b/event/up

### (2) Join packet subscription

```
application/[ApplicationID]/device/[DevEUI]/event/join
```

e.g. application/1/device/ 2cf7f1202100029b/event/join

### (3) Status packet subscription

```
application/[ApplicationID]/device/[DevEUI]/event/status
```

e.g. application/1/device/ 2cf7f1202100029b/event/ status

### 5.3.3 Scheduling a Downlink

The default topic for scheduling downlink payloads is:

```
application/[ApplicationID]/device/[DevEUI]/command/down
```

The ApplicationID and DevEUI of the device will be taken from the topic.

Example payload:

```
{
  "confirmed": true,      // whether the payload must be sent as confirmed data down or not
  "fPort": 10,           // FPort to use (must be > 0)
  "data": "...."        // base64 encoded data (plaintext, will be encrypted by ChirpStack Network Server)
  "object": {           // decoded object (when application coded has been configured)
    "temperatureSensor": {"1": 25}, // when providing the 'object', you can omit 'data'
    "humiditySensor": {"1": 32}
  }
}
```

## 5.4 ChirpStack Application Server


### 5.4.1 Log on to the background

According to the Gateway IP obtained in Section 4.1, log in the Web UI.

The login address: **IP:8080** (if IP is 192.168.8.100, enter 192.168.8.100:8080)

Username(default): **admin**

Password(default): **admin**



ChirpStack Login

Username / email \*


admin

Password \*


.....

LOGIN

### 5.4.2 Add the Network-servers



The screenshot shows the ChirpStack Web UI. The top navigation bar is blue with the ChirpStack logo and a search bar. The left sidebar contains a menu with items like Dashboard, Network-servers, Gateway-profiles, Organizations, All users, and API keys. The 'Network-servers' item is highlighted with a red box. A red arrow points from this box to a '+ ADD' button in the top right corner of the main content area. The main content area displays a table with columns 'Name' and 'Server', and a pagination control showing 'Rows per page: 10' and '0-0 of 0'.




The screenshot shows the 'Add Network-server' form in ChirpStack. The form has three tabs: 'GENERAL', 'GATEWAY DISCOVERY', and 'TLS CERTIFICATES'. The 'GENERAL' tab is active. There are two input fields:

- Network-server name \***: Contains the text 'test-network-server'. A red box highlights this field with a circled '1' next to it.
- Network-server server \***: Contains the text 'localhost:8005'. A red box highlights this field with a circled '2' next to it.

Below the input fields is a blue button labeled 'ADD NETWORK-SERVER'.

- ① Network-server name: custom name.
- ② Network-server server: the default value is **localhost:8005**

Refer to: <https://www.chirpstack.io/network-server/install/config/>. You can modify it in the “Network Server Configuration”.



The screenshot shows the 'Configuration' page in ChirpStack. The left sidebar contains a navigation menu with 'Network Server' expanded to show 'Configuration'. The main content area displays a configuration file with various settings. A red box highlights the following configuration block:


```
# Network-server API
#
# This is the network-server API that is used by ChirpStack Application Server o
# custom components interacting with ChirpStack Network Server.
[network_server.api]
# ip:port to bind the api server
bind="0.0.0.0:8000"

# ca certificate used by the api server (optional)
ca_cert=""


# tls certificate used by the api server (optional)
tls_cert=""

# tls key used by the api server (optional)
tls_key=""
```

Below the highlighted block, there are sections for 'Gateway settings' and 'CA certificate and key file (optional)'.




### 5.4.3 Create the Gateway-profiles



- ① Name: custom name.
- ② Enabled channels: 0, 1, 2  
EU channels: 0, 1, 2

US902-923 channels (sub-band 2): 8, 9, 10, 11, 12, 13, 14, 15, 65

③ Network-server: select the Network-server you created earlier.



ChirpStack

Search organization, application, gateway or device

admin

Dashboard

Network-servers

Gateway-profiles

Organizations

All users

API keys

chirpstack

Org. dashboard

Org. users

Org. API keys

Service-profiles

Device-profiles

Gateways

Applications

Multicast-groups

Gateway-profiles / Create


Name \*  
test-gateway-profiles  
A short name identifying the gateway-profile.

Enabled channels \*  
0, 1, 2  
The channels active in this gateway-profile as specified in the LoRaWAN Regional Parameters specification. Separate channels by comma, e.g. 0, 1, 2. Extra channels must not be included in this list.

Network-server \*  
test-network-server

ADD EXTRA CHANNEL CREATE GATEWAY-PROFILE

Click the “GREATE GATEWAY-PROFILE”.



ChirpStack

Search organization, application, gateway or device

admin

Dashboard

Network-servers

Gateway-profiles

Organizations

All users

API keys


Gateway-profiles

+ CREATE HELP

Name	Network-server
test-gateway-profiles	test-network-server

Rows per page: 10 1-1 of 1

#### 5.4.4 Create the Service-profiles



ChirpStack

Search organization, application, gateway or device

admin

Dashboard

Network-servers

Gateway-profiles

Organizations

All users

API keys

chirpstack

Org. dashboard

Org. users

Org. API keys

**Service-profiles**

Device-profiles

Gateways

Applications

Multicast-groups


Service-profiles

Name

Network Server

Rows per page: 10 0-0 of 0

+ CREATE



ChirpStack

Search organization, application, gateway or device

admin

Dashboard

Network-servers

Gateway-profiles

Organizations

All users

API keys

chirpstack

Org. dashboard

Org. users

Org. API keys

Service-profiles

Device-profiles

Gateways

Applications

Multicast-groups

Service-profile name \*

test-service-profile ①

A name to identify the service-profile.

Network-server \*

test-network-server ②

The network-server on which this service-profile will be provisioned. After creating the service-profile, this value can't be changed.

Add gateway meta-data ③

GW metadata (RSSI, SNR, GW geoloc., etc.) are added to the packet sent to the application-server.

Enable network geolocation

When enabled, the network-server will try to resolve the location of the devices under this service-profile. Please note that you need to have gateways supporting the fine-timestamp feature and that the network-server needs to be configured in order to provide geolocation support.

Device-status request frequency

0

Frequency to initiate an End-Device status request (request/day). Set to 0 to disable.

Minimum allowed data-rate \*

0 ④

Minimum allowed data rate. Used for ADR.

Maximum allowed data-rate \*



0

Maximum allowed data rate. Used for ADR.

CREATE SERVICE-PROFILE

- ① Service-profile name: custom name.
- ② Network-server: select the Network-server you created earlier.
- ③ Add gateway meta-data: select it.
- ④ Default values are usually used.


## 5.4.5 Create the Device-profiles

- ① Device-profile name: custom name.
- ② Network-server: select the Network-server you created earlier.
- ③ LoRaWAN MAC version: 1.0.2 (only for SenseCAP Node)
- ④ LoRaWAN Regional Parameters revision: B (only for SenseCAP Node)

- ⑤ Max EIRP: 0
- ⑥ Uplink interval (seconds) : 3600  
Be consistent with the node's upload interval.

Click the “JOIN(OTAA/ABP)”, and select “Device supports OTAA”.




To get a SenseCAP Sensor Node on quick decoding, we provide a piece of code.

Click the “CODEC”, and select “Custom JavaScript codec functions”.

Then view <https://github.com/Seeed-Solution/TTN-Payload-Decoder/blob/master/decoder.js> , please copy the code to “function decode” FUNC.

```
function Decoder (bytes, port) {
  // init
  var bytesString = bytes2HexString(bytes)
    .toLocaleUpperCase();
  .....
  return binaryData.toString()
    .replace(/./g, "");
}
```



Device-profiles / test-device-profile DELETE

GENERAL JOIN (OTAA / ABP) CLASS-B CLASS-C CODEC TAGS

Payload codec

Custom JavaScript codec functions

By defining a payload codec, ChirpStack Application Server can encode and decode the binary device payload for you.


```

1 // Decode decodes an array of bytes into an object.
2 // - fPort contains the LoRaWAN fPort number
3 // - bytes is an array of bytes, e.s. [225, 230, 255, 0]
4 // - variables contains the device variables e.g. {"calibration": "3.5"} (both the key / value are of type string)
5 // The function must return an object, e.g. {"temperature": 22.5}
6 function Decode(fPort, bytes, variables) {
7
8     function Decoder(bytes, port) {
9         // init
10        var bytesString = bytes2HexString(bytes)
11        toLocaleUpperCase();
12        var decoded = {
13            // valid
14            valid: true,
15            err: 0,
16            // bytes
17            payload: bytesString,
18            // messages array
19        };
20
21        // Encode encodes the given object into an array of bytes.
22        // - fPort contains the LoRaWAN fPort number
23        // - obj is an object, e.g. {"temperature": 22.5}
24        // - variables contains the device variables e.g. {"calibration": "3.5"} (both the key / value are of type string)
25        // The function must return an array of bytes, e.g. [225, 230, 255, 0]
26        function Encode(fPort, obj, variables) {
27            return [];
28        }
29    }
30
31    return Decoder(bytes, fPort);
32 }
    
```

The function must have the signature `function Decode(fPort, bytes)` and must return an object. ChirpStack Application Server will convert this object to JSON.

Add the return value at the end:

`return Decoder(bytes, fPort);`



GENERAL JOIN (OTAA / ABP) CLASS-B CLASS-C CODEC TAGS

Payload codec

Custom JavaScript codec functions

By defining a payload codec, ChirpStack Application Server can encode and decode the binary device payload for you.

```

317        var item = arr[forArr];
318        var data = parseInt(item, 16)
319        .toString(2);
320        var dataLength = data.length;
321        if (data.length !== 8) {
322            for (var i = 0; i < 8 - dataLength; i++) {
323                data = "0" + data;
324            }
325        }
326        binaryData.push(data);
327    }
328    return binaryData.toString()
329    .replace(/,/g, "");
330 }
331
332
333 return Decoder(bytes, fPort);
334 }
    
```

The function must have the signature `function Decode(fPort, bytes)` and must return an object. ChirpStack Application Server will convert this object to JSON.


Finally, click "Create".

## 5.5 Add Sensor Node to ChirpStack LoRa Server

### 5.5.1 Get Node's EUI and Key


Refer to section 3.1.

### 5.5.2 Create an Application



The screenshot shows the ChirpStack web interface. The top navigation bar includes the ChirpStack logo, a search bar, and a user profile for 'admin'. The left sidebar contains a menu with items like Dashboard, Network-servers, Gateway-profiles, Organizations, All users, API keys, and a dropdown for 'chirpstack'. The 'Applications' menu item is highlighted with a red box. A red arrow points from this menu item to the '+ CREATE' button in the top right corner of the main content area. The main content area displays the 'Applications' page with a table that has columns for ID, Name, Service-profile, and Description. Below the table, there is a pagination control showing 'Rows per page: 10' and '0-0 of 0'. The URL at the bottom of the page is '192.168.8.100:8080/#/organizations/1/applications'.

- ① Application name: custom name.
- ② Application description: custom description.
- ③ Service-profile: select the Service-profile you created earlier.



**Applications / Create**


Application name \*  
test-app  
The name may only contain words, numbers and dashes. ①

Application description \*  
testing ②

Service-profile \*  
test-service-profile ③  
The service-profile to which this application will be attached. Note that you can't change this value after the application has been created.

CREATE APPLICATION


### 5.5.3 Create a Gateway



**Gateways**

+ CREATE

Last seen	Name	Gateway ID	Network server	Gateway activity (30d)
Rows per page: 10 0-0 of 0 < >				




The screenshot shows the ChirpStack web interface for configuring a gateway. The 'GENERAL' tab is active, and the following fields are highlighted with red boxes and numbered callouts:

- 1** Gateway name: test-gw
- 2** Gateway description: testing
- 3** Gateway ID: 2c f7 f1 10 14 30 00 00
- 4** Network-server: test-network-server
- 5** Gateway-profile: test-gateway-profiles
- 6** Gateway discovery enabled:  Gateway discovery enabled

- ① Gateway name: custom name.
- ② Gateway description: custom description.
- ③ Gateway ID: the gateway EUI, see the gateway's label.
- ④ Network-server: select the Network-server you created earlier.
- ⑤ Gateway-profile: select the Gateway-profile you created earlier.
- ⑥ Default values are usually used.

## 5.5.4 Create a Device



Applications / test-app / Devices / Create

**GENERAL**    VARIABLES    TAGS

Device name \*  
868-node  
The name may only contain words, numbers and dashes.

Device description \*  
868 test

Device EUI \*  
2c f7 f1 20 21 00 02 9b    MSB    ↻

Device-profile \*  
test-device-profile


Disable frame-counter validation  
Note that disabling the frame-counter validation will compromise security as it enables people to perform replay-attacks.

Device is disabled  
ChirpStack Network Server will ignore received uplink frames and join-requests from disabled devices.

CREATE DEVICE

- ① Device name: custom name.
- ② Device description: custom description.
- ③ Device EUI: the Node's EUI.
- ④ Device-profile: select the Device-profile you created earlier.
- ⑤ Don't check and ignore it.

Click "Create" and enter the App KEY (Application Key, refer to section 3.1).



Applications / test-app / Devices / 868-node    DELETE

DETAILS    CONFIGURATION    **KEYS (OTAA)**    ACTIVATION    DEVICE DATA    LORAWAN FRAMES    FIR >

Application key \*  
AF 64 F8 EF 18 78 BC 6A 3A 73 DC 7C FF 63 D6 D9    MSB    ↻    📄    🗑️

For LoRaWAN 1.0 devices. In case your device supports LoRaWAN 1.1, update the device-profile first.

Gen Application key    MSB    ↻    📄    🗑️


For LoRaWAN 1.0 devices. This key must only be set when the device implements the remote multicast setup specification / firmware updates over the air (FUOTA). Else leave this field blank.

SET DEVICE-KEYS

### 5.5.5 Power on

The power switch is hidden inside the device. Open the device and turn on the power before installing the sensors. Here is the step-by-step instruction:

- 4) Loosen the Sensor Probe by turning the cap counterclockwise. Use the white cap opener to make this process easier. The image below uses TH Sensor as an example and applies to all other SenseCAP sensors.



- 5) After opening the device, turn the switch to "ON", and the LED on the lower right corner will flash, indicating that the power is on. Wait for about 10 seconds, then the LED will flash quickly for 2 seconds, indicating that the device is connected to the network.




- 6) After the device is connected to the network, connect the Sensor Probe back with the Sensor Node Controller by turning it clockwise. Please note that the labels on both parts should be aligned as shown in the image below, otherwise the two parts will not be attached to function properly and data will not be uploaded.

### 5.5.6 Sensor Node Working Status

You can refer to the LED indicator for the Sensor Node for its working status. Please see the status

explanations in the image below:



## LED Status

After powering on the device


1. LED flashes once after powering on, then turn OFF
2. After 10 seconds, LED flashes quickly for 2 seconds, indicating it has joined the network
3. After joining the network, the LED stays off to save energy
4. Push the reset button to re-join the network if the LED does not start flashing 15 seconds after powering on

### 5.5.7 Checking Data Upload

On the “DEVICE DATA” page in the web, you can view the data that the gateway has received from the Sensor Node.

To get measurement ID information, please visit :

[https://sensecap-docs.seeed.cc/sensor\\_types\\_list.html](https://sensecap-docs.seeed.cc/sensor_types_list.html)



ChirpStack

Search organization, application, gateway or device

admin

Applications / test-app / Devices / 868-node

DELETE


DETAILS CONFIGURATION KEYS (OTAA) ACTIVATION **DEVICE DATA** LORAWAN FRAMES FIR >

HELP PAUSE DOWNLOAD CLEAR

9:30:51 AM	up	▼
9:30:40 AM	up	▼
9:30:29 AM	up	▼

## 5.6 Add a 3rd Part Node Device

- (1) Refer to the previous section to configure the gateway.
- (2) Add a new device to Application.



The screenshot shows the ChirpStack web interface. The top navigation bar includes the ChirpStack logo, a search bar, and a user profile for 'admin'. The left sidebar contains a menu with items like Dashboard, Network-servers, Gateway-profiles, Organizations, All users, API keys, and Applications (highlighted with a red box). The main content area is titled 'Applications / test-app' and features a 'DELETE' button. Below this is a tabbed interface with 'DEVICES', 'APPLICATION CONFIGURATION', 'INTEGRATIONS', and 'FUOTA'. The 'DEVICES' tab is active, showing a table with the following data:


Last seen	Device name	Device EUI	Device profile	Link margin	Battery
an hour ago	<a href="#">868-node</a>	2cf7f1202100029b	<a href="#">test device-profile</a>	n/a	n/a

At the bottom right of the table, there is a 'Rows per page: 10' dropdown and '1-1 of 1' with navigation arrows. A red arrow points from the 'Applications' menu item in the sidebar to the '+ CREATE' button in the top right corner of the device list.

- (3) Refer to data parsing and tutorials for third-party devices.

## 6 The Node Connects to a Standard Gateway

SenseCAP Sensor Nodes are designed on The Things Network LoRaWAN servers, the firmware supports standard LoRaWAN 1.0.2 protocol, making it possible to connect to other 3rd-party LoRaWAN gateways and servers.



### 6.1 Node Frequency Plans

Frequency Plans	
EU868	Uplink: 868.1 - SF7BW125 to SF12BW125 868.3 - SF7BW125 to SF12BW125 and SF7BW250 868.5 - SF7BW125 to SF12BW125 867.1 - SF7BW125 to SF12BW125 867.3 - SF7BW125 to SF12BW125 867.5 - SF7BW125 to SF12BW125 867.7 - SF7BW125 to SF12BW125 867.9 - SF7BW125 to SF12BW125 868.8 – FSK  Downlink: Uplink channels 1-9 (RX1) 869.525 - SF9BW125 (RX2 downlink only)
US915	Uplink: 903.9 - SF7BW125 to SF10BW125 904.1 - SF7BW125 to SF10BW125 904.3 - SF7BW125 to SF10BW125 904.5 - SF7BW125 to SF10BW125 904.7 - SF7BW125 to SF10BW125 904.9 - SF7BW125 to SF10BW125 905.1 - SF7BW125 to SF10BW125

905.3 - SF7BW125 to SF10BW125

904.6 - SF8BW500

Downlink:

923.3 - SF7BW500 to SF12BW500

923.9 - SF7BW500 to SF12BW500

924.5 - SF7BW500 to SF12BW500

925.1 - SF7BW500 to SF12BW500

925.7 - SF7BW500 to SF12BW500

926.3 - SF7BW500 to SF12BW500

926.9 - SF7BW500 to SF12BW500

927.5 - SF7BW500 to SF12BW500

Seeed Technology Co., Ltd. Authorised

## 6.2 A Standard LoRaWAN Gateway Configuration Example

Typically, the LoRaWAN gateway needs to set the server address and uplink and downlink channel parameters for the end device. Refer to the gateway user manual to configure the server. Here, a common LoRaWAN gateway (US915) is taken as an example to explain how to configure the communication parameters of the Sensor Node.

The detailed configuration parameters for the Sensor Node are described here:

[https://github.com/Jenkinlu001/SenseCAP-LoRaWAN/tree/master/LoRaWAN\\_Node\\_Parameters](https://github.com/Jenkinlu001/SenseCAP-LoRaWAN/tree/master/LoRaWAN_Node_Parameters)

### 6.2.1 Radio Settings

Find radio settings or frequency settings in the background of the gateway.

```
radio 0 enable√  
Radio_0 frequency: 904300000  
Radio_0 for tx√  
Radio_0 tx min frequency: 923000000  
Radio_0 tx max frequency: 928000000  
radio 1 enable√  
Radio_1 frequency: 905000000
```

## LoRa Gateway Settings

Configuration to communicate with LoRa devices and LoRaWAN server

[General Settings](#) [Radio Settings](#) [Channels Settings](#)

radio 0 enable

Radio\_0 frequency

Radio\_0 for tx

Radio\_0 tx min frequency

Radio\_0 tx max frequency

radio 1 enable

Radio\_1 frequency

Radio\_1 for tx

Save & Apply

Save

Reset

### 6.2.2 Channel Settings

Please refer to the items in the following image for channel settings.

## LoRa Gateway Settings

Configuration to communicate with LoRa devices and LoRaWAN server

[General Settings](#)
[Radio Settings](#)
[Channels Settings](#)

 multiSF channel 0 enable 

 multiSF channel 0 radio 

 multiSF channel 0 IF 

 multiSF channel 1 enable 

 multiSF channel 1 radio 

 multiSF channel 1 IF 

 multiSF channel 2 enable 

 multiSF channel 2 radio 

 multiSF channel 2 IF 

 multiSF channel 3 enable 

 multiSF channel 3 radio 

 multiSF channel 3 IF 

 multiSF channel 4 enable 

 multiSF channel 4 radio 

 multiSF channel 4 IF 

 multiSF channel 5 enable 

 multiSF channel 5 radio 

 multiSF channel 5 IF 

 multiSF channel 6 enable 

 multiSF channel 6 radio 

 multiSF channel 6 IF 

 multiSF channel 7 enable 

 multiSF channel 7 radio 

 multiSF channel 7 IF 

 lorastd channel enable 

 LoRa channel radio 

 LoRa channel IF 

 LoRa channel SF 

 LoRa channel BW 




### 6.2.3 Power on

Refer to section 4.5.5

### 6.2.4 Sensor Node Working Status

Refer to section 4.5.6

### 6.2.5 Checking Data Upload

On the log page in the background of the gateway, you can view the data that the gateway has received from the Sensor Node.


Seeed Technology Co., Ltd. Authorised

## 6.3 Modify Node's EUI, KEY, and Duty

Connect serial ports (as shown in the image below), turn on the power, launch the serial port monitoring tool on your computer, set the Baud Rate as 115200.

(1) Use the USB to TTL wire (Please leave power port, aka 3V3 unconnected):


TX---RX
RX---TX
GND---GND



(2) Install the Serial Tool. Download via: <https://github.com/Seeed-Solution/SenseCAP-Node-Configuration-Tool/releases/tag/v1.0.2>

Windows: SenseCAP-Node-Configuration-Tool-1.x.x.exe

Mac: SenseCAP-Node-Configuration-Tool-1.0.2-mac.zip



Releases Tags

Latest release

v1.0.2  
50619c6

Compare


**v1.0.2**

KillingJacky released this 7 days ago


fix: change the upload interval range of LoRaPP device to [5, 43200]

Assets 13


latest-linux.yml	414 Bytes
latest-mac.yml	584 Bytes
latest.yml	392 Bytes
SenseCAP-Node-Configuration-Tool-1.0.2-mac.zip	68.7 MB
SenseCAP-Node-Configuration-Tool-1.0.2.ApplImage	70.3 MB
SenseCAP-Node-Configuration-Tool-1.0.2.dmg	70.9 MB
SenseCAP-Node-Configuration-Tool-1.0.2.dmg.blockmap	75.4 KB
SenseCAP-Node-Configuration-Tool-1.0.2.exe	42.8 MB
SenseCAP-Node-Configuration-Tool-Setup-1.0.2.exe	43.3 MB
SenseCAP-Node-Configuration-Tool-Setup-1.0.2.exe.blockmap	47.1 KB
sensecap_node_cfg_tool_1.0.2_amd64.deb	46.6 MB
Source code (zip)	
Source code (tar.gz)	



- (3) Select the COM Port that your tool uses, and click “CONNECT”.  
 Press “SET” button on the Sensor Controller, meanwhile flip the switch to “ON”, and you will see “SenseCAP”.




- (4) ①Device EUI (16 bit) ②App EUI (16 bit) ③App Key (32 bit) ④Data Interval (Sensor collection cycle)



(5) For example: modify the Device EUI

- ① Write the new Device EUI.
- ② Click "WRITE"



(6) The Main Menu shows up, with respective commands. (Use other Serial Port Tool)

- # [r] Read the current device configuration
- # [i] Set the data update interval in minutes
- # [d] Set the Device EUI
- # [a] Set the App EUI
- # [k] Set the App Key
- # [u] Upgrade the firmware
- # [h] Return to console center

## 6.4 Modify the Data Interval Remotely

- (1) Using the Network Server's portal or API to send downlink command, then the Node will respond to the ack.

Note: The downlink command takes effect and responds the next time the node uploads data.

- (2) Select Port 2, Downlink as follow:

0x00	0x89	0x00	prepareId_L	prepareId_H	duty_L	duty_H	crc-L	crc-H
------	------	------	-------------	-------------	--------	--------	-------	-------

0x00	Fixed field
0x89	Fixed field
0x00	Fixed field
prepareId_L	Command ID low byte, you can customize the values, it allow each command ID to be the same
prepareId_H	Command ID high byte, you can customize the values, it allow each command ID to be the same
duty_L	Data interval low byte, you can set the data interval, unit: minute
duty_H	Data interval high byte, you can set the data interval, unit: minute
crc-L	CRC low byte, it's calculated by the CRC-16/CCITT
crc-H	CRC low byte, it's calculated by the CRC-16/CCITT

- (3) When you send the downlink command, the Node responds to the ack command.

0x00	0x1F	0x00	prepareId_L	prepareId_H	result	0x00	crc-L	crc-H
------	------	------	-------------	-------------	--------	------	-------	-------

0x00	Fixed field
0x1F	Fixed field
0x00	Fixed field
prepareId_L	Command ID low byte, it is the same as the downlink command
prepareId_H	Command ID high byte, it is the same as the downlink command
result	If the downlink command is in force, it responds 0x01, else it responds 0x00
0x00	Fixed field
crc-L	CRC low byte, it's calculated by the CRC-16/CCITT
crc-H	CRC low byte, it's calculated by the CRC-16/CCITT

**For example:** Set the Node's data interval is 10 minutes.

Send the downlink command (HEX):

**00 89 00 11 22 0A 00 38 B4**

0x00	0x89	0x00	prepareId_L	prepareId_H	duty_L	duty_H	crc-L	crc-H
00	89	00	11	22	0A	00	38	B4


ACK Response:

**00 1F 00 11 22 01 00 78 0F**

0x00	0x1F	0x00	prepareId_L	prepareId_H	result	0x00	crc-L	crc-H
00	1F	00	11	22	01	00	78	0F

## 6.4.1 Modify the Data Interval via the Chirpstack

(1) Click to “Application→Devices→Node→DETAILS”




(2) Enqueue downlink payload:


- a) Port: 2
- b) Select “Confirmed downlink”.
- c) Input the Base64 command,

Set the Node’s data interval is 10 minutes, and send the downlink command (HEX): **00 89 00 11 22 0A 00 38 B4**

Then, use a hex to base64 tool (<https://cryptii.com/pipes/hex-to-base64> ).



So, the base64 command is **A1kAESIKADi0**



**Details**

Name	OF
Description	testing
Device-profile	<a href="#">test-device-profiles</a>

**Status**

Last seen at	Feb 1, 2021 1:42 PM
State	enabled

**Enqueue downlink payload**

Port\*  a)

Confirmed downlink b)

BASE64 ENCODED JSON OBJECT


Base64 encoded string\*  c)

[ENQUEUE PAYLOAD](#)

**Downlink queue**

FCnt	FPort	Confirmed	Base64 encoded payload
6	2	yes	AIIKAESIKADID

- d) Click the “ENQUEUE PAYLOAD”, the “downlink queue” will display command.  
When the command disappears after you refresh, the command has been sent.



**Enqueue downlink payload**

Port\*

Please note that the FPort value must be > 0.

Confirmed downlink

BASE64 ENCODED JSON OBJECT

Base64 encoded string\*

[ENQUEUE PAYLOAD](#)

**Downlink queue**

FCnt	FPort	Confirmed	Base64 encoded payload
------	-------	-----------	------------------------

# 7 Decoding

In the gateway or server background, similar packets can be viewed.( If the data is encrypted, it usually needs to be decrypted using base64)

**APPLICATION DATA**
|| pause clear

uplink
downlink
activation
ack
error

Filters

time	counter	port				
▼ 11:19:12		0				
▲ 11:19:16	5	2	confirmed	payload: 01 01 10 B0 68 00 00 01 02 10 88 F4 00 00 8C FF	Measurement Data packets	
▼ 11:18:58		0				
▲ 11:19:02	4	2	confirmed	payload: 00 19 00 58 68 43 00 00 00 AB 5E		
▼ 11:18:42		0				Initial Packets
▲ 11:18:46	3	2	confirmed	payload: 01 06 00 00 00 00 00 2F 87		
▼ 11:18:28		0				
▲ 11:18:32	2	2	confirmed	payload: 00 00 00 01 01 00 01 00 07 00 64 00 05 00 01 01 00 01 01 00 01 01 02 00 54 00 00 15 01 03 00 30		
▼ 11:18:15		0				
▲ 11:18:19	1	2	confirmed	payload: 00 00 00 00 00 00 00 00 00		
▼ 11:17:57		0				
▲ 11:18:01	0	2	confirmed	payload: 00 00 00 00 00 00 00 00 00		
⚡ 11:17:52				dev addr: 26 02 22 C0	app eui: 80 00 00 00 00 00 08	deveui: 2C F7 F1 21 10 70 00 54

**Notice:**

With successful access to the network, please connect the Sensor Probe back to the Sensor Node Controller by turning it clockwise. Please note the labels on both sides should be aligned as the image below, or it will not be put back in the right way. When the Sensor Probe is connected to the Sensor Node Controller correctly, the device can upload data.

## 7.1 Packet Parsing

### Packet Initialization

After being powered on or reboot, SenseCAP Sensor Nodes will be connected to the network using OTAA activation method. Each Sensor Node will send data packets to the server, including the following data:

**Initial packets** (no need to learn about these initial packets)

- One packet with device info including hardware version, software version, battery level, sensor hardware & software version, sensor EUI, power, and sensor power time counter at each channel.

### Measurement data packets

The only thing we should pay attention to is the sensor measurement data packets

**APPLICATION DATA** || pause 🗑️ cle


---

Filters: uplink downlink activation ack error

time	counter	port			
11:19:12		0			
11:19:16	5	2	confirmed	payload: 01 01 10 B0 68 00 00 01 02 10 88 F4 00 00 8C FF	Measurement data packets
11:18:58		0			

### Packet Structure

The structure of the frame is shown in the image below.



**1 byte for channel**, default as 1, means the sensor has been well connected.

**2 bytes for frame type**, in this case, it will be 0110 and 0210, means temperature value and humidity value

**4 bytes for content**, is the sensor value with CRC

The frame content is sent in **little-endian byte order**

#### 7.1.1 Example 1 - Air Temperature & Humidity Sensor:

Air Temperature & Humidity Sensor measurement packet: 010110B068000001021088F400008CFF

Divide the data into 3 sections

1	Air Temperature	010110B0680000	<p>01 is the channel number.</p> <p>0110 is 0x1001 (<i>little-endian byte order</i>), which is the measurement ID for air temperature.</p> <p>B0680000 is actually 0x000068B0, whose equivalent decimal value is 26800. Divide it by 1000, and you' ll get the actual measurement value for air temperature as <b>26.8°C</b>.</p>
2	Air Humidity	01021088F40000	<p>0210 is 0x1002 (<i>little-endian byte order</i>), which is the measurement ID for air humidity.</p> <p>88F40000 is actually 0x0000F488, whose equivalent decimal value is 62600. Divide it by 1000, and you' ll get the actual measurement value for air humidity as 62.6%RH.</p>
3	CRC	8CFF	The CRC verification part.

### 7.1.2 Example 2 - CO2 Sensor:

CO2 Sensor measurement packet: 010410E08D05009802

Divide the data into 3 sections

1	CO2	010410E08D0500	<p>01 is the channel number.</p> <p>0410 is 0x1004 (<i>little-endian byte order</i>), which is the measurement ID for CO2.</p>
---	-----	----------------	--

			<b>E08D0500</b> is actually 0x00058DE0, whose equivalent decimal value is 364000. Divide it by 1000, and you' ll get the actual measurement value for CO2 as <b>364ppm</b> .
3	CRC	<b>9802</b>	The CRC verification part.

### 7.1.3 Example 3 - Soil Moisture and Temperature Sensor:

Soil Moisture and Temperature Sensor measurement packet: **010610007D0000010710725100009A21**

Divide the data into 3 sections

1	Soil Temperature	<b>010610007D0000</b>	<b>01</b> is the channel number.  <b>0710</b> is 0x1007 ( <i>little-endian byte order</i> ) , which is the measurement ID for soil temperature.  <b>007D0000</b> is actually 0x00007D00, whose equivalent decimal value is 32000. Divide it by 1000, and you' ll get the actual measurement value for Soil Temperature as <b>32.0°C</b> .
2	Soil Moisture	<b>01071072510000</b>	<b>0710</b> is 0x1007 ( <i>little-endian byte order</i> ) , which is the measurement ID for soil moisture.  <b>72510000</b> is actually 0x00005172, whose equivalent decimal value is 20850. Divide it by 1000, and you' ll get the actual measurement value for Soil

			Moisture as 20.85%.
3	CRC	9A21	The CRC verification part.

### 7.1.4 Example 4 – Light Intensity Sensor:

Light Intensity Sensor measurement packet: 010310A0320000C3B6

Divide the data into 3 sections

1	Light Intensity	010310A0320000	<p>01 is the channel number.</p> <p>0310 is 0x1003 (<i>little-endian byte order</i>), which is the measurement ID for Light Intensity.</p> <p>A0320000 is actually 0x000032A0, whose equivalent decimal value is 12960. Divide it by 1000, and you'll get the actual measurement value for Light Intensity as 12.96Lux.</p>
3	CRC	C3B6	The CRC verification part.

### 7.1.5 Example 5 – Barometric Pressure Sensor:

Barometric Pressure Sensor measurement packet: 010510284A140652B7

Divide the data into 3 sections

1	Barometric Pressure	010510284A1406	<p>01 is the channel number.</p> <p>0510 is 0x1003 (<i>little-endian byte order</i>), which is the measurement ID for Barometric Pressure.</p>
---	---------------------	----------------	--

			284A1406 is actually 0x06144A28, whose equivalent decimal value is 101993000. Divide it by 1000, and you' ll get the actual measurement value for Barometric Pressure as 101993Pa.
3	CRC	52B7	The CRC verification part.

To get more measurement ID, please visit [https://sensecap-docs.seeed.cc/sensor\\_types\\_list.html](https://sensecap-docs.seeed.cc/sensor_types_list.html)

## 7.2 Exception

Please note the counter number. After 10 packets, it will follow one special packet with battery info. You can either ignore this packet or get rid of the battery info in your code.

**APPLICATION DATA** || pause 🗑 clear

Filters: uplink downlink activation ack error

time	counter	port		
11:54:22		0		
11:54:26	12	2	confirmed	payload: 01 01 10 58 66 00 00 01 02 10 0C F8 00 00 68 85
11:49:21		0		
11:49:25	11	2	confirmed	payload: <span style="border: 1px solid red; padding: 2px;">00 07 00 64 00 05 00</span> <span style="border: 1px solid red; padding: 2px;">01 01 10 58 66 00 00 01 02 10 70 F8 00 00 44 3E</span>
11:44:19		0		
11:44:23	10	2	confirmed	payload: 01 01 10 58 66 00 00 01 02 10 00 FA 00 00 E4 A7
11:39:18		0		
11:39:22	9	2	confirmed	payload: 01 01 10 58 66 00 00 01 02 10 38 F9 00 00 AA E1
11:34:16		0		
11:34:21	8	2	confirmed	payload: 01 01 10 BC 66 00 00 01 02 10 A8 F7 00 00 BF FC

Original Info: 000700640005000101105866000001021070F80000443E

Battery Info: 00070064000500

Measurement Info: 0101105866000001021070F80000443E

### Example:

Battery & TH Sensor measurement packet: 000700640005000101105866000001021070F80000443E

Divide the data into 3 sections

1	Battery	<span style="background-color: green;">000700</span> <span style="background-color: red;">6400</span> <span style="background-color: cyan;">0500</span>	
2	Temperature	<span style="background-color: green;">01</span> <span style="background-color: red;">0110</span> <span style="background-color: yellow;">58660000</span>	<p><span style="background-color: green;">01</span> is the channel number.</p> <p><span style="background-color: red;">0110</span> is 0x1001 (<i>little-endian byte order</i>), which is the measurement ID for air temperature.</p>

			<p><b>58660000</b> is actually 0x00006658, whose equivalent decimal value is 26200. Divide it by 1000, and you' ll get the actual measurement value for air temperature as <b>26.2°C</b>.</p>
2	Humidity	<p><b>01021070F80000</b></p>	<p><b>0210</b> is 0x1002 (<i>little-endian byte order</i>) , which is the measurement ID for air humidity.</p> <p><b>70F80000</b> is actually 0x0000F870, whose equivalent decimal value is 63600. Divide it by 1000, and you' ll get the actual measurement value for air humidity as 63.6%RH.</p>
3	CRC	<p><b>443E</b></p>	<p>The CRC verification part.</p>

## 8 Device Installation

In this chapter, we will introduce the gateway and sensor nodes, their respective installation processes, as well as the dos and don'ts. Before installing, please check the part list to ensure nothing is missing.



## 8.1 Part List

### 8.1.1 Gateway Part List



The LoRa Gateway comes with a standard antenna. If you need ultra-long-distance communication, you will need to purchase a high-gain fiberglass antenna.

Item	Name	Quantity
1	LoRa Gateway	1
2	LoRa Antenna	1
3	4G Antenna	1
4	Allen Hex Key	1
5	Mounts	4
6	Power Adapter	1
7	Power Extension Cable (5M)	1
8	Ferrules / Aluminum piece	2 / 2
9	M5 Self-drilling Screw	8
10	Antenna Lightning Protector (*Optional)	1
11	LoRa Fiberglass Omni Antenna (*Optional)	1
12	LoRa Antenna Brackets (*Optional)	1

### 8.1.2 Sensor Node Part List

The accessories for different sensors may vary. The common parts are as follows:

Item	Name	Quantity
1	Sensor	1
2	Bracket	1
3	M4 Self-drilling Screw	4
4	M3 Self-drilling Screw	2

### 8.1.3 Other Accessories & Tool List

For installing in different scenarios, you might need to purchase extra accessories or tools.


Item	Name	Quantity
1	GND Copper Wire (2.5mm <sup>2</sup> )	2
2	Pliers	1
3	M4x12 Grounding Screw	1
4	Waterproof Self-adhesive Tape (to protect antenna connection part)	1
5	M6 Self-drilling Screw (to install the gateway on the wall)	4

## 8.2 Gateway Installation


### 8.2.1 Gateway Installation Methods

- **Installing on a pole (Use the Mounts)**

Firstly, use M5 self-drilling screws (included in the package) to fasten the 4 brackets onto the gateway. And then use cable ties to fasten the gateway onto the pole. The recommended pole diameter is 70mm.




Put cable ties through the holes of the bracket and pull to fasten onto the pole. To get a better communication range, it is recommended to mount the gateway 3 meters above the ground. If there are tall buildings around, the gateway should be kept away from the building or mounted on top of the tall building.



- **Installing on a pole (Use the Ferrules and Aluminum pieces)**


Firstly, use M5 self-drilling screws (included in the package) to fasten the 2 Aluminum pieces onto the gateway. And then use ferrules to fasten the gateway onto the pole. The recommended pole diameter is 76mm.



**Note:** If the pole is made of metal, the antenna should be pulled higher than the metallic part of the pole, or the communication signal will have interfered.

- **Installing on the Wall**


Firstly, use M5 self-drilling screws (included) to fasten the 4 brackets onto the enclosure of the gateway (refer to the image below for directions). And then fasten the gateway onto the wall with screws.




**Note:** The screws (that fasten gateway onto the wall) are not included in the package. Please prepare screws according to the wall materials (recommended screw diameter: 6mm).

## 8.2.2 Installation Precautions

- 1) In mountainous or thunderstorm-stricken areas, please take lightning protection measures. For the fiberglass LoRa antenna, you will need to install a lightning arrester and make sure it is connected to the ground. Besides, the gateway should be mounted lower than the lightning rod.
- 2) When installing the gateway in the outdoor environment, the connected part should be protected with waterproof tape, to enhance waterproof performance and lengthen device lifespan. As shown below, use self-adhesive tape to protect the connection. Take a rubber tape at the length of 10cm ~ 15cm, pull it to twice of that length



wind the tape clockwise to the connected part of the antenna.



**Note:** The tape must be wound clockwise because the antenna is fastened clockwise. Otherwise, the antenna may loosen.


If the sensor has wires, install threaded tubes:



### 8.2.3 Installing Fiberglass LoRa Antenna

There are two kinds of LoRa antennas: the normal LoRa antenna (included in the package), and the fiberglass LoRa antenna (to be purchased separately). We will introduce how to install the fiberglass LoRa antenna.

- 1) Fasten the lightning arrester onto the antenna port.



- 2) As shown in the image below, please fasten the fiberglass antenna onto the base part, and then fasten the whole part onto the vertical cylinder (maximum cylinder diameter: 50mm).
- 3) Use a 1-meter antenna feed line to connect the lightning arrester with the fiberglass antenna.



### 8.2.4 Installing Ground Cable


Here we will connect the lightning arrester to the GND screw port on the gateway with a ground cable, and then connect the whole device to the ground. The image below shows the location of the GND port at the backside of the gateway.

- 1) Prepare two copper cables, a shorter one (approx. 30cm) for connecting the lightning arrester with the GND screw port (on the gateway), and a longer one for connecting the device to the ground.
- 2) Fasten the lightning arrester to the short copper cable with screws, and then connect the two copper cables to the GND screw port. Use the screw to connect and fasten them.
- 3) Once the two cables are connected, connect the other end of the long cable to the ground. Depending on your actual installation environment, you can connect it to the ground directly or connect it to the copper ground bars.


## 8.3 Installing Sensor Node

### 8.3.1 Installing the Sensor Node Bracket

Specially designed for installing SenseCAP Sensor Nodes, the bracket consists of a bracket and a sliding cap. With designated screw-holes, the bracket helps fasten the Sensor Node firmly onto a pole or a wall.



- 1) To install on a pole, you can use zip ties to fasten the bracket (recommended pole dimension is 50-70mm in diameter). Please refer to the following image for bracket directions.




- 2) To install on the wall or other surfaces, you can use self-drilling screws to fasten the bracket onto the surface.


### 8.3.2 Installing Sensor Nodes

After installing brackets, let's install sensors.

- 1) The Sensor Probe should be placed vertically downward with the label facing outward. Be consistent with the bracket gap. Make sure the circle part in the middle of Sensor Node is aligned with the middle of the bracket, and then press the Sensor Node to fit into the bracket. A click/snap sound indicates that the Sensor Node has been installed successfully. Try to manually twist it to make sure the Sensor Node is locked to the bracket securely.
- 2) Secure by fastening the bracket cap as instructed in the image.
- 3) Place two self-drilling screws on the bracket to increase firmness and help prevent theft.



**Note:** Do not insert the Sensor Node into the bracket from the top, or it will not fasten the onto the bracket securely.




### 8.3.3 Dos and Don'ts in Installing Sensor Probes

The same instruction applies to installing the different Sensor Nodes. However, there are some tips to keep in mind when installing certain Sensor Nodes.

- **Light Sensor**

The Sensor Probe of the Light Sensor needs to be placed vertically upward, and there should not be anything obstructing sunlight from the Sensor Probe.



- **CO2 Sensor**

The Sensor Probe can be fastened with self-drilling screws. Please refer to the image below for the probe direction. The end without the cables should point downward to prevent rain or dust from getting into the probe. Also, the device should be in a place with good ventilation.

