

## TP-Link AC1750 Router

### Shipment Content:

- 1 x Protective Case
- 1 x Router
- 3 x Antennas
- 1 x Power Adapter

### Quick Setup:

1. **Carefully screw in the 3 antennas into the back of the router** and position them upwards. *Skip this step for units with fixed antennas.*
2. **Plug in the power adapter and a DHCP hard line** from the venue onto the router's **WAN** port (blue). Press the power button on the back to turn on the router. *Allow 1-3 minutes for the router to light up when ready.*




*Power LED, the device is ready.*

*-5GHz shows that your router is broadcasting WiFi.*

*-2.4GHz only if your rental requires it.*

*-Internet "Green", physical hardline connection established.*

3. **Connect your Wired devices (e.g. Ethernet enabled Printer)** Connect the Ethernet cable to one of the LAN (1-4) ports in the back of the router. Plug the other end of the cable into the printer or PC. *The LAN LED on the router lights up when connected.*



4. **Connect your wireless devices (e.g. Tablet / PC)** Open the camera app on your device and scan the QR-Code on the bottom of the router. Alternatively use the default SSID (Wireless Network Name) on the bottom of the router along with the password in your *Important Documents Folder* to connect wirelessly.
5. **Via WPS (e.g. WPS enabled Printer)** Press (*do not hold*) the WPS button on the back of the router until the WPS LED starts flashing. Then proceed to set the printer on WPS mode as per its setup document. *Allow 1-2 minutes to establish a connection. Once the WPS changes from flashing to solid a connection has been established.*

**Please DO NOT HOLD the WPS/Reset button on the back of the router.**



- 1 Power Plug
- 2 Power Button
- 3 WAN
- 4 Ethernet
- 5 WPS Button
- 6 Antenna

### Setup Video Guide:

Scan this QR code with your phone camera for video.



### Contact our Support Team:

[www.choose2rent.com/help](http://www.choose2rent.com/help)  
+1 (800) 622-6484 Ext. 3 (USA)  
+49 40 226 360 - 590 (Europe)

## TP-Link AC1750 Router

### **Troubleshooting:**

*What if...*

... the router does not power up?	Please check if the power plugs are connected in tightly. Switch On and Off again. <i>Wait 3 mins.</i>
... the Internet light is Orange?	The device is not getting an Internet connection, make sure the hardline is plugged into the router's <b>WAN</b> port. Ask your venue 1) if the venue's hardline has a splash screen, your venue then requires the routers MAC address, it can be found on the bottom of the router 2) verify with the venue that the hardline is <b>DHCP</b> not static.
... the LAN light is OFF?	No physical connection to printer or PC. Make sure the cable is properly plugged in on both ends and the other unit is powered up.
... wrong/incorrect password.	Please verify Caps Lock is off. Use the password provided in the <i>Important Documents Folder</i> .
... the 2.4G light is OFF?	Your unit is pre-set to work only on the 5.0GHz wireless connection.

### **Setup Video Guide:**

Scan this QR code with your phone camera for video.



### **Contact our Support Team:**

www.choose2rent.com/help  
 +1 (800) 622-6484 Ext. 3 (USA)  
 +49 40 226 360 - 590 (Europe)