z Systems

Open Systems Adapter Integrated Console Controller User's Guide



SC27-9003-02

Note

Before using this information and the products it supports, read the information in <u>"Notices" on page</u> <u>109</u>. You should also familiarize yourself with the *zEnterprise* 196, System *z*10, System *z*9 and eServer *zSeries Open Systems Adapter-Express Customer's Guide and Reference*, SA22–7935, Hardware Management Console Operations Guide, SC28-6830, and System *z*10 Enterprise Class Support Element Operations Guide, Version 2.10.0, SC28-6868.

This edition, SC27-9003-02, refers to the IBM[®] Open Systems Adapter Integrated Console Controller for the following operating systems: z/OS Version 1 Release 2 or higher (5694-A01), and z/OS.e Version 1 Release 3 or higher (5655-G52), Open Systems Adapter Support Facility for z/Virtual Machine/Enterprise (z/VM) Version 3 Release 1, Version 4 Release 2 (Program Number 5654-A17), and Version 4 Release 3 or higher (Program Number 5739-A03), OSA/SF for VSE Version 2 Release 2 (part of VSE Central Functions 6.1.1, 5686-066) in VSE/ESA Version 2 Release 2.6 (5690-VSE) or higher, and to all subsequent releases and modifications until otherwise indicated in new editions or technical newsletters. This edition replaces SC27-9003-01.

There may be a newer version of this document in PDF format available on **Resource Link**. From the <u>Resource Link home</u> <u>page (www.ibm.com/servers/resourcelink)</u>, click on **Library** on the navigation bar. A newer version is indicated by a lower case, alphabetic letter following the form number suffix (for example: 00a, 00b, 01a, 01b).

Last updated: 2019-06-24

[©] Copyright International Business Machines Corporation 2016, 2019.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Contents

Figures	vii
Tables	xi
About this publication	xiii
Who should use this publication	xiii
What is included in this publication	xiii
Related publications	xiii
A note on terminology	xiv
How to send your comments to IBM	xv
If you have a technical problem	xv
Summary of changes	xvii
Summary of changes for SC27-9003-01	xvii
Chapter 1. Open Systems Adapter Integrated Console Controller overview	1
Planning considerations	1
Redundancy	1
Security support	1
Certificate and key management	2
Recommended PCOMM levels	2
Chapter 2. Server definition rules	3
Client connection rules	3
Chapter 3. Defining your OSA-ICC to the system's hardware configuration	5
Defining an OSC CHPID via IOCP	5
Steps for defining an OSC CHPID via HCD	6
IOCP statements	
Chapter 4. Displaying and managing OSA-ICC	11
Hardware Management Console and Support Element console	11
Steps for accessing the Advanced Facilities window	11
Accessing the Advanced Facilities window from the HMC	11
Accessing the Advanced Facilities window from the SE	13
OSA-ICC configuration and debug windows	13
Advanced Facilities windows	16
View port parameters	17
Run port diagnostics	19
Set card mode	21
Display client connections	22
Display active session configuration	23
Display active server configuration	24
Chapter 5. Configuring OSA-ICC	27
Panel configuration options	27
Edit server configuration	

Edit session configuration	
Validate panel values	33
Display validate panel errors	
Chapter 6. Manually configuring OSA-ICC	35
Manual configurations options	35
Import source file	
Export source file	37
Import source file via FTP	38
Export source file via FTP	
Edit source file	
Sections of the configuration file	40
Configuration file syntax	42
Validate source file	45
Validating a manual configuration file	45
Activate configuration	
Display activate configuration errors	
Chapter 7. Debug utilities	49
Ping Utility	49
Trace route utility	51
Drop session	53
Logo Controls	54
Query command	54
Chapter 8. OSA-ICC TLS Encrypted Session Support	59
x.509 Certificate Management	59
Cancel command	61
Manage Security Certificates panel with edit certificate feature	61
Using a shared self-signed certificate	62
Using an externally signed certificate with a shared certificate scope	63
Switching from an external certificate to a shared self-signed certificate	63
Using an individual self-signed certificate	64
Using an individual self-signed certificate with modifying attributes	
Using an externally signed certificate with an individual certificate scope	
Using an externally signed certificate with modifying attributes	69
View self-signed certificate	07 70
Switching from an external certificate to an Individual self-signed	
Switching from an individual self-signed to a shared self-signed (switch certificate scope)	
Supported cipher suites	72 72
Chapter 9. OSA-ICC programming considerations	
3270 Client Support	75
Chapter 10. eNetwork Personal Communications (PCOMM) configuration	77
Defining a PCOMM TN3270F session	77
Defining a secure PCOMM TN3270E session	
Importing self-signed or CA signed certificate	01 81
Defining the secure PCOMM TN2270E section	10 00
Chapter 11. Error and warning messages	91
Debugging tips	101
Annendix A. ASCII table	103
	103
Annendix B. Sample signed certificates	105

I

Sample certificate signing request Sample self-signed certificate	
Appendix C. Network topology	
Notices	
Trademarks	
Index	

Figures

I

1. CPC status page (CP Assist for Crypto functions highlighted)	2
2. Hardware configuration main menu	6
3. Hardware Management Console workplace window	12
4. OSA Advanced Facilities window	12
5. Reset to defaults	14
6. Card Specific Advanced Facilities window	15
7. View port parameters windows (1 of 2)	17
8. View port parameters windows (2 of 2)	18
9. Export Source File	19
10. File Transfer Information	19
11. Run port diagnostics window	20
12. Port identifier	20
13. Run port diagnostics window	21
14. Set card mode window	21
15. Display client connections window	22
16. Display active session configuration window	23
17. Display active server configuration window	25
18. Edit server configuration window	28
19. Panel configuration options window	30
20. Edit session configuration window	31
21. Edit session configuration window	33
22. Validate panel values window	34

24. Manual configuration window	36
25. Import source file window	
26. Export source file window	
27. Import source file via FTP window	
28. Export source file via FTP window	
29. OSC validate source file window	46
30. Successful validate source file	46
31. Activate configuration window	
32. Display activate configuration errors window	
33. Debug utilities window	49
34. Ping Utility	
35. Ping Utility response	51
36. Trace route utility	
37. Trace route utility output	53
38. Drop session utility	53
39. Logo Controls	
40. Query command	55
41. Query command help information	55
42. Query arp command output	56
43. Query command output for route	56
44. Query command output for osass	
45. Query command output for osaps	57
46. Manage Security Certificates window	60
47. Manage Security Certificates window	62
48. Manage Security Certificates window	

49. Change OSA-ICC Certificate Scope	65
50. Manage Security Certificates window	66
51. Edit Certificate window	
52. Save certificates changes confirmation	67
53. Save successful message	68
54. Manage Security Certificates window	69
55. Export Certificate Signing Request	
56. Certificate view	71
57. Customize Communication window	78
58. Telnet3270 window	79
59. E - Capture — [24x80]	
60. IBM Key Management, Open icon	82
61. IBM Key Management, Open window	83
62. IBM Key Management, Password Prompt	
63. IBM Key Management, Signer Certificates	85
64. IBM Key Management, filename and location of signer certificate	
65. IBM Key Management, filename and location of signer certificate	
66. IBM Key Management, new signer certificate	88
67. Section connected securely	89
68. Custom Configuration Options, Security Setup tab	90
69. Network topology Diagram 1	
70. Network topology diagram	

Tables

1. Connection rules matrix	4
2. Informational and error messages from OsaIccMsg	91
3. Errors from validate source file	91
4. Warnings from validate source file	99
5. Errors from validate windows	
6. Warnings from validate windows	101

About this publication

This document describes the configuration process for the Open Systems Adapter Integrated Console Controller.

Who should use this publication

This document is intended for the technical staff who will configure the Open Systems Adapter Integrated Console Controller.

What is included in this publication

This publication contains the following chapters and appendixes:

- Chapter 1, "Open Systems Adapter Integrated Console Controller overview," on page 1 is an introduction to the Open Systems Adapter-Express Integrated Console Controller.
- Chapter 2, "Server definition rules," on page 3 summarizes the rules for defining either or both physical ports and clients (sessions) during OSA-ICC dual-port configuration.
- Chapter 3, "Defining your OSA-ICC to the system's hardware configuration," on page 5 describes how to define your OSA-ICC PCHID to the system's hardware configuration.
- <u>Chapter 4, "Displaying and managing OSA-ICC," on page 11</u> describes the tasks for configuring your OSA-ICC.
- <u>Chapter 5, "Configuring OSA-ICC," on page 27</u> shows how to use panel entries to configure your OSA-ICC.
- <u>Chapter 6, "Manually configuring OSA-ICC," on page 35</u> show how to manually configure your OSA-ICC.
- <u>Chapter 7, "Debug utilities," on page 49</u> shows such OSA-ICC utilities as Debug, Ping, and Trace Route.
- <u>Chapter 8, "OSA-ICC TLS Encrypted Session Support," on page 59</u> shows the ways to configure TLS on OSA-ICC.
- <u>Chapter 9, "OSA-ICC programming considerations," on page 75</u> provides brief programming tips for 3270 client support.
- Chapter 10, "eNetwork Personal Communications (PCOMM) configuration," on page 77 provides an example of defining a PCOMM 3270 session.
- <u>Chapter 11, "Error and warning messages," on page 91</u> describes errors and warnings issued from the validate source file and validate panels.
- Appendix A, "ASCII table," on page 103 displays an ASCII table.
- <u>Appendix B, "Sample signed certificates," on page 105</u> provides a sample certificate signing request and a sample self-signed certificate.
- <u>Appendix C, "Network topology," on page 107</u> provides a diagram and description of the OSA-ICC network topology.

Related publications

Important

Please ensure that you are using the most recent version of all related documentation.

Other IBM publications that you will find helpful and that you should use along with this publication include:

- IOCP User's Guide for ICP IOCP, SB10-7037
- HCD User's Guide, SC33-7988

A note on terminology

Throughout this publication, certain equipment terms and short versions of product names are used to make the information more easily understood. These are:

1000Base-T

1000Base-T Ethernet feature capable of 10, 100, or 1000 Mbps

GbE

Gigabit Ethernet feature

OSA

Abbreviation for Open Systems Adapter. This document deals exclusively with the OSA-Express features and may refer to OSA-Express as OSA.

OSA-Express

Abbreviation for Open Systems Adapter-Express features.

OSA-ICC

Abbreviation for Open Systems Adapter-Express Integrated Console Controller features.

PCOMM

The Host Access Client Package which includes the eNetwork Personal Communications emulator.

TLS

Transport Layer Security.

How to send your comments to IBM

We invite you to submit comments about the z/OS[®] product documentation. Your valuable feedback helps to ensure accurate and high-quality information.

Important: If your comment regards a technical question or problem, see instead <u>"If you have a technical</u> problem" on page xv.

Submit your feedback by using the appropriate method for your type of comment or question:

Feedback on z/OS function

If your comment or question is about z/OS itself, submit a request through the <u>IBM RFE Community</u> (www.ibm.com/developerworks/rfe/).

Feedback on IBM Knowledge Center function

If your comment or question is about the IBM Knowledge Center functionality, for example search capabilities or how to arrange the browser view, send a detailed email to IBM Knowledge Center Support at ibmkc@us.ibm.com.

Feedback on the z/OS product documentation and content

If your comment is about the information that is provided in the z/OS product documentation library, send a detailed email to <u>mhvrcfs@us.ibm.com</u>. We welcome any feedback that you have, including comments on the clarity, accuracy, or completeness of the information.

To help us better process your submission, include the following information:

- · Your name, company/university/institution name, and email address
- The following deliverable title and order number: OSA-ICC User's Guide, SC27-9003-02
- The section title of the specific information to which your comment relates
- The text of your comment.

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute the comments in any way appropriate without incurring any obligation to you.

IBM or any other organizations use the personal information that you supply to contact you only about the issues that you submit.

If you have a technical problem

If you have a technical problem or question, do not use the feedback methods that are provided for sending documentation comments. Instead, take one or more of the following actions:

- Go to the IBM Support Portal (support.ibm.com).
- Contact your IBM service representative.
- Call IBM technical support.

xvi z Systems: Open Systems Adapter Integrated Console Controller User's Guide

Summary of changes

Changes have been made to this document.

This document contains terminology, maintenance, and editorial changes. Technical changes or additions to the text and illustrations are indicated by a vertical line to the left of each change.

Summary of changes for SC27-9003-01

This version has received editorial and terminology updates.

Extensive changes and additions were made to <u>Chapter 8</u>, "OSA-ICC TLS Encrypted Session Support," on page 59.

xviii z Systems: Open Systems Adapter Integrated Console Controller User's Guide

Chapter 1. Open Systems Adapter Integrated Console Controller overview

The IBM Open Systems Adapter Integrated Console Controller (OSA-ICC) provides tn3270e connectivity to non-SNA DFT 3174-type host connections. The OSA-ICC 3270 sessions allow you to IPL your logical partitions within any channel subsystem (CSS) and provides System Operator/Master consoles for z/OS, z/VM[®], and z/VSE. The defined OSA-ICC sessions can also be used by TSO, VM, or VSE system programmers as standard tn3270e consoles.

Each OSA-ICC is capable of handling 120 sessions. The OSA-ICC uses TCP/IP connections over an Ethernet LAN to attach to workstations that are running an RFC 2355 compliant TN3270E emulator.

New for z13 (D27K MCL P08440.002) and above is the introduction of Transport Layer Security (TLS) encrypted session support. Specifically designed for Master Consoles, this support can also provide encryption for your standard TSO-like sessions. The new function provides the capability to support 48 concurrent TLS sessions through a single OSA-ICC adapter.

IBM has tested the Host Access Client Package which includes the eNetwork Personal Communications emulator (PCOMM) Level 20150317 S and above. For other tn3270e emulator questions, contact the emulator's product vendor directly for terms, conditions, prices and other product details.

Your system can have one or more OSA-ICC features defined. Before you can use an OSA–ICC as a 3270 control unit, you must configure it. OSA-ICC configuration windows are accessible on your Hardware Management Console and your Support Element (SE) console. These windows allow you, the system programmer, to customize each OSA-ICC on your system.

Planning considerations

Redundancy

It is strongly recommended that production environments use redundant configurations where operator consoles are defined through two different OSA-ICC LANs on two different OSA cards to prevent the loss of console control in the unlikely event of a failure. The OSA-ICC documentation and support material assumes this is the case and shows appropriate configuration information for one OSA-ICC feature.

Security support

Newly added with z13 (D27K MCL P08440.002) and above is the ability to connect console clients to the ICC securely, using Transport Layer Support (TLS) as the connection protocol. TLS and its predecessor, Secure Sockets Layer (SSL), are cryptographic protocols designed to provide communications security over a computer network. With OSA-ICC TLS support, the requirement for an external VPN to provide security is no longer necessary.

The CP Assist for Crypto Functions (CPACF) must be installed and enabled before the OSA-ICC TLS support can be configured and enabled. You can verify the function by checking the CPC Status Page (Figure 1 on page 2).

S17B Details - S17B							i	
Instance Information	Product Information	Acceptable CP/PCHID Status	STP Inforn	nation	Energy Management			
Ensemble name:NET_ENSEnsemble HMC:OSAHMCCP status:Service requiredGroup:CPCChannel status:ExceptionsActivation profile:DEFAULTCrypto status:Last profile used:DEFAULTFlash status:Service state:false								
Alternate SE status:NoneNumber of ICFs:0IOCDS identifier:A0Number of IFLs:0IOCDS name:NOV113CSNumber of zIIPs:0System mode:Logically PartitionedDual AC power maintenance:FaultDetectedLock out disruptive tasks:Yes • NoCP Assist for Crypto functions: Installed					sted			
OK Apply Change Options Cancel Help								

Figure 1. CPC status page (CP Assist for Crypto functions highlighted)

Certificate and key management

Limited OSA-ICC TLS key management is provided. A single key, self-signed X.509 certificate, and certificate request is stored on the password protected SE and in the configuration information stored on the OSA adapter. We expect the customer to manage and secure additional certificates if required.

The certificate and key are protected by checksum and date on the closed SE system. The checksum and date are verified every time the key/certificate is loaded by the OSA-ICC adapter.

When creating or importing certificates, the strength of the allowed private key is fixed by firmware. The files are stored in PEM format. Digital signatures are generated using RSA.

Recommended PCOMM levels

Recommended PCOMM levels for OSA-ICC:

- PCOMM Level 6.014, dated 20150317 S for non-TLS Sessions
- PCOMM Level 6.016, dated 20151006 S for TLS Sessions

Note:

Users at lower levels might experience unstable connections that repeatedly drop and recover when used with OSA-ICC cards on z13s processors.

Chapter 2. Server definition rules

OSA-ICC server rules include the following:

- Unique TCP Port number for each physical port
- Unique secure TCP Port number for each physical port
- · Different subnet for each physical port host IP
- Single defined common gateway

Client connection rules

When a client is connecting to the OSA-ICC, the client gets assigned a session number based on what is in the client session table. If the client does not meet the criteria described later in this section, or there are no more free sessions, that client's connection attempt is refused.

Two rules define connections:

- What can be defined in the session table
- · How a client is assigned to a session

Two inputs to the session table:

- The client's IP
- The LU name (also called group name)

The session table has the following rules (configured via panels or via manually edited source file):

- Each session must contain at least one of the following element:.
 - Session LU name
 - IP address
- A session can contain both a client's IP and a session LU name.
- A session may have only an LU name or only a client's IP.
- The same LU name cannot be specified in multiple images (CSS/IIDs). It may, however, be used multiple times within the same image.
- If a session has the LU name and IP defined, then another session can not have that same LU name without also specifying an IP address. If you attempt to use the LU name by itself, you will get return code 1223 or 1224, depending on what session was defined first (one with both LU name and IP address, or one with just LU name).
- For example:

```
session1 : CSS= 1 MIFID= 1 GROUP= "LU1" CLIENT_IP= 10.10.10.1
session2 : CSS= 1 MIFID= 1 GROUP= "LU1" -
```

These two sessions are in conflict - this would be an error.

Example 2:

session1 :	CSS= 1 MIFID= 1	GROUP= "LU1"	CLIENT_IP= 10.10.10.1
session2 :	CSS= 1 MIFID= 1	GROUP= "LU1"	CLIENT_IP= 10.10.10.2

These two sessions are not in conflict.

Example 3:

```
session1 : CSS= 1 MIFID= 1 GROUP= "LU1"
session2 : CSS= 1 MIFID=1 GROUP= "LU2"
```

These two sessions are not in conflict - because session 2 uses a different LU.

• IP has to be unique per partition when no LU is specified.

Client assignment hierarchy:

- If the client has specified an LU name, then the first available session with that LU name will be considered. Furthermore, if that session entry has a client's IP address specified, the address of the incoming client must also match.
- If the client has specified an LU name, then first available session with that LU name will be considered. Furthermore, if that session entry has NO client's IP address specified, then the IP address of the incoming client has no meaning.

Table 1. Connection rules matrix					
Rule	Session Configuration	Client's configuration	Effect		
1	No LU name, and no IP	Not allowed	No connection		
2	Unique LU name specified	Defined LU	Connection		
3	LU name specified	Defined LU	Connection		
	unique to this partition	No or non-matching LU or defined in multiple CSS/image	No Connection		
4	LU name and client	Good LU, good IP	Connection		
	IP address specified	Good LU, non-matching Client IP	No connection		
		No or non-matching LU, matching Client IP	No connection		
		No or non-matching LU, matching Client IP	No connection		
		No or non-matching LU, matching Client IP	No connection		
		No or non-matching LU, matching Client IP	No connection		
5	Unique IP specified	IP good	Connection		
		IP bad or defined in multiple CSS/ images	No connection		
6	Client IP specified	Defined IP	Connection		
	unique to this partition	No/non-matching IP or defined in multiple CSS/images	No connection		

• IP filter rule applies whenever the Client IP is defined.

Chapter 3. Defining your OSA-ICC to the system's hardware configuration

To use an OSA Card as an OSA-ICC adapter, the OSA-Express channel must be defined as an OSC CHPID. In order for your system to recognize an OSC CHPID, you must define the CHPID in your Input/Output Configuration Dataset (IOCDS) via the Hardware Configuration Definition (HCD) tool, or the Input/Output Configuration Program (IOCP).

Each OSA-ICC feature requires a unique CHPID, control unit, and device range definition. A OSC CHPID cannot be defined to span control units.

Although only 120 devices (sessions) can be configured on the ICC card at one time, the IOCDS definitions can contain more than 120 configurable devices.

Defining an OSC CHPID via IOCP

Following is a sample IOCP configuration for defining an OSA-ICC channel. For instructions on defining an OSA-ICC channel via HCD, see "Steps for defining an OSC CHPID via HCD" on page 6.

RESOURCE PART: The RESOURCE statement defines all of the logical partitions and the logical channel subsystems (LCSSs) in the configuration. It also assigns a MIF image ID to each logical partition (for example, logical partition MVS1 has MIF ID 3 in LCSS 1).

CHPID PCHID: The OSA-Express port is associated with PCHID 1C0. The channel path is defined to have CHPID 80 in logical channel subsystems (LCSSs) 0, 1, and 2 and, because the PART keyword is not used, to each logical partition in the LCSSs.

CNTLUNIT: The control unit definition is assigned control unit number 1000 and has access to all LCSSs. Since you can only assign a single control unit to an physical port path, be sure to include every CSS for which you want to have TN3270E sessions.

IODEVICE ADDRESS: Device numbers 2400-245F are defined and available to every logical partition in each of the LCSSs. A total of 768 devices (8 logical partitions * 96 devices) are available in the configuration but only a maximum of 120 can be configured for use.

Note: If you are using HCD to define your configuration it is important that you select control unit type OSC and device type 3270-X for OSA-ICC.

Recommendation: If you define multiple IOCDSs with different OSA configurations respectively, before Power-On-Reset, please export the OSA-ICC configuration file to a USB device or transfer to a server via ftp/sftp. For more information on importing and exporting your definitions, see <u>"Import source file" on page 36</u> and <u>"Export source file" on page 37</u>.

Steps for defining an OSC CHPID via HCD

About this task

Following is an example HCD configuration for defining an OSA-ICC channel. For instructions on defining an OSA-ICC channel via IOCP, see <u>"Defining an OSC CHPID via IOCP" on page 5</u>. The OSA-ICC function requires a unique CHPID, control unit, and device definition.

Note: You can only dynamically delete console devices after first removing console names with IEAVG730 or IEARELCN. For more information, see *z/OS HCD Planning*, GA22–7525 or *z/OS MVS Planning: Operations*, SA22–7601.

Channel path definition

Procedure

1. From the HCD main menu, Select option 1, and press Enter. The Define, Modify, or View Configuration Data menu is displayed.



Figure 2. Hardware configuration main menu

2. Select Option 3 "Processors", and press Enter. The Processor List is displayed.

- 3. Select the processor to update, and press Enter. The Actions on Selected Processors screen is displayed. The screen selection options are identified here by the action code entered, rather than the screen item number, to avoid confusion when a particular HCD menu changes.
- 4. On the Actions on Selected Processors screen, select S "Work with attached channel paths", and press Enter. The Channel Subsystem List is displayed.
- 5. On the Channel Subsystem List, select the required CSSID, and press enter. The Actions on Selected Channel Subsystems screen is displayed.
- 6. On the Actions on Selected Channel Subsystems screen, select S "Work with attached channel paths", and press Enter. The Channel Path List is displayed.

7. On the Channel Path List, press F11 to add a channel path. The Add Channel Path screen is displayed.

- 8. On the Channel Path List, enter the:
 - Channel path ID
 - Channel ID
 - Channel path type OSC (to define the OSA-ICC function)
 - Operation mode SHR (to share this channel path among logical partitions)
 - Description
- 9. Complete the channel path definitions on the screen, press Enter. The Define Access List is displayed.
- 10. Complete the Access List for the partitions sharing the channel, and press Enter. The Candidate List Definition screen is displayed.
- 11. On the Candidate List Definition screen, select the partitions to include in the candidate list and press Enter, or simply press Enter if you do not want any additional partitions in the candidate list. The Channel Path List screen is displayed.

Results

Control unit definition

- 1. Select the CHPID just defined (CHPID 04, in our configuration), and press Enter. The Actions on selected channel paths screen is displayed.
- _____
- 2. On the Actions on selected channel paths screen, select S "Work with attached control units", and press Enter. The Control Unit List is displayed.
- 3. On the Control Unit List, press F11 to add a control unit. The Add Control Unit screen is displayed.
- 4. On the Add Control Unit screen, enter the:
 - Control unit number
 - Control unit type OSC
 - Description
- 5. Complete the channel path definitions on the screen, and press Enter. The Select Processor / CU screen is displayed.
- 6. On the Select Processor / CU screen, select the processor for the control unit, and press Enter. The Actions on Selected Processors screen is displayed.
- 7. On the Actions on Selected Processors screen, select S for Select (connect, change), and press Enter. The Add Control Unit screen is displayed. The Add Control Unit screen shows the OSC control unit information just entered. Note the unit address is set to 00 and the number of units must be 254.

- 8. Confirm the control unit definitions on the screen are correct, and press Enter. The Select Processor / CU screen is displayed again.
- 9. Press Enter again to return to the Control Unit List screen.

Device definition

1. From the Control Unit List screen select the control unit, and press Enter. The Actions on Selected Control Units screen is displayed.

- 2. On the Actions on Selected Control Units screen, select S "Work with attached devices", and press Enter. The I/O Device List is displayed.
- 3. On the I/O Device List, press F11 to add a device. The Add Device screen is displayed.
- 4. On the Add Device screen, enter the:
 - Device number
 - Number of devices
 - Device type 3270-X. Device type 3270-X is the only valid device type for the OSA-ICC function. The HCD configuration process will not allow any other device type to be defined.
 - Description
- 5. Complete the device definitions on the screen, and press Enter. The Update Serial Number, Description and VOLSER screen is displayed, press Enter. The Device / Processor Definition screen is displayed.
- 6. On the Device / Processor Definition screen, select the required processor, and press Enter. The Define Device / Processor screen is displayed.
- 7. On the Define Device / Processor screen, you have the option of changing the starting unit address. Verify the value and press Enter. The Device / Processor Definition screen is again displayed.
- 8. On the Device / Processor Definition screen, press Enter. The Define Device to Operating System Configuration screen is displayed.
- 9. On the Define Device to Operating System Configuration screen, select the operating system to which you want to connect the devices, and press Enter. The Actions on selected Operating Systems screen is displayed.
- 10. On the Actions on selected Operating Systems screen, select S and press Enter. The Define Device Parameter / Features screen is displayed.
- 11. On the Define Device Parameter / Features screen make appropriate changes based on your environment, then press Enter. The Assign / Unassign Device to Esoteric screen will appear.

- 12. On the Assign / Unassign Device to Esoteric screen make appropriate changes based on your environment, then press Enter.
- 13. Repeat the process for each operating system as needed, then exit from the Define Device to Operating System Configuration screen, by pressing F3 or F12.
- 14. You should now be at the Device List window. Press F3 multiple times to return to the main HCD screen (Hardware Configuration), for activating or processing the configuration data you just defined.

Note:

- 1. With the introduction of z/OS V2R1, you can now add and delete CONSOLE definitions dynamically.
- 2. If any of the Console addresses defined are going to be used as MVS NIP consoles, then addition steps are needed:
 - · Select 1 Operating system configuration
 - Select config ID with /
 - Option 6, work with consoles
 - F11 to add console addresses to the NIP CONSOLE LIST
 - · Continue with the Production IODF step

IOCP statements

The following is an example of the IOCP statements generated by HCD for the configuration of the logical partitions, both OSC CHPIDs, and the associated control unit and device definitions.

RESOURCE PARTITION=((CSS(0),(A0A,A),(A0B,B),(A0C,C),(A0D,D),(A* 0E,E),(A0F,F),(A01,1),(A02,2),(A03,3),(A04,4),(A05,5),(A* 06,6),(A07,7),(A08,8),(A09,9)),(CSS(1),(A1A,A),(A1B,B),(* A1C,C),(A1D,D),(A1E,E),(A1F,F),(A11,1),(A12,2),(A13,3),(* A14,4),(A15,5),(A16,6),(A17,7),(A18,8),(A19,9))), * MAXDEV=((CSS(0),64512),(CSS(1),64512)) CHPID PATH=(CSS(0),07),SHARED, * PARTITION=((A0A,A0B,A0C,A01,A02,A03,A04,A05,A06,A07,A08,* A09),(=)),PCHID=380,TYPE=0SC CHPID PATH=(CSS(1),07),SHARED, * PARTITION=((A1A,A1B,A11,A12,A13,A14,A15,A16,A17,A18,A19)* ,(=)),PCHID=381,TYPE=0SC CNTLUNIT CUNUMBR=E200,PATH=((CSS(0),07)),UNIT=0SC IODEVICE ADDRESS=(E200,120),MODEL=X,CUNUMBR=(E200),UNIT=3270 IODEVICE ADDRESS=(E300,120),MODEL=X,CUNUMBR=(E300),UNIT=3270

Refer to *Input/Output Configuration Program User's Guide for ICP IOCP*, SB10-7037 for further information about IOCP and IOCDSs.

10 z Systems: Open Systems Adapter Integrated Console Controller User's Guide

Chapter 4. Displaying and managing OSA-ICC

Before you can connect any TN3270E session to the ICC, the OSA Adapter must be online to the Hardware Management Console or the Support Element (SE).

Hardware Management Console and Support Element console

You can manage your OSA-ICC from the Advance Facilities window which is accessible from either your Hardware Management Console (HMC) or your Support Element (SE) console. These two consoles are the only way you can access the OSA-ICC configuration windows. For more information on these consoles, see the content in the SE and HMC (Version 2.12.1) publications, which has been incorporated into the help information. This information is located from the SE and HMC. You can also access this help information from IBM Knowledge Center (www.ibm.com/support/knowledgecenter).

Steps for accessing the Advanced Facilities window

About this task

This manual assumes that the user has a basic understanding of how to access and manage their system using the SE or HMC.

Before you can connect any TN3270E session to the ICC, the OSA Adapter must be online to the partition.

Note: This section shows examples of using the Hardware Management Console and the SE, because the initial windows to select the PCHID are different.

Be aware of the following OSA-ICC initialization time delays:

- 1. OSA ICC initialization: 20-25 seconds; therefore, wait 20 25 seconds before performing config off or any other SE panel operations.
- 2. CEC Activate: Wait for 20-25 seconds after active message completion before performing CEC deactivate.

Accessing the Advanced Facilities window from the HMC

Procedure

1. From the Hardware Management Console workplace window, click **Tasks Index** on the left-hand navigation pane.

Hardware Management Console					
	Welcome (HMC Version)				
🗖 Welcome					
🗄 📗 Systems Management	Welcome to the Hardware Management Console (H also manage ensembles. Click on the links in the na	MC). From here you can manage this HMC as well as servers, images, and other resources. Available with the appropriate code vigation pane at the left to begin.			
🗄 Ensemble Management					
🗗 Custom Groups	Systems Management	Manage systems and images. Set up, configure, view current status, troubleshoot, and apply solutions.			
🗉 븚 HMC Management	🔚 Ensemble Management	Manage systems in an Ensemble and its workloads, hypervisors, virtual servers, storage, and networks.			
🔀 Service Management	Custom Groups	Manage user-defined groups of objects.			
Tasks Index	🚊 HMC Management	Perform tasks associated with the management of this HMC.			
	🖁 Service Management	Perform tasks associated with servicing this HMC.			
	Tasks Index	Perform tasks by selecting them from a list including task name, description, permitted objects, and execution frequency.			
	🔜 Status Bar	Click on the icons in the status bar to display details of status and messages.			
	Additional Resources				
	🛐 What's New	introduces the latest features of the console			
	Online Information	Additional related online information.			

Figure 3. Hardware Management Console workplace window

- 2. From the Tasks Index, click **OSA Advanced Facilities**.
- 3. The OSA Advanced Facilities window opens. Select the PCHID you wish to configure and select OK.

HMCT	HMCT61: OSA Advanced Facilities 🛛 📃 📉 📉				
	SA Advanc	ed Facilities -	H17 🔳		
Select	a channel IC) and click "OK'			
Select	Channel ID	Channel Type			
0	0130	OSD	A		
0	0150	OSE	Γ		
0	0151	OSE			
0	0170	OSC			
0	0171	OSC			
ОК	Cancel He	elp			

Figure 4. OSA Advanced Facilities window

4. The *Standard Channel Advanced Facilities* window is displayed. Select *Card Specific Advanced Facilities* and click OK.

Accessing the Advanced Facilities window from the SE

Procedure

1. From the SE workplace window, select the CPC that you want, under **Systems Management** on the left-hand navigation pane.

Support Element								900	TEL	IBM.
									pedebug Hel	p Logoff
(+ ⇒ []] []] []] []] []] []] []] []] []] [System Ma Channels	anagement >	S17B > Cha	nnels						
E Welcome	6									
System Management					Filte	er)	Tasks 🔻	Views 🔻	
S17B	Sele ^	Filter	Eilter	Status ^	Sta ^	Swapp ^	Location	ilter	Type	^
Processors	1 I I I I I I I I I I I I I I I I I I I	1013U	Filter		ricaci vou	Filler	N190-0110-0		T IOUT Express	
Channels	Г	📑 013D		😣 Not defined	Reserved		A13B-D219-J	.01	FICON Express	8S
e un Partitions	Г	₩ 0140	0.0B 1.0B 2.0B	Operating	Online		A13B-D120J.	01-D220J.01	OSA-Express55	3
Custom Groups		0144	0.0C 1.0C 2.0C	Operating	Online		A13B-LG21J.	00-LG21J.01	OSA-Express45	3
📕 SE Management	Z	📑 0148 🖄	0.0D 1.0D 2.0D	Operating	Online		A13B-D122J.	01-D222J.01	OSA-Express55	\$
Service Management		👫 014C	1.0E	Operating	Online		A13B-LG23J.	00-LG23J.01	OSA-Express48	3
	E	B 0150	0.0F 1.0F 2.0F	Operating	Online		A13B-LG25J.	00-LG25J.01	OSA-Express49	3
🗏 Tasks Index	Г	1 0170	0.0A 1.0A 2.0A	Operating	Online		A13B-LG35J.	00-LG35J.01	OSA-Express48	3
	Г	E 0180	0.00 1.00	Service Service	Reserved		A06B-LG01-J	.00	OSA-Express45	3
	Г	0184	0.73 1.73	Permanent erro	Standby		A06B-D102-J	.01	OSA-Express55	3
		B 1	0.02.1.02		Opline		A068-LC09 L	00.1.002.1.01	OSA Exprosed	
			Max Pa	ge Size: 500 Tota	I: 55 Filtere	ed: 55 Selecte	ed: 1			
	Tasks: 014	18 🖬 🖂	8-		1.198.0	-				0
	PCHID Details CHPID Operations Channel Operations			ons						
Status: Exceptions and Meesagee										
🗐 🔕 🔲 🗐										
Transferring data from 9.56.196.11										

- 2. Under the CPC, select **Channels**.
- 3. From the Channels display, select the PCHID that you want.

OSA-ICC configuration and debug windows

If it is necessary to bring back the factory defaults, the user can use the "Reset to Defaults" Option of the main window of Advanced Facilities.

Advanced Facilities - PCHID0148	i
Channel ID: 0148 Channel type: OSC-ICC	
Card description:OSA Express5S 1000BASE-T Ethernet	
Select a function: Force error recovery log	
View code level	
Card specific advanced facilities Look up generic access	
Reset to defaults OK Cancel Help	

Figure 5. Reset to defaults

Note: The following functions are not described in this manual:

- Force error recovery
- Card display or alter memory
- View code level
- Card trace/log/dump facilities
- Look up generic access

Management and configuration windows for the ICC are accessed from the Card Specific Advanced Facilities window.

Advanced Fac	ilities - PCHID0148	i
Channel ID:	0148	
LAN port type:	OSC-ICC 3270	
Select a function: View port paramet Run port diagnosti Set card mode Display client conr Display active ses Display active ses Panel configuration Manual configuration Activate configuration Display activate configuration Manual configuration Manual configuration Display activate configuration Manage security configuratio	ers nections sions configuration ver configuration n options on options tion onfiguration messages ertificates	

Figure 6. Card Specific Advanced Facilities window

All OSA-ICC control operations are selected from the *Advanced Facilities* window as shown in <u>"Steps for</u> accessing the Advanced Facilities window" on page 11.

The following is a brief explanation of the tasks you can perform from each of these windows:

Task	Explanation
Run port diagnostics	Allows you to run diagnostics on the physical port.
View port parameters	Allows you to view Network Interface Card statistics for the selected physical port.
Set card mode	Used to set the speed and mode of the physical port.
Display client connections	Used to view Network Interface Card statistics.
Display active session configuration	Displays the active session configuration for a given OSC.
Display active server configuration	Displays the active server configuration for a given OSC.

Task	Explanation	
Panel configuration options	Allows you to edit session configurations, edit server configurations, validate panel values, and view any validate panel errors	
Manual configuration options	Allows you to import a source file, export a source file, edit a source file, and validate a source file.	
Activate configuration	Allows you to activate a configuration.	
Display active configuration errors	Allows you to view any active configuration errors.	
Debug utilities	Allows you to ping a client work station, trace the route of a packet of data to a session, and drop a session.	
Cancel command	Allows you to cancel a command which is executing on an OSC.	

For a complete description of the windows and the meaning of their entry fields, see <u>"Advanced Facilities</u> windows" on page 16.

Advanced Facilities windows

This section describes the following OSA-ICC Advanced Facilities windows:

- View port parameters, see "View port parameters" on page 17
- Run port diagnostics, see <u>"Run port diagnostics" on page 19</u>
- Set card mode, see <u>"Set card mode" on page 21</u>
- Display client connections, see "Display client connections" on page 22
- Display active session configuration, see "Display active session configuration" on page 23
- Display active server configuration, see "Display active server configuration" on page 24
- Panel configuration option, see <u>"Panel configuration options" on page 27</u>
 - Edit session configuration, see "Edit session configuration" on page 30
 - Edit server configuration, see <u>"Edit server configuration" on page 27</u>
 - Validate panel values, see "Validate panel values" on page 33
 - Display validate panel errors, see "Display validate panel errors" on page 34
- Manual configuration options, see Chapter 6, "Manually configuring OSA-ICC," on page 35
 - Import source file, see "Import source file" on page 36
 - Export source file, see "Export source file" on page 37
 - Edit source file, see "Edit source file" on page 39
 - Validate source file, see <u>"Validate source file" on page 45</u>
- Activate configuration, see <u>"Activate configuration" on page 46</u>
- Display activate configuration errors, see "Display activate configuration errors" on page 47
- Debug utilities, see Chapter 7, "Debug utilities," on page 49
 - Ping utility, see "Ping Utility" on page 49
 - Trace route utility, see <u>"Trace route utility" on page 51</u>
 - Drop session, see "Drop session" on page 53
 - Logo Control, see "Logo Controls" on page 54
 - Query Command see <u>"Query command" on page 54</u>
- Manage security certificates

View port parameters

The View port parameters window allows you to view the Network Interface Card statistics. When selected, it gives you statistical and setting information from your OSA-ICC. The port must be active for data to be available. An option is provided to specify the port whose parameters will be displayed.



Figure 7. View port parameters windows (1 of 2)

View Port Parameters - PCHID01	48	i
Channel path: 0148 LAN port type:OSC-ICC 3270 Port Number: 0		
Local MAC address: Universal MAC address: Configured speed, mode: Active speed, mode:	6CAE8 6CAE8 Auto Ne 1000 M	B480BEC B480BEC egotiate lb, Full Duplex
Total packets transmitted: Total packets received: Total octets transmitted: Total octets received: Packets transmitted	0 445654 0 269493	72
1 to 63 bytes: 0 64 to 126 bytes: 0 127 to 254 bytes: 0 255 to 510 bytes: 0 511 to 1022 bytes: 0 1023 to 1517 bytes:0 1518 to MAX bytes:0		
Packets received		
1 to 63 bytes: 463988 64 to 126 bytes: 4077 127 to 254 bytes: 9113 255 to 510 bytes: 901 511 to 1022 bytes: 153 1023 to 1517 bytes:41 1518 to MAX bytes:0		
Broadcast packets transmitted:	0	
Multicast packets received: Multicast packets transmitted: Multicast packets received: Pause frames transmitted:	445493 0 26843 0	i
Pause frames received:	õ	
Receive length error count:	0	
Receive jabber count:	0	
Receive oversize count:	ő	
Receive drops with no free status descrip	tors on NIC: 1	
Receive drops with no free status descrip	tors on LAN driver:0	
Receive drops with no free receive descri	ptors: 1	
Align error count:	0	
OK Export to USB Flash Memory Drive	Export to FTP Location	Help
Ammund		

Figure 8. View port parameters windows (2 of 2)
The data provided from this window can be Exported to a USB Flash Memory Drive or an external FTP/ SFTP Location.

Export Source	e File - PCHID0148							
Enter the file name for the export source file, then click "OK". Export source file name								
OK Cancel	<u>.</u>							
Figure 9. Export Source File								
File Transfer Info	rmation - PCHID0148							
Please enter the target in that will be used for expo	nformation (IP address, userid, password, and file name) orting, then click "OK".							
Source: null								
IP address	*							
User identification	*							
Password	*							
Fully qualified file name	*							
Use secure FTP OK Cancel Help								

Figure 10. File Transfer Information

Run port diagnostics

The **Run port diagnostics** window is used to run diagnostics. The purpose of running these diagnostics is to verify functionality of the hardware. Running port diagnostics will stop regular traffic on the card and cause all sessions to be disconnected. You can run diagnostics normally or with a wrap plug installed.

Run Port Diagnostics - PCHID0148	i
Channel ID: 0148	
LAN port type: OSC-ICC 3270	
Select a physical port identifier and click "OK" to run diagnostics, or click "Cancel" to cancel	
Dhysical part Identifian	
Physical port identifier: * p	
Diagnostic type	
Normal	
<u>₩</u> rap plug test	
OK Cancel Help	

Figure 11. Run port diagnostics window

Port identifier: Identifies the port on which you want to run diagnostics. The entry field default is 0; however, the desired port can be selected by using the pull down menu.

Advanced Facilities - PCHID0148	i
You are about to run a port diagnostic which may affect all the sessions connected to this PCHID.	
Also after running the port diagnostics, the CHPIDs assigned to this PCHID must be configured off and on to be made operational.	
Click "OK" to continue, or "Cancel" to stop the operation.	
OK Cancel	189
Figure 12. Port identifier	

Run Port Diagnostics	- PCHID0148
Channel ID:	0148
LAN port type:	OSC-ICC 3270
The diagnostic test complete	ed. No errors were detected.
LAN Port status word 0:	0000000
LAN Port status word 1:	00000100
LAN Port status word 2:	F5200000
LAN Port status word 3:	0000000
LAN Port status word 4:	0000000
LAN Port status word 5:	0000000
LAN Port status word 6:	0000000
LAN Port status word 7:	0062A652
OK Cancel	

Figure 13. Run port diagnostics window

Set card mode

The *Set card mode* window is used to set the speed and mode of the OSA-ICC.

Note: This window does not show the current speed or mode of the ICC card. See <u>"View port parameters"</u> on page 17 to see how the card is configured.

Set Card Mode or	Speed - PCHID0148	i
Channel ID:	0148	
LAN port type:	OSC-ICC 3270	
Physical port identifier:	* 0	
Speed/Mode	,	
 Auto Negotiate (includ 100 <u>M</u>b, Full Duplex 	les 1000Mb, Full Duplex)	
OK Cancel Help		

Figure 14. Set card mode window

Physical port identifier: Since there are multiple ports, a selection is made to specify which port speed to set. By default this field is set to zero.

Speed/Mode: The default is Auto Negotiate. If auto-negotiate fails, the default is 100 Mb, full duplex. The speed/mode is changed dynamically, but it is recommended that you do not make this change while sessions are active and connected.

Display client connections

The *Display client connections* you to view currently connected clients. This information is queried at the time you open this window. To refresh the information, exit the window and reopen it.

Same Dis	piay cile	it connection	15 - PCHID020C						
Channel	ID:					020C			
AN port	type:					OSA-ICC	3270		
Session Index	Status	Physical Port Identifier	MAC	Client IP	TCP Port	Socket Number	LT Index	Connect Rule	Disable Logo
1	Connected	0	52:54:00:F9:55:9E	10.55.1.84	49608	134	0	LU Only	No
2	Connected	0	52:54:00:F9:55:9E	fe80::8d4:d1f2:c8d0:76c6	49686	135	1	LU Only	No
3	Connected	0	52:54:00:07:D0:86	10.55.1.5	60826	136	2	LU Only	No
4	Connected	0	52:54:00:07:D0:86	10.55.1.5	60828	137	3	LU Only	No
5	Connected	0	52:54:00:07:D0:86	10.55.1.5	60830	138	4	LU Only	No
6	Connected	0	52:54:00:07:D0:86	10.55.1.5	60832	139	5	LU Only	No
7	Connected	0	52:54:00:07:D0:86	10.55.1.5	60834	140	6	LU Only	No
8	Connected	0	52:54:00:07:D0:86	10.55.1.5	60836	141	7	LU Only	No
9	Connected	0	52:54:00:07:D0:86	10.55.1.5	60838	142	8	LU Only	No
10	Connected	0	52:54:00:07:D0:86	10.55.1.5	60840	143	9	LU Only	No
11	Connected	0	52:54:00:07:D0:86	10.55.1.5	60842	144	10	LU Only	No
12	Connected	0	52:54:00:07:D0:86	10.55.1.5	60844	145	11	LU Only	No
13	Available	0	00:00:00:00:00:00	0.0.0.0	0	0	12	Unknown	No
14	Available	0	00:00:00:00:00:00	0.0.0.0	0	0	13	Unknown	No
15	Available	0	00:00:00:00:00:00	0.0.0.0	0	0	14	Unknown	No

Figure 15. Display client connections window

Session Index specifies the session number. The valid range is from 1–120.

Status specifies whether the session is not configured, available, connected, active, or definition error:

- Not configured: the session has not yet been configured.
- Available: the session has been configured and the client can connect to it.
- Connected: the session has been configured and the client is connected to it.
- DHD pending: the client has been disconnected. However, since DHD was enabled, OSA-ICC has not notified the host operating system that the client is no longer connected.
- Definition error: the session is not a valid session and the client cannot connect. The session CSS, MIFID, or Device Number does not exist or was dynamically deleted during dynamic I/O.
- TLSConnected : the session is connected via a encrypted TLS enabled session.

Physical Port Identifier displays which server port the client is connecting through.

MAC specifies the address of the client that is being connected if the client is on the same LAN. Otherwise, the MAC address of the router is displayed. This field is not cleared after a client has been disconnected. It represents the last valid MAC address of a successfully connected session.

Client's IP specifies the IP address of the attached client.

Port specifies the TCP port number of the ICC server which the client will connect through. This parameter is only useful to IBM Technical Support.

Socket Numbers specifies the Local TCP socket number that uniquely defines the connection. This parameter is only useful to IBM Technical Support.

LT Index the index in the LT table (OSA-ICC Management table). Valid range is from 0–119. 65535 means initialized. This parameter is only useful to IBM Technical Support.

Connect rule can be IP only, LU only, IP & LU, unknown. For more information on connection rules, see Chapter 2, "Server definition rules," on page 3.

LOGO this feature has two values ENABLE/DISABLE. When enabled the three line logo appears on client session, if disabled this three line logo will not appear. For more information on the three line logo display, see Section 4.

Display active session configuration

The *Display active session configuration* window is used to display the active session configuration for a given OSC. This includes a list of the sessions that are configured for the OSC and configuration information about each session.

Se	ssions Configu	ratio	n - PCH	IID0148								i	
Channel	ID:					0148							
LAN port	type:					OSC	-ICC 3270						
Session Index	State	CSS	MIFID	Device Number	LU Name	Client's IP	IP Filter	Session Type	DHD	DHDTO	RSP	RTO	
1	Available	0	01	0560	CONSOLE_001	0.0.0.0	255.255.255.255	Op Console	Disabled	0	Disabled	90	
2	Available	1	01	0561	CONSOLE_002	0.0.0.0	255.255.255.255	TN3270	Enabled	86400	Enabled	90	
3	Def Error	2	0D	0562	CONSOLE_003	0.0.0.0	255.255.255.255	Op Console	Disabled	0	Enabled	60	
4	Available	0	0B	0563	CONSOLE_004	0.0.0.0	255.255.255.255	TN3270	Disabled	0	Disabled	30	
5	Available	2	01	0564	CONSOLE_005	0.0.0.0	255.255.255.255	Printer	Disabled	0	Enabled	30	
6	Available	2	08	0564	CONSOLE_006	0.0.0.0	255.255.255.255	TN3270	Disabled	0	Enabled	30	
7	Available	2	08	0565	CONSOLE_006	0.0.0.0	255.255.255.255	TN3270	Disabled	0	Enabled	30	
8	Available	2	08	0566	CONSOLE_006	0.0.0.0	255.255.255.255	TN3270	Disabled	0	Enabled	30	
9	Available	2	08	0567		10.21.1.252	255.255.255.255	TN3270	Disabled	0	Enabled	30	
10	Available	2	08	0561	CONSOLE_007	10.21.1.253	255.255.255.255	Op Console	Enabled	46400	Enabled	30	
11	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60	
12	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60	
13	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60	
14	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60	
15	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60	
OK H	lelp	-								_			

Figure 16. Display active session configuration window

Session Index specifies the session number.

State specifies whether the session is not configured, available, or has a definition error:

- Not configured: the session has not yet been configured.
- Available: the session has been configured and the client can connect to it.
- Definition error: the session is not a valid session and the client cannot connect. The session CSS, MIFID, or Device Number does not exist or was dynamically deleted during dynamic I/O.

CSS specifies the logical channel subsystem ID. The valid range for CSS is 0–5 (depending on machine configuration).

MIFID is the logical partition MIF image ID. A valid range for the Image Id is 1-F.

Device Number is a number assigned for each device that was defined in the IOCDS.

LU Name defines a group or pool of devices that identifies what session you are going to connect to. Please refer to connection rules. You can specify a unique LU Name for a connection, or the same LU Name spread across multiple entries. You may also omit this field and connect to a particular host session via the client Host IP.

Client's IP (optional) specifies the IP address(es) that the client will use to connect to the session. The client's IP address can remain 0.0.0.0 or empty in order to allow any client to connect to a specific

session. If a non-zero IP is specified, any client with a non-matching IP is rejected. Matching IP addresses are defined by the IP Filter (the next definition).

IP Filter defines a range of client IP addresses that are allowed to connect through a given physical port, and is similar to a Subnet Mask. The IP filter is only applicable when the client's IP address is specified.

• Example 1:

Client's IP value is is 10.20.30.40

IP Filter value is 255.255.255.255

Since all of the bits in the **IP Filter** are on, the IP address of the device that is trying to establish a connection must match the **Client's IP** value exactly. In this example, only 10.20.30.40 will be allowed to connect.

• Example 2:

Client's IP value is 10.20.30.40

IP Filter value is 255.255.255.0

Since all of the bits in the first three octets of **IP Filter** are on and all of the bits in the last octet of IP Filter are off, the IP address of the device that is trying to establish a connection must match the first three octets of **Client's IP** value exactly, but the last octet can be anything. In this example, devices 10.20.30.0 through 10.20.30.255 would be allowed to connect.

Session Type can be TN2370, Op Console (operating system console), or printer

DHD (Defer Host Disconnect) indicates whether or not the session is enabled for Deferred Host Disconnect, a function that allows a client to stay virtually connected to the OSA-ICC even though it may be turned off.

Note: Each z/OS Master Console input/output console session with the DHD option enabled must have a unique LU name to ensure session auto-reconnection and MSC console recovery occurs correctly. See **LU Name**, described previously in this section.

DHDTO (Defer Host Disconnect Time Out): amount of time to wait (in seconds) until OSA-ICC tells the host that the client session has disconnected.

RSP (Response Mode): indicates whether telnet response mode is enabled or disabled. If enabled, the host waits for the client emulator to send an telnet acknowledgement for every packet that is transmitted.

Note:

It is highly recommended that all clients are enabled for Response Mode.

RTO (Response Time Out): specifies how long to wait (in seconds) for a response from the client before performing a client disconnect. The default RTO is 60. The valid range for RTO is 5-300.

Note:

- 1. The phrase Response Time Out and Read Time Out are synonymous for OSA-ICC
- 2. If no RTO is specified, the Missing Interrupt Handler (MIH), or equivalent on the host operating system, should be disabled.
- 3. If an RTO value is specified, MIH should be set to at least 50% greater than the RTO value. MIH is set via the operating system.
- 4. For TLS connected sessions, the recommended value for RTO is 90 seconds.

Display active server configuration

The **Display active server configuration** window is used to display the active TCP/IP connection configuration information about the physical port.

IPv6 protocol support is enabled bringing z14 GA2 code with config off/on or IML. You can configure an IPv4-only, IPv6-only, or both IPv4 and IPv6.

IBM Support Element	
Home Advanced Facilities - PC.	೮×
Server Configuration - PCHID	0178
Channel ID: 0178	
LAN port type: OSA-ICC	C 3270
Physical Port 0 Server name:	P0_178 + 10.55.1.191 /+ 24 3270 3271 →
 ✓ Secure For port (F-66666). ✓ Enable IPv6 Address type: 	Link Local
Host IPv6 address / prefix:	* fe80::9abe:94ff:fe79:11c2 /* 64
IPv6 TCP port (1-65535):	6270
IPv6 secure TCP port (1-65535):	62/1
MTO size (B):	1492
Physical Port 1 Server name: © Enable IPv4 Host IPv4 address / prefix:	P1_178 + 10.55.2.191 /∗ 24 문
IPv4 TCP port (1-65535): IPv4 secure TCP port (1-65535):	3272
	Link Local
Host IPv6 address / prefix: IPv6 TCP port (1-65535): IPv6 secure TCP port (1-65535): MTU size (B):	+ fe80::9abe:94ff:fe79:11c3 /+ 64
TLS version: TLS 1.0	
IPv6 default gateway + 10.55.1	1.1
Close Help	

Figure 17. Display active server configuration window

For **IPv4** configuration:

Enable IPv4

configures the port with an IPv4 address.

Note: If this is not selected, the IPv4 configuration is disabled.

Server Name

specifies the name of the server to which a client is connected. This name will show up in the 3 line logo that gets sent to all connected clients at the end of a successful telnet negotiation. It is for display only and is not used in tn3270e negotiation or data flow. An example of a 3 line logo is provided in "Logo Controls" on page 54.

Host IPv4 Address/prefix

specifies the IP address and prefix associated with this physical port of the OSA-ICC . Prefix to represent the mask in CIDR format.

CIDR notation is a compact representation of an IP address and its associated routing prefix. The notation is constructed from an IP address, a slash ('/'), and a decimal number. The number is the count of leading 1 bits in the subnet mask.

IPv4 Secure TCP Port

specifies the port that server will use to connect with the client without encryption. Valid Range is 1-65535. Set to 0 to disable port.

IPv4 Default Gateway

specifies IP address gateway to clients that are on a different subnet than the OSA_ICC.

MTU Size(B)

specifies the maximum transmission unit (size) to be transferred in one frame. The valid range is from 64–1492 bytes. Refer to your network administrator to determine the maximum frame size your LAN can support.

For IPv6 configuration:

Enable IPv6

configures the port with an IPv6 address.

Note: If this is not selected, the IPv6 configuration is disabled.

Address type

specifies the address type, either local address IPv6 or static address IPv6.

Link-local: local IPv6 address assigned during network initialization.

Static: user-specified IPv6 address.

Host IPv6 Address/prefix

specifies the IP address and prefix associated with this physical port of the OSA-ICC . Prefix to represent the mask in CIDR format.

Note: If Address type link local is selected then auto generated link local IPv6 address is assigned and Host IPv6 Address/prefix is grayed out. You cannot edit system generated link local address.

IPv6 TCP Port

specifies the port that server will use to connect with the client without encryption. Valid Range is 1-65535. Set to 0 to disable port.

IPv6 Secure TCP Port

specifies the port that server will use to connect with the client without encryption. Valid Range is 1-65535. Set to 0 to disable port.

IPv6 Default Gateway

specifies IP address gateway to clients that are on a different subnet than the OSA_ICC.

For **TLS** version, the TLS protocol selection feature is enabled through bringing z14 GA2 code config off/on or IML.

TLS protocol VERSION specifies the minimum TLS protocol version to be supported on the PCHID. And it can be selected via drop down box on the Edit Server configuration panel. There is only one TLS protocol version per adapter.

Note: By default, TLS version 1.0 is set.

The supported TLS versions are 1.0, 1.1 and 1.2.

If TLS 1.0 is selected, the OSA-ICC 3270 server allows secured client connections for protocols TLS 1.0, TLS 1.1, and TLS 1.2.

If TLS 1.1 is selected, the OSA-ICC 3270 server allows secured client connections for protocols TLS 1.1 and TLS 1.2.

If TLS 1.2 is selected, the OSA-ICC 3270 server allowx secured client connections for protocol TLS 1.2.

Chapter 5. Configuring OSA-ICC

Configuring your OSA-ICC results in the creation of a configuration file containing session and server configuration information on the SE disk. You can create or modify this file by entering data into the fields of Panel Configuration Options Task or by using a text editor to manually add or delete entries into the file directly. Panel entry requires that you move through a series of data entry panels and enter configuration data and complete the required fields. Panel entry is especially convenient if you want to make a small number of changes to your configuration file. Once the configuration file is created, regardless of whether it was created via the panel or manual entry methods, either interface can be used to update the file.

Note: In order to make the imported source file the active configuration, you must edit the source file (optional), validate the source file and then activate it. For more information about editing, validating, and activating source files see, <u>"Edit source file" on page 39</u>, <u>"Validate source file" on page 45</u> and <u>"Activate configuration" on page 46</u>. In addition, you may want to export your source file as a backup. For more information on exporting, see <u>"Export source file" on page 37</u>.

Important note:

The OSA-ICC configuration file is generated every time the user configures the pchid on/off or enters Advanced facilities. Therefore, partial editing sessions are not allowed. To save a configuration to an OSA-ICC card, you must validate/activate the configuration. If you wish to save a partially edited configuration file, the user should export the source file via USB or ftp in the Manual Configurations Options window.

Important note:

If you try to activate a configuration that has validation errors in it, the configuration file will be returned to the last good configuration. Validation Warnings are allowed (return code < 1000 are considered warnings). Configurations with warnings can be successfully activated.

Panel configuration options

The *Panel configuration options* window is the high level selection window for the configuration options that are used for editing a session or server configuration, validating window values, and/or viewing validate window values errors. To choose a window configuration option, select an option and click OK.

Edit server configuration

The *Edit server configuration* window is used to edit the server configuration for a given OSC.

- If a user wishes to disable a given port the values for Host IP address, TCP port and Subnet Mask must be set to the default state (zero).
- At least one port must be defined at a given time in order for the server to be enabled. Setting a Port number (whether it is the Secure or non-Secure Port) to 0 will disable that connection port type for that OSA-ICC Server IP Address. Figure 18 on page 28 shows Port 1 disabling Secure Connections to it.

Note: To enable only Secure connections to an OSA-ICC Server, set the TCP Port fields in each Physical Port Definition Section to 0. This will disable all non-secure traffic to this OSA-ICC IP Address.

IBM Support Element
Home Advanced Facilities - PC 🖸 🗙
Server Configuration - PCHID0178
Channel ID: 0178 LAN port type: OSA-ICC 3270
Physical Port 0 Server name: P0_178
Physical Port 1 Server name: P1_178
IPv6 TCP port (1-65535): 6272 IPv6 secure TCP port (1-65535): 6273 MTU size (B): 1492 TLS version: TLS 1.0 IPv6 default gateway • 10.55.1.1 IPv6 default gateway • ::
Close Help

Figure 18. Edit server configuration window

The Edit server configuration window is used to edit the server configuration for a given OSC.

IPv6 protocol support is enabled bringing z14 GA2 code with config off/on or IML.

- 1. You can configure an IPv4-only, IPv6-only, or both IPv4 and IPv6.
- 2. If both the check boxes (Enable IPv4 and Enable IPv6) are not selected then the given port is disabled
- 3. At least one port must be defined at a given time in order for the server to be enabled. Setting a Port number (whether it is the Secure or non-Secure Port) to 0 will disable that connection port type for that OSA-ICC Server IP Address. Figure 18 on page 28 shows Port 1 disabling Secure Connections to it.
- 4. Use this drop down box to select the minimum TLS protocol version(1.0 or 1.1 or 1.2) to be supported on the PCHID.

Note: By default, TLS version 1.0 is set.

Note: To enable only Secure connections to an OSA-ICC Server, set the TCP Port fields in each Physical Port Definition Section to 0. This will disable all non-secure traffic to this OSA-ICC IP Address.

The Edit server configuration window requires the following input:

For IPv4 configuration:

Enable IPv4

configures the port with an IPv4 address.

Note: If this is not selected, the IPv4 configuration is disabled.

Server Name

specifies the name of the server to which a client is connected. This name will show up in the 3 line logo that gets sent to all connected clients at the end of a successful telnet negotiation. It is for display only and is not used in tn3270e negotiation or data flow. An example of a 3-line logo is provided in "Logo Controls" on page 54.

Host IPv4 Address/prefix

specifies the IP address and prefix associated with this physical port of the OSA-ICC . Prefix to represent the mask in CIDR format.

CIDR notation is a compact representation of an IP address and its associated routing prefix. The notation is constructed from an IP address, a slash ('/'), and a decimal number. The number is the count of leading 1 bits in the subnet mask.

IPv4 Secure TCP Port

specifies the port that server will use to connect with the client without encryption. Valid Range is 1-65535. Set to 0 to disable port.

IPv4 Default Gateway

specifies IP address gateway to clients that are on a different subnet than the OSA_ICC.

MTU Size(B)

specifies the maximum transmission unit (size) to be transferred in one frame. The valid range is from 64–1492 bytes. Refer to your network administrator to determine the maximum frame size your LAN can support.

Note: This field is applicable to both IPv4 and IPv6 connections.

For IPv6 configuration:

Enable IPv6

configures the port with an IPv6 address.

Note: If this is not selected, the IPv6 configuration is disabled.

Address type

specifies the address type, either local address IPv6 or static address IPv6.

Link-local: local IPv6 address assigned during network initialization.

Static: user-specified IPv6 address.

Host IPv6 Address/prefix

specifies the IP address and prefix associated with this physical port of the OSA-ICC . Prefix to represent the mask in CIDR format.

Note: If Address type link local is selected then auto generated link local IPv6 address is assigned and Host IPv6 Address/prefix is grayed out. You cannot edit system generated link local address.

IPv6 TCP Port

specifies the port that server will use to connect with the client without encryption. Valid Range is 1-65535. Set to 0 to disable port.

IPv6 Secure TCP Port

specifies the port that server will use to connect with the client without encryption. Valid Range is 1-65535. Set to 0 to disable port.

IPv6 Default Gateway

specifies IP address gateway to clients that are on a different subnet than the OSA_ICC.

For **TLS** version, the TLS protocol selection feature is enabled through bringing z14 GA2 code config off/on or IML.

1. Use the drop down box to select the minimum TLS protocol version(1.0 or 1.1 or 1.2) to be supported on the PCHID

Note: By default, TLS version 1.0 is set.

- 2. Downgrading the protocol version **does not terminate** the SSL sessions that are active on higher protocol version. That is,
 - Have sessions connected at protocol version 1.2
 - Edit the server config panel and change the protocol version to 1.1
 - Validate and activate
 - Upon activate, sessions connected with protocol 1.2 will not be terminated.
- 3. Upgrading the protocol version **does not terminate** the SSL sessions that are active on lower protocol version. That is,
 - Have sessions connected at protocol version 1.0
 - Edit the server config panel and change the protocol version to 1.1
 - Validate and activate
 - Upon activate, sessions connected with protocol 1.0 will not be terminated.

Note: The recommended value for MTU is 1492.

Edit session configuration

The *Edit session configuration* window is used to edit the session configuration for a given OSC. This includes a list of the sessions that are configured for the OSC and configuration information about each session. To open the **Edit session configuration** window, select Edit sessions configuration from the **Panel configuration options** window:



Figure 19. Panel configuration options window

The following is the **Edit session configuration** window:

Edit Sessions Configuration - PCHID0148

To change session data, select a line and click "Change".

Channel ID:

LAN port type:

i

0148 OSC-ICC 3270

ect	Session Index	State	CSS	MIFID	Device Number	LU Name	Client's IP	IP Filter	Session Type	DHD	DHDTO	RSP	RTO
0	1	Available	0	01	0560	CONSOLE_001	0.0.0.0	255.255.255.255	Op Console	Disabled	0	Disabled	90
0	2	Available	1	01	0561	CONSOLE_002	0.0.0.0	255.255.255.255	TN3270	Enabled	86400	Enabled	90
0	3	Def Error	2	0D	0562	CONSOLE_003	0.0.0.0	255.255.255.255	Op Console	Disabled	0	Enabled	60
	4	Available	0	0B	0563	CONSOLE_004	0.0.0.0	255.255.255.255	TN3270	Disabled	0	Disabled	30
	5	Available	2	01	0564	CONSOLE_005	0.0.0.0	255.255.255.255	Printer	Disabled	0	Enabled	30
	6	Available	2	08	0564	CONSOLE_006	0.0.0.0	255.255.255.255	TN3270	Disabled	0	Enabled	30
	7	Available	2	08	0565	CONSOLE_006	0.0.0.0	255.255.255.255	TN3270	Disabled	0	Enabled	30
	8	Available	2	08	0566	CONSOLE_006	0.0.0.0	255.255.255.255	TN3270	Disabled	0	Enabled	30
	9	Available	2	08	0567		10.21.1.252	255.255.255.255	TN3270	Disabled	0	Enabled	30
0	10	Available	2	08	0561	CONSOLE_007	10.21.1.253	255.255.255.255	Op Console	Enabled	46400	Enabled	30
	11	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60
	12	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60
	13	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60
	14	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60
	15	Not configured	0	00	0000		0.0.0.0	255.255.255.255	Unknown	Disabled	0	Disabled	60

Save Change Cancel Help

Figure 20. Edit session configuration window

To edit a field:

- 1. Select the radio button for the entry you want to edit
- 2. Click the change button at the bottom of the window
- 3. Make any desired changes. Be sure to scroll down to view all the fields that you can edit. For a description of the fields, see the field descriptions below.
- 4. Click OK to save the updated session information or the information will be lost.
- 5. Click Save on the Edit Session Configuration window or the information will be lost.
- 6. Validate and activate your changes. For more information on validating and activating see <u>"Validate</u> panel values" on page 33 and <u>"Activate configuration" on page 46</u>. In addition, you may want to export your configuration as backup. For more information on exporting, see <u>"Export source file" on</u> page 37.

Important Note: If you try to activate a configuration that has validation errors in it, the configuration file will be returned to the last good configuration. Validation Warnings are allowed (return code < 1000 are considered warnings). Configurations with warnings can be successfully activated.

Index specifies the session number.

State specifies whether the session is not configured, available, or has a definition error:

- Not configured: the session has not yet been configured.
- Available: the session has been configured and the client can connect to it.
- Definition error: the session is not a valid session and the client cannot connect. The session CSS, MIFID, or Device Number does not exist or was dynamically deleted during dynamic I/O.

CSS specifies the logical channel subsystem (LCSS) ID number. A valid range for CSS is 0-5.

MIFID is the logical partition MIF image ID. It specifies the logical partition within the LCSS with which the device will communicate. A valid range for the Image Id is 1–F.

Device Number is a number assigned for each device that was defined in the IOCDS.

LU Name defines a group or pool of devices which identifies what session you are going to connect to. See <u>"Client connection rules" on page 3</u> for more information. You can specify a unique LU Name for a connection, or the same LU Name spread across multiple entries. You may also omit this field and connect to a particular host session via the client's IP address.

Client's IP (optional) specifies the IP address that a client will use to connect to the session. The client's IP address can remain 0.0.0.0 or empty in order to allow any client to connect to a specific session. If a non-zero IP is specified, any client with a non-matching IP will be rejected.

IP Filter gives a range of client IP addresses that are allowed to connect through a given physical port. This IP filter is only applicable when the client's IP address is specified.

Session Type can be TN2370, Op Console (operating system console), or printer.

DHD (Defer Host Disconnect): indicates whether or not the session is enabled for Deferred Host Disconnect (a function that allows a client to stay virtually connected to the OSA-ICC even though it may be turned off).

1. Disable

Immediately notify host OS of a disconnect

After reconnecting, a manual Vary on-line (at an alt zOS Ops Console) must be performed to reconnect the Session.

2. Enable with defaulted deferment of 60 seconds

Wait for 60 seconds before notifying host OS

- If reconnected within 60 seconds, simulate a "3270 Clear key"
- z/OS MCS console support will reformat the screen and continue
- 3. Enable with no timeout for deferment

Never notify the host OS (will leave in disconnected state)

4. Enable with user specified defaulted deferment

The same as item 2 in this list, with a different time value

DHDTO (Defer Host Disconnect Time Out): amount of time to wait (in seconds) until OSA-ICC tells the host that the client session has disconnected.

RSP (Response Mode) indicates whether response mode is enabled or disabled. If enabled, the host waits for the client to send an acknowledgement on the Telnet level for every read, write, or packet it receives.

Note:

It is highly recommended that all clients are enabled for Response Mode.

RTO (Response Time Out) specifies how long to wait (in seconds) for a response from the client before performing a client disconnect. The valid range for RTO is 5-300.

Note:

- 1. The phrase Response Time Out and Read Time Out are synonymous for OSA-ICC
- 2. If no RTO is specified, Missing Interrupt Handler (MIH) should be disabled. If an RTO value is specified, MIH should be set to at least 50% greater than the RTO value. MIH is set via the operating system.
- 3. For TLS connected sessions, the recommended value for RTO is 90 seconds.
- 4. The default RTO is 60 seconds.

Edit Session Co	onfiguration - PCHID0148	i
Channel ID: 0 [°] LAN port type: 0 Session Index Session state CSS Value	I48 SC-ICC 3270 2 Available	
MIFID	1	
Device number	0561	
LU name	CONSOLE_002	
Client's IP address	* 0.0.0.0	
IP Filter	* <mark>255.255.255.255</mark>	
Session type • TN3270 Operat	or <u>C</u> onsole <u>P</u> rinter	
Disable Enable with defaul Enable with <u>n</u> o tim Enable with <u>u</u> ser s	ted deferment of <u>6</u> 0 seconds eout for deferment pecified defaulted deferment	
D Basponse mode	efer host disconnect time value (seconds) 86400	
• <u>E</u> nable <u>D</u> isable		
Note: If tin Read Timeout Low (<u>5</u> second) Medium (10 second) High (60 seconds) User specified time	the response mode is enabled, then the timeout is specified via the neout value setting.	read
R	ead timeout value (seconds) 90	(5 -
If this session is activeOKDelete Session	then changing configurations can cause client connection to drop.	000)

Figure 21. Edit session configuration window

To remove a session definition, click Delete Session on the bottom of the window.

Validate panel values

The Validate panel values window is used to validate any values entered in the configuration windows.

Note:

- 1. In order to make your validated session the active configuration, you must activate it. For more information about activating see <u>"Activate configuration" on page 46</u>. In addition, you may want to export your source file as a backup. For more information on exporting, see <u>"Export source file" on page 37</u>.
- 2. 2. For a list of errors and warnings that you might receive after validating, see <u>Chapter 11</u>, "Error and warning messages," on page 91.

If you receive errors during your validation, you must fix them before you can activate the configuration. If you receive warnings during your validation, you may still activate your configuration. However, it is suggested that you address these warnings and re-validate before you activate your configuration.



Figure 22. Validate panel values window

Display validate panel errors

The **Display validate panel errors** window is used to view any errors you might have received while validating. For a list of errors and warnings that you might receive, see <u>Chapter 11</u>, "Error and warning messages," on page 91.

// @@@ Error 1010 Session 2 and session 1 are defining same device; i.e. same css/mifid/device

Figure 23. Display validate panel errors window

Other Examples of Error and Warning Messages :

// @@@ Error 1126: This Session # has already been configured

// @@@ warning: This session is in Definition Error state

Chapter 6. Manually configuring OSA-ICC

Configuring your OSA-ICC results in the creation of a session configuration file on the SE disk. You can create this file by entering data via window entry or by manually editing the file. The window entry requires that you move through a series of data entry windows and enter configuration data in those windows. Your other option is to edit your configuration manually using your favorite workstation editor. Manual editing is faster for changing multiple data entries because of the editing capabilities of most workstation editors.

You can edit the configuration file on your Hardware Management Console or SE console or you can export the configuration file via FTP or to a USB or other supported device, edit it using the editor of your choice, and import back to the SE. You can also edit the configuration file directly on the SE console by selecting the *Edit source file* window under the *Manual configurations options* window.

Note: In order to make the imported source file the active configuration, you must edit the source file (optional), validate the source file and then activate it. For more information about editing, validating, and activating source files see, <u>"Edit source file" on page 39</u>, <u>"Validate source file" on page 45</u> and <u>"Activate configuration" on page 46</u>. In addition, you may want to export your source file as a backup. For more information on exporting, see "Export source file" on page 37.

Important note:

The OSA-ICC configuration file is generated every time the user configures the pchid on/off or enters Advanced facilities. Therefore partial editing sessions are not allowed. To save a configuration to an OSA-ICC card, you must validate/activate the configuration. If you wish to save a partially edited configuration file, the user should export the source file via USB or ftp in the Manual Configurations Options window.

Important note:

If you try to activate a configuration that has validation errors in it, the configuration file will be returned to the last good configuration. Validation Warnings are allowed (return code < 1000 are considered warnings). Configurations with warnings can be successfully activated.

Important Note: If you try to activate a configuration that has validation errors in it, the configuration file will be returned to the last good configuration. Validation Warnings are allowed (return code < 1000 are considered warnings). Configurations with warnings can be successfully activated.

Manual configurations options

The *Manual configurations options* window is the high level selection window for the manual configuration options that are used for importing a source file, exporting a source file, editing a source file, and validating a source file. Manual configuration is the most efficient way to create a configuration file because it allows you to create and modify a configuration file with the editor of your choice.

To choose a manual configuration option, select a utility option and click OK.

Manual	Configuration Options - PCHID0148	
Channel ID: LAN port type	0148 :OSC-ICC 3270 file options	
Import sou Export sou Import sou Export sou Edit sourc Validate so	urce file urce file urce file by FTP urce file by FTP e file ource file	
Note:	After source file has been validated, you must use the Activate Configuration function on the Advanced Facilities panel to make it active, or your present changes will be log	st.
OK Cance	Help	

Figure 24. Manual configuration window

Import source file

If you have previously saved a copy of a OSA-ICC configuration, it must be imported before the changes can be applied.

Steps for importing a configuration file

Before you begin: You must be aware of the naming requirements for a configuration file. These requirements are that the filename has a maximum of eight characters.

- 1. Insert USB device into SE or HMC. If you are working from the SE, your import will be from the SE. If you are working from the Hardware Management Console, the import will be from the Hardware Management Console. If your Hardware Management Console is in single object operation, you must insert the USB or other supported device in the SE.
- 2. From the *Manual configuration options* window select *Import source file*. The *Import source file* window appears with a list of all the files on the disk.

For example:



Figure 25. Import source file window

3. Highlight the file you would like to import and click OK. The file you specified will be imported.

Note: The OSA-ICC can only import one file at a time. Subsequent imports will overwrite the present configuration you are working on even if the remote file has a different name.

Warning: Although you can import any file listed, trying to validate and activate a file that is not a configuration file will fail.

Export source file

The *Export source file* window is used to export a session configuration file to a USB or other supported device so you can save your configurations or edit the configuration file with your editor.

Steps for exporting a configuration file

Before you begin: You must be aware of the naming requirements for a configuration file. These requirements are that the filename has a maximum of eight characters.

- Insert USB flash drive or other supported device containing the source file into your USB flash drive or other supported device. If you are working from the SE, your export will be from the SE. If you are working from the Hardware Management Console, the export will be from the Hardware Management Console. If your Hardware Management Console is in single object operation, you must insert the USB or other supported device in the SE.
- 2. From the *Manual configuration options* window select *Export source file*. The *Export source file* will appear.

For example:



Figure 26. Export source file window

3. Type in the name to be given to the exported configuration file in the Export source file name field and click OK.

Import source file via FTP

If you exported a configuration file for editing you must import it in order to use it.

Steps for importing a configuration file via FTP or SFTP

Before you begin: You must be aware of the naming requirements for a configuration file. These requirements are that the filename has a maximum of eight characters.

1. From the *Manual configuration options* window select *Import source file via FTP*. The *Import source file via FTP* will appear.

For example:



Please enter the source information (IP address, userid, password, and file name) that will be used for importing, then click "OK".

Target: PCHID:0148 Configuration Source

IP address	*
User identification	*
Password	*
Fully qualified file name	*
Use secure FTP OK Cancel Help	

Figure 27. Import source file via FTP window

2. Enter the IP address, user identification, password, and fully qualified file name and click OK. The file you specified will be imported. You can choose to import your file securely by clicking the Use secure FTP option on the transfer window.

Warning: Although you can import any file listed, trying to validate and activate a file that is not a configuration file will fail.

3. Edit (optional), validate your imported source file, and activate the configuration. For an example of a source file, see "Example of a correct configuration file with warning" on page 40.

Export source file via FTP

The **Export source file via FTP** panel is used to export a session configuration file via FTP so you can edit the configuration file with your editor. You can also use this panel to export your configuration options as a backup.

Steps for exporting a configuration file via FTP

Before you begin: You must be aware of the naming requirements for a configuration file. These requirements are that the filename has a maximum of eight characters.

1. From the *Manual configuration options* window select *Export source file via FTP*. The *Export source file via FTP* will appear.

For example:



Figure 28. Export source file via FTP window

2. Type in the IP address, user identification, password, and fully qualified file name to be given to the exported configuration file and click OK. You can choose to import your file securely by clicking the Use secure FTP option on the transfer window.

Edit source file

If you have exported your configuration file, you can use a workstation editor of your choice. Otherwise you can edit the file from the *Edit source file* window.

Note: In order to make the edited source file the active configuration, you must import the source file (only if you are using a workstation editor and not the edit source file window), validate the source file, and then activate it. For more information about exporting, validating, and activating source files see, "Import source file" on page 36, "Validate source file" on page 45 and "Activate configuration" on page 46.

Steps for editing a source file

- 1. From the **OSC manual configuration** window select **Edit source file**. Your source file will be displayed.
- 2. Make any necessary changes and save. For an example of a source file see, <u>"Example of a correct</u> configuration file with warning" on page 40.
- 3. Validate your source file to check for any errors. If the file did not validate error free, the errors messages will appear directly in your source file. For an example of a source file with errors in it see, "Example of a configuration file with an error" on page 42.

Sections of the configuration file

There are three sections contained in the configuration file – only two of which are necessary for configuration.

- 1. The first Section is an informational comment section. All comments are proceeded with the // symbol. This section provides status on what time and version of code was used to generate the configuration file. The user is not required to add these comments to configuration files they generate themselves. It is purely informational. Typical information that could be provided (subject to change) is as follows:
 - // This file has been generated from the binary file /console/data/iqzc0148.hut
 - // by the SE ICC Java Code on 2016.02.26-19:09:05
 // Java Code Level= 605 OSA Code Version= 0
 - // Java code Level= 605 USA code version= 0
 // Certificate Activate Time 2016.02.26-19:09:03
 - // Certificate Create Time (only full if this chpid created Certs) N/A
 - // Certificate Files Date created on SE2016.02.19-13:03:52
- 2. The second section is called the Server Configuration section and includes parameters about the OSC Server definitions. Tags are used in the file, to delineate certain information relating to the configuration. In the file, the first line of the server section must be **<OSC_SERVER>** and the last line of the server section must be **</OSC_SERVER>**.

Within the **<CONFIG_SESSION>** section of the file are the individual session configuration parameters. Each set session parameters begins with the **<SESSION***x>* tag and ends with the **</ SESSION***x>* tag where *x* is the index number of the TN3270 session within the configuration. In addition to the previous session definition tags, the dual-port defined sessions contain a new IP_FILTER tag.

3. The third section of the configuration file includes parameters about the TN3270E sessions you want to configure on your OSA-ICC. You can configure up to 120 sessions on an OSA-ICC.

Note: Only 48 of these sessions can be active on a Secure TCP port connection at one time.

The first line of the session section must be **<CONFIG_SESSION>** and the last line must be **</ CONFIG_SESSION>**.

Within the **<CONFIG_SESSION>** section of the file are the individual session configuration parameters. Each set of session parameters begins with the **<SESSION***x***>** tag and ends with the **</SESSION***x***>** tag where *x* is the index number of the TN3270 session within the configuration.

Example of a correct configuration file with warning

The following is an example of a configuration file. This example matches the window and Manual Configuration window examples given throughout the document

```
// This file has been generated from the binary file /console/data/iqzc0148.hut
// by the SE ICC Java Code on 2016.02.26-19:09:05
// Java Code has been generated by the binary file /console/data/iqzc0148.hut
// Java Code Level= 605 OSA Code Version= 0
// Certificate Activate Time 2016.02.26-19:09:03
// Certificate Create Time (only full if this chpid created Certs) N/A
// Certificate Files Date created on SE2016.02.19-13:03:52
<OSC_SERVER>
<OSC_PHYSICAL_PORT0>
  HOST IP= 10.55.1.190
 SUBNET_MASK= 255.255.255.0
PORT= 3270
  SECURE_PORT= 3271
HOST_LL_ADDRESS/PREFIX= fe80::9abe:94ff:fe79:14dc/64
  ADDR_TYPE= LINK_LOCAL
  HOST_IPV6_ADDRESS/PREFIX= fe80::9abe:94ff:fe79:14dc/64
IPV6_PORT= 6270
  IPV6_SECURE_PORT= 6271
  ETHERNET_FRAME= DIX
  MTU = 1492
  NAME= 17C 0
</OSC_PHYSICAL_PORT0>
<OSC PHYSICAL PORT1>
  HOST_IP= 10.55.2.190
  SUBNET_MASK= 255.255.255.0
  PORT= 3272
```

SECURE_PORT= 3273 HOST_LL_ADDRESS/PREFIX= fe80::9abe:94ff:fe79:14dd/64 ADDR_TYPE= LINK_LOCAL HOST_IPV6_ADDRESS/PREFIX= fe80::9abe:94ff:fe79:14dd/64 IPV6_PORT= 6272 IPV6_SECURE_PORT= 6273 ETHERNET_FRAME= DIX MTU= 1492 NAME= 17C 1 </OSC_PHYSICAL_PORT1> TLS VERSION= 1.0 DEFAULT_GATEWAY= 10.55.1.1 IPV6_DEFAULT_GATEWAY= 2::1 </OSC_SERVER> <CONFIG_SESSION> <SESSION1> CSS= 00 IID= 01 DEVICE= 0560 GROUP= "CONSOLE_001" CONSOLE_TYPE= 2 RESPONSE= OFF READ_TIMEOUT= 90 </SESSION1> <SESSION2> // @@@ warning: This session is in Definition Error state CSS= 01 IID= 01 DEVICE= 0a60 GROUP= "CONSOLE_002" CONSOLE_TYPE= 1 RESPONSE= ON READ_TIMEOUT= 90 DEFER_HOST_DISCONNECT= 86400 </SESSION2> <SESSION3> CSS= 02 IID= 0D DEVICE= 0562 GROUP= "CONSOLE_003" CONSOLE_TYPE= 2 RESPONSE= ON READ_TIMEOUT= 60 </SESSION3> <SESSION4> CSS= 00 IID= 0B DEVICE= 0a61 GROUP= "CONSOLE_004" CONSOLE_TYPE= 1 RESPONSE= 0FF READ_TIMEOUT= READ_TIMEOUT= 30 </SESSION4> <SESSION5> CSS= 02 IID= 01 DEVICE= 0a62 GROUP= "CONSOLE 005" CONSOLE_TYPE= 3 RESPONSE= ON READ_TIMEOUT= 30 </SESSION5> <SESSION6> CSS= 02 IID= 08 DEVICE= 0a63 GROUP= "CONSOLE_006" CONSOLE_TYPE= 1 RESPONSE= ON READ_TIMEOUT= 30 </SESSION6> <SESSION7> CSS= 02 IID= 08 DEVICE= 0a64 GROUP= "CONSOLE_006" CONSOLE_TYPE= 1 RESPONSE= ON READ_TIMEOUT= READ_TIMEOUT= 30 </SESSION7> <SESSION8> CSS= 02 IID= 08 DEVICE= 0a65 GROUP= "CONSOLE_006" READ_TIMEOUT= 30 CONSOLE TYPE= 1 RESPONSE= ON </SESSION8> <SESSION9> CSS= 02 IID= 08 DEVICE= 0a66 RESPONSE= ON CONSOLE_TYPE= 1 READ_TIMEOUT= 30 </SESSION9> <SESSION10> CSS= 02 IID= 08 DEVICE= 0a67 GROUP= "CONSOLE_007" RESPONSE= ON CONSOLE_TYPE= 2 READ_TIMEOUT= 30 DEFER_HOST_DISCONNECT= 46400 </SESSION10> </CONFIG_SESSION>

Example of a configuration file with an error

The following is another example of a configuration file. The configuration file also includes a sample error message that you would see after validating a file and receiving a error.

```
// @@@ Error 1010: Sessions 2 and 1 are defining same device;
// i.e. same css/mifid/device
// This file has been generated from the binary file /console/data/iqzc0148.hut
// by the SE ICC Java Code on 2016.02.26-19:09:05
// Java Code Level= 605 OSA Code Version= 0
// Certificate Activate Time 2016.02.26-19:09:03
// Certificate Create Time (only full if this chpid created Certs) N/A
// Certificate Files Date created on SE2016.02.19-13:03:52
<OSC_SERVER>
<OSC_PHYSICAL_PORT0>
  HOST_IP= 10.55.1.190
  SUBNET_MASK= 255.255.255.0
PORT= 3270
  SECURE_PORT= 3271
HOST_LL_ADDRESS/PREFIX= fe80::9abe:94ff:fe79:14dc/64
  ADDR_TYPE= LINK_LOCAL
 HOST_IPV6_ADDRESS/PREFIX= fe80::9abe:94ff:fe79:14dc/64
IPV6_PORT= 6270
IPV6_SECURE_PORT= 6271
  ETHERNET_FRAME= DIX
  MTU= 1492
  NAME= 17C 0
</OSC_PHYSICAL_PORT0>
<OSC PHYSICAL PORT1>
  HOST IP= 10.55.2.190
  SUBNET_MASK= 255.255.255.0
PORT= 3272
  SECURE_PORT= 3273
HOST_LL_ADDRESS/PREFIX= fe80::9abe:94ff:fe79:14dd/64
ADDR TYPE LINK LOCAL
  HOST_IPV6_ADDRESS/PREFIX= fe80::9abe:94ff:fe79:14dd/64
IPV6_PORT= 6272
  IPV6_SECURE_PORT= 6273
  ETHERNET FRAME= DIX
  MTU= 1492
NAME= 17C_1
</OSC_PHYSICAL_PORT1>
  TLS_VERSION= 1.0
  DEFAULT_GATEWAY= 10.55.1.1
IPV6_DEFAULT_GATEWAY= 2::1
</OSC_SERVER>
<CONFIG_SESSION>
<SESSION1>
CSS= 00 IID= 01 DEVICE= 0a61 GROUP= "CONSOLE 001"
CONSOLE_TYPE= 2
                     RESPONSE= OFF
                                         READ_TIMEOUT= 90
</SESSION1>
<SESSION2>
CSS= 00 IID= 01 DEVICE= 0a62 GROUP= "CONSOLE_002"
CONSOLE_TYPE= 1
                      RESPONSE= ON
                                         READ_TIMEOUT= 90
DEFER_HOST_DISCONNECT= 86400
</SESSION2>
```

Configuration file syntax

The manual configuration file syntax includes the server and client tag identifiers and their corresponding values. These tags define the same parameters as the Panel Entry input fields, although tag syntax may be slightly different from panel defined names. For example, ETHERNET_FRAME= defines the same parameter as Frame type in the panel. The format of the manual configuration file is as shown in "An example of a correct configuration file" in the previous page. The following general rules apply to tag placement:

1. Tags that are immediately followed by an equal sign (=) need associated values.

- 2. There can be no space between the tag and the '=' sign.
- 3. There must be a space immediately after the '=' sign.
- 4. Tags can be placed in any order given that they are within the bounds of their delimiters.

- 5. Server tags must be within the server delimiters.
- 6. Session tags must be within the Inner Session Delimiter and these inner delimiters must be within the Session Definition Delimiters.

The following is a list of the tags, delimiters and their descriptions.

Server tag identifier descriptions

 \parallel

This indicates that any text until the end of the line is treated as a comment.

Note: Any user-entered comment is erased during activation.

<OSC_SERVER>

This tag indicates the beginning of the server configuration data. There can be only one such tag in the configuration file. It must be followed by the **</OSC_SERVER>** tag, or a syntax error is produced.

</OSC_SERVER>

This tag is the delimiter for the server configuration section. There can be only one such tag in the configuration file. It must be preceded by the **<OSC_SERVER>** tag, or a syntax error is produced.

HOST_IP=

This tag is used to label the Host's IP address; a value that follows it should be an IP address in dotted format (for example, 10.21.1.228). This address is assigned to the OSA-ICC server, and this is the address that TN3270E clients will be connecting to. The following is an example of using this tag: HOST_IP= 10.21.1.228. This tag is required for configuration and there is no default value.

PORT=

The server's port. The port number on which the OSA3270 server will be listening (accepting) nonsecure clients. For example, PORT= 3270. It is acceptable to use any valid port number the integer range 1 to 65535. This is a required tag for server configuration. Setting this value to 0 will block nonsecure connections to this OSA-ICC physical port.

HOST_LL_ADDRESS/PREFIX

An auto-generated Link Local address and prefix.

ADDR_TYPE=

The Address Type string can have two vaues: STATIC or LINK_LOCAL.

HOST_IPV6_ADDRESS/PREFIX=

User-configured IPv6 address and prefix that can be a Link local or static IPv6 address.

IPV6_PORT, IPV6_SECURE_PORT=

Port numbers to be used for opening IPv6 Non-SSL and SSL listen servers.

SUBNET_MASK=

Subnet mask of the network to which the OSA ICC server is connected.

ETHERNET_FRAME=

Specifies the Ethernet standard SNAP versus DIX.

MTU=

Specifies the maximum size to be transferred in one frame. A valid range is from 256–1492. A user would use an MTU size of less than 1492 when the routing equipment does not support anything above 576. This is a required tag for configuration. By default MTU is set to 576.

NAME=

The name can be up to 15 characters and is not case sensitive. Acceptable input characters include ASCII values in the range 0x21 through 0x7E. See <u>Appendix A</u>, "ASCII table," on page 103 for more information. This tag is required for configuration and there is no default value. It is displayed in the 3 line logo. See "Logo Controls" on page 54.

TLS_VERSION

Indicates the minimum TLS protocol version supported by the PCHID. It is configurable via the config source file by giving protocol version 1.0, 1.1, and 1.2. There is only one per adapter.

DEFAULT_GATEWAY

Only one per adapter.

IPV6_DEFAULT_GATEWAY

IPv6 default gateway to be configured.

Client tag identifier descriptions

<CONFIG_SESSION>

Marks the beginning of the session configuration.

</CONFIG_SESSION>

Marks the end of the session configuration.

<SESSION#>

Marks the beginning of the individual session configuration; it must be followed by the </SESSION#> tag. Everything between the <SESSION#> and </SESSION#> tags is treated as configuration data for one session. # is replaced by the corresponding index of the session. This number is in the range 1-120. Each number can be used only once.

</SESSION#>

Marks the ending of the individual session configuration; it must be preceded by the <SESSION#> tag. Client tags (tags following this definition) within this boundary beginning with <SESSION#> and ending with </SESSION#> can be defined in any order. Each tag can appear only once for a particular session.

CSS=

The channel subsystem number. The valid range is 0-5. This number is compared with IOCDS to make sure that it is defined. This tag is required for configuration and there is no default value.

MIFID= or IID=

The image ID for the session. The valid range is 1-F. This number is compared with IOCDS to make sure that it is defined. This tag is required for configuration and there is no default value.

DEVICE=

This is the device number associated to the session. This hexadecimal number will be compared with IOCDS to make sure that it is defined. The valid range is 0-65535. This tag is required for configuration and there is no default value.

GROUP=

Any valid ASCII characters except double quotes. The name must be included in double quotes. Acceptable input characters include ASCII values in the range displayed in <u>Appendix A</u>, "ASCII table," on page 103. This tag is required for configuration and there is no default value.

CLIENT_IP=

This is the IP address that the client will use to connect to this session. CLIENT_IP should be in a dotted decimal format, for example, 10.21.1.252. Specifying a CLIENT_IP is optional. However, omitting this tag r will allow any client to connect to a specific session.

CONSOLE_TYPE=

Specifies the session type: 1 (TN3270), 2 (master system operator console) or 3 (printer). The default configuration file should contain number descriptions in the comments next to the line with this tag. This is a required tag for configuration it is defaulted to: CONSOLE_TYPE= 1.

DEFER_HOST_DISCONNECT=

Indicates the amount of time to wait (in seconds) until the session tells the host you have disconnected. For example, if you wanted to turn your PC off without the host knowing you left, you would specify a value of 0. Then, DEFER_HOST_DISCONNECT will be enabled, but no timeout for deferment will be enforced. The host will never be informed that you have logged off. For example, DEFER_HOST_DISCONNECT= 0 If this tag is not used, then Defer Host Disconnect will be disabled for particular session. If value is specified, then it will be used as a deferment timeout parameter. For example, DEFER_HOST_DISCONNECT= 120 the valid range for this parameter is 1-86400. This tag is optional for file configuration, by default there is no DHD.

Note: Each z/OS Master Console input/output console session, with the DHD option enabled: Must have a unique LU name to ensure session auto-reconnection and MSC console recovery occurs correctly. See "LU Name" in <u>"Display client connections" on page 22</u>.

RESPONSE=

Response mode can be ON or OFF; that is, enabled or disabled. This tag is optional in file configuration, by default it is OFF.

Note: It is highly recommended to set Response Mode on, RESPONSE= ON.

READ_TIMEOUT=

Read timeout (RTO) is defaulted to 60 seconds, but if the user wishes to customize this parameter, they can do so by assigning number n to read timeout, as in READ_TIMEOUT= n. The valid range for n is 5-300 seconds. This tag is optional in file configuration.

Note:

- 1. If no RTO is specified, Missing Interrupt Handler (MIH) should be disabled. If an RTO value is specified MIH should be set to at least 50% greater than the RTO value. MIH is set via the operating system.
- 2. For secure sessions, the recommended value for this parameter is 90. For non-secure sessions, the recommended value for this parameter is 60.

IP_FILTER=

The IP_FILTER tag is similar to the network subnet mask; it defines a range of IP addresses that can connect to a given session. Clients requesting to connect that fit within the range of the IP_FILTER will be allowed to connect. Likewise clients with IP addresses outside this range requesting to connect will be refused a connection. The IP_FILTER is only applicable if the CLIENT_IP tag is specified. By default this tag is assigned the value 255.255.255.255, this is equivalent to specifying a unique client IP to the session definition.

Validate source file

Once you have edited a configuration file you must validate it in order to ensure that the file is valid before activating it. Here are the steps for validating a configuration file.

Important Note: If you try to activate a configuration that has validation errors in it, the configuration file will be returned to the last good configuration. Validation Warnings are allowed (return code < 1000 are considered warnings). Configurations with warnings can be successfully activated.

Validating a manual configuration file

- 1. From the OSC manual configuration window select Validate source file.
- 2. If the source file you are validating has errors or warnings, they will be included in comments in the source file. Only the first error will be detected. Therefore, you must fix that error and validate the source file again to determine if there are any additional errors. For an example of a source file with warnings in it, see "Example of a configuration file with an error" on page 42. For a list of errors that you might receive, see Chapter 11, "Error and warning messages," on page 91. Here is the window you will see if your source file has errors:



Figure 29. OSC validate source file window

You must fix all errors (return code 1000 or greater) before activating your configuration. **If you don't, you will receive the same errors while attempting to activate and your valid source file will be lost.**

3. If the validate was successful, you will receive a message stating that validation of your source file was successful. Click OK.



Figure 30. Successful validate source file

Activate configuration

The *Activate configuration* window is used to activate a valid session configuration file. If you choose to activate a configuration file, connected sessions that have pending configuration changes will disconnect and then reconnect with the new configuration options in effect if the emulator's auto reconnect feature is enabled.

Warning: You must validate the source file before you activate the configuration. Activating a configuration makes any changes made effective immediately. This could result in active sessions being dropped.

Important Note: If you try to activate a configuration that has validation errors in it, the configuration file will be returned to the last good configuration. Validation Warnings are allowed (return code < 1000 are considered warnings). Configurations with warnings can be successfully activated.

Note: You may want to export the configuration to save it as backup. For more information on exporting, see <u>"Export source file" on page 37</u>.

Advanced Fac	ilities - PCHID0148	i
Channel ID:	0148	
LAN port type:	OSC-ICC 3270	
Select a function: View port paramet Run port diagnosti Set card mode Display client conr Display active ses Display active ses Panel configuration Manual configuration Manual configuration Display activate configuration Display activate configuration Display activate configuration Display activate configuration Debug utilities Manage security configuration	ers nections sions configuration ver configuration n options on options tion onfiguration messages ertificates	

Figure 31. Activate configuration window

Display activate configuration errors

The **Display activate configuration errors** window is used to view the file which contains configuration error messages if any exist. If a configuration validated successfully, there are no activate configuration errors.



Figure 32. Display activate configuration errors window

For a list of possible errors and warnings, see <u>Chapter 11, "Error and warning messages," on page 91</u>.

z Systems: Open Systems Adapter Integrated Console Controller User's Guide

Chapter 7. Debug utilities

The **Debug utilities** window is the high level selection window for the debug utilities that are used for debugging a problem with a session on an OSC.

To choose an OSC debug utility option, select a utility option and click OK.



Figure 33. Debug utilities window

Ping Utility

The *Ping Utility* window is used to ping an active session to verify the status of the connection. A user can also ping the server's own IP address to verify the server's connection.

Ping Utility - PCHID0148

LAN port type: OSC-ICC 3270

This ping debug utility is intended for connectivity verification and not for network performance measurement.

Client's IP address	10.21.1.215	
┌ Length (in bytes)		7
○ Default(256) ○ Custom lengt	h	
Custom length	256	(8 - 32000)
Count		7
 Default(<u>1</u>) <u>C</u>ustom count 		
Custom count	1	(1 - 10)
┌ Timeout (in seconds) ———		7
• Default(10) Custom timeou	ıt	
Custom timeout	10	(1 - 30)
OK Cancel Help		



The Ping utility requires the following input:

- Client's IP address (IPv4 or IPv6): Specifies the IP address of the device you want to ping
- Length: You can select the default length of 256 bytes or enter a custom length of between 8 and 3200 bytes
- Count: You can select the default count of 1 or enter a custom count of between 1 and 10
- Timeout: You can select the default timeout value of 10 seconds or enter a custom timeout value.

The Ping utility issues the following response:

Ping Utility - PCHID014	8	
Channel ID: LAN port type: Ping Results	0148 OSC-ICC 3270	
PING 10.21.1.215 (10.21.1.21 264 bytes from 10.21.1.215: 10.21.1.215 ping statist	15) 256(284) bytes of data. icmp_seq=1 ttl=64 time=6.54 ms tics	
<pre>1 packets transmitted, 1 red rtt min/avg/max/mdev = 6.54</pre>	ceived, 0% packet loss, time 0ms 7/6.547/6.547/0.000 ms	
		h

Figure 35. Ping Utility response

Trace route utility

The *Trace route utility* window is used to trace the route to the client interface specified by the IP address. The results of the trace route will give you every hop from OSA-ICC to the interface specified by the client's IP address.



Figure 36. Trace route utility

The trace route utility requires the following input:

- · Client's IP address: The IP address of the device you want to ping
- Max TTL: You can select the default maximum of 30 or enter a custom value of between 1 and 255
- Attempts: You can select the default number of attempts of 3 or enter a custom number of between 1 and 20
- Port: You can select the default port of 4096 or enter a custom port value of between 2048 and 60000
- Wait time in seconds: Specifies how long to wait for a trace route operation to complete.
- Extra Debug messages: If you select yes, extra debug messages are included in the result of the trace route.

The trace route utility issues the following output:

Trace Route Utility - PCHID0148		
nannel ID:	0148	
N port type:	OSC-ICC 3270	
ace Houte Hesults		
aceroute to 10.21.1.215 (10.21.1.215), 10.21.1.215 (10.21.1.215) 0.324 ms	30 hops max, 38 byte packets 3.343 ms 1.854 ms	
		1
DK		

Figure 37. Trace route utility output

Drop session

The **Drop session** window is used to drop a session from an OSA-ICC. You can use this window if you need to drop a session because you can't get to a client or you have a bad connection.

If you selected auto-reconnect during the customization of your PCOMM session, drop session will not work. The auto-reconnect option will automatically reconnect your session after you drop it.

Drop Session - P	CHID0148	
Channel ID:	0148	
LAN port type:	OSC-ICC 3270	
Enter the session index Session index	to drop.	
Note: If auto-reconnect is enabled on the 3270 emulator session, then the session will reconnect automatically after it is dropped. You may want to temporarily disable auto-reconnect before dropping the session.		

Figure 38. Drop session utility

The drop utility requires a session index number to identify which session to drop.

The drop session window requires the following input:

• Session index: specifies the session number. This is always the LT Index + 1.

Logo Controls

The *Logo Controls* window is used to enable or disable the 3 line logo sent to the client on initial telnet negotiation success – Please refer to Figure 59 on page 80.

Logo Contro	ols - PCHID0148		i
Channel ID:	0148		
LAN port type:	OSC-ICC 3270		
Enter the session index.			
Session index:	1	(1 - 120)	
 Enable Logo (client will receive logo screen - normal) Disable Logo (client will not receive logo screen - debug) 			
OK Cancel I	Help		

Figure 39. Logo Controls

The logo controls utility requires a session index from the session table number to identify which session's logo will be enabled or disabled.

The drop session window requires the following input:

- Session index: The index from the session table.
- Button selection to Enable Logo or Disable Log

Query command

The **Query Command utility** window is used as an informational query command interface to the OSA-ICC microcode. Information useful for troubleshooting can be queried via this function.

Depending on the version of ICC Firmware you might have the following set of available commands.

- help get the list of supported commands
- arp display osa arp table
- route display osa network route table
- osass display socket list z13 GA2
- osaps display osa process list z13 GA2
- osals display files
- osaps display active processes
- ip6nebr display IPv6 neighbors mac address z14 GA2
- route6 display IPv6 route table z14 GA2
| Query Cor | mmand - PCHID0148 | i |
|-----------------|-----------------------------|---|
| Channel ID: | 0148 | |
| LAN port type: | OSC-ICC 3270 | |
| Enter query com | mand text, then click "OK". | |
| Query command: | help | |
| OK Cancel | Help | |

Figure 40. Query command

The query command utility requires an input command. Some commands may require additional input parameters. For a list of supported commands type help. A supported command is further explained by entering help then the command name.

Channel ID:	0274	
_AN port type:	OSA-ICC 3270	
Query Command Results		
Supported query commands are:		
1. help		
2. route		
3. arp		
4. osass		
o. osaps		
. qdump		
/. osamsg		
3. osals		
9. routeo		
10. iponebr		
To find out more about each command use:		
help [command]		

Figure 41. Query command help information

The query command window requires the following input:

- Name of command
- Command parameters

The results of a query command are displayed on a window after successful execution of that command.

	Command - PCHID014	8
LAN port typ Query Comr	e: nand Results	OSC-ICC 3270
Index	IP Address	MAC Address
1 2 3 4	10.21.2.223 10.21.1.211 10.21.2.223 10.21.1.217	00:0d:60:1c:c7:46 00:05:1b:a2:03:54 <incomplete> 00:0d:60:1c:c7:14</incomplete>
OK		

Figure 42. Query arp command output

Query Command -	PCHID0148		0149		
LAN port type: Query Command Results			OSC-IC	C 3270	
Index IP Address	IP Mask	Gateway	Flags	Ref.Count	Use Count
1 0.0.0.0 0.0.0.0 2 10.21.1.0 3 10.21.2.0	10.21.1.1 255.255.255.0 255.255.255.0	0.0.0.0	UG 0 U U	0 0 0	0 0
Flags definitions: U route is up H target is a he G use gateway R reinstate rour D dynamically in M modified from A installed by a C cache entry ! reject route	ost te for dynamic m nstalled by daem routing daemon addrconf	routing non or red or redire	irect ct		

Figure 43. Query command output for route

Query Command - I	PCHID0148		
Channel ID:		0148	
LAN port type:		OSC-ICC 3270	
Query Command Results			
======Listen Sockets		===	
Local Address:Port			
10.21.1.228:3270			
10.21.2.228:3271			
10.21.1.228:4000			
=====Conn	ections==============		
Local Address:Port	Peer Address:Port	State	
10.21.1.228:3270	10.21.1.211:49754	ESTABLISHED	
10.21.1.228:4000	10.21.1.217:4185	ESTABLISHED	
10.21.1.228:4000	10.21.1.211:49812	ESTABLISHED	
10.21.1.228:3270	10.21.1.217:4170	ESTABLISHED	
			1
OK			

Figure 44. Query command output for osass

		Query C	ommand	I - PCHID0148			
C	hanr	nel ID:			0)148	
	Ам р	on type:			C C	56-166 3270	
C	luery	Commar	nd Result	ts			
P	ID	USER	TIME	COMMAND			
	1	root	0:02	{init} /bin/sh /sbin/	init		
	2	root	0:00	[kthreadd]			
	3	root	0:00	[ksoftirqd/0]			
	4	root	0:00	[kworker/0:0]			
	5	root	0:00	[kworker/0:0H]			
	6	root	0:00	[kworker/u2:0]			
	7	root	0:00	[khelper]			
	8	root	0:00	[kdevtmpfs]			
	9	root	0:00	[netns]			
	10	root	0:00	[writeback]			
	11	root	0:00	[bioset]			
	12	root	0:00	[kblockd]			
	14	root	0:00	[kswapd0]			
	15	root	0:00	[crypto]			
	21	root	0:00	[deferwq]			
	22	root	0:00	[kworker/u2:1]			
	23	root	0:00	[k]ournald]			11.
	OK						

Figure 45. Query command output for osaps

z Systems: Open Systems Adapter Integrated Console Controller User's Guide

Chapter 8. OSA-ICC TLS Encrypted Session Support

Beginning with z13 GA2, OSA -ICC provides Transport Layer Security (TLS) encrypted session support to the OSA-ICC adapter. TLS is a widely used protocol which provides privacy between two communicating applications (generally a client and a server). With the TLS support in OSA-ICC, clients are authenticated through X.509 public key certificates. TLS requires an underlying transport protocol (usually TCP/IP) for data transmission and reception. The TLS protocol can be used to negotiate an encryption algorithm and session key before a client application transmits or receives data. Once the session key is negotiated, data is exchanged encrypted.

Key management (RSA) takes place during the TLS session "handshake". For RSA, a pre-master secret is encrypted using the server's public-key and sent by the client to the server. The pre-master secret is decrypted by the server using the server's private-key, so that client and server then share the pre-master secret. The pre-master secret is used to generate the symmetric key used for data transmission over the TLS session.

OSA-ICC provides:

- Encryption of data for privacy and integrity
- Tunneling of other TCP/IP-based sessions (such as TN3270e) over encrypted channels.

Note: OSA-ICC supports certificates of up to 16 KB.

x.509 Certificate Management

Limited OSA-ICC TLS key management is provided. A single key, self-signed X.509 certificate, and certificate request is stored on the password protected SE and in the configuration information stored on the OSA adapter. The customer is expected to manage and secure additional certificates if required.

The certificate and key are protected by checksum and date on the closed SE system. The checksum and date are verified every time the key/certificate is loaded by the OSA-ICC adapter.

OSA-ICC Encryption Assumptions (subject to change as enhanced protocols and encryption methods become available):

- Support both per PCHID certificate and per Z system certificate
- Support will be provided for Transport Layer Security TLS1.0, TLS1.1, and TLS 1.2
- 256 (Secure Hash Algorithm) SHA-2 with 2048 bit RSA key to be used for the handshake/certificate validation
- Advanced Encryption Standard (AES) AES-128 is the only cipher supported for the session key versus support is provided for certificates signed by a trusted CA or self-signed
- · CA-signed certificate formats supported are .pem and .p7b
- Only one self-signed certificate will be generated per system (not per OSC CHPID or card) stored in .pem format
- Enablement of secure ports will be done at the SE/HMC, and will only be allowed if the CPACF facility is enabled
- Self-signed certificates [Per chpid and Renewed system wide certificate] have 10-year expiration
- Only server side authentication is supported (no client authentication)
- If TLS-encrypted sessions are supported by the OSA-ICC , the Manage Security Certificates panel are available.

Manage Security Certificates - M51

Channel ID: 017C LAN port type: OSA-ICC 3270

OSA-ICC certificate scope: Use shared certificate

OSA-ICC certificate type: Self-signed

OSA-ICC certificate expiration: Aug 20 16:57:17 2028 GMT

Change...

Actions:

CExport self-signed certificate (.pem)

O Reload self-signed certificate

O Regenerate OSA-ICC key and self-signed certificate

O Create certificate signing request (.csr)

O Import signed certificate (.pem or .p7b)

OView certificate

Apply	Close	Help
-------	-------	------

Figure 46. Manage Security Certificates window

The new functions will be used to verify that all PCs connecting to the Secure TCP port have the appropriate keys to manage the data flow between the connections.

The following functions are supported:

OSA-ICC Certificate Scope

The scope of the currently Installed certificate on the PCHID. And It will have either of the two values from Self-signed or Certificate Authority (CA)-signed.

OSA-ICC Certificate Type

The type of the currently Installed certificate on the PCHID. And It will have either of the two values from self signed or CA signed values.

OSA-ICC Certificate Expiration

The expiration date of the currently installed certificate on the PCHID.

Export Self Signed Certificate

On first Initialization, the OSA SE microcode generates a self Signed Certificate and stores it in the configuration file and on the SE disk. When you click this button, the SE copies the file off of the SE disk and places it on a USB device or ready for ftp/sftp to an external server. By default, this certificate is loaded onto the OSA-ICC when a secure port is defined in the server configuration window.

Reload Self-Signed Certificate

Using this option, you can reload the self-signed certificate. That is, if the current scope is Individual, then per CHPID self-signed certificate is reloaded; likewise, if it shares certificate scope, then shared self-signed certificate will be reloaded.

Create Certificate Signing Request

On first Initialization, the OSA SE microcode generates a Certificate Signing Request and stores it in the configuration file and on the SE disk. When you click this button, the SE copies the file off the SE disk and places it on a USB device or ready for ftp/sftp to an external server. This file could then be sent to an external CA to create a certificate or used to generate a local certificate by an in-house certificate generation program. The resulting certificate is imported to the OSA via the "Import Certificate" function.

Import Signed Certificate

Using this option, you can import the CA signed certificate on to PCHID. Supported formats are only .pem or .p7b.

View Certificate

Using this option, you can view the currently installed active certificate contents.

If the certificate changes or expires, all connections established are terminated.

To enable this function you must configure a Secure Port in the Server Configuration window, and then apply the appropriate certificate to your client. For a client using the OSA generated self-signed certificate you must export the self signed certificate to your client, import that certificate into your workstations certificate management software, and point your client to the secure socket number. See <u>Chapter 10</u>, <u>"eNetwork Personal Communications (PCOMM) configuration," on page 77</u> for an example of how to set this up for Pcomm.

Cancel command

The *Cancel Command utility* window allows you to cancel an I/O command that is executing on an OSC.

Manage Security Certificates panel with edit certificate feature

Manage Security Certi	ficates - M51	
Channel ID: 017C		
LAN port type: OSA-ICC 3270)	
OSA-ICC certificate scope:	Use individual certificate	Change
OSA-ICC certificate type:	Self-signed	
OSA-ICC certificate expiration	n: Aug 19 18:22:00 2028 GMT	
Actions:		
OExport self-signed certification	te (.pem)	
○ Reload self-signed certific	ate	
O Create certificate signing r	equest (.csr)	
○ Import signed certificate (.p	pem or .p7b)	
OView certificate		
○Edit certificate		

Figure 47. Manage Security Certificates window

Help

Close

Edit Certificate

Apply

This option is available whenever the active certificate installed on the PCHID is with Individual scope. Using this option, you can edit the given certificate with the respective organization specific requirements. Edit certificate feature is supported for the Individual Certificate scope with self signed or CA signed certificate type values. Modifying and saving the certificate attributes terminates all of the existing console connections.

If the certificate changes or expires, all connections established are terminated.

Using a shared self-signed certificate

To configure TLS on OSA-ICC with a self-signed certificate:

- 1. Enter a non 0 value into the Secure Port Number for one or both of the OSA-ICC physical ports.
 - a. You can do this via the Window or Manual Configuration Options
- 2. Validate the Configuration
- 3. Activate the Configuration
- 4. Enter the Manage Security Certificate Window
- 5. Select Export Self-Signed Certificate
 - a. Export via USB or FTP

Note: Be sure to specify a filetype of .pem.

- 6. Copy Self-Signed Certificate to Workstation being configured for TLS encryption
- 7. On Client Workstation Import Self-Signed Certificate into Certificate Management Software provided on the Workstation (program will be unique to OS or emulator used. See Certificate management on your Workstation's Operating System or Application Software for more details)
- 8. Setup Workstation TN3270e emulator parameters
 - a. Configure OSA-ICC IP
 - b. Secure Port Number
 - c. Lu Name (Group Name)
 - d. Select TLS version and FIPS mode (if applicable)
- 9. Connect TN3270e Client

Using an externally signed certificate with a shared certificate scope

To configure TLS on OSA-ICC with an externally signed certificate:

- 1. Enter a non 0 value into the Secure Port Number for one or both of the OSA-ICC physical ports.
 - a. You can do this via the Window or Manual Configuration Options
- 2. Validate the Configuration
- 3. Activate the Configuration
- 4. Enter the Manage Security Certificate Window
- 5. Select Export Certificate Signing Request
 - a. Export via USB or FTP
- 6. Copy Certificate Request to Workstation or USB media to provide to external CA or to generate your own certificate by running through a local Certificate generator. Certificate Signing request fields cannot be modified.
- 7. Obtain CA or locally signed certificate in .pem or .p7b format
 - a. Place on media or workstation to import into OSA-ICC and Client Workstation
- 8. On OSA-ICC Select Import certificate
 - a. Import via USB or FTP
- 9. On Client Workstation Import CA or locally signed Certificate into Certificate Management Software provided on the Workstation (program will be unique to OS or emulator used. See Certificate management on your Workstation's Operating System or Application Software for more details)
- 10. Setup Workstation TN3270e emulator parameters
 - a. Configure OSA-ICC IP
 - b. Secure Port Number
 - c. Lu Name (Group Name)
 - d. Select TLS version and FIPS mode (if applicable)
- 11. Connect TN3270e Client

Switching from an external certificate to a shared self-signed certificate

To return to a self-signed certificate:

- 1. Enter the Manage Security Certificate window
- 2. Select Reload Self-Signed Certificate

- 3. Select Export Self-Signed Certificate
 - a. Export via USB or FTP
- 4. Copy Self-Signed Certificate to Workstation being configured for TLS encryption
- 5. On Client Workstation Import Self-Signed Certificate into Certificate Management Software provided on the Workstation (program will be unique to OS or emulator used. See Certificate management on your Workstation's Operating System or Application Software for more details)
- 6. Setup Workstation TN3270e emulator parameters
 - a. Configure OSA-ICC IP
 - b. Secure Port Number
 - c. Lu Name (Group Name)
 - d. Select TLS version and FIPS mode (if applicable)
- 7. Connect TN3270e Client

Using an individual self-signed certificate

To configure TLS on OSA-ICC with a self-signed certificate:

- 1. Consider Non zero secure port is defined on the PCHID and shared self signed certificate is active
- 2. On the Manage Security Certificates window, change the scope from the shared certificate to individual certificate scope.



Figure 48. Manage Security Certificates window

3. Change OSA ICC Certificate scope

Home V OSA Advanced Facilities C X	
Change OSA-ICC Certificate Scope - M88	
Choose the scope for which certificate actions will apply for PCHID 01CC. OUse the shared certificate for this PCHID ③Use an individual certificate for this PCHID	Hitting Change Certificate Scop change the scope to Use shared certificate Use individual certific
OK Cancel Help	
Home OSA Advanced Facilities 🖸 🗙	
Change OSA-ICC Certificate Scope - M88	
PCHID 01CC will be changed from using the shared certificate to use an individual certificate.	
Any existing TLS connections using the shared certificate will be terminated.	
Are you sure you want to change the certificate scope for PCHID 01CC?	
Change Certificate Scope Cancel	

Figure 49. Change OSA-ICC Certificate Scope

- 4. Select Export Self-Signed Certificate
 - a. Export via USB or FTP

Note: Be sure to specify a filetype of .pem.

- 5. Copy Self-Signed Certificate to Workstation being configured for TLS encryption
- 6. On Client Workstation Import Self-Signed Certificate into Certificate Management Software provided on the Workstation (program will be unique to OS or emulator used. See Certificate management on your Workstation's Operating System or Application Software for more details).
- 7. Set up Workstation TN3270e emulator parameters
 - a. Configure OSA-ICC IP
 - b. Secure Port Number
 - c. Lu Name (Group Name)
 - d. Select TLS version and FIPS mode (if applicable)
- 8. Connect TN3270e Client

Using an individual self-signed certificate with modifying attributes

To configure TLS on OSA-ICC with a self-signed certificate:

1. Consider the PCHID is using default individual self-signed certificate i.e perform the steps given in "Using an individual self-signed certificate"

Certificate Scope will

individual certificate.



Manage Security Certificates - M51

Channel ID: 017C LAN port type: OSA-ICC 3270

OSA-ICC certificate scope: Use individual certificate OSA-ICC certificate type: Self-signed OSA-ICC certificate expiration: Aug 19 18:22:00 2028 GMT Change...

Actions:

©Export self-signed certificate (.pem)

O Reload self-signed certificate

O Create certificate signing request (.csr)

O Import signed certificate (.pem or .p7b)

OView certificate

OEdit certificate

Apply	Close	Help
-------	-------	------

Figure 50. Manage Security Certificates window

Edit Certificate - PCHID 017C

Edit the donaits of the contrino	ute and then some changes.
Certificate type	Set signed
Subject name	
Common name	Osalo:/TLSServer
Organization	
Organization unit	
Country or region	v
State or province	×
Locality	
Valid until	Date" 518-0229 [2] Time" 16:50:00
Subject alternative name	
DNS-name	· ADO NEW
P address	③ ADD NEW
Email address	© ADD NEW
 See additional certificate 	brish
CANCEL	LAVE HELP

Figure 51. Edit Certificate window

- 2. Enter Manage security certificates panel.
- 3. Select the Edit Certification option and it will allow the user to enter all the below certificate signing request attributes
 - a. Common name,
 - b. Organization,
 - c. Organization unit,
 - d. Country or region,
 - e. State or province, Locality
 - f. And Subject Alternative Names like IP address, DNS name and Email address
- 4. After editing the attributes, click Save.

?	Save certificates changes confirmation
	Saving changes to the certificate will cause existing client trusted certificates to be invalidated for PCHID 017C.
	Do you want to save the certificate changes?
	CANCEL

Figure 52. Save certificates changes confirmation

5. Click continue, the certificate update progress appears, follows by the save successful Informational message.

GARDANCE

Dranging the certificate causes existing client-trusted certificates to be invalid. Clients must install and trust the updated certificate. Save successful (ACT05239I)

PCHID 017C certificate changes were successfully saved.

CLOSE

Figure 53. Save successful message

- 6. Click CLOSE to return to the Manage Security Certificates window.
- 7. Select View Certificate and confirm that the certificate got updated with the Step 3 changes.
- 8. Select Export Self-Signed Certificate
 - a. Export via USB or FTP

Note: Be sure to specify a filetype of .pem.

- 9. Copy Self-Signed Certificate to Workstation being configured for TLS encryption
- 10. On Client Workstation Import Self-Signed Certificate into Certificate Management Software provided on the Workstation (program will be unique to OS or emulator used. See Certificate management on your Workstation's Operating System or Application Software for more details).
- 11. Set up Workstation TN3270e emulator parameters
 - a. Configure OSA-ICC IP
 - b. Secure Port Number
 - c. Lu Name (Group Name)
 - d. Select TLS version and FIPS mode (if applicable)
- 12. Connect TN3270e Client

Using an externally signed certificate with an individual certificate scope

This scenario is applicable to both individual certificate with modified attributes or default individual selfsigned attributes:

- 1. Consider the PCHID is defined and is active with either external CA signed or individual self signed certificate
- 2. Select Export Certificate Signing Request
 - a. Export via USB or FTP
- 3. Copy Certificate Request to Workstation or USB media to provide to external CA or to generate your own certificate by running through a local Certificate generator.
- 4. Obtain CA or locally signed certificate in .pem or .p7b format.
 - a. Place on media or workstation to import into OSA-ICC and Client Workstation
- 5. On OSA-ICC Select Import certificate
 - a. Export via USB or FTP
- 6. On Client Workstation Import CA or locally signed Certificate into Certificate Management Software provided on the Workstation (program will be unique to OS or emulator used. See Certificate management on your Workstation's Operating System or Application Software for more details)
- 7. Setup Workstation TN3270e emulator parameters

- a. Configure OSA-ICC IP
- b. Secure Port Number
- c. Lu Name (Group Name)
- d. Select TLS version and FIPS mode (if applicable)
- 8. Connect TN3270e Client

Using an externally signed certificate with modifying attributes

To use an externally signed certificate with modifying attributes:

- 1. Consider the PCHID is using default individual self-signed certificate i.e perform the steps given in "Using an individual self-signed certificate"
- 2. Enter Manage security certificates panel.

Manage Security Certificates - M51
Channel ID: 017C

LAN port type: OSA-ICC 3270

OSA-ICC certificate scope: Use individual certificate OSA-ICC certificate type: Certificate Authority (CA)-signed OSA-ICC certificate expiration: Sep 18 03:59:59 2021 GMT

Actions:

- Reload self-signed certificate
- O Import signed certificate (.pem or .p7b)
- OView certificate
- Edit certificate



Figure 54. Manage Security Certificates window

- 3. Select the Edit Certification option and it will allow the user to enter all the below certificate signing request attributes
 - a. Common name,
 - b. Organization,
 - c. Organization unit,
 - d. Country or region,
 - e. State or province, Locality
 - f. Subject Alternative Names like IP address, DNS name and Email address
- 4. Modify the required attributes for the externally signed certificate and click Next button
- 5. Next export certificate signing request panel pops up so either choose FTP or USB media to get the modified certificate signing request.

Change...

Export Certificate Signing Request

Select an export method and click EXPORT.

Export to FTP server

Export to USB

Figure 55. Export Certificate Signing Request

- 6. Copy this modified Certificate Signing Request to Workstation or USB media to provide to external CA or to generate your own certificate by running through a local Certificate generator
- 7. With the above steps, the existing console sessions will not be disconnected.
- 8. Obtain CA or locally signed certificate in .pem or .p7b format
 - a. Place on media or workstation to import into OSA-ICC and Client Workstation
- 9. On OSA-ICC Select Import certificate
 - a. Import via USB or FTP
- 10. On Client Workstation Import CA or locally signed Certificate into Certificate Management Software provided on the Workstation (program will be unique to OS or emulator used. See Certificate management on your Workstation's Operating System or Application Software for more details).
- 11. Set up Workstation TN3270e emulator parameters
 - a. Configure OSA-ICC IP
 - b. Secure Port Number
 - c. Lu Name (Group Name)
 - d. Select TLS version and FIPS mode (if applicable)
- 12. Connect TN3270e Client

View self-signed certificate

This action enables you to view such currently installed certificate contents as Common name, Issuer details, Certificate validity, and encryption thumb print.

Home OSA Adva	nced Facilities - M51 X View Certificate
View C	ertificate - 0178
OsalccTL	SServer
Self-signed roo Expires: Monda	t certificate 1y, June 26, 2028 at 10:19:55 AM GMT-04:00
 See certific 	ite details
Subject name	
Common name	OsalccTLSServer
Issuer name	
Common name	OsalccTLSServer
Serial number	14918304052564694265
Version	3
Valid not after	Monday, June 26, 2028 at 10:19:55 AM GMT-04:00
Valid not before	Friday, June 29, 2018 at 10:19:55 AM GMT-04:00
Fingerprints	
SHA-1 fingerpr	nt 11 C9 DA 95 93 5D 27 32 EE 3A AF 15 73 21 2C 02 D3 BE A0 64
SHA-256 finge	print C3 CF B2 49 1D 74 D8 22 77 BF D6 20 E1 5E D1 3C

Figure 56. Certificate view

Switching from an external certificate to an Individual self-signed

To return to an individual self-signed certificate:

- 1. Consider the PCHID is defined and is active with either external CA signed or individual self signed certificate.
- 2. Enter the Manage Security Certificate window.
- 3. Select Reload Self-Signed Certificate.
- 4. Select Export Self-Signed Certificate.
 - a. Export via USB or FTP.
- 5. Copy Self-Signed Certificate to Workstation being configured for TLS encryption.
- 6. On Client Workstation Import Self-Signed Certificate into Certificate Management Software provided on the Workstation (program will be unique to OS or emulator used. See Certificate management on your Workstation's Operating System or Application Software for more details.).
- 7. Set up Workstation TN3270e emulator parameters.
 - a. Configure OSA-ICC IP
 - b. Secure Port Number
 - c. Lu Name (Group Name)
 - d. Select TLS version and FIPS mode (if applicable).
- 8. Connect TN3270e Client.

Switching from an individual self-signed to a shared self-signed (switch certificate scope)

To return to system wide shared self signed certificate:

- 1. Consider secured port is defined and is active with either external CA signed or individual self signed certificate.
- 2. Enter the Manage Security Certificate window.
- 3. Select Reload Self-Signed Certificate.
- 4. Select Export Self-Signed Certificate.
 - a. Export via USB or FTP.
- 5. If the client work station is not installed with shared self signed certificate then follow the steps (a and b) below; otherwise, go to the next step.
 - a. Copy Self-Signed Certificate to Workstation being configured for TLS encryption.
 - b. On Client Workstation Import Self-Signed Certificate into Certificate Management Software provided on the Workstation (program will be unique to OS or emulator used. See Certificate management on your Workstation's Operating System or Application Software for more details.).
- 6. Set up Workstation TN3270e emulator parameters.
 - a. Configure OSA-ICC IP
 - b. Secure Port Number
 - c. Lu Name (Group Name)
 - d. Select TLS version and FIPS mode (if applicable).
- 7. Connect TN3270e Client.

Supported cipher suites

TLSv1.0

Ciphers:

- TLS_RSA_WITH_AES_128_CBC_SHA (rsa 2048) A
- TLS_RSA_WITH_AES_256_CBC_SHA (rsa 2048) A
- TLS_RSA_WITH_CAMELLIA_128_CBC_SHA (rsa 2048) A
- TLS_RSA_WITH_CAMELLIA_256_CBC_SHA (rsa 2048) A

Compressors:

NULL Cipher preference: client

TLSv1.1

Ciphers:

- TLS_RSA_WITH_AES_128_CBC_SHA (rsa 2048) A
- TLS_RSA_WITH_AES_256_CBC_SHA (rsa 2048) A
- TLS_RSA_WITH_CAMELLIA_128_CBC_SHA (rsa 2048) A
- TLS_RSA_WITH_CAMELLIA_256_CBC_SHA (rsa 2048) A

Compressors:

NULL Cipher preference: client

TLSv1.2

Ciphers:

- TLS_RSA_WITH_AES_128_CBC_SHA (rsa 2048) A
- TLS_RSA_WITH_AES_128_CBC_SHA256 (rsa 2048) A
- TLS_RSA_WITH_AES_128_GCM_SHA256 (rsa 2048) A
- TLS_RSA_WITH_AES_256_CBC_SHA (rsa 2048) A
- TLS_RSA_WITH_AES_256_CBC_SHA256 (rsa 2048) A
- TLS_RSA_WITH_AES_256_GCM_SHA384 (rsa 2048) A
- TLS_RSA_WITH_CAMELLIA_128_CBC_SHA (rsa 2048) A
- TLS_RSA_WITH_CAMELLIA_256_CBC_SHA (rsa 2048) A

Compressors:

NULL Cipher preference: client Least strength: A MAC address: 98:BE:94:79:14:DC (IBM)

74 z Systems: Open Systems Adapter Integrated Console Controller User's Guide

Chapter 9. OSA-ICC programming considerations

3270 Client Support

The **OSA-ICC** only supports TCP/IP RFC 2355 compliant Telnet TN3270E emulator programs, such as *IBM eNetwork Personal Communications*. These clients appear to the z/OS Operating System as non-SNA, DFT terminals.

76 z Systems: Open Systems Adapter Integrated Console Controller User's Guide

Chapter 10. eNetwork Personal Communications (PCOMM) configuration

For recommended PCOMM levels for OSA-ICC, see "Recommended PCOMM levels" on page 2.

The following is an example of defining a PCOMM 3270 session. The example uses PCOMM version 6.014 for Windows. If you are using a different version, your windows may look slightly different.

When using IBM eNetwork Personal Communications (PCOMM) for client TN3270E display sessions, the following statement must be present in the PCOMM profile files (xxx.WS) to ensure that printer WCC controls are ignored if sent by the host:

[LT]

IgnoreWCCStartPrint=Y

If this statement is not present in your PCOMM profile files you will have to edit the xxx.WS files on your client PC with a PC text editor to add the statement lines.

Defining a PCOMM TN3270E session

About this task

Start from the Windows desktop - Operating System Level Dependent

Procedure

1. Select Programs --> IBM Personal Communications --> Start or Configure Sessions

The IBM Personal Communication (PCOMM) Session Manager window is displayed.

2. Click New Session

The Customized Communication window is displayed:

- Type of Host zSeries
- Interface LAN
- Attachment Telnet3270

Customize Communication

Interface: LAN Attachment: Telnet 3270 Interface Session Parameters Connection Overview Interface Attachment Type of TCP/IP TCP/IP	
Attachment: Telnet 3270 Link Parameters Connection Overview Interface Type of TCP/IP TCP/IP	
Link Parameters Session Parameters Connection Overview Interface Interface Attachment TCP/IP	
Connection Overview Interface Attachment Type of TCP/IP	
Interface Attachment Type of	
Щ	f Host
LAN Telnet3270	zSeries
This connection provides access to an IBM zSeries host over a TCP/IP network, using TN3270 or TN3270E interface. Support for Service Location Protocol, SSL V3 and TLS1.0 secure layer encryption, load balancing and backup host is also provided. This selection is used in networks that typically run TCP/IP protocols. This connectivity can also be used to connect to a host network through a firewall which supports NVT.	r -

X

Figure 57. Customize Communication window

3. Click Link Parameters

4. Define the connection from the workstation to the OSA-ICC server.

Telnet3270				— ———————————————————————————————————
Host Definition Autom	atic Host Location Security	Setup Printer	Association	
	Host Name or IP Address		LU or Pool Name	Port Number
Primary	10.21.1.228		CONSOLE_001	3270
Backup 1				23
Backup 2				23
Connection Options				
Connection Timeout	6 🕂 Se	econds		
Auto-reconnect				
Try connecting to	last configured host infinitely	/		
Keep Alive				
F Enable Telnet	Keep Alive	NOP	V	
Keep Alive Time O	ut	180	Seconds	
	[ОК	Cancel	.pply Help

Figure 58. Telnet3270 window

5. Enter the Host name or IP Address.

The values in Host Name or IP Address and Port Number were specified when defining the OSA-ICC server configuration. For more information on defining your OSA-ICC server Configuration see, <u>"Edit server configuration" on page 27</u>.

6. Enter the Port Number.

This must match the Port Number (either secure or non-secure) in the OSA-ICC Configuration

7. Enter the LU or Group Name.

This must match the LU name in the OSA-ICC server configuration.

8. Click OK on the Telnet3270 window.

Note:

a. It is recommended that you select auto-reconnect. However, understand that the drop session option for configuring an OSA-ICC will not work as expected. The auto-reconnect option will

automatically reconnect your session after you drop it. For more information on the drop session option, see <u>"Drop session" on page 53</u>.

- b. z/OS Master Console input/output console session, with the DHD option enabled:
 - Must have the auto-reconnect function enabled.
 - Must have a unique LU name to ensure session auto-reconnection and MSC console recovery occurs correctly. See "LU Name" in "Display client connections" on page 22.

Results

If you wish, use the Session Parameters option in Customize Communication to set a screen size other than 24 by 80. It is recommended that your screen size matches the operating system screen size.

For z/OS:

- Display type 3277 model 2 has a screen size of 24 rows by 80 columns.
- Display type 3277 model 3 has a screen size of 32 rows by 80 columns.

See your VTAM definitions for z/OS and your Operating System console definitions for more details.

Clicking OK on the Customize Configuration window causes PCOMM to initiate the connection to the host.

If the host session is ready for communication, the screen displayed shows your connection information for this session. For example:

과] Session A - [24 x 80]	
File Edit View Communication Actions Window Help	
<pre>** OSC Index 01 connected to 148_1 via IP Addr 10.21.1.228:3270</pre>	жж
** LT Index=00 CSSID=00 MIFID=01 CU=0 UA=60 LUName=CONSOLE_001	жж
** Type=2965-N10 Mfg=IBM SN=00000006D1D7 CHPID=0D Status=Active	жж
10.21.1.211:49754	
M <u>A</u> A	01/001
¹⁰ Connected to remote server/host 10.21.1.228 using lu/pool CONSOLE 001 and port 3270	1

Figure 59. E - Capture — [24x80]

Line 1: 148_1 is the defined server name; 10.21.1.228:3270 shows the defined server address and port number.

Line 2: session index; CSS number; MIF ID number, logical CU number (always 0); unit address for this device; LU name.

Line 3: information for the connected processor.

• Machine Type: Machine specific

- Mfg Info: set to IBM
- SN: Serial Number
- CHPID: Chpid Number
- **Status**: Active or Inactive Active denotes LPAR has been activated for this defined connection and is ready to be enabled by the Host Operating System

Important Note: When using IBM eNetwork Personal Communications (PCOMM) for client TN3270E display sessions, the following statement must be present in the PCOMM profile files (xxx.WS) to ensure that printer WCC controls are ignored if sent by the host:

[LT] IgnoreWCCStartPrint=Y UndefinedCode=Y

If these statements are not present in your PCOMM profile files you will have to edit the xxx.WS files on your client PC with a PC text editor to add the statement lines.

Defining a secure PCOMM TN3270E session

About this task

This procedure involves the following:

- 1. "Importing self-signed or CA signed certificate " on page 81
- 2. "Defining the secure PCOMM TN3270E session" on page 89

Importing self-signed or CA signed certificate

About this task

Start from the Windows desktop - Operating System Level Dependent

Procedure

1. Select Programs --> IBM Personal Communications --> Utilities --> Certificate Management

The IBM Key Management window is displayed.

2. Click the Open icon.

💯 IBM Key Management	
Key Database File Create View Help	
Key database information DB-Type:	
File Name:	
Token Label:	
Key database content	
Personal Certificates	Receive
	Delete
	Vie <u>w</u> /Edit
	Import
	Recre <u>a</u> te Request
	Rename
	Now Solf Signed
	new sen-signed
	Extract Certificate
To start, please select the Key Database File menu to work with a key database	

Figure 60. IBM Key Management, Open icon

3. From the Open window, click OK

🤼 IBM Key Management			
Key Database <u>File</u> <u>C</u> reate	<u>V</u> iew <u>H</u> elp		
		Key database information	
DB-Type:			
File Name:			
Token Label:			
		Key database content	
Personal Certificates	Open		Receive
	Key database type	CMS 🗸	Delete
	File Name:	PCommClientKeyDb.kdb Browse	
	Location:	C:\Users\kav\AppData\Roaming\\BM\PERSON~1\	Vie <u>w</u> /Edit
		<u>O</u> K <u>Cancel</u>	Import
			Recreate Request
			Rena <u>m</u> e
			New Self-Signed
			Extract Certificate
To start, please select the K	Key Database File menu	to work with a key database	

Figure 61. IBM Key Management, Open window

4. In the Password Prompt, enter **pcomm**.

🜉 IBM Key Management		
Key Database <u>F</u> ile <u>C</u> reate <u>V</u> iew <u>H</u> elp		
	Key database information	
DB-Type:		
File Name:		
Token Label:		
	Key database content	
Personal Certificates	▼	Receive
	Password Prompt	Delete
	Password:	Delete
		Vie <u>w</u> /Edit
	<u>QK</u> <u>Reset</u> <u>Cancel</u>	Import
		Recreate Request
		Rename
		New Self-Signed
		Extract Certificate
To start, please select the Key Database File menu	to work with a key database	

Figure 62. IBM Key Management, Password Prompt

5. Click the down arrow under **Key database content** to select the type of certificate and select **Signer Certificates**

👰 IBM Key Mana	igement - [C:\Users\kay\AppData\Roaming\JBM\PERSON~1\PCommClientKeyDb.kdb]			
Key Database <u>F</u> i	le <u>C</u> reate <u>V</u> iew <u>H</u> elp			
D 🗳				
	Key database information			
DB-Type:	CMS			
File Name:	C:\Users\kay\AppData\Roaming\IBM\PERSON~1\PCommClientKeyDb.kdb			
Token Label:				
	Kov database content			
Signer Certific	ates 🗸	<u>A</u> dd		
Entrust net Cer	rtification Authority (2048)	Delete		
Entrust.net Client Certification Authority				
Entrust.net Global Client Certification Authority				
Entrust.net Global Secure Server Certification Authority				
Entrust.net Secure Server Certification Authority				
new s17 cert	1			
S17 Icc Cert	Populate			
Thawte Person	nal Basic CA	Dename		
Thawte Persor	al Freemail CA	<u>kenam</u> e		
Thawte Person	nal Premium CA			
Thawte Premiu	um Server CA			
Thawte Primar	y Root CA			
Thawte Primar	y Root CA - G2 ECC			
Thawte Server	CA			
Veri Sign Class	1 Public Primary Certification Authority			
The requested a	ction has successfully completed!			

Figure 63. IBM Key Management, Signer Certificates

6. Click the Add button

The Open window is displayed.

7. Enter the filename and location of the signer certificate and click **OK**.

🧸 IBM Key Manag	gement - [C:\Users\kay\Ap	pData\Roaming\IBM\PERSON~1\PCor	nmClientKeyDb.kdb]			
Key Database <u>F</u> ile	e <u>C</u> reate <u>V</u> iew <u>H</u> elp					
D 🚄	🖬 😤 🕵 🍱					
		Key databas	e information			
DB-Type:	CMS					
File Name:	File Name: C:\Users\ka\\AppData\Roamino\\BM\PERSON~1\PCommClientKeyDb kdb					
Token Label:						
		Key datab	ase content			
Signer Certifica	Open			—	<u>A</u> dd	
Entrust.net Cert	tification At Eile Name:	icc.cert		Browse	Delete	
Entrust.net Glob	oal Client Contion:	C:\Users		1	View/Edit	
Entrust.net Glob	oal Secure				vie <u>w</u> icuita.	
Entrust.net Sec	ure Server	<u>O</u> K	<u>C</u> ancel		Extract	
new s17 cert						
S81 new cert					Populate	
Thawte Persona	al Basic CA				Rename	
Thawte Persona	al Freemail CA					
Thawte Persona	al Premium CA					
Thawte Premiu	m Server CA					
Thawte Primary	Root CA					
Thawte Primary	(ROOL LA - 62 ELL					
VeriSign Class	1 Public Primary Certifica	ation Authority				
The requested ac	tion has successfully co	mpleted!				

Figure 64. IBM Key Management, filename and location of signer certificate

8. From the Enter a Label window, type a name (for example, OSA-ICC Cert) and click **OK**.

🧸 IBM Key Manag	gement - [C:\Users\kay\AppData\R	paming\IBM\PERSON~1\PCommClientKeyDb.kdb]				
Key Database <u>F</u> ile	e <u>C</u> reate <u>V</u> iew <u>H</u> elp					
D 🚄	🖬 🎽 🕵 🗔					
		Key database information				
DB-Type:	CMS					
File Name:	C:\Users\kay\AppData\Roaming\	BM\PERSON~1\PCommClientKeyDb.kdb				
Token Label:	Token Label:					
		Key database content				
Signer Certifica	Open			id		
Entrust.net Cert	tification At File Name:	icc.cert	Browse De	lete		
Entrust.net Glob	al Client C Location:	C:\Users	View	/Edit		
Entrust.net Glob Entrust.net Sect	bal Secure ure Server	<u>O</u> K <u>C</u> ancel	E <u>x</u> tr	act		
S17 Icc Cert S81 new cert			Рори	ılate		
Thawte Persona	al Basic CA		Ren	ame		
Thawte Persona	al Freemail CA					
Thawte Persona	al Premium CA					
Thawte Premiur	m Server CA					
Thawte Primary	Root CA - G2 ECC					
Thawte Server	CA					
VeriSign Class	1 Public Primary Certification Aut	hority	-			
		· · · ·				
The requested ac	tion has successfully completed					

Figure 65. IBM Key Management, filename and location of signer certificate

The Name is now in the Key Database Content window and the certificate is ready to use.

🧱 IBM Key Management - [C:\Users\kay\AppData\Roaming\IBM\PERSON~1\PCommClientKeyDb.kdb]	
Key Database Eile Create View Help	
Key database information	
DB-Type: CMS	
File Name: C:\Users\kay\AppData\Roaming\\BM\PERSON~1\PCommClientKeyDb.kdb	
Token Label:	
Key database content	
Signer Certificates	Add
Entrust.net Certification Authority (2048) Entrust.net Client Certification Authority Entrust.net Global Client Certification Authority Entrust.net Global Secure Server Certification Authority Entrust.net Secure Server Certification Authority OSA-ICC Cert S17 Icc Cert S81 new cert Thawte Personal Basic CA Thawte Personal Freemail CA Thawte Personal Freemail CA Thawte Personal Premium CA Thawte Premium Server CA Thawte Primary Root CA Thawte Primary Root CA - G2 ECC Thawte Server CA VeriSign Class 1 Public Primary Certification Authority	Delete View/Edit Extract Populate Rename
The requested action has successfully completed!	

Figure 66. IBM Key Management, new signer certificate

Results

Session Connected Securely



Figure 67. Section connected securely

The lock symbol in bottom left hand Status Area indicates a Secure versus Non-Secure Connection.

The Client IP and TCP Port Number are shown on the Console (for example, 10.21.1.211:49812) and matches the information shown on Display Client Connections.

The bottom status line reports Connected through TLS1.1 encryption through Server IP, LU Name and Secure Port Number all set in OSA-ICC Server Configuration.

Defining the secure PCOMM TN3270E session

About this task

The initial setup for IP, LU Name, and Port Number is the same as for a non-secure session.

Procedure

1. Under Link Parameters in the Custom Configuration Options choose the Security Setup Tab.

ost Definition Automatic Host Location Security Setup	Printer Association
Enable Security	
IBM Global Security Kit (GSKit)	Advanced
C Microsoft Crypto API (MSCAPI)	Advanced
Security Protocol	
TLS1.1	
Enable FIPS Mode (TLS Protocol only)	
- Server Authentication	
Check for Server Name and Certificate Name Match	1
Client Authentication	
Send Personal Certificate to Server if it is Requested	1
Certificate Selection	
Send Personal Certificate Trusted by Server	
C Send Personal Certificate Based on Key Usage	
Key Usage	
C Select or Prompt for Personal Client Certificate	
Select now	

Figure 68. Custom Configuration Options, Security Setup tab

- 2. Click Enable Security
- 3. Choose your security package.
 - This example uses IBM Global Security Lit (GSKit).
- 4. Select the Security Protocol (TLS 1.1)
- 5. Select the FIPS mode (Enable)
- 6. Make sure the following is left unchecked:
 - Telnet negotiated
 - Server Authentication
 - Client Authentication
Chapter 11. Error and warning messages

New for OSA-ICC for z13 is support to create error and warning messages directly to the iqyylog.

The new tag OsaIccMsg provides a limited set or error and warning messages. The entry provides 8 bytes of information. The first 4 bytes (E191212A in the example), is the SE reference tag and is for information only. The next 4 bytes provide the PCHID number (0148) and the message code. Message details are provided in Table 2 on page 91.

Table 2. Informational and error messages from OsaIccMsg. The first three messages in the table are Informational, while the final three are Errors.

Тад	Meaning
0×1001	Informational: The TLS files were created on the SE Disk by this PCHID
0×1002	Informational: The key and certificates were regenerated by this PCHID
0×1003	Informational: The key and certificates files were added to this PCHID configuration file
0×E001	Error: No Hut File (temporary Configuration file) present on the SE Disk
0×E002	Error: Bad Hul File (Configuration File) present on the SE Disk
0×E003	Error: No Hul File (Configuration File) present on the SE Disk

By validating your configuration file, either by the *Validate panel values* window or the *Validate Source File* window, you are checking for any errors in your configuration. Any errors or warning you receive can be viewed in either the *Display Validate panel values* window or in the source file as comments. Table 3 on page 91 is a list of errors and warnings that you could receive. Note that Errors (1000 and up) must be corrected before attempting to activate a configuration.

Table 3. Errors from validate source file	
Code	Text
1010	// @@@ error: Sessions X and Y are defining same device; i.e. same css/mifid/device
1020	// @@@ error: Can't have multiple <osc_server> tags</osc_server>
1021	// @@@ error: Can't have <ocs_server> tag within session configuration</ocs_server>
1022	// @@@ error: Card configuration already done
1030	// @@@ error: Illegal position
1031	// @@@ error: Server configuration section has to be closed by
1032	// @@@ error: Missing HOST_IP tag
1033	// @@@ error: Missing PORT tag

Table 3. Errors from validate source file (continued)	
Code	Text
1034	// @@@ error: Missing DEFAULT_GATEWAY tag
1035	// @@@ error: Missing SUBNET_MASK tag
1036	// @@@ error: Missing ETHERNET tag
1037	// @@@ error: Missing NAME tag
1038	// @@@ error: Missing MTU tag
1039	// @@@ error: Can't have multiple HOST_IP tags
1040	// @@@ error: No host IP value
1041	// @@@ error: Can't have host IP outside of card configuration area
1042	// @@@ error: Host IP value is in bad format
1043	// @@@ error: Have to define host IP between <osc_physical_port#> and <!--<br-->OSC_PHYSICAL_PORT#> tags</osc_physical_port#>
1044	// @@@ error: Host name value is too long - 15 char is Max.
1045	// @@@ error: No host name value
1046	// @@@ error: Unsupported name format
1047	// @@@ error: Can't have name outside of card configuration area
1048	// @@@ error: Can't have multiple NAME tags
1049	// @@@ error: Have to define host name between <osc_physical_port#> and <!--<br-->OSC_PHYSICAL_PORT#> tags</osc_physical_port#>
1050	// @@@ error: No host port value
1051	// @@@ error: Can't have host port outside of card configuration area
1052	// @@@ error: Out of range port value
1053	// @@@ error: Can't have multiple PORT tags
1054	// @@@ error: Have to define host port between <osc_physical_port#> and <!--<br-->OSC_PHYSICAL_PORT#> tags</osc_physical_port#>
1055	// @@@ error: Host port value used for previous physical port definition
1056	// @@@ error: Host IP value used for previous physical port definition
1057	// @@@ error: Host IP for Physical Port 0 and Physical Port 1 are defined in the same segment
1060	// @@@ error: No gateway router value

Table 3. Errors from validate source file (continued)	
Code	Text
1061	// @@@ error: Can't define gateway outside of the card configuration area
1062	// @@@ error: Invalid gateway address value or format
1063	// @@@ error: Can't have multiple DEFAULT_GATEWAY tags
1065	// @@@ error: No value for TLS protocol version
1067	// @@@ error: No value for HOST_LL_ADDRESS/ PREFIX, must be auto generated link local address
1068	// @@@ error: No value for ADDR_TYPE, use LINK_LOCAL or STATIC keyword
1069	// @@@ error: No value for HOST_IPV6_ADDRESS/ PREFIX, expects link local or static ipv6 address
1070	// @@@ error: No subnet mask value
1071	// @@@ error: Can't define subnet mask outside of the card configuration area
1072	// @@@ error: Invalid subnet address value or format
1073	// @@@ error: Can't have multiple SUBNET_MASK tags in card configuration area
1074	<pre>// @@@ error: Have to define host subnet mask between <osc_physical_port#> and <!-- OSC_PHYSICAL_PORT#--> tags</osc_physical_port#></pre>
1080	// @@@ error: No value for Ethernet standard
1081	// @@@ error: Can't define Ethernet standard outside of card configuration
1082	// @@@ error: Unknown Ethernet standard value or format
1083	// @@@ error: Can't have multiple ETHERNET tags in card configuration area
1084	<pre>// @@@ error: Have to define host Ethernet standard between <osc_physical_port#> and </osc_physical_port#> tags</pre>
1086	// @@@ error: No value for Auto generated Link Local address
1090	// @@@ error: No value for MTU
1091	// @@@ error: Can't define MTU outside of card configuration
1092	// @@@ error: MTU value outside of 256-1492 range
1093	// @@@ error: MTU value has to be a decimal number

I

Table 3. Errors from validate source file (continued)	
Code	Text
1094	// @@@ error: Can't have multiple MTU tags in card configuration area
1095	// @@@ error: Have to define host MTU between <> and <> tags
1100	// @@@ error: Can't have <config_session> tag within card configuration area</config_session>
1101	// @@@ error: Can't have multiple <config_session> tags</config_session>
1102	// @@@ error: Sessions configuration already done
1110	// @@@ error: Illegal position
1120	// @@@ error: <session# end="" needs="" to="" with="">, i.e.<session#></session#></session#>
1121	// @@@ error: Trying to configure session outside of session configuration area
1122	// @@@ error: Session # is not between [1 and 120]
1123	// @@@ error: Overlapping configuration for different session
1124	// @@@ error: , i.e.
1125	// @@@ error: Wrong session # in a tag
1126	// @@@ error: This Session # has already been configured
1127	// @@@ error: Session # has to be a decimal number
1128	// @@@ error: This session is missing one of the mandatory tags : css, iid or device
1130	// @@@ error: Can't define CSS outside of session configuration area
1131	// @@@ error: Have to define CSS between <session#> and </session#> tags
1132	// @@@ error: Unsupported CSS value
1133	// @@@ error: CSS value is not present
1134	// @@@ error: Can't have multiple CSS tags in session configuration area
1140	// @@@ error: Can't define MIFID (IID) outside of session configuration area
1141	// @@@ error: Have to define MIFID (IID) between <session#> and </session#> tags

Table 3. Errors from validate source file (continued)	
Code	Text
1142	// @@@ error: Unsupported MIFID (IID) value. Range is [01 - 0F].
1143	// @@@ error: MIFID (IID)value not present
1144	// @@@ error: Can't have multiple MIFID (IID) tags in session configuration area
1150	// @@@ error: Can't define device outside of session configuration area
1151	// @@@ error: Have to define device between <session#> and </session#> tags
1152	// @@@ error: Unsupported device value
1153	// @@@ error: Device value not present
1154	// @@@ error: Can't have multiple DEVICE tags in session configuration area
1160	// @@@ error: Can't define group name outside of session configuration area
1161	// @@@ error: Have to define group name between <session#> and </session#> tags
1162	// @@@ error: Unsupported group length
1163	// @@@ error: Group name value not present
1164	// @@@ error: Group name value not present or no quotes
1165	// @@@ error: Can't have multiple GROUP tags in session configuration area
1170	// @@@ error: Can't define client's IP outside of session configuration area
1171	// @@@ error: Have to define client IP between <session#> and </session#> tags
1172	// @@@ error: Client IP value in bad format
1173	// @@@ error: Client IP value not present
1174	// @@@ error: Can't have multiple IP_FILTER tags in session configuration area
1175	// @@@ error: Client mask selected bits are unsupported based on CIDR notation
1180	// @@@ error: Can't define type outside of session configuration area
1181	// @@@ error: Have to define console type between <session#> and </session#> tags
1182	// @@@ error: Undefined console type value
1183	// @@@ error: Console type value not present

Table 3. Errors from validate source file (continued)	
Code	Text
1184	// @@@ error: Can't have multiple CONSOLE_TYPE tags in session configuration area
1190	// @@@ error: Can't define Defer Host Disconnect outside of session configuration area
1191	// @@@ error: Have to define Defer Host Disconnect between <session#> and <!--<br-->SESSION#> tags</session#>
1192	// @@@ error: Value for a Defer Host Disconnect has to be a whole decimal number
1193	// @@@ error: Defer Host Disconnect value either too small or too large.
1194	// @@@ error: Defer Host Disconnect value not present
1195	// @@@ error: Can't have multiple DEFER_HOST_DISCONNECT tags in session configuration area
1200	// @@@ error: Can't define Response outside of session configuration area
1201	// @@@ error: Have to define Response between <session#> and </session#> tags
1202	// @@@ error: Unsupported value of Response
1203	// @@@ error: Response value not present
1204	// @@@ error: Can't have multiple RESPONSE tags in session configuration area
1210	// @@@ error: Can't define Read timeout outside of session configuration area
1211	// @@@ error: Have to define Read timeout between <session#> and </session#> tags
1212	// @@@ error: Read timeout value is too small. Range is (5-300]
1213	// @@@ error: Read timeout value is too large. Range is (0-300]
1214	// @@@ error: Read timeout value is not present
1215	// @@@ error: Read timeout value should be a whole decimal number
1216	// @@@ error: Can't have multiple READ_TIMEOUT tags in session configuration area
1221	// @@@ error:1221 LU (group) name has to be unique per partition (CSS.IID). LU names in sessions X and Y are in conflict.

Table 3. Errors from validate source file (continued)	
Code	Text
1222	// @@@ error: 1222: Session IP has to be unique per partition (CSS.IID) when is used without Group (LU) name. IPs in sessions X and Yare in conflict.
1223	// @@@ error: 1223: When used in combination with the IP, LU name can't be used again, if it was already used in other session by it self. Sessions X and Y are in conflict.
1224	// @@@ error: 1224: Same LU name can't be used again, if it was already used in other session together with IP. Sessions X and Y are in conflict.
1225	// @@@ error: 1225: Neither group (LU) name nor IP is specified for session # X. At least one has to be specified
1283	// @@@ error: Server data must be defined before validation process
1290	// @@@ error: Illegal Token
1300	// @@@ error: Can't define IP filter outside of session configuration area
1301	// @@@ error: Can't define IP filter without client IP
1302	// @@@ error: Have to define IP filter between <session#> > and </session#> > tags
1303	// @@@ error: IP filter value is in bad format
1304	// @@@ error: IP filter value not present
1305	// @@@ error: Can't have multiple IP_FILTER tags in session configuration area
1306	// @@@ error: Client mask has already been defined
1310	<pre>// @@@ error: <osc_physical_port# end="" needs="" to="" with="">, i.e. <osc_physical_port#></osc_physical_port#></osc_physical_port#></pre>
1311	// @@@ error: Trying to configure physical port outside of physical port configuration area
1312	// @@@ error: Physical port # is not between [0 and 1]
1313	// @@@ error: Overlapping configuration for different physical port
1314	/ @@@ error: <osc_physical_port# needs="" to<br="">end with >; i.e. </osc_physical_port#>
1315	// @@@ error: Wrong physical port # in a <br OSC_PHYSICAL_PORT#> tag
1316	// @@@ error: This Physical port # has already been configured

Code	Text
1317	// @@@ error: Physical port # has to be a decimal number
1318	// @@@ error: Missing <osc_physical_port#> tag</osc_physical_port#>
1933	// @@@ error: No Valid Port number specified
1934	// @@@ error: IPV4 Secure Port matches NonSecure port number
1952	// @@@ error: IPV4 Out of range port value
1955	// @@@ error: IPV4 Host Secure port value used for previous physical Secure port definition
5056	// @@@ error: Invalid TLS Version
5059	// @@@ error: IPV6 Host port value used for previous physical port definition
5060	// @@@ error: IPV6 Out of range port value
5061	// @@@ error: IPV6 Host Secure port value used for previous physical Secure port
5062	// @@@ error: IPV6 Out of range secure port value
5064	// @@@ error: IPV6 Host/Link LL IP value used for previous physical port definition
5065	// @@@ error: IPV6 Host IP value is in bad format
5066	// @@@ error: IPV6 Have to have a least one non- zero port between <osc_phsyical_port#> and tags</osc_phsyical_port#>
5067	// @@@ error: IPV6 prefix value is out of range[1-128]
5068	// @@@ error: IPV6 Secure Port matches NonSecure port number
5069	// @@@ error: IPV6 port numbers matches to ipv4
6061	// @@@ error: Invalid IPV6 address type string
6062	// @@@ error: Missing HOST IPV6 PREFIX
6063	// @@@ error: Missing IPV6 Link Local PREFIX
6066	// @@@ error: Bad IPv6 syntax format missing slash /
6067	// @@@ error: Bad IPv6 syntax format - invalid prefix value after /
6068	// @@@ error: Link local address is not same as Auto generated on
6069	// @@@ error: Invalid IPV6 Address / is not correc
6070	// @@@ error: Invalid Link Local IPV6 Address

L

Table 3. Errors from validate source file (continued)	
Code	Text
6071	// @@@ error: HOST IPV6 address and Address type are not matching
6072	// @@@ error: Writing subnet mask Exception Error
6073	// @@@ error: Invalid IPV4 prefix value
6074	// @@@ error: IPV6 HOST address is not valid for NONE cfg
6075	// @@@ error: IPV6 Have to have a least one non- zero port between <osc_phsyical_port#> and</osc_phsyical_port#>
6076	// @@@ error: IPV6 default gateway address[All Zeros] is not valid for the STATIC
6077	// @@@ error: Invalid IPV6 address
6078	// @@@ error: Port is defined but IPV4 Host IP value is in bad format
6079	// @@@ error: Secure Port is defined but IPV4 Host IP value is in bad format
6080	// @@@ error: IPV6 address is in bad format missing /prefix
6081	// @@@ error: Configured HOST IPV6 address/ prefix is not same as auto generated
6082	// @@@ error: Missing IPV4 prefix or subnet value
6083	// @@@ error: Configuring Link Local prefix is not valid while Link is down
6084	// @@@ error: Configuring Link Local IPV6 address is not valid while Link is down
6085	// @@@ error: Configuring IPv4 is not valid while Link is down
6086	// @@@ error: Bad IPv6 syntax format

I

I

I

I

I

I

Table 4. Warnings from validate source file	
Code	Text
506	// @@@ warning: 506 This session is in Definition Error state because CSS is not defined in IOCDS
507	// @@@ warning: 507 This session is in Definition Error state because IID is not defined for CSS in IOCDS
508	// @@@ warning: 508 This session is in Definition Error state because Device is not defined for IID in IOCDS
509	// @@@ warning: 509 This session is in Definition Error state because device is not defined in IOCDS

Table 5. Errors from validate windows	
Code	Text
1010	// @@@ Error 1010: Session # X and session # Y are defining same device; i.e. same css/mifid/ device
1042	// @@@ Error 1042: Invalid server IP value:
1046	// @@@ Error 1046: Unsupported name format: XXXXX
1052	// @@@ Error 1052: Invalid server port value: XXXXX
1055	// @@@ Error 1055: Host port value used for previous physical port definition
1056	// @@@ Error 1056: Host IP value used for previous physical port definition
1057	// @@@ Error 1057: Host IP for Physical Port 0 and Physical Port 1 are defined in the same segment
1082	// @@@ Error 1082: Invalid server LAN PARM value: XXXXX
1092	// @@@ Error 1092: Invalid server MTU value: XXXXX
1132	// @@@ Error 1032 :Session # X has out of range CSS value.
1142	// @@@ Error 1042 :Session # X has out of range IID value.
1152	// @@@ Error 1052 :Session # X has out of range deviceNumber value.
1162	// @@@ Error 1162: Session #X has invalid group name length
1163	// @@@ Error 1163: Session #X has invalid group name
1172	// @@@ Error 1172: Session #X has invalid session IP value
1182	// @@@ Error 1082 :Session # X has invalid Type.
1202	// @@@ Error 1202 :Session # X has invalid RSP value.
1212	// @@@ Error 1212 :Session # X has invalid RTO value.
1221	// @@@ Error 1221 : LU (group) name has to be unique per partition (CSS.IID). LU names in sessions X and " Y are in conflict.
1222	// @@@ Error 1222 :Session IP has to be unique per partition (CSS.IID) when is used without Group (LU) name. IPs in sessions X and Y are in conflict.

Table 5. Errors from validate windows (continued)						
Code	Text					
1223	// @@@ Error 1223 :When used in combination with the IP, LU name can't be used again, if it was already used in other session by it self. Sessions X and Y are in conflict.					
1224	// @@@ Error 1224: Same LU name can't be used again, if it was already used in other session together with IP. Sessions X and Y are in conflict.					
1225	// @@@ Error 1225: Neither group (LU) name nor IP is specified for session # X. At least one has to be specified.					
1303	// @@@ Error 1303 Session #X has invalid IP mask					
1992	// @@@ Error There is no HUL or HUT present or with zero size					

Table 6. Warnings from validate windows						
Code	Text					
62	// @@@ Warning 62 :Invalid server gateway value: XXXXX					
72	// @@@ Warning 72:Invalid server subnetMask value: XXXXX					
506	// @@@ warning: Session X is in Definition Error state because CSS is not defined in IOCDS					
507	// @@@ warning: Session X is in Definition Error state because IID is not defined for CSS in IOCDS					
508	// @@@ warning: Session X is in Definition Error state because device is not defined for IID in IOCDS					
509	// @@@ warning: Session X is in Definition Error state because device is not defined in IOCDS					

Debugging tips

I

New for OSA-ICC for z13 is support to create error and warning messages directly to the iqyylog.

- 1. Update the config trm with the required IPv4 subnet mask and ICC calculates the prefix and populates into server configuration panel. From the GA2 driver onwards, server configuration panel expects CIDR representation of IPv4 address.
- 2. Link local IPv6 address will not be populated if the interface is not wired; that is, it will be blank.
- 3. Execute the **osass** command to see the list of TCP/IP listen servers opened on the given server configuration and list of network sessions connected to PCHID with the current state.
- 4. From z14 GA2 and beyond, hardware configuration changing from 3270 to 3215 (and from 3215 to 3270):
 - Need to perform "Reset To Defaults" after backing up the old config source trm file.
 - After reset to factory settings reload/validate and activate the backup config source trm file.

- 5. For SSL certificates, always check the "certificate scope[Shared or Individual]" and "certificate type" on the Manage Security certificates to understand the active certificate on the PCHID.
- 6. Imported certificate fail or success can be verified by looking at the following sock master HYDRA INFO traces:
 - ERR_USER_CERT_IMPORT importing certificate is failed
 - SUCCESS_USER_CERT_IMPORT certificate import went successful

The following are problem determination tips on connection to client sessions.

- 1. Use the View Port Parameter (see <u>"View port parameters" on page 17</u>) to check if the OSA port 0/1 has a good network connection:
 - a. Active speed, mode: 1000Mb or 100Mb, Full duplex
 - b. An "Unknown" connection means a lost network connection; get your network administrator to help. Total packets Transmitted/Received counts should be increasing between each display.
- 2. Use the Debug utilities in Chapter 7, "Debug utilities," on page 49
 - a. Use the PING utility to PING the gateway and client session IP addresses.
 - b. PING passed between the client and OSA, but still unable to establish connections.
 - c. Manually take the trace and log for IBM Support.
 - d. Pick the card trace/log/dump facilities (see <u>"OSA-ICC configuration and debug windows" on page</u> 13) on the OSA-ICC PCHID. Do the Read Trace Buffer and follow by the Read Log Buffer option (concurrent).
- 3. Send the trace and log to IBM, as follows:
 - a. On the HMC/Tasks Index and pick the Transmit Service Data, Select the CEC.
 - b. Pick Support System for sending the log to IBM
 - c. Pick Hydra service data for the OSA trace/log data.
- 4. Choose Send to send the data
 - a. Open a problem record on HMC
 - b. On the HMC/Tasks Index and pick Report a Problem, select the CEC
 - c. Pick I/O option
- 5. Additional information to be mentioned:
 - a. Failing OSA-ICC PCHID number
 - b. Which LPAR image or images were having problems
 - c. Any problem determination was done, if Read Trace/Log Buffer were collected during the error condition.

Appendix A. ASCII table

Char	Dec	Oct	Hex	Char	Dec	Oct	Hex	Char	Dec	Oct	Hex
Char (sp) ! # \$ % & ' ()) * + , / 0 1 2 3 4 5 6 7 °	Dec 32 33 34 35 36 37 38 39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 55 55	Oct 0040 0041 0042 0043 0044 0045 0046 0047 0050 0051 0052 0053 0054 0055 0056 0057 0060 0061 0062 0063 0064 0065 0066 0067 0067	Hex 0x20 0x21 0x22 0x23 0x24 0x25 0x26 0x27 0x28 0x27 0x28 0x22 0x22 0x22 0x24 0x22 0x22 0x22 0x22 0x23 0x23 0x24 0x24 0x25 0x26 0x26 0x27 0x28 0x27 0x28 0x28 0x28 0x26 0x26 0x27 0x28 0x26 0x27 0x28 0x28 0x26 0x26 0x26 0x27 0x28 0x26 0x30 0x33 0x34 0x35 0x36 0x37 0x36 0x37 0x37	Char @ A B C D E F G H I J K L M N O P Q R S T U V W Y	Dec 64 65 66 67 68 69 70 71 72 73 74 75 76 77 78 79 80 81 82 83 84 85 86 87 88	Oct 0100 0101 0102 0103 0104 0105 0106 0107 0110 0111 0112 0113 0114 0115 0116 0117 0120 0121 0122 0123 0124 0125 0126 0127 0120	Hex 0x40 0x41 0x42 0x43 0x44 0x45 0x46 0x47 0x48 0x49 0x44 0x40 0x44 0x40 0x44 0x40 0x42 0x40 0x41 0x50 0x51 0x52 0x53 0x54 0x55 0x56 0x56 0x56 0x56 0x56 0x56 0x56	Char ` a b c d e f g h i j k l m n o p q r s t u v v	Dec 96 97 98 99 100 101 102 103 104 105 106 107 108 109 110 111 112 113 114 115 116 117 118 119 120	Oct 0140 0141 0142 0143 0144 0145 0146 0147 0150 0151 0152 0153 0154 0155 0156 0157 0160 0161 0162 0163 0164 0165 0166 0167 0170	Hex 0x60 0x61 0x62 0x63 0x64 0x65 0x66 0x67 0x68 0x69 0x68 0x69 0x6a 0x66 0x66 0x66 0x66 0x66 0x67 0x68 0x66 0x67 0x68 0x67 0x68 0x67 0x68 0x67 0x68 0x67 0x68 0x66 0x67 0x68 0x67 0x70 0x71 0x72 0x73 0x74 0x75 0x76 0x77 0x76
/ 8	55 56	0067	0x37 0x38	W X	87 88	012/ 0130	0x57 0x58	w x	119 120	0167 0170	0x/7 0x78
9 :	57 58	0071 0072	0x39 0x3a	Y Z	89 90	0131 0132	0x59 0x5a	y z	121 122	0171 0172	0x79 0x7a
; <	59 60	0073	0x3b 0x3c		91 92 02	0133 0134 0125	0x5b 0x5c 0x5d		123 124	0173 0174	0x/b 0x7c 0x7d
= > ?	61 62 63	0075 0076 0077	0x3u 0x3e 0x3f] ^	93 94 95	0135 0136 0137	0x5d 0x5e 0x5f	} ~	125	0175	0x7d 0x7e

Figure 69. Network topology Diagram 1

z Systems: Open Systems Adapter Integrated Console Controller User's Guide

Appendix B. Sample signed certificates

Sample certificate signing request

```
Certificate Request:
    Data:
        Version: 0 (0x0)
        Subject: CN=OsaIccTLSServer
Subject Public Key Info:
            Public Key Algorithm: rsaEncryption
Public-Key: (2048 bit)
                 Modulus:
                     00:c1:bb:47:cb:de:77:22:59:51:5b:3e:4e:f1:db:
9b:14:5a:b7:42:ef:51:78:e2:b4:c5:73:1a:c7:93:
                     36:6d:5c:28:4f:dd:ef:ea:e5:60:ac:00:aa:ff:35:
                     60:f6:05:1a:0b:30:14:5b:df:7b:0e:23:33:86:1d:
                     16:0c:65:bd:7e:7c:32:e1:d4:95:51:e5:3e:c6:1b:
                     6c:c8:7a:17:d0:c4:d7:4b:67:62:8a:52:6a:e0:78:
                     ce:b4:14:97:9f:a4:63:87:5b:36:d9:ab:d9:ac:30:
                     7e:55:32:a1:ed:01:2e:e4:e9:92:a2:d0:00:b1:16:
                     91:56:2f:6f:5c:5d:72:9f:5e:98:f5:dd:a3:bc:d5:
                     c2:3a:18:7d:bf:f4:88:f7:a1:c7:ec:78:30:a5:4c:
                     09:9b:69:c5:af:ff:b5:d0:5c:b4:11:95:02:76:67:
                     7e:84:b9:55:67:18:46:43:0c:55:67:40:dc:1c:92:
                     36:3d:68:51:01:14:b7:83:04:cb:cb:3f:f3:8c:de:
                     23:31:d8:a7:16:de:21:fb:1d:46:07:da:23:82:5c:
                     2a:b0:e3:f5:49:fb:ee:ba:a7:a2:3d:cf:f6:1d:7c:
                     46:16:c8:cf:39:da:10:0c:d8:70:14:db:6f:52:c3:
                     89:7c:09:51:6b:20:ed:1a:b8:54:43:f4:ce:82:7e:
                     a9:5b
                 Exponent: 65537 (0x10001)
        Attributes:
            a0:00
    Signature Algorithm: sha256WithRSAEncryption
         46:18:6e:f3:69:3e:2a:08:9d:a3:07:a9:cf:d3:bd:bd:79:7b:
         25:ef:3f:8f:ba:24:f6:fb:64:3f:19:d6:d2:bf:58:bd:75:1c:
         b5:66:4f:e1:a9:e5:e3:0b:e8:4d:cf:25:d5:13:0c:11:df:48:
         da:10:bb:3c:68:28:0a:f0:8b:e2:80:5e:0d:42:da:2d:8c:11:
         8d:5b:62:6d:06:cf:83:81:9b:36:7a:dd:43:43:33:64:bf:e5:
         7c:33:21:51:e2:46:01:09:16:f6:9a:dd:c5:d5:c5:2a:08:ef:
         b1:2d:e4:26:8d:99:ab:93:c7:73:49:3c:1a:d5:ae:0b:d4:70:
         a1:b4:9f:2f:9e:4a:34:fb:b9:e3:c1:85:41:04:ae:91:39:d1:
         a9:e0:1c:8c:6e:c8:12:01:3c:1a:67:6e:5c:2e:c3:58:93:43:
         18:ab:f0:5a:3b:a1:f4:e9:22:6d:7a:ef:d3:e6:4a:65:6d:0c:
         1b:c2:dc:e6:d0:63:d7:93:b8:6c:d0:00:7c:6b:7a:20:f2:26:
         5e:f0:57:fd:c4:56:56:c5:de:eb:0b:bc:24:a6:c2:61:ee:4b:
         0e:c6:3e:23:46:3c:17:fe:0e:ae:92:9d:5e:49:86:e0:6d:4d:
         94:99:31:be:9b:ba:e6:3b:44:83:13:33:88:a1:02:b2:70:19:
         3d:f0:dc:da
```

Sample self-signed certificate

```
Certificate:

Data:

Version: 3 (0x2)

Serial Number:

da:50:cb:99:52:41:22:88

Signature Algorithm: sha256WithRSAEncryption

Issuer: CN=OsaIccTLSServer

Validity

Not Before: Jan 29 16:51:44 2016 GMT

Not After : Jan 28 16:51:44 2019 GMT

Subject: CN=OsaIccTLSServer

Subject Public Key Info:

Public Key Algorithm: rsaEncryption

Public Key Algorithm: rsaEncryption

Public-Key: (2048 bit)

Modulus:

00:c1:bb:47:cb:de:77:22:59:51:5b:3e:4e:f1:db:

9b:14:5a:b7:42:ef:51:78:e2:b4:c5:73:1a:c7:93:
```

36:6d:5c:28:4f:dd:ef:ea:e5:60:ac:00:aa:ff:35: 60:f6:05:1a:0b:30:14:5b:df:7b:0e:23:33:86:1d: 16:0c:65:bd:7e:7c:32:e1:d4:95:51:e5:3e:c6:1b: 6c:c8:7a:17:d0:c4:d7:4b:67:62:8a:52:6a:e0:78: ce:b4:14:97:9f:a4:63:87:5b:36:d9:ab:d9:ac:30: 7e:55:32:a1:ed:01:2e:e4:e9:92:a2:d0:00:b1:16: 91:56:2f:6f:5c:5d:72:9f:5e:98:f5:dd:a3:bc:d5: c2:3a:18:7d:bf:f4:88:f7:a1:c7:ec:78:30:a5:4c: 09:9b:69:c5:af:ff:b5:d0:5c:b4:11:95:02:76:67: 7e:84:b9:55:67:18:46:43:0c:55:67:40:dc:1c:92: 36:3d:68:51:01:14:b7:83:04:cb:cb:3f:f3:8c:de: 23:31:d8:a7:16:de:21:fb:1d:46:07:da:23:82:5c: 2a:b0:e3:f5:49:fb:ee:ba:a7:a2:3d:cf:f6:1d:7c: 46:16:c8:cf:39:da:10:0c:d8:70:14:db:6f:52:c3: 89:7c:09:51:6b:20:ed:1a:b8:54:43:f4:ce:82:7e: a9:5b Exponent: 65537 (0x10001) X509v3 extensions: X509v3 Subject Key Identifier: 4E:9E:53:8E:2E:0F:2B:04:CC:C4:EB:B4:41:FC:B0:67:5C:E0:6E:B8 X509v3 Authority Key Identifier: keyid:4E:9E:53:8E:2E:0F:2B:04:CC:C4:EB:B4:41:FC:B0:67:5C:E0:6E:B8

X509v3 Basic Constraints: CA:TRUE Signature Algorithm: sha256WithRSAEncryption 23:ee:f7:02:fe:48:92:0e:8f:df:36:bc:c2:16:e6:b2:e4:a4: 75:67:d5:f5:74:c9:eb:91:76:d7:d0:b0:44:f6:58:ac:1b:a8: 40:6b:34:31:8b:75:a5:cb:75:ae:1b:4b:e9:ee:80:54:8b:57: d2:aa:7b:a8:0a:66:2e:8e:3b:a6:46:5d:0a:ea:c2:69:68:62: 56:53:74:83:e4:a5:79:ec:e3:ae:e9:ab:54:9c:c2:60:05:f5: 04:02:99:57:73:81:5b:6e:6b:cf:72:47:63:7d:be:51:fd:a0: 2c:5a:59:80:bc:00:23:25:fa:74:39:2c:7b:c1:34:c4:57:e5: 43:f4:33:2a:d6:11:7c:8d:5a:8e:77:f4:bc:41:04:c9:0d:9d: 6e:8a:be:65:f4:2d:e7:7a:29:5c:cc:c8:e5:a9:3d:55:d7:35: b4:5e:cf:01:4c:58:2f:e5:df:b4:4c:a0:b5:e1:b2:a8:89:8a: Oa:44:3d:bb:ff:22:9c:a9:70:a7:54:30:1a:bd:ae:ca:08:fb: 4f:05:0d:d5:7a:bf:03:8f:6f:ae:ed:08:2f:f1:e6:dc:10:ae: 4e:a8:12:76:05:60:b3:be:8f:14:55:21:a9:bd:fe:39:84:c0: 16:7c:53:69:92:07:67:ab:5d:9c:59:bd:47:02:55:2c:f0:18: 69:c3:14:21

Appendix C. Network topology

The OSA-ICC adapter supports two physical ports for each pchid. The server definition for each physical port defines a unique secure and/or non-secure TCP port number, IP address and subnet. These server definitions allow for an isolated Local Area Network (LAN) to be created for each physical port. Any external network traffic is routed through a common default gateway defined for both ports. An example illustrating an OSA-ICC multi-port connection is given in the network topology diagram in Figure 70 on page 107.



Figure 70. Network topology diagram

Figure 70 on page 107 shows connectivity to an ICC adapter where each physical port (P0, P1) is configured on a different broadcast domain (LAN). Both P0 and P1 clients communicate with OSA through

the defined TCP port. The external network traffic is only allowed to travel in one direction through P0 because the local clients reside on the same subnet as the default gateway. The clients connected to P1 are restricted to communicate only with the clients of that subnet.

Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not give you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing IBM Corporation North Castle Drive Armonk, NY 10504-1785 U.S.A.

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Any performance data contained herein was determined in a controlled environment. Therefore, the results obtained in other operating environments may vary significantly. Some measurements may have been made on development-level systems and there is no guarantee that these measurements will be the same on generally available systems. Furthermore, some measurements may have been estimated through extrapolation. Actual results may vary. Users of this document should verify the applicable data for their specific environment.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

All statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

All IBM prices shown are IBM's suggested retail prices, are current and are subject to change without notice. Dealer prices may vary.

This information is for planning purposes only. The information herein is subject to change before the products described become available.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to the names and addresses used by an actual business enterprise is entirely coincidental.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.

Trademarks

IBM, the IBM logo, and ibm.com[®] are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. If these and other IBM trademarked terms are marked on their first occurrence in this information with a trademark symbol ([®] or [™]), these symbols indicate U.S. registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of IBM trademarks is available on the Web at <u>Copyright and Trademark information</u> (www.ibm.com/legal/copytrade.shtml).

Java and all Java-based trademarks are trademarks of Sun Microsystems, Inc. in the United States, other countries, or both.

Microsoft, Windows, Windows NT, and the Windows logo are trademarks of Microsoft Corporation in the United States, other countries, or both.

Linux is a trademark of Linus Torvalds in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Other company, product, and service names, which may be trademarks or service marks of others.

Index

A

Activate configuration 46

С

cancel command $\underline{61}$ cipher suites $\underline{72}$

D

Debug utilities <u>49</u> Display activate configuration errors <u>47</u> Display active server configuration <u>24</u> Display active session configuration <u>23</u> Display client connections <u>22</u> Display validate panel errors <u>34</u> Drop session <u>53</u>

E

Edit server configuration 27 Edit session configuration 30 Edit source file 39 Editing a source file, steps for 39 Export source file 37 Exporting a configuration file via FTP, steps for 39 Exporting a configuration file, steps for 37 Exporting a source file via FTP, steps for 39

F

feedback \underline{xv}

I

Import a configuration file, steps for $\underline{36}$ Import source file $\underline{36}$ Importing a configuration file via FTP, steps for $\underline{38}$ Importing a source file via FTP, steps for $\underline{38}$

L

logo controls <u>54</u>, <u>59</u>, <u>61</u>, <u>70</u>

Μ

Manual configuration options <u>35</u>

0

OSA-ICC configuration and debug windows 13

Ρ

Panel configuration options <u>27</u> Ping utility <u>49</u>

Q

query command 54

R

returning to a self-signed certificate <u>63</u>, <u>68</u>, <u>71</u>, <u>72</u> Run port diagnostics <u>19</u>

S

Sample certificate signing request <u>105</u> Sample self-signed certificate <u>105</u> sending to IBM reader comments <u>xv</u> Set card mode 21

T

tasks accessing the Advance Facilities window steps for <u>11</u>, <u>13</u> defining a PCOMM session steps for <u>77</u> defining a secure PCOMM TN3270E session steps for <u>81</u>, <u>89</u> defining an OSC CHPID via HCD steps for <u>6</u> importing self-signed or CA signed certificate steps for <u>81</u> Trace route utility <u>51</u>

U

using a self-signed certificate <u>62, 64, 65, 69</u> Using an externally signed certificate <u>63</u>

V

Validate panel values <u>33</u> Validate source file <u>45</u> View port parameters 17



SC27-9003-02

